









RIGHT VIEW

- OPTIONAL STEAM INLET 1/2"NPT (AIR-OPERATED) REQUIRES AIR CONNECTION, A1. SUDS OVERFLOW TO SEWER, 1-3/4"ID HOSE CONNECTION
- OR 1-1/2"NPT (PART OF ELECTRICALLY OPERATED REUSE RAIN OPTION
- R4 AIR-OPERATED REUSE INLET, 3/4" GARDEN HOSE
- CONNECTION, MALE THREAD IORMALLY CLOSED REUSE DRAIN, 3" PIPE SOCKET JOINT.
- NORMALLY OPEN SEWER DRAIN, 3" PIPE SOCKET JOINT. OPTIONAL AIR-OPERATED REUSE INLET AND ELECTRICALLY
- OPERATED REUSE DRAIN-REQUIRES: R2, R3, R4, R5,
- L1 3 COMPARTMENT SUPPLY, OPTIONAL
- OPTIONAL STARCH TANK AIR INLET 1/4"NPT, REQUIRED FOR AIR-OPERATED REUSE
- INLET OR AIR-OPERATED STEAM, CUSTOMER MUST SUPPLY AIR STRAINER

LEGEND

- AS OF THIS WRITING, THE MINIMUM CLEARANCE REQUIRED BY U.S. NATIONAL ELECTRIC COOPS, FROM ELECTRIC BOX TO ANY OBJECT IS:

  36 [914] IF OBJECT IS AN UNGROUNDED (INSULATED) WALL.

  42 [1067] IF OBJECT IS AN UNGROUNDED (INSULATED) WALL.

  43 [129] IF OBJECT IS ANY LIVE PART.
  CHECK LOCAL ELECTRIC CODES FOR FURTHER RESTRICTIONS.

  5 CUSTOMER TO SUPPLY CIRCUIT BREAKER OR FUSED BRANCH CIRCUIT DISCONNECT (SAFETY) SWITCHES WITH LAG TYPE FUSES FROM POWER SOURCE TO MACHINE. A SEPARATE GROUND WIRE MUST BE CONNECTED FROM DISCONNECT TO EQUIPMENT.

  4 BASELINE "Z" IS THE SAME FOR ALL MILNOR MACHINES AND IS SHOWN ON ALL DIMENSIONAL DRAWINGS. THE DISTANCE BETWEEN BASELINE "Z" AND THE FINISHED FLOOR MAY VARY (WITH CHANGES IN FLOOR HEIGHT) AS REQUIRED TO INSURE THAT BASELINE "Z" IS HORIZONTAL AND ALL COMPONENTS REQUIRING GROUT ARE SET ON A MINIMUM 1" [25] THICK GROUT BED.

  3 USE REFERENCE LINES "X", "Y", AND "Z" TO LOCATE ALL SERVICE CONNECTIONS.

  NUMBERS IN BRACKETS [] DENOTE DIMENSIONS IN MILLIMETERS.

  1 ALL DIMENSIONS SHOWN ARE APPROXIMATE, SUBJECT TO NORMAL MANUFACTURING TOLERANCES, AND TO OCCASIONAL CHANGES WITHOUT NOTICE THROUGH REDESIGN AND/OR RELOCATION OF COMPONENTS, ETC. DO NOT USE FOR CONSTRUCTION UNLESS CERTIFIED, AND IN NO EVENT PRE-PIPE CLOSER THAN FIVE FEET FROM MACHINE. FACTORY MUST BE CONSULTED FOR DIMENSIONS IF MACHINE IS TO BE MOVED THROUGH NATION OF COMPONENTS, ETC. DO NOT USE FOR CONSTRUCTION MACHINE. FACTORY MUST BE CONSULTED FOR DIMENSIONS IF MACHINE IS TO BE MOVED THROUGH NATION OF COMPONENTS. CAND THE FIELD NEARLY AND THE PROPERTY OF PRINCES.

MOST REQUIATORY AUTHORITIES (INCLUDING OSHA IN THE USA) HOLD THE OWNER/USER ULTIMATELY RESPONSIBLE TO MAINTAIN A SAFE WORKING ENVIRONMENT. ACCORDINGLY, THE OWNER/USER MUST REOCONIZE ALL PORESEABLE SAFETY HAZARDS, FURNISH SAFETY INSTRUCTIONS AND GUIDANCE TO ALL PERSONNEL WHO MAY COME IN CONTACT WITH THE INSTALLATION, AND PROVIDE ALL NECESSARY ADDITIONAL SAFETY GUARDS, RECKES, RESTRANTS, DEVICES, ETC., NOT FURNISHED BY THE EQUIPMENT MANUFACTURER OR VENDOR.

MANUFACTURER OR VENDOR.

ATTENTION

THE FLOOR AND/OR OTHER SUPPORT COMPONENTS MUST HAVE SUFFICIENT
STRENGTH (AND RIGIDITY WITH DUE CONSIDERATION FOR NATURAL OR RESONANT
FREQUENCY THEREOF) TO WITHSTAND THE FULLY LOADED WEIGHT OF THE MACHINE
INCLUDING THE GOODS, THE WATER, AND ANY REPEATED SINUSOIDAL (ROTATING) FORCE
GENERATED DURING ITS OPERATION, WITTE THE FACTORY FOR ADDITIONAL MACHINE
DATA FOR USE BY A COMPETENT SOIL AND/OR STRUCTURAL ENGINEER.

## 30022VRJ OPTIONS



BD3022VRJCB 2020034D

PELLERIN MILNOR CORPORATION
P.O. Box 400 Kenner, LA 70063, USA, Phone 504/467–9591,
FAX 504/469–1849, Email: milnorinfo@milnor.com