



	(PART OF OPTIONAL DUAL DRAIN).
W4	OPTIONAL AIROP REUSE (IF NO STEAM), 1/2" NPT,
	(PART OF OPTIONAL DUAL DRAIN).
T2	OVERFLOW, 3" ID HOSE SUPPLIED
	OPTIONAL REUSE TANK, 3022X8W ONLY.
S1	OPTIONAL STEAM, 1/2" NPT
L4	5 COMPARTMENT SUPPLY
L3	ADDITIONAL LIQUID SUPPLY INLETS FOR 15 PORT PERISTALTIC
	DUAL DRAIN (REUSE), 3" PIPE SOCKET JOINT
D1	DRAIN DRAIN (SEWER), 3' PIPE SOCKET JOINT
A1	AIR CONNECTION 1/4" NPT, FOR REUSE WATER INLET(AIROP)
	(PART OF OPTIONAL DUAL DRAIN).
ITEM	LEGEND

NOTES

- NOTES

 6 AS OF THIS WRITING, THE MINIMUM CLEARANCE REQUIRED BY U.S. NATIONAL ELECTRIC CODES, FROM ELECTRIC BOX TO ANY OBJECT IS:

 36 [914] IF OBJECT IS AN UNGROUNDED (INSULATED) WALL.

 42 [1057] IF OBJECT IS A GROUNDED WALL (B. BAPE CONCRETE, BRICK, ETC.)

 48 [1219] IF OBJECT IS ANY LIVE PART.

 CHECK LOCAL ELECTRIC CODES FOR FURTHER RESTRICTIONS.

 5 CUSTOMER TO SUPPLY CIRCUIT BREAKER OR FUSED BRANCH CIRCUIT DISCONNECT (SAFETY) SWITCHES WITH LIG TYPE FUSES FROM POWER SOURCE TO MACHINE. A SEPARATE GROUND WIRE MUST BE CONNECTED FROM DISCONNECT TO EQUIPMENT.

 4 RASELINE Z" IS THE SAME FOR ALL MILNOR MACHINES AND IS SHOWN ON ALL DIMENSIONAL DRAWINGS. THE DISTANCE BETWEEN BASELINE Z" AND THE FINISHED FLOOR MAY VARY (WITH CHANGES IN FLOOR HEIGHT) AS REQUIRED TO INSURE THAT BASELINE Z" IS FORIZONTAL AND ALL COMPONENTS REQUIRING GROUT ARE SET ON A MINIMUM 1" [25] THICK GROUT BED.

 3 USE REFERENCE LINES "X", "Y", AND "Z" TO LOCATE ALL SERVICE CONNECTIONS.

3 USE REFERENCE LINES "X", "Y", AND "2" TO LOCATE ALL SERVICE CONNECTIONS.

2 NUMBERS IN BRACKETS [] DENOTE DIMENSIONS IN MILLIMETERS.

1 ALL DIMENSIONS SHOWN ARE APPROXIMATE, SUBJECT TO NORMAL MANUFACTURING TOLERANCES, AND TO OCCASIONAL CHANGES WITHOUT NOTICE THROUGH REDESION AND/OR RELOCATION OF COMPONENTS, ELE DO NOT USE FOR CONSTRUCTION UNLESS CERTIFIED, AND IN NO EVENT PRE-PIPE CLOSER THAN FIVE FEET FROM MACHINE. FACTORY MUST BE CONSULTED FOR DIMENSIONS IF MACHINE IS TO BE MOVED THROUGH NARROW OR LOW CORRIDORS ON OPENINGS.

ATTENTION

MOST REGULATORY AUTHORITIES (INCLUDING OSHA IN THE USA) HOLD THE OWNER/USER ULTIMATELY RESPONSIBLE TO MAINTAIN A SAFE WORKING ENVIRONMENT. ACCORDINGLY, THE OWNER/USER MUST RECOQUIZE ALL FORSESHABLE SAFETY HAZARDS, FURNISH SAFETY INSTRUCTIONS AND CUIDANCE TO ALL PERSONNEL WHO MAY COME IN CONTACT WITH THE INSTALLATION, AND PROVIDE ALL NECESSARY ADDITIONAL SAFETY GUARDS, FENCES, RESTRAINTS, DEVICES, ETC., NOT FURNISHED BY THE EQUIPMENT MANUFACTURER OR VENDOR.

MANUFACTURER OR VENDOR.

ATTENTION

THE FLOOR AND/OR OTHER SUPPORT COMPONENTS MUST HAVE SUFFICIENT STRENGTH (AND RIGIDITY WITH DUE CONSIDERATION FOR NATURAL OR RESONANT FREQUENCY THEREOF) TO WITHSTAND THE FULLY LOADED WEIGHT OF THE MACHINE INCLUDING THE GOODS, THE WATER, AND ANY REPEATED SINUSOIDAL (ROTATING) FORCES GENERATED DURING ITS OPERATION, WRITE THE FACTORY FOR ADDITIONAL MACHINE DATA FOR USE BY A COMPETENT SOIL AND/OR STRUCTURAL ENGINEER.

