



Manual Number: MCWXAA01  
Edition (ECN): 2025305

# Installation, Parts, and Service

## 30022X8J, 30022X8R



PELLERIN MILNOR CORPORATION Post Office Box 400, Kenner, Louisiana 70063-0400, U.S.A.



## Contents

1 General Service and Safety-Related Components.....	7
Limited Standard Warranty .....	8
1.1 How to Get the Necessary Repair Components .....	9
1.2 Trademarks .....	9
1.3 Safety — Suspended Washer Extractors .....	10
1.3.1 Safety Alert Messages—Internal Electrical and Mechanical Hazards .....	10
1.3.2 Safety Alert Messages—Cylinder and Processing Hazards .....	10
1.3.3 Safety Alert Messages—Unsafe Conditions .....	12
1.3.3.1 Damage and Malfunction Hazards .....	12
1.3.3.1.1 Hazards Resulting from Inoperative Safety Devices.....	12
1.3.3.1.2 Hazards Resulting from Damaged Mechanical Devices .....	12
1.3.3.2 Careless Use Hazards .....	13
1.3.3.2.1 Careless Operation Hazards—Vital Information for Operator Personnel (see also operator hazards throughout manual) .....	13
1.3.3.2.2 Careless Servicing Hazards—Vital Information for Service Personnel (see also service hazards throughout manuals).....	13
1.4 Installation Tag Guidelines .....	14
Safety Placards and Locations 30022 and 36026 X8J/X8R and 42026 and 42032 X7J/X7R .....	18
Safety Placards and Locations – ISO 30022 and 36026 X8J/X8R and 42026 and 42032 X7J/ X7R.....	20
Panels and Covers .....	22
Shipping Brackets 30022X8J, 30022X8W, 30022X8R.....	24
1.5 Torque Requirements for Fasteners .....	25
1.5.1 Torque Values .....	25
1.5.1.1 Fasteners Made of Carbon Steel .....	25
1.5.1.1.1 Without a Threadlocker .....	25
1.5.1.1.2 With a Threadlocker .....	27
1.5.1.2 Stainless Steel Fasteners .....	29
1.5.2 Preparation.....	30
1.5.3 How to Apply a Threadlocker .....	31
1.5.3.1 Blind Holes.....	31
1.5.3.2 Through Holes .....	31
2 Important Installation Precautions.....	33
2.1 External Fuse/Breaker, Wiring, and Disconnect Requirements .....	33
2.1.1 Fuse or Circuit Breaker Size.....	33
• If a fuse is used.....	33
• If a standard circuit breaker is used .....	33
• If an inverse time circuit breaker is used .....	33
2.1.2 Wire Size .....	33
2.1.3 Ground.....	34
2.1.4 Disconnect Switch for Lockout/Tagout.....	34
2.1.5 Using GFCI (Ground Fault Circuit Interrupter) Device.....	34
2.2 Vital Information About the Forces Imparted to Supporting Structures by Launder- ing Machines .....	34
2.2.1 Disclaimer of Responsibility .....	35
2.2.2 Major Design Considerations .....	35

2.2.3 Primary Information Sources .....	36
2.3 Prevent Damage from Chemical Supplies and Chemical Systems .....	36
2.3.1 How Chemical Supplies Can Cause Damage.....	37
• Dangerous Chemical Supplies and Wash Formulas.....	37
• Incorrect Configuration or Connection of Equipment .....	37
2.3.2 Equipment and Procedures That Can Prevent Damage.....	39
• Use the chemical manifold supplied. ....	39
• Close the line.....	40
• Do not let a vacuum occur.....	40
• Flush the chemical tube with water.....	40
• Put the chemical tube fully below the inlet.....	40
• Prevent leaks. ....	40
3 Installation Procedures .....	41
3.1 Handling a Washer-extractor from Delivery to Final Location .....	41
3.1.1 Notices.....	41
• Qualified Personnel Only .....	41
• Disclaimer .....	41
• Other Tasks .....	41
3.1.2 Facility Prerequisites .....	42
3.1.3 Rigger Precautions.....	42
3.1.4 Technician Precautions .....	44
• Can the Door(s) Be Opened Before Utilities are Connected? .....	46
3.2 Connection Precautions for Washer-extractors .....	46
3.2.1 Notices.....	47
• Machine Must Be Anchored .....	47
3.2.2 Utility Requirements and Related Information .....	47
3.2.3 Plumber Precautions .....	48
3.2.4 Electrician Precautions .....	49
3.2.5 Chemical Supplier Precautions.....	50
3.3 Servicing the Door to Open it with Power Off or with a Malfunctioning Door Lock .....	51
3.3.1 Disassembly .....	51
3.3.1.1 Removing the Handle and Opening the Door .....	51
3.3.1.2 Removing the Door Latch Shaft from the Door Lock Mechanism .....	54
3.3.2 Reinstalling the Shaft and Door Handle .....	54
3.4 Setting Door Interlock Switches .....	56
3.4.1 How The Door Interlock Switches Work .....	56
3.4.2 Adjusting the Door Interlock Switches .....	58
4 Drive Assemblies.....	59
4.1 Drive Pulley and Belt Maintenance .....	59
4.1.1 Pulley Requirements.....	59
4.1.1.1 Condition of Grooves on Pulleys .....	60
4.1.1.2 Pulley and Shaft Position.....	60
4.1.1.3 Keep Run-Out in Tolerance.....	61
4.1.2 Belt Requirements .....	62
4.1.2.1 Condition of Belts.....	63
4.1.2.2 Tension of Belts .....	64



4.1.3 The pulleys must stay aligned when you adjust the belt tension.....	65
4.1.4 How to Do Maintenance on Pulleys and Belts .....	66
4.1.4.1 Typical Steps to Replace Pulleys and Belts.....	66
4.1.4.2 Examples of Procedures Used at the Milnor® Factory to Align Pulleys .....	67
Drive Components Identification .....	70
Drive Motor Installation .....	72
Bearing Housing Components .....	76
Bearing Housing Components and Installation .....	82
5 Cylinder and Shell Assemblies.....	86
Cylinder Installation .....	88
6 Door Assemblies .....	92
Door Assembly and Installation 30022 X8J/X8R .....	94
Door Handle and Lock Actuator .....	98
Door Lock Mechanisms MCR12; MCT16/18/27; MWF18/27; MWR27/36; MWT12/16/18/27; 3015/3022T6X, VRJ, V8Z, VZZ; 30022 X8J/X8R; 36021V5J, V5Z, V7Z; 36026V5J, V5Z, V7Z; 42026V5J, V6Z. 42030V6J, V6Z.....	101
7 Suspension.....	104
Suspension Components and Installation .....	105
Suspension Settings 3022X_, 3626X8_, 4226X7_, 4232X7_ .....	108
Shock Absorbers .....	110
8 Chemical Supply Devices.....	112
Inlet for 10 Peristaltic Chemical Supplies .....	113
Soap Chute Components and Installation 3022X_ .....	117
Five Compartments for Dry Chemical Supplies .....	120
9 Water and Steam.....	125
Water and Steam Schematic and Primary Components 3022X_ .....	126
Water Manifold & Peristaltic Boxes .....	128
Water Inlet Components and Installation 3022X .....	131
Steam Inlet Components and Installation .....	134
Drain Valve Installation .....	136
3 Inch Electrical Drain Valve .....	138
Cool Down Components and Installation .....	140
Electric Heat 3022X, 3626X, 4226X, 4232X.....	142
10 Control and Sensing .....	143
Water Level Switch & Temperature Sensor 3022X8J, 3022X8R.....	144
11 Recirculation.....	146
Reuse Tank, Recirculation Pump, and Piping 30022X8W, 30022X8R.....	148
12 Dimensional Drawings .....	152
BD3022X8CE/2025262D – 30022X8J, X8R .....	153
BD3022X8CB/2025262D – 30022X8J, X8R Options .....	154
13 Dimensional Drawings: Pedestals.....	155
BD3022XBASBE/2025262D — Pedestal Base 3022X8J, X8R .....	157

## Figures

Figure 1	30022 X8J/X8R .....	18
Figure 2	36026 X8J/X8R .....	18

Figure 3	42026 and 42032 X7J/X7R.....	19
Figure 4	30022 X8J/X8R .....	20
Figure 5	36026 X8J/X8R .....	20
Figure 6	42026 and 42032 X7J/X7R.....	21
Figure 7	General Views.....	22
Figure 8	The Bolts in Milnor® Equipment.....	25
Figure 9	Apply Threadlocker in a Blind Hole.....	31
Figure 10	Apply Threadlocker in a Through Hole.....	32
Figure 11	Use heat for disassembly of fasteners with threadlocker.....	32
Figure 12	How Rotating Forces Act On the Foundation .....	36
Figure 13	Incorrect Configurations That Let the Chemical Supply Go In the Machine by a Siphon.....	38
Figure 14	Incorrect Configurations That Let the Chemical Supply Go In the Machine by Gravity.....	39
Figure 15	Examples of Manifolds for Chemical Tubes. Your equipment can look different.....	39
Figure 16	A Configuration that Prevents Flow in the Machine When the Pump is Off (if the chemical tube and tank have no pressure) .....	40
Figure 17	Door Handle Spoke Set Screw.....	52
Figure 18	Handle Spoke Spring and Ball.....	52
Figure 19	Front Retaining Clip and Thrust Washer .....	53
Figure 20	Rear Flange Bearing (being removed) and Retaining Clip (arrow).....	53
Figure 21	Return Spring After Separation from Shaft Cam.....	53
Figure 22	Door Lock Slider Pin in the Door Lock Mechanism .....	54
Figure 23	Removing the Shaft from the Lock Mechanism.....	54
Figure 24	Shaft in the 9 o'clock Position Showing Spring Retaining Hole .....	55
Figure 25	Shaft with Return Spring Installed.....	55
Figure 26	Inserting Ball and Spring in Handle Spoke .....	56
Figure 27	Adjusting Set Screw.....	56
Figure 28	Door locking sequence.....	57
Figure 29	Examples of drives this instruction applies to: one or more V-belts, attached V-belts and tooth belts .....	59
Figure 30	Pulley Groove Condition .....	60
Figure 31	Pulley and Shaft Position.....	61
Figure 32	Run-out .....	62
Figure 33	Typical Pulley Assembly .....	62
Figure 34	Types of Belt Damage.....	64
Figure 35	A Tension Mechanism that will not Change the Angle of the Pulleys .....	65
Figure 36	Some Pairs of Tension Mechanisms that Can Change the Angle of the Pulleys.....	65
Figure 37	Use a straight edge, a string, or a laser to make sure that all pulleys are in the same plane.....	67
Figure 38	Use a level to make sure that the pulleys are at the same slope. ....	68
Figure 39	Dial indicator used to find the axial and radial run-out of a pulley. ....	68
Figure 40	General View .....	70
Figure 41	Drive Motor Installation .....	72
Figure 42	Detail View .....	73

Figure 43	Detail View .....	73
Figure 44	Bearing Housing .....	76
Figure 45	Bearing Housing Front.....	77
Figure 46	Bearing Housing Rear.....	78
Figure 47	Cylinder Installation .....	88
Figure 48	Cylinder Installation .....	89
Figure 49	Cylinder and Bearing Installation.....	89
Figure 50	Cylinder and Bearing Installation.....	90
Figure 51	Door Handle and Lock Actuator.....	98
Figure 52	Shim Adjustment Steps.....	99
Figure 53	Installed Views.....	113
Figure 54	10 Inlets for Peristaltic Liquid Chemical Systems.....	114
Figure 55	Inlet Manifold .....	115
Figure 56	Soap Chute .....	117
Figure 57	Installed Views.....	118
Figure 58	The Vacuum Breaker and Related Components .....	118
Figure 59	General Views.....	120
Figure 60	Detail View .....	120
Figure 61	Water to the Five Compartments for Dry Chemical Supplies .....	121
Figure 62	Valve Manifold .....	122
Figure 63	Valve Assembly .....	122
Figure 64	Tank .....	148
Figure 65	Recirculation Pump.....	149
Figure 66	Recirculation Piping .....	150

## Tables

Table 1	Trademarks .....	9
Table 2	Parts List—Safety Placards and Locations 30022 and 36026 X8J/X8R and 42026 and 42032 X7J/X7R.....	19
Table 3	Parts List—Safety Placards and Locations – ISO 30022 and 36026 X8J/X8R and 42026 and 42032 X7J/X7R.....	21
Table 4	Parts List—Panels and Covers .....	23
Table 5	Parts List—Shipping Brackets 30022X8J, 30022X8W, 30022X8R.....	24
Table 6	Torque Values for Standard Fasteners with Maximum 5/16-inch Diameters and No Lubricant .....	25
Table 7	Torque Values for Standard Fasteners Larger Than 5/16-inch Diameters and No Lubricant .....	26
Table 8	Torque Values for Plated Fasteners with Maximum 5/16-inch Diameters and No Lubricant .....	26
Table 9	Torque Values for Plated Fasteners Larger Than 5/16-inch Diameters and No Lubricant .....	27
Table 10	Threadlocker by the Diameter of the Bolt (see below Note ) .....	27
Table 11	Torque Values if You Apply LocTite 222 .....	28
Table 12	Torque Values if You Apply LocTite 242 .....	28
Table 13	Torque Values if You Apply LocTite 262 .....	28
Table 14	Torque Values if You Apply LocTite 272 (High-Temperature) .....	29
Table 15	Torque Values if You Apply LocTite 277 .....	29

Table 16	Torque Values for Stainless Steel Fasteners 5/16-inch and Smaller .....	29
Table 17	Torque Values for Stainless Steel Fasteners Larger Than 5/16-inch .....	30
Table 18	Typical Tools for Pulley and Belt Maintenance .....	66
Table 19	Parts List—Drive Components Identification .....	71
Table 20	Parts List—Drive Motor Installation .....	74
Table 21	Parts List—Bearing Housing Components .....	79
Table 22	Parts List—Bearing Housing Components and Installation .....	85
Table 23	Parts List—Cylinder Installation .....	91
Table 24	Parts List—Door Assembly and Installation 30022 X8J/X8R .....	97
Table 25	Parts List—Door Handle and Lock Actuator .....	100
Table 26	Parts List—Door Lock Mechanisms MCR12; MCT16/18/27; MWF18/27; MWR27/36; MWT12/16/18/27; 3015/3022T6X, VRJ, V8Z, VZZ; 30022 X8J/X8R; 36021V5J, V5Z, V7Z; 36026V5J, V5Z, V7Z; 42026V5J, V6Z. 42030V6J, V6Z.....	103
Table 27	Parts List—Suspension Components and Installation .....	107
Table 28	Parts List—Shock Absorbers .....	111
Table 29	Parts List—Inlet for 10 Peristaltic Chemical Supplies .....	115
Table 30	Parts List—Soap Chute Components and Installation 3022X_ .....	119
Table 31	Parts List—Five Compartments for Dry Chemical Supplies .....	123
Table 32	Parts List—Water and Steam Schematic and Primary Components 3022X_ .....	127
Table 33	Parts List—Inlet for Six Peristaltic Chemical Supplies and Water .....	129
Table 34	Parts List—Water Inlet Components and Installation 3022X .....	133
Table 35	Parts List—Steam Inlet Components and Installation .....	135
Table 36	Parts List—Drain Valve Installation .....	137
Table 37	Parts List—3 Inch Electrical Drain Valve .....	138
Table 38	Parts List—Cool Down Components and Installation .....	141
Table 39	Parts List—Electric Heat 3022X, 3626X, 4226X, 4232X .....	142
Table 40	Parts List—Water Level Switch & Temperature Sensor 3022X8J, 3022X8R.....	145
Table 41	Parts List—Reuse Tank, Recirculation Pump, and Piping 30022X8W, 30022X8R.....	151

# **1 General Service and Safety-Related Components**

**BMP720097 / 25142**

BRUUUM01.1 0000229985 E.2 F.4 3/31/25, 3:24 PM Released

## **PELLERIN MILNOR CORPORATION LIMITED STANDARD WARRANTY**

We warrant to the original purchaser that MILNOR machines including electronic hardware/software (hereafter referred to as "equipment"), will be free from defects in material and workmanship for a period of one year from the date of shipment (unless the time period is specifically extended for certain parts pursuant to a specific MILNOR published extended warranty) from our factory with no operating hour limitation. This warranty is contingent upon the equipment being installed, operated and serviced as specified in the operating manual supplied with the equipment, and operated under normal conditions by competent operators.

Providing we receive written notification of a warranted defect within 30 days of its discovery, we will—at our option—repair or replace the defective part or parts, EX Factory (labor and freight specifically NOT included). We retain the right to require inspection of the parts claimed defective in our factory prior to repairing or replacing same. We will not be responsible, or in any way liable, for unauthorized repairs or service to our equipment, and this warranty shall be void if the equipment is tampered with, modified, or abused, used for purposes not intended in the design and construction of the machine, or is altered in any way without MILNOR's written consent.

Parts damaged by exposure to weather, to aggressive water, or to chemical attack are not covered by this warranty. For parts which require routine replacement due to normal wear—such as gaskets, contact points, brake and clutch linings, belts, hoses, and similar parts—the warranty time period is 90 days.

We reserve the right to make changes in the design and/or construction of our equipment (including purchased components) without obligation to change any equipment previously supplied.

ANY SALE OR FURNISHING OF ANY EQUIPMENT BY MILNOR IS MADE ONLY UPON THE EXPRESS UNDERSTANDING THAT MILNOR MAKES NO EXPRESSED OR IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR ANY PARTICULAR USE OR PURPOSE OR ANY OTHER WARRANTY IMPLIED BY LAW INCLUDING BUT NOT LIMITED TO REDHIBITION. MILNOR WILL NOT BE RESPONSIBLE FOR ANY COSTS OR DAMAGES ACTUALLY INCURRED OR REQUIRED AS A RESULT OF: THE FAILURE OF ANY OTHER PERSON OR ENTITY TO PERFORM ITS RESPONSIBILITIES, FIRE OR OTHER HAZARD, ACCIDENT, IMPROPER STORAGE, MIS-USE, NEGLIGENCE, POWER OR ENVIRONMENTAL CONTROL MALFUNCTIONS, DAMAGE FROM LIQUIDS, OR ANY OTHER CAUSE BEYOND THE NORMAL RANGE OF USE. REGARDLESS OF HOW CAUSED, IN NO EVENT SHALL MILNOR BE LIABLE FOR SPECIAL, INDIRECT, PUNITIVE, LIQUIDATED, OR CONSEQUENTIAL COSTS OR DAMAGES, OR ANY COSTS OR DAMAGES WHATSOEVER WHICH EXCEED THE PRICE PAID TO MILNOR FOR THE EQUIPMENT IT SELLS OR FURNISHES.

THE PROVISIONS ON THIS PAGE REPRESENT THE ONLY WARRANTY FROM MILNOR AND NO OTHER WARRANTY OR CONDITIONS, STATUTORY OR OTHERWISE, SHALL BE IMPLIED.

WE NEITHER ASSUME, NOR AUTHORIZE ANY EMPLOYEE OR OTHER PERSON TO ASSUME FOR US, ANY OTHER RESPONSIBILITY AND/OR LIABILITY IN CONNECTION WITH THE SALE OR FURNISHING OF OUR EQUIPMENT TO ANY BUYER.

BMP720097/25142

BNUUUM01 / 2019342

BNUUUM01 0000250121 F.4 1/2/20, 2:14 PM Released

## 1.1 How to Get the Necessary Repair Components

BNUUUM01.C01 0000250120 A.3 B.3 F.4 1/2/20, 2:14 PM Released

You can get components to repair your machine from the approved supplier where you got this machine. Your supplier will usually have the necessary components in stock. You can also get components from the Milnor® factory.

Tell the supplier the machine model and serial number and this data for each necessary component:

- The component number from this manual
- The component name if known
- The necessary quantity
- The necessary transportation requirements
- If the component is an electrical component, give the schematic number if known.
- If the component is a motor or an electrical control, give the nameplate data from the used component.

To write to the Milnor® factory:

Pellerin Milnor Corporation  
Post Office Box 400  
Kenner, LA 70063-0400  
UNITED STATES

Telephone: 504-712-7775

Fax: 504-469-9777

Email: [parts@milnor.com](mailto:parts@milnor.com)

BNUUUU02 / 2023296

BNUUUU02 0000158094 F.4 7/20/23, 10:58 AM Released

## 1.2 Trademarks

BNUUUU02.R01 0000158093 G.2 F.2 F.4 7/20/23, 10:57 AM Released

These words are trademarks of Pellerin Milnor® Corporation and other entities:

**Table 1. Trademarks**

AutoSpot™	GreenFlex™	MilMetrix®	PulseFlow®
CBW®	GearTrace™	MilTouch™	RAM Command™
Drynet™	GreenTurn™	MilTouch-EX™	RecircONE®
E-P Express®	Hydro-cushion™	MilRAIL®	RinSave®
E-P OneTouch®	Mentor®	Miltrac™	SmoothCoil™



**Table 1 Trademarks (cont'd.)**

E-P Plus®	Mildata®	MilVision™	Staph Guard®
Gear Guardian®	Milnor®	PBW™	

BNWSUS08 / 21224

BNWSUS08 0000348933 F.4 5/26/21, 12:00 PM Released

## 1.3 Safety — Suspended Washer Extractors

BNWSUS08.C01 0000348932 A.2 F.4 5/26/21, 11:48 AM Released

### 1.3.1 Safety Alert Messages—Internal Electrical and Mechanical Hazards

BNWSUS01.C03 0000234965 A.2 A.4 F.4 1/2/20, 2:19 PM Released

The following are instructions about hazards inside the machine and in electrical enclosures.



**WARNING: Electrocutation and Electrical Burn Hazards** — Contact with electric power can kill or seriously injure you. Electric power is present inside the cabinetry unless the main machine power disconnect is off.

- ▶ Do not unlock or open electric box doors.
- ▶ Do not remove guards, covers, or panels.
- ▶ Do not reach into the machine housing or frame.
- ▶ Keep yourself and others off of machine.
- ▶ Know the location of the main machine disconnect and use it in an emergency to remove all electric power from the machine.



**WARNING: Entangle and Crush Hazards** — Contact with moving components normally isolated by guards, covers, and panels, can entangle and crush your limbs. These components move automatically.

- ▶ Do not remove guards, covers, or panels.
- ▶ Do not reach into the machine housing or frame.
- ▶ Keep yourself and others off of machine.
- ▶ Know the location of all emergency stop switches, pull cords, and/or kick plates and use them in an emergency to stop machine motion.

### 1.3.2 Safety Alert Messages—Cylinder and Processing Hazards

BNWSUS03.C03 0000234973 A.2 A.3 F.4 1/2/20, 2:19 PM Released

The following are instructions about hazards related to the cylinder and laundering process.





**DANGER: Entangle and Sever Hazards** — Contact with goods being processed can cause the goods to wrap around your body or limbs and dismember you. The goods are normally isolated by the locked cylinder door.

- ▶ Do not attempt to open the door or reach into the cylinder until the cylinder is stopped.
- ▶ Do not touch goods inside or hanging partially outside the turning cylinder.
- ▶ Do not operate the machine with a malfunctioning door interlock.
- ▶ Open pocket machines only—Do not jog the cylinder and pull the goods at the same time.
- ▶ Open pocket machines only—Keep yourself and others clear of cylinder and goods during jogging operation.
- ▶ Do not operate the machine with malfunctioning two-hand manual controls.
- ▶ Know the location of all emergency stop switches, pull cords, and/or kick plates and use them in an emergency to stop machine motion.
- ▶ Know the location of the main machine disconnect and use it in an emergency to remove all electric power from the machine.



**WARNING: Crush Hazards** — Contact with the turning cylinder can crush your limbs. The cylinder will repel any object you try to stop it with, possibly causing the object to strike or stab you. The turning cylinder is normally isolated by the locked cylinder door.

- ▶ Do not attempt to open the door or reach into the cylinder until the cylinder is stopped.
- ▶ Do not place any object in the turning cylinder.
- ▶ Do not operate the machine with a malfunctioning door interlock.
- ▶ Open pocket machines only—Keep yourself and others clear of cylinder and goods during jogging operation.
- ▶ Do not operate the machine with malfunctioning two-hand manual controls.



**WARNING: Confined Space Hazards** — Confinement in the cylinder can kill or injure you. Hazards include but are not limited to panic, burns, poisoning, suffocation, heat prostration, biological contamination, electrocution, and crushing.

- ▶ Do not attempt unauthorized servicing, repairs, or modification.



**WARNING: Explosion and Fire Hazards** — Flammable substances can explode or ignite in the cylinder, drain trough, or sewer. The machine is designed for washing with water, not any other solvent. Processing can cause solvent-containing goods to give off flammable vapors.

- ▶ Do not use flammable solvents in processing.
- ▶ Do not process goods containing flammable substances. Consult with your local fire department/public safety office and all insurance providers.

### 1.3.3 Safety Alert Messages—Unsafe Conditions

BNWSUS04.C01 0000235002 A.2 A.3 F.4 12/10/20, 4:36 PM Released

#### 1.3.3.1 Damage and Malfunction Hazards

BNWSUS04.C02 0000235001 A.2 A.3 F.4 12/10/20, 4:36 PM Released

##### 1.3.3.1.1 Hazards Resulting from Inoperative Safety Devices

BNWSUS04.C03 0000235000 A.2 A.6 F.4 12/10/20, 4:36 PM Released




**DANGER: Entangle and Sever Hazards** — Cylinder door interlock—Operating the machine with a malfunctioning door interlock can permit opening the door when the cylinder is turning and/or starting the cycle with the door open, exposing the turning cylinder.

- ▶ Do not operate the machine with any evidence of damage or malfunction.



**WARNING: Multiple Hazards** — Operating the machine with an inoperative safety device can kill or injure personnel, damage or destroy the machine, damage property, and/or void the warranty.

- ▶ Do not tamper with or disable any safety device or operate the machine with a malfunctioning safety device. Request authorized service.



**WARNING: Electrocution and Electrical Burn Hazards** — Electric box doors—Operating the machine with any electric box door unlocked can expose high voltage conductors inside the box.

- ▶ Do not unlock or open electric box doors.



**WARNING: Entangle and Crush Hazards** — Guards, covers, and panels—Operating the machine with any guard, cover, or panel removed exposes moving components.

- ▶ Do not remove guards, covers, or panels.

##### 1.3.3.1.2 Hazards Resulting from Damaged Mechanical Devices

BNWSUS04.C04 0000234999 A.2 A.4 F.4 12/10/20, 4:36 PM Released



**WARNING: Multiple Hazards** — Operating a damaged machine can kill or injure personnel, further damage or destroy the machine, damage property, and/or void the warranty.

- ▶ Do not operate a damaged or malfunctioning machine. Request authorized service.



**WARNING: Explosion Hazards — Cylinder**—A damaged cylinder can rip apart during extraction, puncturing the shell and discharging metal fragments at high speed.

- ▶ Do not operate the machine with any evidence of damage or malfunction.



**WARNING: Explosion Hazards — Clutch and speed switch (multiple motor machines)**—A damaged clutch or speed switch can permit the low speed motor to engage during extract. This will over-speed the motor and pulleys and can cause them to rip apart, discharging metal fragments at high speed.

- ▶ Stop the machine immediately if any of these conditions occur: • abnormal whining sound during extract • skidding sound as extract ends • clutches remain engaged or re-engage during extract

### 1.3.3.2 Careless Use Hazards

BNWSUS04.C05 0000234998 A.2 A.3 F.4 12/10/20, 4:36 PM Released

#### 1.3.3.2.1 Careless Operation Hazards—Vital Information for Operator Personnel (see also operator hazards throughout manual)

BNWSUS04.C06 0000234997 A.2 A.4 F.4 12/10/20, 4:36 PM Released




**WARNING: Multiple Hazards** — Careless operator actions can kill or injure personnel, damage or destroy the machine, damage property, and/or void the warranty.

- ▶ Do not tamper with or disable any safety device or operate the machine with a malfunctioning safety device. Request authorized service.
- ▶ Do not operate a damaged or malfunctioning machine. Request authorized service.
- ▶ Do not attempt unauthorized servicing, repairs, or modification.
- ▶ Do not use the machine in any manner contrary to the factory instructions.
- ▶ Use the machine only for its customary and intended purpose.
- ▶ Understand the consequences of operating manually.

#### 1.3.3.2.2 Careless Servicing Hazards—Vital Information for Service Personnel (see also service hazards throughout manuals)

BNWSUS04.C07 0000234996 A.2 A.4 F.4 12/10/20, 4:36 PM Released



**WARNING: Electrocution and Electrical Burn Hazards** — Contact with electric power can kill or seriously injure you. Electric power is present inside the cabinetry unless the main machine power disconnect is off.

- ▶ Do not service the machine unless qualified and authorized. You must clearly understand the hazards and how to avoid them.

- ▶ Abide by the current OSHA lockout/tagout standard when lockout/tagout is called for in the service instructions. Outside the USA, abide by the OSHA standard in the absence of any other overriding standard.



**WARNING: Entangle and Crush Hazards** — Contact with moving components normally isolated by guards, covers, and panels, can entangle and crush your limbs. These components move automatically.

- ▶ Do not service the machine unless qualified and authorized. You must clearly understand the hazards and how to avoid them.
- ▶ Abide by the current OSHA lockout/tagout standard when lockout/tagout is called for in the service instructions. Outside the USA, abide by the OSHA standard in the absence of any other overriding standard.



**WARNING: Confined Space Hazards** — Confinement in the cylinder can kill or injure you. Hazards include but are not limited to panic, burns, poisoning, suffocation, heat prostration, biological contamination, electrocution, and crushing.

- ▶ Do not enter the cylinder until it has been thoroughly purged, flushed, drained, cooled, and immobilized.

BNWXAI01 / 2025332

BNWXAI01 0000829620 F.4 8/11/25, 10:04 AM Released

## 1.4 Installation Tag Guidelines

BNWXAI01.R01 0000187244 B.3 D.2 F.4 8/11/25, 10:04 AM Released


30022X8J	30022X8R	36026X8J	36026X8R
42026X7J	42026X7R	42032X7J	42032X7R



**NOTICE:** This information may apply to models in addition to those listed above. It applies to paper tags. It does not apply to the vinyl or metal safety placards, which must remain permanently affixed to the machine and replaced if no longer readable.

Paper tags on the machine provide installation guidelines and precautions. The tags can be tie-on or adhesive. You can remove tie-on tags and white, adhesive tags after installation. Yellow adhesive tags must remain on the machine.

The following entries explain the installation tags. Each entry includes: 1) the tag illustration, 2) the tag part number at the bottom of the tag, and 3) the meaning of the tag.


Symbol	Explanation
	Read the manuals before proceeding. This symbol appears on most tags. The machine ships with safety, operator, and routine maintenance guides for customer use. Milnor dealer manuals for installing, commissioning, and servicing the machine are also available from the Milnor Parts department.



B2TAG88005: This carefully built product was tested and inspected to meet Milnor performance and quality standards by (identification mark of tester).




B2TAG94078: Do not forklift here; do not jack here; do not step here—whichever applies.



B2TAG94079: Rig for crane lifting (either 3-point or 4-point, depending on the number of lifting eyes provided) using a steep angle on the chains (closer to vertical than horizontal).


B2TAG94081: Motor must rotate in this direction. On single motor washer-extractors and centrifugal extractors, the drive motor must turn in this direction during draining and extraction. This tag is usually wrapped around a motor housing. If the motor turns in the opposite direction when the machine is first tested, the electrical hookup is incorrect and must be reversed as explained in the schematic manual.




B2TAG94084: Do not lift from one corner of the machine, as this can cause the frame to rack, damaging it.



B2TAG94097: The cylinder must rotate **counterclockwise** during draining and extraction (spin) when viewed from here (rear of machine). Otherwise, reverse the electric power connections, as explained in the schematic manual.



B2TAG94099: Do not strike the shell door when fork-lifting. This can cause the door to leak.




B2T2001013: Hot water connection.




B2T2001014: Cold water connection.



B2T2001015: Reuse (third) water connection. (Optional)




B2T2001016: Flushing water connection. This is the water that goes into the supply compartment or pumped chemical manifold to flush chemicals into the machine.



B2T2001028: Look for tags inside the machine. These tags may identify shipping restraints to be removed or components to be installed. Do not start the machine until these actions are completed.



B2T2002013: Do not start the machine until shipping restraints are removed. This tag will appear on the outside of the machine to alert you to the presence of internal shipping restraints. A tag will also appear on the restraint to help identify it. Most, but not all shipping restraints display the color red. Some shipping restraints are also safety stands. Do not discard these.



B2T2003001: Hold the side of the connection stationary with a wrench as you tighten the connection with another wrench. Otherwise, you may twist components, such as valves, damaging them.



B2T2004027: Steam connection. (Optional)

Safety Placards and Locations

2 Sheets

30022 and 36026 X8J/X8R and 42026 and 42032 X7J/X7R



**NOTE:** Replace placard immediately, if removed or unreadable. Approximate locations of placards are shown. If aluminum placard, mounting holes are provided on machine. Use #8 self-tapping screws.

Figure 1. 30022 X8J/X8R





Figure 2. 36026 X8J/X8R





Safety Placards and Locations

2 Sheets

30022 and 36026 X8J/X8R and 42026 and 42032 X7J/X7R

Figure 3. 42026 and 42032 X7J/X7R




Table 2. Parts List—Safety Placards and Locations

Find the assembly for your machine and the letter shown in the "Item" column. The components for your machine will show this letter or the word "all" in the "Used In" column. The numbers shown in the "Item" column are those shown in the illustrations.				
Used In	Item	Part Number	Description/Nomenclature	Comments
Components				
all	1	01 10631A	NPLT:SHELL FRT WARN NOTILT-TCA	
all	2	01 10377A	NPLT:ELEC HAZARD LG-TCATA	
all	3	01 10699A	NPLT:SERV HZRD-PLYEST-TCATA	

Safety Placards and Locations – ISO

2 Sheets

30022 and 36026 X8J/X8R and 42026 and 42032 X7J/X7R



**NOTE:** This document is for placards that agree with ISO. Replace placard immediately, if removed or unreadable. Approximate locations of placards are shown. If aluminum placard, mounting holes are provided on the machine. Use #8 self-tapping screws.

Figure 4. 30022 X8J/X8R





Figure 5. 36026 X8J/X8R



## Safety Placards and Locations – ISO

2 Sheets

30022 and 36026 X8J/X8R and 42026 and 42032 X7J/X7R

Figure 6. 42026 and 42032 X7J/X7R




Table 3. Parts List—Safety Placards and Locations – ISO

Find the assembly for your machine and the letter shown in the "Item" column. The components for your machine will show this letter or the word "all" in the "Used In" column. The numbers shown in the "Item" column are those shown in the illustrations.				
Used In	Item	Part Number	Description/Nomenclature	Comments
none				
Components				
A	1	01 10631X	NPLT:WE1-NONTILT WARNINGS FRT	30022 and 36026 X8J/X8R
B	1	01 10631Y	NPLT:SHELL FRT WARN NOTILT-ISO	42026 and 42032 X7J/X7R
all	2	01 10377	NPLTE:"WARNING" 4X4	
all	3	01 10628X	NPLT:NONTILT W/E WARNING SIDE	

Figure 7. General Views



## Panels and Covers

2 Sheets

**Table 4. Parts List—Panels and Covers**

Find the assembly for your machine and the letter shown in the "Item" column. The components for your machine will show this letter or the word "all" in the "Used In" column. The numbers shown in the "Item" column are those shown in the illustrations.				
Used In	Item	Part Number	Description/Nomenclature	Comments
Reference Assemblies				
	A	GGS3022X8	INSTALL COVER 3022X8J	
Components				
all	1	02 02925	COVER= SIDE 3022X8	
all	2	02 02929	COVER REAR 3022X8J	
all	3	02 02931	COSM TOP COVER 3022X8	
all	4	15N110H	RDWASHHD TORXBOLT M6-1X25MM ZN	
all	5	15G004HB	EXTRUNUT M6-1 GRIP 0.8-4MM	


Shipping Brackets

1 Sheet

30022X8J, 30022X8W, 30022X8R



**NOTE:** Shipping brackets must be used to move the machine. Before operating the machine, remove all shipping brackets (painted red). For further instructions, see BNWUUI03, Washer Extractor Installation.



Legend

- A . . . 4, 5, 6, Typical
- B . . . 7, Typical

Table 5. Parts List—Shipping Brackets

Find the assembly for your machine and the letter shown in the "Item" column. The components for your machine will show this letter or the word "all" in the "Used In" column. The numbers shown in the "Item" column are those shown in the illustrations.				
Used In	Item	Part Number	Description/Nomenclature	Comments
Components				
all	1	W2 02937	ANGLE SHIPPING WELD	
all	2	02 02936	SHELL SHIPPING STRAP	
all	3	02 23543	BRKT=SHIP LOWER FRNT	
all	4	15K129	HEXFLGSCR 1/2-13X1-1/4ZN. GR 5	
all	5	15G222B	HEXFLGNUT 1/2-13 ZINC	
all	6	15U280	FL+WASHER(USS STD)1/2 ZNC PL+D	
all	7	15K154G	INDHEXFLGSCR 1/2-13X1+3/4GR5 Z	

BNUUUN02 / 2019125


BNUUUN02 0000222452 F.4 1/2/20, 2:14 PM Released

## 1.5 Torque Requirements for Fasteners

BNUUUN02.C01 0000222451 A.3 B.3 F.4 1/2/20, 2:14 PM Released

The document about the assembly gives the torque requirements for other fasteners. **If fastener torque specifications or threadlocker requirements in an assembly document are different from this document, use the assembly document.**

**Figure 8. The Bolts in Milnor® Equipment**

The Marks on Bolt Heads	Legend
	<p><b>A</b> . . . SAE Grades 1 and 2, ASTM A307, and stainless steel</p> <p><b>B</b> . . . Grade BC, ASTM A354</p> <p><b>C</b> . . . SAE Grade 5, ASTM A449</p> <p><b>D</b> . . . SAE Grade 8 and ASTM A354 BD</p>

### 1.5.1 Torque Values

BNUUUN02.C02 0000222449 A.3 B.3 F.4 1/2/20, 2:14 PM Released

These tables give the standard dimension, grade, threadlocker, and torque requirements for fasteners frequently used on Milnor® equipment.



**NOTE:** Data from the Pellerin Milnor® Corporation “Bolt Torque Specification” (bolt\_torque\_milnor.xls/2002096).

#### 1.5.1.1 Fasteners Made of Carbon Steel

BNUUUN02.C03 0000222448 A.3 B.3 F.4 1/2/20, 2:14 PM Released

##### 1.5.1.1.1 Without a Threadlocker

BNUUUN02.C04 0000222447 A.3 B.3 F.4 1/2/20, 2:14 PM Released

**Table 6. Torque Values for Standard Fasteners with Maximum 5/16-inch Diameters and No Lubricant**

Dimension	The Grade of the Bolt							
	Grade 2		Grade 5		Grade 8		Grade BC	
	Pound-Inches	N-m	Pound-Inches	N-m	Pound-Inches	N-m	Pound-Inches	N-m
1/4 x 20	66	7	101	11	143	16	126	14
1/4 x 28	76	9	116	13	163	18	–	–
5/16 x 18	136	15	209	24	295	33	258	29
5/16 x 24	150	17	232	26	325	37	–	–

**Table 7. Torque Values for Standard Fasteners Larger Than 5/16-inch Diameters and No Lubricant**

Dimension	The Grade of the Bolt							
	Grade 2		Grade 5		Grade 8		Grade BC	
	Pound-Feet	N-m	Pound-Feet	N-m	Pound-Feet	N-m	Pound-Feet	N-m
3/8 x 16	20	27	31	42	44	59	38	52
3/8 x 24	23	31	35	47	50	68	—	—
7/16 x 14	32	43	49	66	70	95	61	83
7/16 x 20	36	49	55	75	78	105	—	—
1/2 x 13	49	66	75	102	107	145	93	126
1/2 x 20	55	75	85	115	120	163	—	—
9/16 x 12	70	95	109	148	154	209	134	182
9/16 x 18	78	106	121	164	171	232	—	—
5/8 x 11	97	131	150	203	212	287	186	252
5/8 x 18	110	149	170	231	240	325	—	—
3/4 x 10	172	233	266	361	376	510	329	446
3/4 x 16	192	261	297	403	420	569	—	—
7/8 x 9	167	226	429	582	606	821	531	719
7/8 x 14	184	249	473	641	668	906	—	—
1 x 8	250	339	644	873	909	1232	796	1079
1 x 12	274	371	704	954	994	1348	—	—
1 x 14	281	381	723	980	1020	1383	—	—
1 1/8 x 7	354	480	794	1077	1287	1745	1126	1527
1 1/8 x 12	397	538	891	1208	1444	1958	—	—
1 1/4 x 7	500	678	1120	1519	1817	2464	1590	2155
1 1/4 x 12	553	750	1241	1682	2012	2728	—	—
1 3/8 x 6	655	888	1469	1992	2382	3230	2085	2827
1 3/8 x 12	746	1011	1672	2267	2712	3677	—	—
1 1/2 x 6	869	1178	1949	2642	3161	4286	2767	3751
1 1/2 x 12	979	1327	2194	2974	3557	4822	—	—

**Table 8. Torque Values for Plated Fasteners with Maximum 5/16-inch Diameters and No Lubricant**

Dimension	The Grade of the Bolt							
	Grade 2		Grade 5		Grade 8		Grade BC	
	Pound-Inches	N-m	Pound-Inches	N-m	Pound-Inches	N-m	Pound-Inches	N-m
1/4 x 20	49	6	76	9	107	12	95	11
1/4 x 28	56	6	88	10	122	14	—	—
5/16 x 18	102	12	156	18	222	25	193	22
5/16 x 24	113	13	174	20	245	28	—	—



**Table 9. Torque Values for Plated Fasteners Larger Than 5/16-inch Diameters and No Lubricant**

Dimension	The Grade of the Bolt							
	Grade 2		Grade 5		Grade 8		Grade BC	
	Pound-Feet	N-m	Pound-Feet	N-m	Pound-Feet	N-m	Pound-Feet	N-m
3/8 x 16	15	20	23	31	33	44	29	38
3/8 x 24	17	23	26	35	37	49	–	–
7/16 x 14	24	32	37	50	52	71	46	61
7/16 x 20	27	36	41	55	58	78	–	–
1/2 x 13	37	49	56	76	80	106	70	93
1/2 x 20	41	55	64	85	90	120	–	–
9/16 x 12	53	70	81	110	115	153	101	134
9/16 x 18	59	79	91	122	128	174	–	–
5/8 x 11	73	97	113	150	159	212	139	186
5/8 x 18	83	110	127	172	180	240	–	–
3/4 x 10	129	173	200	266	282	376	246	329
3/4 x 16	144	192	223	297	315	420	–	–
7/8 x 9	125	166	322	430	455	606	398	531
7/8 x 14	138	184	355	474	501	668	–	–
1 x 8	188	250	483	644	682	909	597	796
1 x 12	205	274	528	716	746	995	–	–
1 x 14	210	280	542	735	765	1037	–	–
1 1/8 x 7	266	354	595	807	966	1288	845	1126
1 1/8 x 12	298	404	668	890	1083	1444	–	–
1 1/4 x 7	375	500	840	1120	1363	1817	1192	1590
1 1/4 x 12	415	553	930	1261	1509	2013	–	–
1 3/8 x 6	491	655	1102	1470	1787	2382	1564	2085
1 3/8 x 12	559	758	1254	1672	2034	2712	–	–
1 1/2 x 6	652	870	1462	1982	2371	3161	2075	2767
1 1/2 x 12	733	994	1645	2194	2668	3557	–	–

**1.5.1.1.2 With a Threadlocker**

BNUUUN02.C05 0000222446 A.3 B.3 F.4 1/2/20, 2:14 PM Released

**Table 10. Threadlocker by the Diameter of the Bolt (see below Note )**

LocTite Product	Dimension			
	1/4-inch	1/4- to 5/8-inch	5/8- to 7/8-inch	1-inch +
LocTite 222	OK			
LocTite 242		OK		
LocTite 262			OK	
LocTite 272			High temperature	
LocTite 277				OK



**NOTE:** The acceptable bolt size ranges for various LocTite® threadlocking products is the LocTite manufacturer's **general** recommendation. Specific applications sometime require that a LocTite product is applied to a bolt size outside the ranges shown here. For example, Milnor® specifies LocTite 242 for use on certain 1" bolt applications and has confirmed this usage with the LocTite manufacturer. You may see variances such as this in the documentation for specific machine assemblies.

**Table 11. Torque Values if You Apply LocTite 222**

Dimension	The Grade of the Bolt							
	Grade 2		Grade 5		Grade 8		Grade BC	
	Pound-Inches	N-m	Pound-Inches	N-m	Pound-Inches	N-m	Pound-Inches	N-m
1/4 x 20	60	7	96	11	132	15	108	12
1/4 x 28	72	8	108	12	144	16	–	–

**Table 12. Torque Values if You Apply LocTite 242**

Dimension	The Grade of the Bolt							
	Grade 2		Grade 5		Grade 8		Grade BC	
	Pound-Feet	N-m	Pound-Feet	N-m	Pound-Feet	N-m	Pound-Feet	N-m
5/16 x 18	11	15	17	23	25	34	22	30
5/16 x 24	13	18	19	26	27	37	27	37
3/8 x 16	20	27	31	42	44	60	38	52
3/8 x 24	23	31	35	47	50	68	–	–
7/16 x 14	32	43	49	66	70	95	61	83
7/16 x 20	36	49	55	75	78	106	–	–
1/2 x 13	49	66	75	102	107	145	93	126
1/2 x 20	55	75	85	115	120	163	–	–
9/16 x 12	70	95	109	148	154	209	134	182
9/16 x 18	78	106	121	164	171	232	–	–
5/8 x 11	97	132	150	203	212	287	186	252
5/8 x 18	110	149	170	230	240	325	–	–

**Table 13. Torque Values if You Apply LocTite 262**

Dimension	The Grade of the Bolt							
	Grade 2		Grade 5		Grade 8		Grade BC	
	Pound-Feet	N-m	Pound-Feet	N-m	Pound-Feet	N-m	Pound-Feet	N-m
3/4 x 10	155	210	240	325	338	458	296	401
3/4 x 16	173	235	267	362	378	512	–	–
7/8 x 9	150	203	386	523	546	740	477	647
7/8 x 14	165	224	426	578	601	815	–	–

**Table 14. Torque Values if You Apply LocTite 272 (High-Temperature)**

Dimension	The Grade of the Bolt							
	Grade 2		Grade 5		Grade 8		Grade BC	
	Pound-Feet	N-m	Pound-Feet	N-m	Pound-Feet	N-m	Pound-Feet	N-m
1 x 8	350	475	901	1222	1272	1725	1114	1510
1 x 12	383	519	986	1337	1392	1887	—	—
1 x 14	393	533	1012	1372	1428	1936	—	—
1-1/8 x 7	496	672	1111	1506	1802	2443	1577	2138
1-1/8 x 12	556	754	1247	1691	2022	2741	—	—
1-1/4 x 7	700	949	1568	2126	2544	3449	2226	3018
1-1/4 x 12	774	1049	1737	2355	2816	3818	—	—
1-3/8 x 6	917	1243	2056	2788	3335	4522	2919	3958
1-3/8 x 12	1044	1415	2341	3174	3797	5148	—	—
1-1/2 x 6	1217	1650	2729	3700	4426	6001	3873	5251
1-1/2 x 12	1369	1856	3071	4164	4980	6752	—	—

**Table 15. Torque Values if You Apply LocTite 277**

Dimension	The Grade of the Bolt							
	Grade 2		Grade 5		Grade 8		Grade BC	
	Pound-Feet	N-m	Pound-Feet	N-m	Pound-Feet	N-m	Pound-Feet	N-m
1 x 8	325	441	837	1135	1181	1601	1034	1402
1 x 12	356	483	916	1242	1293	1753	—	—
1 x 14	365	495	939	1273	1326	1798	—	—
1-1/8 x 7	461	625	1032	1399	1674	2270	1464	1985
1-1/8 x 12	516	700	1158	1570	1877	2545	—	—
1-1/4 x 7	650	881	1456	1974	2362	3202	2067	2802
1-1/4 x 12	719	975	1613	2187	2615	3545	—	—
1-3/8 x 6	851	1154	1909	2588	3097	4199	2710	3674
1-3/8 x 12	970	1315	2174	2948	3526	4781	—	—
1-1/2 x 6	1130	1532	2534	3436	4110	5572	3597	4877
1-1/2 x 12	1271	1723	2852	3867	4624	6269	—	—

### 1.5.1.2 Stainless Steel Fasteners

BNUUUN02.C06 0000222445 A.3 B.3 F.4 1/2/20, 2:14 PM Released

**Table 16. Torque Values for Stainless Steel Fasteners 5/16-inch and Smaller**

Dimension	316 Stainless		18-8 Stainless		18-8 Stainless with Loctite 767	
	Pound-Inches	N-m	Pound-Inches	N-m	Pound-Inches	N-m
1/4 x 20	79	9	76	9	45	5
1/4 x 28	100	11	94	11	56	6
5/16 x 18	138	16	132	15	79	9
5/16 x 24	148	17	142	16	85	10

**Table 17. Torque Values for Stainless Steel Fasteners Larger Than 5/16-inch**

Dimension	316 Stainless		18-8 Stainless		18-8 Stainless with Loctite 767	
	Pound-Feet	N-m	Pound-Feet	N-m	Pound-Feet	N-m
3/8 x 16	21	28	20	27	12	16
3/8 x 24	23	31	22	29	13	18
7/16 x 14	33	44	31	42	19	25
7/16 x 20	35	47	33	45	20	27
1/2 x 13	45	61	43	58	26	35
1/2 x 20	47	64	45	61	27	37
9/16 x 12	59	81	57	77	34	46
9/16 x 18	66	89	63	85	38	51
5/8 x 11	97	131	93	125	56	75
5/8 x 18	108	150	104	141	62	84
3/4 x 10	132	179	128	173	77	104
3/4 x 16	130	176	124	168	75	101
7/8 x 9	203	275	194	263	116	158
7/8 x 14	202	273	193	262	116	157
1 x 8	300	406	287	389	172	233
1 x 14	271	367	259	351	156	211
1-1/8 x 7	432	586	413	560	248	336
1-1/8 x 12	408	553	390	529	234	317
1-1/4 x 7	546	740	523	709	314	425
1-1/4 x 12	504	683	480	651	288	390
1-1/2 x 6	930	1261	888	1204	533	722
1-1/2 x 12	732	992	703	953	422	572

## 1.5.2 Preparation

BNUUUN02.T01 0000222511 B.2 B.3 F.4 4/20/23, 9:05 AM Released



**WARNING: Fire Hazard** — Some solvents and primers are flammable.

- ▶ Use threadlocker and primers with sufficient airflow.
- ▶ Do not use flammable material near ignition sources.

1. Clean all threads with a wire brush or a different tool.
2. Remove the grease from the fasteners and the mating threads with solvent. Make the parts dry.




**NOTE:** LocTite 7649 Primer™ or standard solvents will remove grease from parts.

3. Apply a spray of LocTite 7649 Primer™ or equal on the fasteners and the mating threads. Let the primer dry for one minute minimum.

### 1.5.3 How to Apply a Threadlocker

BNUUUN02.T02 0000222508 B.2 B.3 F.4 4/20/23, 9:09 AM Released




**CAUTION: Malfunction Hazard** — Heat, vibration, or mechanical shocks can let the fasteners loosen if you do not apply the threadlocker correctly. Loose fasteners can cause malfunctions of the equipment.

- Read the threadlocker manufacturer's instructions and warnings. Obey these instructions.

Apply the threadlocker only to the areas where the fastener threads and the mating threads engage.

**Figure 9. Apply Threadlocker in a Blind Hole**



#### 1.5.3.1 Blind Holes

BNUUUN02.T03 0000222507 A.3 B.3 F.4 1/2/20, 2:14 PM Released


1. Apply the threadlocker down the threads to the bottom of the hole.
2. Apply the threadlocker to the bolt.
3. Tighten the bolt to the value shown in the correct table ([Table 10: Threadlocker by the Diameter of the Bolt \(see below Note \), page 27](#) to [Table 16: Torque Values for Stainless Steel Fasteners 5/16-inch and Smaller, page 29](#) ).

#### 1.5.3.2 Through Holes

BNUUUN02.T04 0000222506 A.3 B.3 F.4 11/26/19, 2:51 PM Released

1. Put the bolt through the assembly.
2. Apply the threadlocker only to the bolt thread area that will engage the nut.
3. Tighten the bolt to the value shown in the correct table ([Table 10: Threadlocker by the Diameter of the Bolt \(see below Note \), page 27](#) to [Table 16: Torque Values for Stainless Steel Fasteners 5/16-inch and Smaller, page 29](#) ).

**Figure 10. Apply Threadlocker in a Through Hole**




### 1.5.3.3 Disassembly

BNUUUN02.C07 0000222444 A.3 B.3 F.4 11/26/19, 2:59 PM Released

For high-strength threadlocker, apply heat for five minutes. Disassemble with hand tools while the parts are hot.

For low-strength and moderate-strength threadlocker, disassemble with hand tools.

**Figure 11. Use heat for disassembly of fasteners with threadlocker.**



## 2 Important Installation Precautions

BFUUUF01 / 2023174

BNUUUF01 0000109243 F.4 4/26/23, 10:44 AM Released

### 2.1 External Fuse/Breaker, Wiring, and Disconnect Requirements

BNUUUF01.C01 0000109242 A.4 D.2 F.4 1/2/20, 2:14 PM Released

An external fuse **or** circuit breaker and a disconnect switch must be provided in the facility for (and dedicated to) the machine. These may be in the same or separate, **permanently mounted** electric boxes. Electric power and ground connections will be made between the incoming power junction box on the machine and this external box (or one of the boxes).

#### 2.1.1 Fuse or Circuit Breaker Size

BNUUUF01.R01 0000109241 A.4 D.2 F.4 1/2/20, 2:14 PM Released

Refer to the “External Fuse and Wire Sizes...” document for your machine model. This document will be found in the machine's installation manual, available from the parts department. Choose the fuse or circuit breaker from the appropriate column of the table provided, as follows:

**If a fuse is used** — Match the fuse listed in the “Fuse” column for your machine's voltage. The specified fuse sizes are consistent with the USA National Electric Code (NEC), section 430-52, exception No. 2, Part B, which states: “The rating of a time-delay (dual-element) fuse shall be permitted to be increased, but shall in no case exceed 225 percent of the full-load current.”

**If a standard circuit breaker is used** — Match the amperage rating listed in the “Breaker” column for your machine's voltage.

**If an inverse time circuit breaker is used** — Match the characteristics (amperage rating) of the fuse listed in the “Fuse” column for your machine's voltage. When applied to an inverse time circuit breaker, the specified fuse sizes are consistent with the USA National Electric Code (NEC), section 430-52, exception No. 2, Part C, which states: “The rating of an inverse time circuit breaker shall be permitted to be increased, but shall in no case exceed 400 percent for full-load currents of 100 amperes or less.”

#### 2.1.2 Wire Size

BNUUUF01.R02 0000109240 A.4 D.2 F.4 1/2/20, 2:14 PM Released

Use wiring no smaller than that listed for your machine's voltage in the “Wire size...” column in the “External Fuse and Wire Sizes...” document. The table value applies to runs up to 50 feet (15 meters). Use the next larger size for runs 50 to 100 feet (15 to 30 meters). Use wire two sizes larger for runs greater than 100 feet (30 meters). If an inverse time circuit breaker is used and local codes require a larger wire size than that specified by Milnor, abide by the local code.



**NOTICE:** The specified wire size may appear too small for the fuse or circuit breaker shown. However, it is consistent with both the load imposed and with the USA National Electric Code.

### 2.1.3 Ground

BNUUUF01.R03 0000109239 A.4 D.2 F.4 1/2/20, 2:14 PM Released

The ground wire and connections must ensure a reliable earth ground (zero potential). Use wiring of at least as large a gauge as that required for incoming power. Do not rely on conduit, machine anchorage, etc. Use the ground lug provided in the incoming power junction box on the machine.

### 2.1.4 Disconnect Switch for Lockout/Tagout

BNUUUF01.R04 0000109238 A.5 D.2 F.4 1/2/20, 2:14 PM Released

The disconnect switch must permit personnel to disconnect and lockout/tagout electric power from the machine. In the USA, refer to OSHA standard 1910.147 “The control of hazardous energy (lockout/tagout)”. Refer to the USA National Electric Code for requirements on locating the switch. In other locales, abide by these standards if no other local codes apply.

### 2.1.5 Using GFCI (Ground Fault Circuit Interrupter) Device

BNUUUF01.R05 0000571262 A.2 D.2 F.4 4/26/23, 10:44 AM Released

The AC Drive will most likely cause the GFCI protection device to trip. The reason the AC Drive will cause this tripping of the GFCI is the Common Mode Current or Common Mode Noise (CM Noise) that the VFD is producing.

Use a GFCI with a higher trip level.



**NOTE:** Choose a GFCI designed specifically for an AC drive. The operation time should be at least 0.1 s with sensitivity amperage of at least 200 mA per drive. The output waveform of the drive may cause an increase in leakage current. This may in turn cause the leakage breaker to malfunction. Increase the sensitivity amperage or lower the carrier frequency to correct the problem.

Use a type B GFCI according to IEC/EN 60755.

BNUUUI01 / 2019392

BNUUUI01 0000189337 F.4 1/2/20, 2:14 PM Released

## 2.2 Vital Information About the Forces Imparted to Supporting Structures by Laundering Machines

BNUUUI01.C01 0000189336 A.5 C.3 F.4 1/2/20, 2:14 PM Released

This document replaces Milnor® document BIWUUI02.

All laundering machines impart static and dynamic forces to the supporting structures (foundation and soil, floor, and building). Static forces include the machine weight plus the weight of the goods and water. Dynamic forces are those imparted by various machine movements as explained in [Section 2.2.2 : Major Design Considerations, page 35](#). The dynamic forces imparted to supporting structures can cause vibration and noise outside of the laundry room if supporting structures are inadequate.



## 2.2.1 Disclaimer of Responsibility

BNUUUUI01.C02 0000189359 B.3 C.3 F.4 1/2/20, 2:14 PM Released

Pellerin Milnor Corporation accepts no responsibility for damage or loss as a result of:

- inadequate supporting structures
- interference with the use of the facility caused by machine operation

The facility owner/operator is solely responsible to ensure that:

- supporting structures are strong enough, with a reasonable safety factor, to safely support the operating machine or group of machines
- supporting structures are rigid enough to isolate vibrations and noise to the laundry room


If the owner/operator does not possess the necessary expertise to ensure that the facility can safely and functionally accommodate the equipment, it will be necessary to consult the appropriate expert(s), such as a structural engineer, soils engineer, and/or architect.

## 2.2.2 Major Design Considerations

BNUUUUI01.C03 0000189358 A.5 C.3 F.4 1/2/20, 2:14 PM Released

- Vibration and/or noise can be felt or heard outside of the laundry room as a result of the following, if supporting structures are not sufficiently rigid:
  - Extraction (the spinning cylinder) in washer-extractors and centrifugal extractors, imparts sinusoidal forces to supporting structures as shown in [Figure 12: How Rotating Forces Act On the Foundation, page 36](#). In rigid washer-extractors, these forces are up to 30 times that of suspended washer-extractors of the same capacity.
  - Extraction forces can be magnified many times if the rotation frequency matches the resonant frequency of supporting structures. To avoid this, supporting structures must have a natural resonant frequency many times greater than any possible rotation speed of the machine or combination of rotation speeds of all machines.
  - Each time goods fall in the rotating cylinder of a washer, washer-extractor, centrifugal extractor, or dryer, this can impart a force to the supporting structures.
  - The intermittent start and stop actions of large components inside the machine, particularly in a tilting washer-extractor, press-extractor, or centrifugal extractor, can impart intermittent forces to the supporting structures.
- The possibility of adverse consequences is significantly greater for upper floor installations than for installations at grade. Always consult a structural engineer for such an installation.
- The possibility of adverse consequences is significantly greater for installations at grade if subsidence causes a void between the foundation and the soil or if the soil itself does not provide adequate strength and rigidity. Some possible remedies are the addition of pilings or a deeper foundation, installed as to be monolithic with the existing foundation.
- Machine forces can cause damage to the machine or the floor without the correct anchorage.
- Applicable building codes, even when met, do not guarantee sufficient structural support and isolation of machine forces to the laundry room.

**Figure 12. How Rotating Forces Act On the Foundation**



**NOTE:** This figure applies to both rigid and suspended washer-extractors and to both at-grade and upper floor installations.

## 2.2.3 Primary Information Sources

BNUUUI01.C04 0000189357 A.5 C.3 F.4 1/2/20, 2:14 PM Released

Milnor® provides, or can provide the following information of use to engineers and architects, for the given machine model:

- The machine dimensional drawing, found in the installation manual, specifies the machine's required anchorage.
- The Milnor® Service Department can provide static and dynamic load values and frequency (extract speed) values on request.



**NOTICE:** All data is subject to change without notice and may have changed since last printed. It is the responsibility of the potential owner/operator to obtain written confirmation that any data furnished by Milnor® applies for the model number(s) and serial number(s) of the purchased machine(s).

BIWUUI03 / 2019296

BNUUUR02 0000160550 F.4 1/2/20, 2:14 PM Released

## 2.3 Prevent Damage from Chemical Supplies and Chemical Systems

BNUUUR02.C01 0000160549 B.3 E.3 F.4 1/2/20, 2:14 PM Released

All Milnor® washer-extractors and CBW® tunnel washers use stainless steel with the ANSI 304 specification. This material gives good performance when chemical supplies are correctly applied. If chemical supplies are incorrectly applied, this material can be damaged. The damage can be very bad and it can occur quickly.

Chemical supply companies usually:

- supply chemical pump systems that put the supplies in the machine,

- connect the chemical pump system to the machine,
- write wash formulas that control the chemical concentrations.

The company that does these procedures must make sure that these procedures do not cause damage. **Pellerin Milnor Corporation accepts no responsibility for chemical damage to the machines it makes or to the goods in a machine.**

### 2.3.1 How Chemical Supplies Can Cause Damage

BNUUUR02.R01 0000160548 B.5 E.3 F.4 10/1/21, 11:24 AM Released

**Dangerous Chemical Supplies and Wash Formulas** — Some examples that can cause damage are:

- a very high concentration of chlorine bleach,
- a mixture of acid sour and hypo chlorite,
- chemical supplies (examples: chlorine bleach, hydrofluosilicic acid) that stay on the stainless steel because they are not quickly flushed with water.


The book “Textile Laundering Technology” by Charles L. Riggs gives data about correct chemical supplies and formulas.

**Incorrect Configuration or Connection of Equipment** — Many chemical systems:


- do not prevent a vacuum in the chemical tube (for example, with a vacuum breaker) when the pump is off,
- do not prevent flow (for example, with a valve) where the chemical tube goes in the machine.

Damage will occur if a chemical supply can go in the machine when the chemical system is off. Some configurations of components can let the chemical supplies go in the machine by a siphon ([Figure 13, page 38](#)). Some can let chemical supplies go in the machine by gravity ([Figure 14, page 39](#)).

**Figure 13. Incorrect Configurations That Let the Chemical Supply Go In the Machine by a Siphon**



**Figure 14. Incorrect Configurations That Let the Chemical Supply Go In the Machine by Gravity**




## 2.3.2 Equipment and Procedures That Can Prevent Damage

BNUUUR02.R02 0000160545 B.3 E.3 F.4 1/2/20, 2:14 PM Released

**Use the chemical manifold supplied.** — There is a manifold on the machine to attach chemical tubes from a chemical pump system. The manifold has a source of water to flush the chemical supplies with water.

**Figure 15. Examples of Manifolds for Chemical Tubes. Your equipment can look different.**




**Close the line.** — If the pump does not always close the line when it is off, use a shutoff valve to do this.

**Do not let a vacuum occur.** — Supply a vacuum breaker in the chemical line that is higher than the full level of the tank.

**Flush the chemical tube with water.** — If the liquid that stays in the tube between the pump and the machine can flow in the machine, flush the tube with water after the pump stops.

**Put the chemical tube fully below the inlet.** — It is also necessary that there is no pressure in the chemical tube or tank when the system is off.

**Figure 16. A Configuration that Prevents Flow in the Machine When the Pump is Off (if the chemical tube and tank have no pressure)**



**Prevent leaks.** — When you do maintenance on the chemical pump system:

- Use the correct components.
- Make sure that all connections are the correct fit.
- Make sure that all connections are tight.

# 3 Installation Procedures

BNWUUI03 / 2019426

BNWUUI03 0000254788 F.4 1/2/20, 2:19 PM Released

## 3.1 Handling a Washer-extractor from Delivery to Final Location

BNWUUI03.C01 0000254787 C.5 B.7 F.4 1/2/20, 2:19 PM Released

This document supersedes documents BIIFLI01, BIRUUI01, MSIN0206AE, and MSIN0301AE as of October 1, 2019. It applies to all Milnor® washer-extractor models in production as of October 1, 2019.

**owner/management** the purchaser of the machine or their representative. Usually the consignee.

**transportation company** the person(s) or contractor(s) who transports the machine to the facility where it will be installed. The carrier.

**rigger** the person(s) or contractor(s) responsible to off-load the machine from the delivery vehicle, move it to its final location, and anchor it to the foundation. This can be the dealer but is often another company hired by the dealer.

**technician** a person trained in servicing Milnor® products and responsible to remove shipping restraints. This is usually a dealer employee.

### 3.1.1 Notices

BNWUUI03.R04 0000257899 A.4 B.7 F.4 1/2/20, 2:19 PM Released

**Qualified Personnel Only** — Do not attempt to move, anchor, or remove restraints from the machine unless you are a rigger or technician, as defined above.

**Disclaimer** — Pellerin Milnor Corporation is not responsible for damage to the machine after it leaves the factory. Pellerin Milnor Corporation strongly recommends that the consignee (usually the owner/management) carefully inspect the machine in its protective wrapping before off-loading and inspect the uncovered machine after off-loading. If damage occurred in transit, ensure that the transportation company acknowledges the damage in writing. Submit a damage claim as soon as possible.

**Other Tasks** — This document addresses common tasks that the rigger and technician will perform. Other tasks, not explained here, can be needed. Information about other tasks is usually provided by the dealer, the Milnor® Applications Engineering department, or the Milnor® Service department. Examples are:

- Placement of the machine on a platform, such as for laundry cart clearance or to accommodate unusual drain conditions.
- Partial disassembly and reassembly, possible on some models, for movement through small spaces.

### 3.1.2 Facility Prerequisites

BNWUUI03.R01 0000254786 B.4 B.7 F.4 1/2/20, 2:19 PM Released

Required Condition	Supporting Information
structural support	See document BNUUUI01 “Vital Information About the Forces Imparted to Supporting Structures by Laundering Machines” which can be found in the installation manual and also at <a href="https://milnor.sharefile.com/d-s8408ba617d244d98">https://milnor.sharefile.com/d-s8408ba617d244d98</a> .
protected storage	If the machine must be stored temporarily, it must be protected from dampness and excessive temperatures.
access to the final location	See the machine dimensional drawing, which can be found at the end of the installation manual, for overall dimensions. Partial disassembly is sometimes possible. Contact the Milnor® Service department.
clearances for machine movement and maintenance	See the dimensional drawing.
operational clearances	Adequate clearance around controls and for movement of laundry equipment such as carts. See the dimensional drawing.
available utilities	See the dimensional drawing and the external fuse and wire document.
available drain(s)	See the dimensional drawing. The drain valve(s) must have unrestricted access to a drain trough of sufficient capacity in the foundation.
laundry room ventilation	The machine will contribute heat and vapors to the laundry room, which must provide adequate ventilation.

### 3.1.3 Rigger Precautions


BNWUUI03.R02 0000254785 B.6 B.7 F.4 1/2/20, 2:19 PM Released




**CAUTION: Incorrect rigging** — can cause mishaps and costly machine damage.

- ▶ Know and accommodate the machine shipping weight.
- ▶ Use only lifting eyes for crane lifting.
- ▶ Use long cables or a spreader bar for crane lifting.
- ▶ Leave the machine skidded as long as possible.
- ▶ Protect fragile or sensitive machine components.
- ▶ Prepare the foundation and install anchor bolts correctly.
- ▶ Set the machine at the correct height and level.
- ▶ Apply machinery grout evenly so that support is distributed.
- ▶ Tighten anchors alternately so that the hold-down force is distributed.



Precaution	Explanation
Know and accommodate the machine shipping weight.	Use lifting and moving equipment appropriate for the machine shipping weight, as shown on the Bill of Lading. To obtain the shipping weight in advance, contact the Milnor® Transportation department.
Use only lifting eyes for crane lifting.	Machines designed for crane lifting are provided with lifting eyes either on the structural frame or on the shell, hidden behind cosmetic panels.
Use long cables or a spreader bar for crane lifting.	
Leave the machine skidded as long as possible.	If the machine is skidded, leave the machine on the skids until the machine is as close as possible to its final location. Use care to avoid contact between the fork lift forks and fragile machine components on the un-skidded machine.
Protect fragile or sensitive machine components.	After the machine is uncovered, carefully find and read all tags on the outside of the machine. White and manila paper tags are installation precautions. See the Installation Tag Guidelines in the installation manual for additional information.
Prepare the foundation and install anchor bolts correctly.	Anchor bolt sizes and locations are shown on the dimensional drawing in the back of the installation manual. However, Milnor® recommends to use the actual machine as a template to accurately locate where the anchor bolts are to be installed in the foundation. See the anchor bolt detail on the dimensional drawing. It is not permissible to omit anchor bolts.

Precaution	Explanation
Set the machine at the correct height and level.	<p>Use blocking to get the machine base level and the base pads a minimum of 1" (25 mm) above the floor. Example:</p> 
Apply machinery grout evenly so that support is distributed.	Fill all voids between the foundation and each base pad with industrial strength, non-shrinking grout. Allow the grout to fully cure per the grout instructions.
Tighten anchors alternately so that the hold-down force is distributed.	Raise the machine slightly and remove the wood blocking. Install a flat washer and nut on each anchor bolt and tighten incrementally in an alternating pattern. After tightening, check each anchor at least twice.



### 3.1.4 Technician Precautions

BNWUUI03.R03 0000257735 A.5 B.7 F.4 1/2/20, 2:19 PM Released



**CAUTION: Overlooked or mishandled shipping restraints** — can cause costly machine damage.

- ▶ Leave all internal shipping restraints in place until the machine is anchored.
- ▶ Check for and remove shipping tie wraps.
- ▶ Check for and remove suspension hold-down hardware, if applicable.
- ▶ Check for and remove red shipping brackets, if applicable.
- ▶ See the “Cylinder inspection” warning and inspect the cylinder for smoothness.

Precaution	Explanation
Leave all internal shipping restraints in place until the machine is anchored.	The machine can have one or more internal shipping restraints to help protect components from damage until the machine is anchored. These are located inside the housing or inside electric cabinets.
Check for and remove shipping tie wraps.	<p>Examples (varies with machine model):</p> 
Check for and remove suspension hold-down hardware, if applicable.	<p>See also the service manual. Example:</p> 
Check for and remove red shipping brackets, if applicable.	Shipping brackets are painted red. See the shipping brackets parts document in the service manual.



Precaution	Explanation
See the “Cylinder inspection” warning and inspect the cylinder for smoothness.	Inspect the cylinder and perforations for smoothness. <b>Pellerin Milnor Corporation cannot accept cylinder finish damage claims after the machine has been placed in service.</b> Machines are shipped with the shell door(s) closed. See the section below for information on how to open the shell door(s).



**WARNING: Cylinder inspection** — can trap you in the cylinder or seriously injure you.

- ▶ Never enter, or place body parts in the cylinder when power is supplied to the machine.
- ▶ If the machine is connected to power, lockout/tag-out power at the external disconnect switch.
- ▶ mechanically restrain the cylinder from turning.
- ▶ Have an assistant present in case of emergency.

**Can the Door(s) Be Opened Before Utilities are Connected?** — The shell doors on all Milnor® washer-extractors in current production, except for the side-loading, barrier models, have one of two types of door latch: electric-operated or air operated.

Door Type	How To Open
Electric-operated: 	The machine leaves the factory with the door latched closed but not locked. Turn the door knob to open the door even when the machine does not have power. If the door will not open, the door lock mechanism moved to the locked position due to shaking in transit. In this event, wait until the machine is connected to electric power and use the controls to open the door.
Air-operated: 	The machine leaves the factory with the door(s) closed and locked (with the door plunger extended). It is possible to temporarily replace the air line that retracts the door plunger with a source of compressed air to open the door when no other utilities are connected. Otherwise, wait until utilities are connected to the machine and use the controls to open the door.

BNWUUI04 / 2021322

BNUUUF01 0000255072 F.4 8/2/21, 10:05 AM Released

## 3.2 Connection Precautions for Washer-extractors

BNWUUI04.C01 0000255071 B.2 C.2 F.4 8/2/21, 10:05 AM Released

This document supersedes documents BNWBUI01, BNWBUI02, BNWBUI03, BNWBUI04, BIRQVI01, BIMUUI02, and BIIFUI01. It applies to all Milnor® washer-extractor models in production as of October 1, 2019.

**plumber** the person(s) or contractor licensed or otherwise accepted by the local jurisdiction to perform the plumbing work described herein, and qualified to do so.

**electrician** the person(s) or contractor licensed or otherwise accepted by the local jurisdiction to perform the electrical work described herein, and qualified to do so.

**chemical supplier** the person(s) or contractor with detailed knowledge of 1) the machine controller configuration and operation, and 2) the pumped chemical delivery system, if such a system is to be used.

### 3.2.1 Notices

BNWUUI04.R03 0000255231 C.2 A.7 F.4 1/2/20, 2:19 PM Released

**Qualified Personnel Only** — Do not attempt to connect utilities to the machine unless you are a plumber, electrician, or chemical supplier, as defined above.

**Machine Must Be Anchored** — Utility connections are to be made only after the machine has been anchored. See BNWUUI03 “Handling a Washer-extractor from Delivery to Final Location.”

**Other Tasks** — This document and the documents it references address common tasks that the plumber, electrician, and chemical supplier will perform. Other tasks, not explained here, can be needed. Information about these tasks is usually provided by the dealer, the Milnor® Applications Engineering department, or the Milnor® Service department. An example is electrical interfacing with a remote Mildata® data collection system.

### 3.2.2 Utility Requirements and Related Information

BNWUUI04.R05 0000255583 A.12 C.2 F.4 1/2/20, 2:19 PM Released

Type of Information	Value or Where to Find
equipment list showing model and options purchased	For the dealer, see the order acknowledgement.
plumbing connection fitting types, sizes, and locations	See the standard and options dimensional drawings for your model located at the back of the installation manual.
water pressure range	10 – 75 psi (69 – 531 kPa) required
Cv value	See the specification sheet for your model available online at: <a href="https://www.milnor.com/specification-sheets/">https://www.milnor.com/specification-sheets/</a> . The Cv value assists the piping designer in determining flow rates and pressures.
steam pressure range	30 – 115 psi (207 – 793 kPa) required, if applicable
compressed air pressure range	85 – 110 psi (586 – 758 kPa) required, if applicable
specified voltage	See the machine nameplate or the order acknowledgement.

Type of Information	Value or Where to Find
available voltages for this model	See the specification sheet for your model available online at: <a href="https://www.milnor.com/specification-sheets/">https://www.milnor.com/specification-sheets/</a> .
multi-machine conditions that can interrupt utility service to a given machine	See dealer publication B22SL94011 “Sizing and Planning a Laundry” found online at: <a href="https://www.milnor.com/wp-content/uploads/2016/01/Sizing-and-Planning-a-Laundry_18323.pdf">https://www.milnor.com/wp-content/uploads/2016/01/Sizing-and-Planning-a-Laundry_18323.pdf</a>
approved plumbing materials	Plumbing materials must comply with applicable codes. The Milnor® factory makes no recommendations for inlet connection materials due to the many variables such as water conditions, materials cost and availability, and ongoing advances in materials technology. When drains must be piped, as apposed to a simple air drop to a sump, rubber hose and PVC are often used.

### 3.2.3 Plumber Precautions

BNWUUI04.R01 0000255070 C.2 A.9 F.4 1/2/20, 2:19 PM Released



**CAUTION: Machine damage and code violations** — can occur as a result of incorrect plumbing.


- ▶ Confirm the reliability of the piped utilities.
- ▶ Maintain connection point diameter.
- ▶ Flush fluid lines.
- ▶ Do not twist valve bodies.
- ▶ Never interchange water valve electrical connections.
- ▶ Install any vacuum breaker(s) provided or required.
- ▶ Install any water strainer(s) provided or required.
- ▶ Install a union and a shutoff valve at each hard piped connection.
- ▶ Connect a dry supply injector flush inlet to hot water and regulate it.

Precaution	Explanation
Confirm the reliability of the piped utilities.	Water and any other piped fluids (steam, compressed air) needed by the machine must be within the specified pressure range and not prone to frequent interruptions when the machine operates. See <a href="#">Section 3.2.2 : Utility Requirements and Related Information, page 47</a> .
Maintain connection point diameter.	The piping between the utility tap and the fitting on the machine must be as large or larger than the fitting. Drain piping or tubing, if any, must provide an unrestricted flow to the sump.
Flush fluid lines.	Foreign material such as debris in air lines, trapped air in water lines, and condensate in steam lines can damage machine components.
Do not twist valve bodies.	Hold a wrench on the valve side of a pipe connection to prevent the valve from twisting when you tighten the connection.

Precaution	Explanation
Never interchange water valve electrical connections.	On machines with air-operated water valves, it is permissible to exchange the pneumatic control lines, if the cold and hot connections were accidentally plumbed in reverse.
Install any vacuum breaker(s) provided or required.	If vacuum (siphon) breaker(s) are provided for fresh water connection(s), but not already installed, install them as shown on the options dimensional drawing. If vacuum breakers are required by code, but not provided, obtain and install the required hardware.
Install any water strainers provided or required.	If water strainer(s) are provided for fresh water connections, install them between the machine and incoming water. For machines with garden hose type water inlets, use 40-mesh strainers.
Install a union and a shutoff valve at each hard-piped connection.	Obtain and install the necessary hardware to permit hard-piped connections to be shut off and disconnected at the machine for maintenance. For the valve, use a ball valve, not, for example, a globe valve.
Connect a dry supply injector flush inlet to hot water and regulate it.	If the machine has a dry supply injector with an external flush water connection and hot water is available, provide hot water to this inlet. The machine will be supplied with a pressure regulator. Install this hardware at the flush water connection and confirm that the regulator is set to 28 psi (193 kPa). Steam in the hot water line will cause the supply injector to malfunction.

### 3.2.4 Electrician Precautions

BNWUUI04.R02 0000255232 C.2 A.7 F.4 1/2/20, 2:19 PM Released



**CAUTION: Machine damage, machine malfunctions, and code violations** — can occur as a result of incorrect electrical connections.

- ▶ Know the machine electrical specifications.
- ▶ Comply with the published external fuse and wire requirements.
- ▶ Confirm the reliability of the electric service.
- ▶ Confirm the machine is phased in correctly.
- ▶ Confirm the correct line voltage setting on a selectable 240/208 volt machine.
- ▶ Attach the stinger leg, if any, only to L3.



Precaution	Explanation
Know the machine electrical specifications.	Refer to the nameplate affixed to the machine.
Comply with the published external fuse and wire requirements.	These requirements are given in document BGUUUF01 “External Fuse/Breaker, Wiring, and Disconnect Requirements” and the external fuse and wire document for your machine. These documents are found at the back of the installation manual. BGUUUF01 is also available at: <a href="https://milnor.sharefile.com/d-s5e1bad2885a447e8">https://milnor.sharefile.com/d-s5e1bad2885a447e8</a>
Confirm the reliability of the electric service.	Voltage fluctuations of more than 10% above or below the specified voltage can damage electrical components, especially motors. The Milnor® factory strongly recommends that unreliable electric service is improved before the machine is put in use.
Confirm the machine is phased in correctly.	An installation tag on the machine shows the correct cylinder rotation at distribution (drain) or extract speed. If the cylinder turns in the wrong direction, reverse the wires connected to L1 and L2. Never move L3. Individual motors were phased in at the factory. Never reconnect individual motors or motor control devices.
Confirm the correct line voltage setting on a selectable 240/208 volt machine.	This precaution applies only if the nameplate voltage says 208/240V. It does not, for example, apply if the nameplate says 208V <b>or</b> 240V. The switch is near the incoming power transformer and must be in the position that matches the service voltage: 240 VAC or 208 VAC.
Attach the stinger leg, if any, only to terminal L3.	Never attach a stinger leg to terminal L1 or terminal L2.

### 3.2.5 Chemical Supplier Precautions

BNWUUI04.R04 0000255482 C.2 A.5 F.4 1/2/20, 2:19 PM Released

**Injury and severe machine damage** can occur as a result of incorrect chemical system installation.

- ▶ Understand and comply with the published connection precautions.
- ▶ Understand the machine controller.

Precaution	Explanation
Understand and comply with the published connection precautions.	The connection precautions are given in document BIWUUI03 “Prevent Damage from Chemical Supplies and Chemical Systems” in the installation manual. BIWUUI03 is also available at: <a href="https://milnor.sharefile.com/d-s79f12e8f11f42a9b">https://milnor.sharefile.com/d-s79f12e8f11f42a9b</a>
Understand the machine controller.	The machine controller is explained in detail in the reference manual for your machine, which is available from the Milnor® Parts department.



BNWUUI05 / 2021465

BNWUUI05 0000327776 F.4 11/11/21, 11:34 AM Released

### 3.3 Servicing the Door to Open it with Power Off or with a Malfunctioning Door Lock

BNWUUI05.C01 0000327775 A.2 B.2 F.4 12/8/20, 10:09 AM Released



**NOTE:** This document supersedes document MSSM0288AE and applies to all washer-extractors with four-spoke door handles, including 30022Hxx, MCRxxxxxx models. The photographs in this document show the older style bare metal door handles but the instructions apply, as well, to newer machines with black, coated handles.

The door is designed to lock as soon as the machine starts a wash cycle. If electrical power to the machine is interrupted during the washing cycle, or if the door interlock mechanism fails to unlock, the door can be opened by **qualified, service personnel** by removing the door handle and a few related components. These components must be properly reinstalled for safe operation.



**WARNING: Entangle and Crush Hazards** — Contact with moving components normally isolated by guards, covers, and panels, can entangle and crush your limbs. These components move automatically.

- ▶ Service the machine only if qualified and authorized.
- ▶ Lock out and tag out power at the main machine disconnect before reaching into the cylinder.



**DANGER: Amputation hazard** — If the door interlock mechanism does not function properly, an operator may be able to open the door and reach into the machine during operation. Goods in the rotating cylinder can wrap around a person's arm and twist it off.

- ▶ Verify proper door lock function during machine operation, before returning the machine to normal service.

#### 3.3.1 Disassembly

BNWUUI05.C02 0000327774 A.1 B.2 F.4 12/7/20, 10:45 AM Released

##### 3.3.1.1 Removing the Handle and Opening the Door

BNWUUI05.T01 0000327773 A.2 B.2 F.4 12/8/20, 10:09 AM Released

The handle is held in place on the shaft with a thrust washer and retaining clip in front of the handle and a flange bearing and retaining clip behind the handle. The amount of turning force the handle can exert on the shaft is adjustable with the four set screws, springs and steel balls—one within each spoke of the handle. The steel balls seat into depressions in the shaft. When properly adjusted, the set screws will apply sufficient spring tension so that the handle will reliably operate the latch, but the handle will ratchet if turned counterclockwise or if too much turning force is applied.

Remove the handle from the shaft as follows:

1. Gently pry the black plastic cap from the center of the handle with a small screwdriver.

2. Attempt to ratchet the handle by turning it counterclockwise by hand. If this is not possible, the springs have too much tension applied. Back off on the four set screws just enough for the handle to ratchet. Typically this happens when the set screws are flush with the surface of the handle spoke as is the case in [Figure 17: Door Handle Spoke Set Screw, page 52](#).
3. Repeat the following sub-steps four times to remove all set screws, springs, and steel balls:
  - a. Remove the set screw from the topmost handle spoke.
  - b. Hold a finger over the hole, then, while keeping your finger on the hole, ratchet the handle counterclockwise until the hole is pointing down.
  - c. Hold one hand or a cup under the handle to catch the contents, then remove your finger, allowing the spring and ball to fall out, as in [Figure 18: Handle Spoke Spring and Ball, page 52](#). Shake the handle if necessary, to work the components free.

**Figure 17. Door Handle Spoke Set Screw**



**Figure 18. Handle Spoke Spring and Ball**



4. Remove the front retaining clip and thrust washer ([Figure 19: Front Retaining Clip and Thrust Washer, page 53](#)), then pull the handle off of the shaft.
5. Normally, the flange bearing will come off with the handle, but if not, remove it as shown in [Figure 20: Rear Flange Bearing \(being removed\) and Retaining Clip \(arrow\), page 53](#). Remove the rear retaining clip. Push against the door to release the retaining clip.

**Figure 19. Front Retaining Clip and Thrust Washer**



**Figure 20. Rear Flange Bearing (being removed) and Retaining Clip (arrow)**



**NOTICE:** Risk of component damage—The *return* spring is located around the shaft, between the door and the shaft cam. The end of the spring is inserted into a small hole in the shaft cam. The spring can stretch and be damaged if it does not separate from the shaft cam.

- Be prepared to work the end of the spring out of the hole in the shaft cam as the door is opened.
6. Slowly open the door. Allow the door latch shaft, which is still captive within the door lock mechanism, to slide out of the door. Watch to be sure the return spring separates from the shaft cam and remains with the door, as shown in [Figure 21: Return Spring After Separation from Shaft Cam, page 53](#) .

**Figure 21. Return Spring After Separation from Shaft Cam**



### 3.3.1.2 Removing the Door Latch Shaft from the Door Lock Mechanism


BNWUUI05.T02 0000327788 A.2 B.2 F.4 12/8/20, 10:09 AM Released




**TIP:** It is easier and more reliable to remove the shaft from the door lock mechanism then to attempt to reinsert the shaft into the door and replace the handle while the shaft is still captive in the door lock.

1. Remove the cover (not shown) from the door lock mechanism ([Figure 22: Door Lock Slider Pin in the Door Lock Mechanism, page 54](#) ).
2. Using a screwdriver, push down the door lock slider pin ([Figure 22, page 54](#)) and rotate the shaft ([Figure 23: Removing the Shaft from the Lock Mechanism, page 54](#) ) counterclockwise to remove it from the lock mechanism.

**Figure 22. Door Lock Slider Pin in the Door Lock Mechanism**



**Figure 23. Removing the Shaft from the Lock Mechanism**




### 3.3.2 Reinstalling the Shaft and Door Handle

BNWUUI05.T03 0000327831 A.2 B.2 F.4 12/8/20, 10:09 AM Released


Once the goods have been removed from the machine and any malfunction of the door lock mechanism, such as a burned out coil or mechanical interference, has been identified and repaired, reinstall the components as follows:

1. Install the cover on the door lock mechanism.
2. Insert the shaft into the open door and seat the end of the return spring into retaining hole in door shaft cam ([Figure 24: Shaft in the 9 o'clock Position Showing Spring Retaining Hole, page 55](#) and [Figure 25: Shaft with Return Spring Installed, page 55](#) ).

**Figure 24. Shaft in the 9 o'clock Position Showing Spring Retaining Hole**



**Figure 25. Shaft with Return Spring Installed**




3. Looking at the rear of the door, rotate the shaft counterclockwise about 90 degrees, until the shaft fully seats into the door. When properly seated, the shaft finger (the latch) will align with the key way on the door lock mechanism.
4. Install the rear retaining clip on the shaft.
5. Slide the door handle and flange bearing onto the shaft.
6. Install the front thrust bearing and retaining clip on the shaft.
7. Repeat the following sub-steps four times—once for each ball, spring, and set screw: ([Figure 26: Inserting Ball and Spring in Handle Spoke, page 56](#) and [Figure 27: Adjusting Set Screw, page 56](#)):
  - a. Drop the ball into the hole of door handle top spoke, followed by the spring, as shown in [Figure 26, page 56](#).
  - b. Install the set screw. As previously stated, the handle should ratchet if more turning force than necessary is applied or if turned counterclockwise. Tighten the set screw until the set screw is flush with the handle. This will provide roughly the correct spring tension.
  - c. Rotate door handle counterclockwise 90 degrees to ratchet it to the next position (with the next spoke on top).



**Figure 26. Inserting Ball and Spring in Handle Spoke**



**Figure 27. Adjusting Set Screw**



8. When all four set screws are in place, check to be sure the handle will ratchet if turned counterclockwise, or if latched with more force than necessary. Make 1/4 turn adjustments to all four set screws if necessary to achieve the proper tension.
9. Install the black plastic cap over the center of the handle.

BNWUUI06 / 2020503

BNWUUI06 0000327830 F.4 12/8/20, 3:11 PM Released

## 3.4 Setting Door Interlock Switches

BNWUUI06.C01 0000327829 A.2 A.3 F.4 12/8/20, 2:23 PM Released

### 3.4.1 How The Door Interlock Switches Work

BNWUUI06.C02 0000327828 A.2 A.3 F.4 12/8/20, 2:23 PM Released



**DANGER: Amputation Hazard** — Turning cylinder can twist off arms.

- ▶ Do not permit this machine to be operated unless door interlock switch SMD (Figure 28: Door locking sequence, page 57 item 3) is set according to these instructions.
- ▶ Do not operate this machine if a visual inspection of the unlocked door shows door lock switch SMD touching the door lock slider, or if the machine operates with the door open.
- ▶ Verify that all components of this system are in good working order.




**NOTE:** Study the illustrations in Figure 28, page 57 while reading the following explanation.

After the door is shut, the turning door catch (item 2) physically contacts door interlock switch SMD (item 3). Actuating this switch tells the microprocessor that the door is closed. Note that the door handle is not locked in place and the door can be opened if needed. The machine can be programmed but cannot start the wash program or allow manual actuation of outputs.

Immediately after the start switch **1** is pushed, the microprocessor energizes solenoid EMDL (item 4), pulling up the door lock slider. The raised door lock slider mechanically locks the door handle in place and actuates door interlock switch SME (item 1). Actuating this interlock switch confirms that the door is closed and locked, allowing the machine to start the wash program.

**Figure 28. Door locking sequence**



### 3.4.2 Adjusting the Door Interlock Switches

BNWUUI06.C03 0000327876 A.2 A.3 F.4 12/8/20, 2:23 PM Released

Periodically inspect the door locking assembly for wear and proper functioning as follows:

1. Remove the cover plate. Manually push the door slider assembly (item 5) down until it stops. Check for a minimum of one sixteenth of an inch clearance (1.6 mm), between the raised portion of the door slider (item 6), and the lever of interlock switch SMD (item 3).
2. Manually push the door slider assembly up until it stops. Check that the rising slider depresses interlock switch SME (item 1), “making” the switch.



# 4 Drive Assemblies


BNUUUM02 / 2023344

BNUUUM02 0000274599 F.4 8/23/23, 9:52 AM Released

## 4.1 Drive Pulley and Belt Maintenance

BNUUUM02.C01 0000274598 A.2 B.2 F.4 2/4/20, 8:08 AM Released

**Figure 29. Examples of drives this instruction applies to: one or more V-belts, attached V-belts and tooth belts**



**NOTICE:** "Remove power from the machine" means use the necessary safety procedure for your location. In the USA, this is the OSHA lockout/tagout (LOTO) procedure. More local requirements can also apply.



**WARNING: Risk of Injury or death** — A machine in operation without safety guards is dangerous. Drive belts can pull in your body or clothing.

- ▶ Remove power from the machine when you do work on the mechanisms.
- ▶ Stay out of the machine frame when you do a test on the machine.
- ▶ Replace all covers before you put the machine into operation.



**TIP:** Read these documents from the Gates Corporation ([www.gates.com](http://www.gates.com)) to know more about pulley and belt maintenance: "Belt Drive Preventive Maintenance & Safety Manual" and "Preserve your investment - Check Engine Belts Often."

### 4.1.1 Pulley Requirements

BNUUUM02.C02 0000274597 A.2 B.2 F.4 2/4/20, 8:08 AM Released

- Keep pulleys free of dirt, oil and other contamination.
- Replace pulleys with groove damage.
- Align pulleys and shafts.

- Keep run-out in tolerance.


#### 4.1.1.1 Condition of Grooves on Pulleys

BNUUUM02.C03 0000274611 A.2 B.2 F.4 2/4/20, 8:08 AM Released

Replace a pulley if:

- the grooves have burrs, cracks, or worn areas that can cause damage to the belts.
- the belts touch the bottom of the groove at any point (Figure 30, page 60).

**Figure 30. Pulley Groove Condition**




#### 4.1.1.2 Pulley and Shaft Position

BNUUUM02.C04 0000274609 A.2 B.2 F.4 2/4/20, 8:08 AM Released

**Align** To adjust parts until they are in a correct position to other parts.

- Always align components when you replace a motor, bearing housing, pulley, or belt.
- The belts must not twist or make unusual noises or show vibration.

**Figure 31. Pulley and Shaft Position**


#### 4.1.1.3 Keep Run-Out in Tolerance

BNUUUM02.C05 0000274606 A.2 B.2 F.4 2/4/20, 8:08 AM Released


**Axial run-out** The difference between the minimum and maximum distance between the face of a pulley and a plane perpendicular to the pulley shaft (Figure 32, page 62, item 1). Incorrect installation or damage can cause a pulley to be not at a 90 degree angle to the shaft.

**Radial run-out** The difference between the minimum and maximum diameter in one turn (Figure 32, page 62, item 2). If a force causes damage to a pulley, it can bend. It will not have a circular shape.

**Figure 32. Run-out**



**Figure 33. Typical Pulley Assembly**




## 4.1.2 Belt Requirements

BNUUUM02.C06 0000274605 A.2 B.2 F.4 2/4/20, 8:08 AM Released

- Replace damaged belts.
- The pulleys must stay aligned when you adjust the belt tension.

- Do not use belts made from cut belts.
- For a drive with more than one belt:
  - Replace all of the belts together.
  - Do not mix new and used belts.
  - Do not mix belts from more than one manufacturer.



**CAUTION: Risk of damage** — A screwdriver or metal tool can cause damage to the belt.

- ▶ Do not push the belt on with a tool.

#### 4.1.2.1 Condition of Belts

BNUUUM02.C07 0000274604 A.2 B.2 F.4 2/4/20, 8:08 AM Released

**Slippage** when the pulley turns more quickly than the belt can move

Slippage occurs if belts are not aligned (see [Section 4.1.1.2 , page 60](#)) or by incorrect tension explained in [Section 4.1.1.2 , page 60](#). Slippage can cause belts to become too hot. Belts must not have a temperature more than 140F (60° C).




**TIP:** The belt storage area must be cool and dry with no sun light.



**TIP:** New and used belts can look the same. These belts will have different strength properties and a small difference in length.

**Figure 34. Types of Belt Damage**



#### 4.1.2.2 Tension of Belts

BNUUUM02.C08 0000274657 A.2 B.2 F.4 2/4/20, 8:08 AM Released

This data does not apply to belts where a spring holds the correct belt tension. Manual tension adjustment is not necessary for this type of drive.

**The correct belt tension is the lowest tension that prevents belt slippage with a full load condition.** If the belt is too tight, this can cause damage to the belt, the pulleys, bearings, and other drive components. If the belt is too loose, this can cause belt slippage. Incorrect belt tension or belt slippage can cause components to make an unusual noise.

When you install a new belt, use these rules to get the correct belt tension:

- Set the tension of the belt when you replace a motor, bearing housing, pulley, or belt.
- Replace all belts on a pair of pulleys when you replace one of them.
- After adjustment, operate the machine in all of its standard conditions to make sure that the belt operates correctly. For example, operate a washer-extractor in its full speed range with a full load of wet goods.
- Adjust the tension when you first install a belt. Do the adjustment again after 24 and 48 hours of operation. All belts will become longer after a short time. A V-belt will move down in the grooves of the pulleys. These conditions will cause the tension to decrease.

When you do scheduled maintenance, examine the belts for correct tension. With operation, belts become longer.

### 4.1.3 The pulleys must stay aligned when you adjust the belt tension


BNUUUM02.C09 0000274654 A.2 B.2 F.4 2/4/20, 8:08 AM Released

Some tension mechanisms do not have an effect on pulley and shaft requirements. Pulleys will stay aligned when you adjust them. [Figure 35, page 65](#) is an example of these. Where tension mechanisms are a pair of threaded rods, you must adjust the nut, on each rod carefully. If not, the pulleys will not stay aligned. Examples of this type are shown in [Figure 36, page 65](#).

**Figure 35. A Tension Mechanism that will not Change the Angle of the Pulleys**



**Figure 36. Some Pairs of Tension Mechanisms that Can Change the Angle of the Pulleys**





## 4.1.4 How to Do Maintenance on Pulleys and Belts

BNUUUM02.C10 0000274653 B.2 F.4 8/23/23, 9:45 AM Released

**Table 18. Typical Tools for Pulley and Belt Maintenance**

Tool	Function	Related Data
Torque wrench	Make the bushing bolts the same torque to get the minimum axial run-out.	Figure 33, page 62, item 2
Laser, straight edge, or string	Align pulleys	Tools are listed in order of preference. Section 4.1.1.2 , page 60 and Figure 37, page 67
Bubble level	Align shafts	Section 4.1.1.2 , page 60 and Figure 38, page 68
Dial indicator	Measure run-out	Section 4.1.1.3 , page 61 and Figure 39, page 68
Sheave (pulley) gage	Examine pulley wear	Figure 30, page 60.
Infrared thermometer	Examine belt temperature	Section 4.1.2.1 , page 63.

### 4.1.4.1 Typical Steps to Replace Pulleys and Belts

BNUUUM02.C11 0000274652 A.2 B.2 F.4 2/4/20, 8:08 AM Released

**Preparation** Remove power from the machine.

**Belt removal** Use the belt tension mechanism to decrease the distance between the pulleys until you have sufficient clearance. Figure 35, page 65 and Figure 36, page 65 show typical belt tension mechanisms.

**Pulley removal** On the typical type of pulley and bushing shown in Figure 33, page 62, use the push-off holes to remove the pulley easily. On special types of pulleys (example: large drive pulley and cone), look at the parts document in the maintenance manual for more data. Some pulleys are too heavy for only one person to hold.

**Pulley installation** Figure 33, page 62 shows the typical pulley and bushing components. Make sure that you keep run-out tolerances when you assemble and tighten the components.

**Belt installation** Decrease the distance between the pulleys to put the belt on easily. Assemble the components carefully. Make sure that the components are aligned. Adjust the belt tension so the belt is tight.


**Test** Before you connect power again, make sure that you remove all tools. Operate the machine with a full load. If the belts slip, increase belt tension with the machine shut down and power removed. Then test again. Make sure that the machine is safe before you put it into regular operation.




### 4.1.4.2 Examples of Procedures Used at the Milnor® Factory to Align Pulleys

BNUUUM02.C12 0000274686 A.3 B.2 F.4 3/6/20, 4:49 PM Released


**Figure 37.** Use a straight edge, a string, or a laser to make sure that all pulleys are in the same plane.



**Figure 38. Use a level to make sure that the pulleys are at the same slope.**




**Figure 39. Dial indicator used to find the axial and radial run-out of a pulley.**



This page intentionally blank

Figure 40. General View




## Drive Components Identification

2 Sheets

**Table 19. Parts List—Drive Components Identification**

Find the assembly for your machine and the letter shown in the "Item" column. The components for your machine will show this letter or the word "all" in the "Used In" column. The numbers shown in the "Item" column are those shown in the illustrations.				
Used In	Item	Part Number	Description/Nomenclature	Comments
Reference Assemblies				
	A	D33 03550	DRIVE CHART 3022X8 VSP50/60	
Components				
all	1	56VB082XM2	VBELT BX82 EA=1BELT	
all	2	56Q1CH	1+1/8"BUSH VPULTYP H,D,QT OR L	
all	3	56030B2H	VPUL 2B3.0/A2.6 2BK32H OR EQUAL	
all	4	X2 03830	MACH=MAIN BEARING PULLEY	
all	5	15E230	STRMACHKEY 3/8SQX2+1/2 TOL.+0	
all	6	15K232A	HEXCAPSCR 3/4-10X2 GR8 ZINC	
all	7	15U321H	FLTWASH 3/4 HARD ASTM F436	
all	8	02 14359A	SHAFT RETNR SPACER 2+3/4" SQ	

Figure 41. Drive Motor Installation



Drive Motor Installation

3 Sheets

Figure 42. Detail View





Figure 43. Detail View



## Drive Motor Installation

3 Sheets


**Table 20. Parts List—Drive Motor Installation**

Find the assembly for your machine and the letter shown in the "Item" column. The components for your machine will show this letter or the word "all" in the "Used In" column. The numbers shown in the "Item" column are those shown in the illustrations.				
Used In	Item	Part Number	Description/Nomenclature	Comments
Reference Assemblies				
	A	ADB3022X8	ASSY=MOTOR MOUNT 3022X8J	
Components				
all	1	02 02904D	MOTOR MT PLATE 3022X8J	
all	2	02 02905	BRACKET MOTOR MTG ADJ 3022X8J	
all	3	02 02904E	MOTOR MT BKT LF/RT 3022X8	
all	5	02 03828	STRAP=MOTOR MNT TEEBOLT	
all	6	02 03829	TEEBOLT=MTR MNT ADJ 3022F8	
all	7	15G236C	HXFINJAMNUT 5/8-11UNC2B ZINC G	
all	8	15U315	LOKWASHER MEDIUM 5/8 ZINCPL	
all	9	17W030	SPHERICAL WASHER SET 5/8 M/F	
all	10	15K162	HXCAPSCR 1/2-13UNC2AX1.5 GR5 P	
all	11	15U300	LOKWASHER REGULAR 1/2 ZINC PLT	
all	12	15G230	HXNUT 1/2-13UNC2B SAE ZINC GR2	
all	13	15K039	HXCAPSCR 1/4-20UNC2AX3/4 GR5 Z	
all	14	15U180	LOCKWASHER MEDIUM 1/4 ZINCPL	
all	15	15G165	HXNUT 1/4-20UNC2BSAE ZC GR2	
all	16	15K110	HEXCAPSCR 3/8-16UNC2AX1.5 GR5-	
all	17	15U241SZ	FLATWASHER 1.5 ODX.406 IDX.25T	
all	18	15U255	LOCKWASHER MEDIUM 3/8 ZINCPL	
all	19	15G205	HXNUT 3/8-16UNC2B ZINC GR2	
all	20	02 03839B	PLATE=MTR MNT REINFORCEMENT	



This page intentionally blank


Figure 44. Bearing Housing



# Bearing Housing Components

4 Sheets


Figure 45. Bearing Housing Front



## Bearing Housing Components

4 Sheets

Figure 46. Bearing Housing Rear



## Bearing Housing Components

4 Sheets

Table 21. Parts List—Bearing Housing Components

Find the assembly for your machine and the letter shown in the "Item" column. The components for your machine will show this letter or the word "all" in the "Used In" column. The numbers shown in the "Item" column are those shown in the illustrations.				
Used In	Item	Part Number	Description/Nomenclature	Comments
Reference Assemblies				
	A	ABM3022XA	MAIN BEAR ASSY 3022X 54A593597	
	B	ABM3022XB	BRING ASSY VIT 3022X 54A593597	
Components				
all	1	15K143D	SOCHDCAPSCR 7/16-14X1.5 SS	
all	2	15Q068A	SOKSETSCR CUP10-32X1/4 SS	
all	3	15K154A	HEXCAPSCR 1/2-13X1.5 G8 ZN	
all	4	15U317B	FLWASH,1.062ODX.531IDX.115 TH	
all	5	27A253	PLUG FOR 1/2BOLTHOLE CAPLUG #4	
all	6	54A915916	TIM#JLM710949C/JLM710910-2.5"BORE	
all	7	54A593597	SET=TIMKEN CUP# 39521(OR CUP# 39520)/CONE# 39590=2.625"BORE (EA=SET)	
all	8	X2 03833B	MACH=SHAFT, 3022X8 54A593597	
all	8	X2 03232A	MACH=SHAFT, 3022H7 54A593597	
all	9	X2 03840H	MACH=MAIN BRNG HOUSING,3022H	
all	10	X2 03831	MACH=FRONT SEAL HOLDER 3022F	
all	11	X2 03832	MACH=REAR SEAL HOLDER 3022F	
all	12	02 03825	SLEEVE=BEARING SHAFT 3022F	
all	13	02 03826	COVER=V-RING SEAL 3022F	
all	14	02 03823A	GASKET=3022F V-RING SEAL	
all	15	15H089S	SPRINGPIN 1/8"DIA X 5/8" LONG	
all	16	02 02294A	SHAFT KEY 3/8 X 3/8	
all	17	15K106FA	BUTSKCAPSC 3/8-16X1.5 SSNYPT	
A	18	24S053	SEAL 2.625X3.625X.437#10051L5	
B	18	24S053V	SEAL 2.625X3.625X.437#10050H5L	
A	19	24S052A	SEAL 2.559X3.55X.315 CR#25430	
B	19	24S052V	SEAL 2.559X3.55X.315VTCR#25431	
all	20	60C151A	ORING 4+1/4ID1/8CS BUNA70#244	
all	21	24S105FN	SEAL 2.48X2.68X2.28X.20V65A-N	
all	22	15E230	STRMACHKEY 3/8SQX2+1/2 TOL.+0	
all	23	20C009	THRDLKSEAL LCT#27731 50CC	
all	24	20C007H	THDLK REMVBL-#24221	
all	25	20C012D	RETAINCMPD ADH LCT#1835205 10CC	
all	26	20C011B	RETAIN CMPD ADH LCT#60905 .5CC	

**Bearing Housing Components**

4 Sheets

**Table 21 Parts List—Bearing Housing Components (cont'd.)**

Find the assembly for your machine and the letter shown in the "Item" column. The components for your machine will show this letter or the word "all" in the "Used In" column. The numbers shown in the "Item" column are those shown in the illustrations.				
Used In	Item	Part Number	Description/Nomenclature	Comments
all	27	20C006P	PRIMER-N #7649 LCT#21348-4	
all	28	20C020	ANTISEIZE TEFLON SEALANT 50ML	
all	29A	02 03818J	SHIM=.003 CRS GREEN	
all	29B	02 03818K	SHIM=.005 CRS BLUE	
all	29C	02 03818L	SHIM=.0075 CRS BLACK	
all	29D	02 03818M	SHIM=.010 CRS RED	

This page intentionally blank


BPWXAB02 / 2021024

BPWXAB02.1 0000329428 A.5 F.4 1/6/21, 5:19 PM Released

## Bearing Housing Components and Installation

4 Sheets

Pulley and related parts are not shown for clarity.







## Bearing Housing Components and Installation

4 Sheets


Detail Views



A-A



B-B



C

## Legend


C . . . Enlarged view

K . . . To install the bearing housing, first apply a .25" [6mm] bead of silicone to this edge of the shell rear.


L . . . Shell rear

Bearing Housing Components and Installation

4 Sheets



D-D



E-E

Legend

- D-D . . Top view
- E-E . . Bottom view

## Bearing Housing Components and Installation

4 Sheets

Table 22. Parts List—Bearing Housing Components and Installation

Find the assembly for your machine and the letter shown in the "Item" column. The components for your machine will show this letter or the word "all" in the "Used In" column. The numbers shown in the "Item" column are those shown in the illustrations.				
Used In	Item	Part Number	Description/Nomenclature	Comments
Reference Assemblies				
	A	GBM3022X8	INSTALL=MAINBRG ASSY 3022X8	
	B	ABM3022XA	MAIN BEAR ASSY 3022X 54A593597	
Components				
all	1	15K231	HEXCAPSCR 3/4-16X1+1/2 GR8 ZIN	Metric
all	2	15U340	LOCKWASH MEDIUM 3/4 ZINCPL	
all	3A	15K215	HXCAPSCR 5/8-18X1.5 ZNCFULL TH	
all	3B	15K225M	HEXCAPSCR M16-2.0X40CLS10.9 Z	
all	4	15U316	FLTWASH 5/8 HARD ASTM F436	
all	5	20C008C	THDLKSEAL LCT24241 RMUBL250CC	
all	6	20C040B	SUPERFLEX CLR RTV SIL 10.1OZ	
all	7	5N0CCLSB42	NPT NIP 1/8XCLS TBE BRASS STD	
all	8	5SCC0CBE	NPT COUP 1/8 BRASS 125# 103A-A	
all	9	53A031B	BODY-EL90MALE.25X1/8 #269C-42B	
all	10	60E004TC	TUBING NYL(NAT)1/4"ODX.17ID	
all	11	53A031XB	BODY-EL90MALE.25X25 #269C-4-4B	
all	12	5SL0EBEC	NPTEL B 90DEG STRT 1/4 BRASS125	
all	13	51E507	HOSESTEM BRASS 1/4MPX1/2HOSEID	
all	14	60E005P	PVC TUBING 1/2"ID X 5/8"OD	
all	15	27A040	HOSECLAMP 7/16-25/32SS W/SCREW	
all	16	5N0C02ABE2	NPT NIP 1/8X2 TBE BRASS STD	
all	17	5SL0CBEA	NPTEL B 90DEG 1/8 BRASS 125#	
all	18	5N0C03AG42	NPT NIP 1/8X3 TBE GALSTL SK40	
all	20	54M029	RELIEFFIT 1/8STR ALEMITE 47200	
all	21	5N0E05AG42	NPT NIP 1/4X5 TBE GALSTL SK40	
all	22	5N0E01KBE2	NPT NIP 1/4X1.5TBE BRASS STD.	
all	23	5SCC0EBE	NPT COUP 1/4 BRASS 150#PSI W/HEX	
all	24	5SP0EFFSSM	NPT PLUG 1/4 SQSLDMAGNET BLKST	


## **5 Cylinder and Shell Assemblies**

This page intentionally blank

## Cylinder Installation

4 Sheets

### Figure 47. Cylinder Installation



## Cylinder Installation

4 Sheets

Figure 48. Cylinder Installation






Figure 49. Cylinder and Bearing Installation



Cylinder Installation

4 Sheets

Figure 50. Cylinder and Bearing Installation





## Cylinder Installation

4 Sheets

Table 23. Parts List—Cylinder Installation

Find the assembly for your machine and the letter shown in the "Item" column. The components for your machine will show this letter or the word "all" in the "Used In" column. The numbers shown in the "Item" column are those shown in the illustrations.				
Used In	Item	Part Number	Description/Nomenclature	Comments
Reference Assemblies				
	A	GSC3022X8	INST=CYL/SHELL/BACK 3022X8J	
Components				
all	1	X2 02904	SHELLFRONT DRILLED 3022X8J	
all	2	X2 02903	INNER SHELL FRONT S/S 3022X8J	
all	3	W2 02901	WELDMENT SHELL 3022X8J	
all	4	ACA3022F8	*ASSY=CYLINDER 3022 F8J/G/P	
all	5	A33 03211	ASSY=SHELL BACK, 3022H7	
all	6	02 14359A	SHAFT RETNR SPACER 2+3/4" SQ	
all	7	02 11196	COVER=SHAFT RETAINER=304S/S	
all	8	02 03208	SHELL FLANGE DOUBLER, 3022H7	
all	9	Y2 03211	MACH=SHELLBACK, 3022H7	
all	10	02 03212	SHELLBACK LINER, 3022H7	
all	11	02 03258	GASKET=SHELLBACK LINER,3022H	
all	12	02 03279	DOUBLER=SHELLBK LINER,3022H	
all	13	15K040T	1/4-20X3/4 TAMPTORXBUTHDN/P SS	
all	14	15U188	FLTWASH 1/4 STD COMM SS18-8	
all	15	15K215	HXCAPSCR 5/8-18X1.5 ZNCFULL TH	
all	16	15U316	FLTWASH 5/8 HARD ASTM F436	
all	17	15K232A	HEXCAPSCR 3/4-10X2 GR8 ZINC	
all	18	15K116	HEXFLGSCR 3/8-16X1.75 GR8 ZINC	
all	19	15G198	HXFLGNUT 3/8-16 ZINC	
all	20	15K127A	HEXFLGSCR 3/8-16 X2.5 GR8 ZINC	
all	21	15B208	HEXCAPSCR 3/4-10X2+1/4 SS18-8	
all	22	20C005	ADH/SEALANT 50CC LCT#271-31	
all	23	20C040B	SUPERFLEX CLR RTV SIL 10.1OZ	
all	24	20C007G	THDLOCKSEAL LCT24231 RMUBL50CC	
all	25	15U350	LOCKWASHER 3/4 MED SS18-8	

## 6 Door Assemblies


This page intentionally blank

Door Assembly and Installation


4 Sheets

30022 X8J/X8R


Door Installation



Door Lock Cover



Hinge



Legend

A-A . . See detail

B-B . . See detail

E . . . See BPW0AD03


F . . . Add or remove shims until the door locks properly and seals.

G . . . 4 instances

## Door Assembly and Installation

4 Sheets


30022 X8J/X8R



## Door Assembly and Installation

4 Sheets

30022 X8J/X8R



## Door Assembly and Installation

4 Sheets

30022 X8J/X8R

**Table 24. Parts List—Door Assembly and Installation**

Find the assembly for your machine and the letter shown in the "Item" column. The components for your machine will show this letter or the word "all" in the "Used In" column. The numbers shown in the "Item" column are those shown in the illustrations.				
Used In	Item	Part Number	Description/Nomenclature	Comments
Reference Assemblies				
	A	A33 10100X	3022XA FLAT SHELL FRONT/DOOR ASSY 30"	
	B	A33 07100G	ASSY=DOOR, 30" FLAT SHELLFRONT	
Components				
all	1	02 03261A	3022XA 30" DOOR FRAME MACHINED	
all	2	98CMCR0971	DOOR INTERLOCK ASSY V8Z VRJ MILNOR ASSY A33 03226B	
all	3	02 03228D	DOOR LOCK BOX COVER 3022V8	
all	4	17S2500A	DOUBLE END 1/4-20X1-1/8 STUD 1/4 ONE END AND 3/4 ONE END CS PRECOTE 85 PATCH	
all	5	15K017	BUTSOKCAPSCR 10-24X1/2 SS	
all	6	02 03229A	30" SHELL DOOR	
all	7	02 03200	DOOR GASKET, 3022H7	
all	8	02 03251	DOOR GLASS, 3022H7	
all	9	02 03297	30" DOOR HINGE SPACER 14GA	
all	10	02 03297A	30" DOOR HINGE SPACER 16GA	
all	11	X2 03296B	HING PIN 3022V8	
all	12	02 03260A	30" DOOR HINGE UPPER	
all	13	02 03260	30" SHELL DOOR HINGE LOWER	
all	14	15K033	BUTSOKCAPSCR 1/4-20X5/8 SS18-8	
all	15	02 04192A	.015 SHIM=DOOR MNT PL,3022H7	
all	16	98CMCR0925	ASSY=DR HNDL MECH	


BPWOAD01 / 2019354

BPWOAD01.1 0000250501 D.3 F.4 11/13/19, 1:32 PM Released

## Door Handle and Lock Actuator

3 Sheets

Figure 51. Door Handle and Lock Actuator






## Door Handle and Lock Actuator

3 Sheets

Figure 52. Shim Adjustment Steps



**Door Handle and Lock Actuator**

3 Sheets

**Table 25. Parts List—Door Handle and Lock Actuator**

Find the assembly for your machine and the letter shown in the "Item" column. The components for your machine will show this letter or the word "all" in the "Used In" column. The numbers shown in the "Item" column are those shown in the illustrations.				
Used In	Item	Part Number	Description/Nomenclature	Comments
Components				
	1	98CMCR0925	Assembly	
all	2	20C007	Adhesive	
all	3	02 04192	Shim, .023	
all	4	02 04192A	Shim, .015	


BPWOAD03 / 2025293

BPWOAD03.1 0000255709 O.3 F.4 7/15/25, 2:47 PM Released

**Door Lock Mechanism**

3Sheets


MCR12; MCT16/18/27; MWF18/27; MWR27/36; MWT12/16/18/27; 3015/3022T6X, VRJ, V8Z, VZZ; 30022  
 X8J/X8R; 36021V5J, V5Z, V7Z; 36026V5J, V5Z, V7Z; 42026V5J, V6Z. 42030V6J, V6Z



## Door Lock Mechanisms


3Sheets

MCR12; MCT16/18/27; MWF18/27; MWR27/36; MWT12/16/18/27; 3015/3022T6X, VRJ, V8Z, VZZ; 30022 X8J/X8R; 36021V5J, V5Z, V7Z; 36026V5J, V5Z, V7Z; 42026V5J, V6Z. 42030V6J, V6Z



### Legend

- A-A** . . Door lock switch “OFF”
- B-B** . . Door lock switch “ON”
- C-C** . . Door closed switch
- J** . . . No air gap
- K** . . . Insert item 2, thin side. Adjust the switch to “OFF.”
- L** . . . Insert item 2, thick side. Adjust the switch to be “ON.”
- M** . . . 3/16” minimum clearance
- N** . . . Measure this while the slider is down.



## Door Lock Mechanisms

3Sheets

MCR12; MCT16/18/27; MWF18/27; MWR27/36; MWT12/16/18/27; 3015/3022T6X, VRJ, V8Z, VZZ; 30022 X8J/X8R; 36021V5J, V5Z, V7Z; 36026V5J, V5Z, V7Z; 42026V5J, V6Z. 42030V6J, V6Z

**Table 26. Parts List—Door Lock Mechanisms**

Find the assembly for your machine and the letter shown in the "Item" column. The components for your machine will show this letter or the word "all" in the "Used In" column. The numbers shown in the "Item" column are those shown in the illustrations.				
Used In	Item	Part Number	Description/Nomenclature	Comments
Assemblies				
	1	98CMCR1206	DOOR INTERLOCK ASSY MCT12	MCR12, MCT16,
	1	98CMCR1205	DOOR INTERLOCK ASSY MWT12	MWT12, MWT16
	1	98CMCR0978	DOOR INTERLOCK ASSY MCT18	MCT18, MCT27
	1	98CMCR0971	DOOR INTERLOCK ASSY V8Z VRJ MILNOR ASSY A33 03226B	MWF18, MWF27, MWT18, MWT27, MCR36E4, MWR36J4, 30015/22T6X, VRJ, V8Z, VZZ, 36021V_, 36026V_, 42026V_, 42030V_
all	2	X2 03306A	MACH=GAGE DR LOCK SWITH, MCR	


## 7 Suspension

BPWXAJ01 / 2021024

BPWXAJ01.1 0000330007 A.3 F.4 1/6/21, 5:16 PM Released


**Suspension Components and Installation**

3 Sheets



Suspension Components and Installation

3 Sheets





## Suspension Components and Installation

3 Sheets


**Table 27. Parts List—Suspension Components and Installation**

Find the assembly for your machine and the letter shown in the "Item" column. The components for your machine will show this letter or the word "all" in the "Used In" column. The numbers shown in the "Item" column are those shown in the illustrations.				
Used In	Item	Part Number	Description/Nomenclature	Comments
Reference Assemblies				
	A	GMS3022X8	INSTAL SUSPENSION 3022X8J	
Components				
all	1	98CX02921G	ROD=SHELL SUPEN MT, CSM 3022FLATBACK	
all	2	15G239S	HEXJAMNUT 3/4-16UNF2 SS18-8	
all	3	W2 02924C	TOP ISOLATOR GUIDE	
all	4	60B135	MM SPRG 3X1X4 F#W223580047	
all	5	54E022	FBRGGTEF3/4X1X1BNT#BJ4F121608	
all	6	54A709	BALL BUSH 1" AURORA COM16	
all	7	02 02923	PLATE TOP MT 3022X8J	
all	8	W2 02922	WELDMENT BALLBUSH MT 3022X8J (CS)	
all	9	X2 02921E	LOWER BALL BUSH MT	
all	10	02 02921H	SPACER=BUSHING LOCKING	
all	11	X2 02921F	ROD=SHELL SUPEN MT	
all	12	02 02921G	PLATE COVER SUSPENSION	
all	13	54JH11000C	SHAFTCOLLAR SPLIT 1" CG#16S	
all	14	56Q1RJA	1" BUSH. QD TYPE JA D#120340	
all	15	15K095	HXCPSCR 3/8-16UNC2AX1 GR5 ZINC	
all	16	15U255	LOCKWASHER MEDIUM 3/8 ZINCPL	
all	17	15G205	HXNUT 3/8-16UNC2B ZINC GR2	
all	18	15K039	HXCAPSCR 1/4-20UNC2AX3/4 GR5 Z	
all	19	15U180	LOCKWASHER MEDIUM 1/4 ZINCPL	
all	20	02 02912	SUPPORT SUSPENSION 3022X8J	
all	21	15K153H	INDHEXFLGSCR1/2-13X1+1/4GR8ZN W/LOCTITE	
all	22	15G222B	HEXFLGNUT 1/2-13 ZINC SERRATED	
all	23	02 02921J	SPACER=BALL BUSH	
all	24	54M021	GRSFIT 1/8PIPE X 1/4STR 1607-B	

Suspension Settings

2 Sheets

3022X\_, 3626X8\_, 4226X7\_, 4232X7\_



Legend


- A . . .** Initially set the lower ball bushing [A] 11" [279] from the shell mounting bracket.
- B . . .** The space between the shell front and the point on the front corner posts where the angle changes should be [B] 1.50" +/- .125".
- C . . .** The space between the lower shell front and the angle on the corner posts should be [C] 1.25" +/- .125".
- D . . .** The height from the bottom of the shell front to the top of the inside base channel should be [D] 6" +/- .5"
- E . . .** The point on the front corner posts where the angle changes
- F . . .** Lower ball bushing
- G . . .** The top of the inside base channel

MODELS:	[A]
3022X_	4-1/2"[114]
3626X_	6-1/2"[165]
4226X_	8"[203]
4232X7_	11"[279]

## Suspension Settings

2 Sheets

3022X\_, 3626X8\_, 4226X7\_, 4232X7\_




BPWXAJ03 / 2021024

BPWXAJ03.1 0000330057 A.3 F.4 1/6/21, 3:57 PM Released

## Shock Absorbers


2 Sheets



Shock Absorbers

2 Sheets

Detailed Views



Legend

A . . . 2 instances  
B . . . 4 instances  
C . . . The two sides use the same suspension.

Table 28. Parts List—Shock Absorbers

Find the assembly for your machine and the letter shown in the "Item" column. The components for your machine will show this letter or the word "all" in the "Used In" column. The numbers shown in the "Item" column are those shown in the illustrations.				
Used In	Item	Part Number	Description/Nomenclature	Comments
Reference Assemblies				
	A	GIC3022X8	INSTALL SHOCK ABSORBER 3022X8J	
Components				
all	1	60BS6838	SHOCK ABSORBER = ARVIN #65907340E	
all	2	02 02901B	BKT=SHOCKMT BASE	
all	3	15K095	HXCPSCR 3/8-16UNC2AX1 GR5 ZINC	
all	4	15G205	HXNUT 3/8-16UNC2B ZINC GR2	
all	5	15U255	LOCKWASHER MEDIUM 3/8 ZINCPL	
all	6	15K201A	HXCAPSCR 1/2"-13X4" GRD 8 ZINC	
all	7	15G230	HXNUT 1/2-13UNC2B SAE ZINC GR2	
all	8	15U280	FL+WASHER(USS STD)1/2 ZNC PL+D	


## 8 Chemical Supply Devices

BPWXAC02 / 2021055

BPWXAC02.1 0000334937 A.4 F.4 2/2/21, 2:38 PM Released

**Inlet for 10 Peristaltic Chemical Supplies**


3 Sheets

**Figure 53. Installed Views**

Inlet for 10 Peristaltic Chemical Supplies

3 Sheets

Figure 54. 10 Inlets for Peristaltic Liquid Chemical Systems





<p><b>Detailed View</b></p>	<p><b>Legend</b></p> <p><b>J</b> . . . 2 instances</p> <p><b>K</b> . . . 10 instances</p>
-----------------------------	---

Find the assembly for your machine and the letter shown in the "Item" column. The components for your machine will show this letter or the word "all" in the "Used In" column. The numbers shown in the "Item" column are those shown in the illustrations.				
Used In	Item	Part Number	Description/Nomenclature	Comments
Reference Assemblies				
	A	GWL3022X	INST=PERISTALL 10 PORT	
Components				
all	1	02 035890	MOLDED LIQ SUPPLY MANFOLD=10	
all	2	02 02946	BRKT=CHEM INJECT 3022X	
all	3	15K039	HXCAPSCR 1/4-20UNC2AX3/4 GR5 Z	
all	4	15G165	HXNUT 1/4-20UNC2BSAE ZC GR2	
all	5	15U185	FLATWASHER(USS STD) 1/4" ZNC P	
all	6	15U180	LOCKWASHER MEDIUM 1/4 ZINCP	
all	7	15K030	HEXCAPSCR 1/4-20UNC2X1/2 GR5 Z	
all	8	5SB0K0GBEO	NPTHEXBUSH 1/2X3/8 BRASS 125#	
all	9	5SL0GBEA	NPTELB 90DEG 3/8 BRASS 125#	
all	10	51E507A	HOSESTEM BRASS 3/8MPX1/2HOSEID	
all	11	60E006C	PVC TUBING NYL.REINF.5IDX.75OD	
all	12	27A040	HOSECLAMP 7/16-25/32SS W/SCREW	
all	13	51E505Y	3/8" HOSE BARB Y CONNECTOR	

**Inlet for 10 Peristaltic Chemical Supplies**

3 Sheets

**Table 29 Parts List—Inlet for 10 Peristaltic Chemical Supplies (cont'd.)**

Find the assembly for your machine and the letter shown in the "Item" column. The components for your machine will show this letter or the word "all" in the "Used In" column. The numbers shown in the "Item" column are those shown in the illustrations.				
Used In	Item	Part Number	Description/Nomenclature	Comments
all	14	60E010	TUBINGPOLYBRAID 1"X1.312	
all	15	27A090	HOSECLAMP 13/16-1.5"CADSC#HS16	
all	16	5KY0P4A	3/4" PVC WYE SCH40 SLIPXSLXSL	
all	17	02 02932	NIPPLE=3/4" PVC WYE	
all	18	12P12ASB	SNAPBUSH 2"X1.75HEYCO#2406	
all	19	12P12KSB	SNAPBUSH 2.5"MH X 1+31/32"	
all	20	5SP0KXFHS	HEXHD PIPE PLUG 1/2"POLYPRO	


BPWXAC01 / 2021055

BPWXAC01.1 0000334918 A.3 F.4 1/28/21, 1:20 PM Released

**Soap Chute Components and Installation**

3 Sheets

3022X\_

**Figure 56. Soap Chute**

Soap Chute Components and Installation

3 Sheets

3022X\_

Figure 57. Installed Views





Figure 58. The Vacuum Breaker and Related Components



# Soap Chute Components and Installation

3 Sheets

3022X\_

Table 30. Parts List—Soap Chute Components and Installation

Find the assembly for your machine and the letter shown in the "Item" column. The components for your machine will show this letter or the word "all" in the "Used In" column. The numbers shown in the "Item" column are those shown in the illustrations.				
Used In	Item	Part Number	Description/Nomenclature	Comments
Reference Assemblies				
	A	GWS3022X8	INST=SOAP CHUTE ASSY 3022X8J	
	B	GVB00001	INST=SIPHON SOAP CHUTE FLUSH	
	C	AVB00001	ASSY=SIPHON SOAP CHUTE FLUSH	
Components				
A	1	AWS30211A	PLASTIC SOAP ASSY	
A	2	27A070	T-BOLT HOSECLAMP 1.94"-2.25"	
A	3	02 03870D	FLEXTUBE=2"ID X 14"LG W/CUFFS	
A	4	60E006C	PVC TUBING NYL.REINF.5IDX.75OD	
A	5	27A045	HOSECLAMP .750"DIA SPRINGTYPE	
A	6	15K053	BUTSOKCAPSCR 5/16-18X3/4 SS18-	
A	7	15G188	HEXLOKNUT 5/16-18 BRASS	
A	8	15G185	HXNUT 5/16-18UNC2B SAE ZINC GR	
A	9	02 04215	PLASTIC SOAP CHUTE BEZEL	
A	10	02 04217	PLASTIC SOAP CHUTE LATCH	
A	11	02 04216	SOAP CHUTE SPLASH GUARD	
A	12	98A002AT	PAD 6"X9"REG.DUTY,TURCO#A90551	
A	13	15G105	HEXMACSCRNUT 8-32UNC2 SS18-8	
A	14	15N095	RDMACSCR 8-32UNC2X3/4 SS18-8	
A	15	15U120B	LOCKWASHER MEDIUM #8 SS18-8	
A	16	51BB0KN00B	BULKHD FITT 1/2"BARBED,POLYPRO	
A	17	27A040	HOSECLAMP 7/16-25/32SS W/SCREW	
B	18	15K037	HEXCAPSCR 1/4-20UNC2AX5/8 GR5	
B	19	15G165	HXNUT 1/4-20UNC2BSAE ZC GR2	
B	20	15U180	LOCKWASHER MEDIUM 1/4 ZINCPL	
B	21	W2 03199	WLMT=SIPHON MOUNT	
C	22	96M021	1/2"VAC BREAKER #LF288A	
C	23	51E509PB	HOSEADAPT 1/2HXNPT POLYETHL	
C	24	51E509PBA	1/2HX1/2NPT HOSE ADAPT 90ELB	
C	25	5N0KCLSG42	NPT NIP 1/2XCLS TBE GALSTLSK40	


BPWXAC03 / 2021073

BPWXAC03.1 0000335028 A.6 F.4 2/9/21, 3:34 PM Released

# Five Compartments for Dry Chemical Supplies

5 Sheets

Figure 59. General Views




## Legend

B . . . Cover, not shown

C . . . 2 instances

D . . . 4 instances


Figure 60. Detail View



## Five Compartments for Dry Chemical Supplies

5 Sheets

Figure 61. Water to the Five Compartments for Dry Chemical Supplies



Five Compartments for Dry Chemical Supplies

5 Sheets

Figure 62. Valve Manifold





Figure 63. Valve Assembly





## Five Compartments for Dry Chemical Supplies

5 Sheets

Table 31. Parts List—Five Compartments for Dry Chemical Supplies

Find the assembly for your machine and the letter shown in the "Item" column. The components for your machine will show this letter or the word "all" in the "Used In" column. The numbers shown in the "Item" column are those shown in the illustrations.				
Used In	Item	Part Number	Description/Nomenclature	Comments
Reference Assemblies				
	A	GWS3022X	3022X8 5COMP SUPPLY ASSY	
	B	AWS3022X	ASSY 3022X8 5COMP SUPPLY	
	C	AWS30221A	5VLV SUPPLY MANIFOLD 3022X	
Components				
all	1	02 02925A	COVER SIDE LF SUPPLY	
C	2	02 03129A	COVER=5COMP SUPPLY 3022X	
C	3	02 03992	HOUSING=SUPPLY MANIFOLD 3022	
all	4	60E085C54A	HOSE ASSY=1/2" X 54"LG	
all	5	5SL0KNFA	NPTL 90DEG 1/2 GALMAL 150#	
all	6	5S0KNFA	NPT TEE 1/2" GALMAL 150#	
all	7	96M001	1/2X3/8" RELIEF VALVE SET31#	
all	8	5N0KCLSG42	NPT NIP 1/2XCLS TBE GALSTLSK40	
C	9	51X017	UNIONSTRADT 1/2"#1404-8-8	
C	10	5SR0P0KNF	NPT RED 3/4X1/2 GALMAL 150#	
C	11	W2 03990A	*WLMT=MANIFOLD SUPPLYINJ 6VLV	
C	12	53A026A	HEXPIPNIP.25X.25 AND#122A-B	
C	13	53A060H	KNURLHOSE NUT 3/4"PW#94GH-12	
C	14	02 03732Z	ADAPTER HOSE THD 3/4"X1/4 NPT	
C	15	53A060HA	WASHER=HOSE #901GH-12	
C	16	96P013B71	3/4" 2WAYPLASTICVAL 240V60C W/L-BRACKET	
C	17	27A040	HOSECLAMP 7/16-25/32SS W/SCREW	
C	18	51P013	PLUG HXCNTRSUNK 1/4"BRASS	
C	19	5SCA0PBE	NPT CAP 3/4 BRASS 125#	
A	20	60E006B	PVC TUBING (BRAID)3/8IDX.60D	
A	21	27A082	HOSECLAMP 2.5625-3.5CADSC#HS48	
A	22	02 03870D	FLEXTUBE=2"ID X 14"LG W/CUFFS	
A	23	27A070	T-BOLT HOSECLAMP 1.94"-2.25"	
A	24	01 10094X	NAMEPLATE: MANUAL FLUSH-ISO	
all	25	09N401BASE	MOUNT COLLAR ONLY #ZB5AZ009	
all	26	09N401CBNO	CONT BLOCK 1-NO #ZBE101	
all	27	09N401PBBK	PUSH BUTTON OPR. BK/BK	
A	29	15K105	HXCAPSCR 3/8-16UNC2A1.25 GR5 P	
A	30	15G205	HXNUT 3/8-16UNC2B ZINC GR2	

## Five Compartments for Dry Chemical Supplies

5 Sheets

**Table 31 Parts List—Five Compartments for Dry Chemical Supplies (cont'd.)**

Find the assembly for your machine and the letter shown in the "Item" column. The components for your machine will show this letter or the word "all" in the "Used In" column. The numbers shown in the "Item" column are those shown in the illustrations.				
Used In	Item	Part Number	Description/Nomenclature	Comments
A	31	15U255	LOCKWASHER MEDIUM 3/8 ZINCPL	
B	32	W2 03611C	SUPPLY CHUTE WELD 3022X (SS)	
B	33	02 03996	LID=3022F8 5COMP. SUPPLY	
B	34	02 03997C	5COMP REAR MOUNT PLT 3022X	
B	35	02 03998C	5COMP FRONT MOUNT PLT 3022X	
B	36	51E504EB	ELB HOSESTEM 3/8HX1/4NPT BRASS	
B	37	17N200B	1/4 NPT HEX LOCKNUT X1/4THICK	
B	38	5SR0G0EBF	NPT RED 3/8X1/4 BRASS 125#	
B	39	27A002	NOZZLE BRASS 3/8" SPRAYSYSTEMS	
B	40	15K086B	HEXCAPSCR 3/8-24X1 SS18-8	
B	41	15U260	LOCKWASHER MEDIUM 3/8 SS18-8	
B	42	24G030N	ROLLED WASH.379ID NYLTITE 37W	
B	43	15G211	HXCPNUT 3/8-24 UNF2 SS18-8	
B	44	15K041S	HEXCAPSCR 1/4-20UNC2AX1 SS18-8	
B	45	15U160	LOCKWASHER MEDIUM #10 SS18-8	
B	46	15G140	HXCAPNT 1/4-20 #C250=20 NKLPLT	
all	47	SA 02 066	*COVER ASSY=SUPPINJ	
all	48	02 03991	MANIFOLD HOUSING COVER PLATE	
C	49	12P11CSB	SNAPBUSH 1.093"MH X .94"ID HEYCO#2166	
C	50	12P11PHP	HOLEPLUG 1+3/4" BLK HEYCO#2773	
all	51	5SU0PNF	NPT UNION 3/4" GALMAL 150#	

## 9 Water and Steam


BPWXAW01 / 2021025

BPWXAW01.1 0000331775 A.4 F.4 1/12/21, 9:03 AM Released

**Water and Steam Schematic and Primary Components**

2 Sheets

3022X\_\_

**Legend**

- A . . .** Hot water to flush the chemical supplies
- B . . .** Hot water inlet
- C . . .** Cold water inlet
- D . . .** Cool down water line (optional)
- E . . .** Steam inlet (optional)
- F . . .** Six inlets for peristaltic liquid chemical systems (optional)
- G . . .** 10 inlets for peristaltic liquid chemical systems
- H . . .** Soap chute
- J . . .** Five compartments to flush in chemical supplies (optional)
- K . . .** Drain valve
- L . . .** Recirculation pump (optional)
- M . . .** Keep this component clean.
- N . . .** Keep this component set to the correct pressure. 28 LBS.
- P . . .** 5 instances
- Q . . .** The standard location of the pressure relief valve.
- R . . .** The alternative location of the pressure relief valve for the five compartments to flush chemical supplies.
- S . . .** Reuse water through the recirculation pump to the door (optional)
- T . . .** Reuse tank (optional)

# Water and Steam Schematic and Primary Components

2 Sheets


3022X\_\_

**Table 32. Parts List—Water and Steam Schematic and Primary Components**

Find the assembly for your machine and the letter shown in the "Item" column. The components for your machine will show this letter or the word "all" in the "Used In" column. The numbers shown in the "Item" column are those shown in the illustrations.				
Used In	Item	Part Number	Description/Nomenclature	Comments
all	1	96J030D	1/2"PRESSREG SET28# FEMXUN #LF25AUB-Z5 #0009255	
all	2	30N100	PRESSGAUGE 1/8"BACKCN.0-30PSI	
all	3	96M001	1/2X3/8" RELIEF VALVE SET31#	
all	4	96P057A71	1/2"NPT X 1/2"ORIFICE 240V 5/6 - BURKERT	
all	5	96D034	BALL VLV - BONOMI 1/2" 171S SS BALL/STEM	
all	6	51T025	Y-STRAINER 1/2" CAST IRON=WATTS#77S-M1 40;EDP- 220308	
all	7	96TDC2BA71	1/2" N/C 2WAY 240V50/60C STEAM	
AB	8A	W2 02555A	WELD X-MACH PIPE NOZZLE 3/8D	
all	8B	98CX02555A	STEAM SPARGER 42X	
all	9	96M021	1/2"VAC BREAKER #LF288A	
all	10	96P013B71	3/4" 2WAYPLASTICVAL 240V60C W/L-BRACKET	
all	11	96D350A71	DRINVAL 3"N/O MTRDR240V 50/60C W/COVER DEPENDO	
all	12	27E955M96	3/4HP 3P PMP 240/420/480 5/6C	
all	13	96D087WE	ANGBODVLV 1.5"N/C H2O BURK BRZ=(BURKERT# 468162)	
all	14	96D087FBA	1.5"BALVAL+ACT BRS N/C BONOMI (SPRING RET)	


## Water Manifold & Peristaltic Boxes

3 Sheets



## Water Manifold &amp; Peristaltic Boxes

3 Sheets



Legend

**B-B** . . Cross Section, Air Space**K** . . . Vent**L** . . . Air Space, 1"[25MM]**M** . . . 30022X8W with tank only**Table 33. Parts List—Inlet for Six Peristaltic Chemical Supplies and Water**

Find the assembly for your machine and the letter shown in the "Item" column. The components for your machine will show this letter or the word "all" in the "Used In" column. The numbers shown in the "Item" column are those shown in the illustrations.				
Used In	Item	Part Number	Description/Nomenclature	Comments
Reference Assemblies				
	A	GA 33 058X	INST=H2O+PERSTAL REAR INLET	
	B	SA 33 058X	ASSY=PLSTC PERSTL 3022X	
Components				
all	1	02 03588M	PERISTALTIC/WATER INLET 3022H	
all	2	02 03588K	36V PERISTALTIC BOX TOP COVER	
all	3	02 03195	PERISTL BOX MOUNT, 3022H8	
all	4	02 02930	PLATE MT PARESTALTIC	

## Water Manifold &amp; Peristaltic Boxes

3 Sheets

**Table 33 Parts List—Inlet for Six Peristaltic Chemical Supplies and Water (cont'd.)**

Find the assembly for your machine and the letter shown in the "Item" column. The components for your machine will show this letter or the word "all" in the "Used In" column. The numbers shown in the "Item" column are those shown in the illustrations.				
Used In	Item	Part Number	Description/Nomenclature	Comments
all	5	12K077	STRAP 1/2" HVY CONDUIT 2-HOLE	
all	6	5N0P01PG41	NPT NIP 3/4X1.75 TOE GAL. S40	
all	7	5SL1ANFA0P	NPTEL B 90DEG 1X3/4 GALMAL 150#	
all	8	5N1A08AG42	NPT NIP 1X8 TBE GALSTL SK40	
all	9	5S1ANFA0P1	NPT TEE 1X1X3/4" GALMAL 150#	
all	10	5N1A03AG42	NPT NIP 1X3 TBE GALSTL SK40	
all	11	51E511	HOSESTEM BRASS 3/4MP X HOSEID	
all	12	27A090	HOSECLAMP 13/16-1.5"CADSC#HS16	
all	13	60E008A	TUBINGNYLREINF.75"IDX1.025"OD	
all	14	60E006C	PVC TUBING NYL.REINF.5IDX.75OD	
all	15	27A040	HOSECLAMP 7/16-25/32SS W/SCREW	
all	16	60E010	TUBINGPOLYBRAID 1"X1.312	
all	18	02 03588B	PERISTALTIC/WATER INLET LONG HOSE	
all	19	15P010	TRDCUT PHILPANHDSCR 10-24X1/2S	
all	20	15N110H	RDWASHHD TORXBOLT M6-1X25MM ZN	
all	21	15G004HB	EXTRUNUT M6-1 GRIP 0.8-4MM	
all	22	15K031	BUTSOKCAPSCR 1/4-20X1/2 SS18-8	
all	23	15U181	LOCKWASHER MEDIUM 1/4 SS18-8	
all	24	27A074	HOSECLAMP 2+1/16-3"CADSC#62040	
all	25	20C009CA	LOCTITE 3032 ADHESIVE	
all	26	5N0KCLSS42	NPT NIP 1/2XCLS TBE 304SS SK40	
all	27	5SR0P0KSF	NPT RED 3/4X1/2 SS304 150#	
all	28	03 25429S	HOSE ADAPT=1"HOSE 3/4"NPT SS	



BPWXAW03 / 2021044


BPWXAW03.1 0000334616 A.3 F.4 1/20/21, 11:43 AM Released

# Water Inlet Components and Installation


3 Sheets

3022X

Pressure Regulator Assembly



Cross Section




Legend

- A . . . Hot water to flush the chemical supplies
- B . . . Hot water inlet
- C . . . Cold water inlet

## Water Inlet Components and Installation

3 Sheets

3022X




# Water Inlet Components and Installation

3 Sheets

3022X

**Table 34. Parts List—Water Inlet Components and Installation**

Find the assembly for your machine and the letter shown in the "Item" column. The components for your machine will show this letter or the word "all" in the "Used In" column. The numbers shown in the "Item" column are those shown in the illustrations.				
Used In	Item	Part Number	Description/Nomenclature	Comments
Reference Assemblies				
	A	SA 33 058W	WATER VALVE ASSY 3022X	
Components				
all	1	96J030D	1/2"PRESSREG SET28# FEMXUN #LF25AUB-Z5 #0009255	
all	2	5N0KCLSBE2	NPT NIP 1/2XCLS TBE BRASS STD	
all	3	5S0KBEA	NPT TEE 1/2" BRASS 125#	
all	4	5SB0K0CBEO	NPTHEXBUSH 1/2X1/8 BRASS 125#	
all	5	30N100	PRESSGAUGE 1/8"BACKCN.0-30PSI	
all	6	5SU0KBE	NPT UNION 1/2" BRASS 125#	
all	7	51E513B	3/4"MHX1/2"FP PARKER#80GH-12-8	
all	8	5N0K03KB42	NPT NIP 1/2X3.5 TBE BRASS STD	
all	9	96P057A71	1/2"NPT X 1/2"ORIFICE 240V 5/6 - BURKERT	
all	10	51E509	HOSESTEM BRASS 1/2MPX1/2HOSEID	
all	11	51E510	HOSESTEM BRASS 1/2MPX3/4HOSEID	
all	12	W2 03588S	3015/22 BRASS H20 MNT WLMT (CS)	
all	13	27A0050	CLP-RGDSTL COND #PS1100-1/2	




## Steam Inlet Components and Installation

2 Sheets

**Table 35. Parts List—Steam Inlet Components and Installation**

Find the assembly for your machine and the letter shown in the "Item" column. The components for your machine will show this letter or the word "all" in the "Used In" column. The numbers shown in the "Item" column are those shown in the illustrations.				
Used In	Item	Part Number	Description/Nomenclature	Comments
Reference Assemblies				
	A	GVS3022X	INST STEAM ASSY 3022X	
	B	AVS3022X	ASSY=STEAM 3022X	
Components				
all	1	51T025	Y-STRAINER 1/2" CAST IRON=WATTS#77S-M1 40;EDP-220308	
all	2	5N0KCLSF42	NPT NIP 1/2XCLS TBE BLKSTL S40	
all	3	5SU0KMF	NPT UNION 1/2" BLKMAL 150#	
all	4	5N0K04AF42	NPT NIP 1/2X4 TBE BLK SK 40	
all	5	96TDC2BA71	1/2" N/C 2WAY 240V50/60C STEAM	
all	6	5N0K05KF42	NPT NIP 1/2X5.5 TBE BLK SK 40	
all	7	5SCC0KMF	NPT COUP 1/2 BLKMAL 150#	
all	8	51X017	UNIONSTRADT 1/2"#1404-8-8	
all	9	5SP0GGFSS	NPT PLUG 3/8 SQ SOLID GALSTL	
all	10	60E508E32A	HOSE SS BRAID 3/8+2ENDS=32LG	
all	11	5SCC0KSF1	NPTCOUP 1/2"SS304 150#BARSTOCK	
	12	W2 02555A	WELD X-MACH PIPE NOZZLE 3/8D	USA-made models only




## Drain Valve Installation

2 Sheets

**Table 36. Parts List—Drain Valve Installation**

Find the assembly for your machine and the letter shown in the "Item" column. The components for your machine will show this letter or the word "all" in the "Used In" column. The numbers shown in the "Item" column are those shown in the illustrations.				
Used In	Item	Part Number	Description/Nomenclature	Comments
Reference Assemblies				
	A	GVD3022X8	INST=DRAINVALVE ASSY 3022X8J	
Components				
all	1	96D350A71	DRINVAL 3"N/O MTRDR240V 50/60C W/COVER DEPENDO	
all	2	02 02934	BKT=DUMPVAL MT	
all	3	02 02934A	DUMPVAL BKT TOP	
all	4	02 03245	MOLDED DRAIN HOSE, 3022H	
all	5	27A088S	HOSECLAMP 3+1/16-4"SSSCR#HSS56	
all	6	60B075	DFW56-33PMSP RUBB CONN.	
all	7	15K039	HXCAPSCR 1/4-20UNC2AX3/4 GR5 Z	
all	8	15G165	HXNUT 1/4-20UNC2BSAE ZC GR2	
all	9	15U180	LOCKWASHER MEDIUM 1/4 ZINCPL	
all	10	15K143B	HEXCAPSCR 7/16-14UNCX1"GR5 ZIN	
all	11	15U280	FL+WASHER(USS STD)1/2 ZNC PL+D	
all	12	15U278	LOCKWASHER MEDIUM 7/16 ZINCPL	
all	13	15G222C	HEXNUT 7/16-14UNC2B ZINC GR2	



**Table 37. Parts List—3 Inch Electrical Drain Valve**

Find the assembly for your machine and the letter shown in the "Item" column. The components for your machine will show this letter or the word "all" in the "Used In" column. The numbers shown in the "Item" column are those shown in the illustrations.				
Used In	Item	Part Number	Description/Nomenclature	Comments
Reference Assemblies				
	A	96D350A71	DRINVAL 3"N/O MTRDR240V 50/60C W/COVER DEPENDO	
Components				




### 3 Inch Electrical Drain Valve

2 Sheets

**Table 37 Parts List—3 Inch Electrical Drain Valve (cont'd.)**

Find the assembly for your machine and the letter shown in the "Item" column. The components for your machine will show this letter or the word "all" in the "Used In" column. The numbers shown in the "Item" column are those shown in the illustrations.				
Used In	Item	Part Number	Description/Nomenclature	Comments
all	1	96D35MTR71	240V 50/60CMTR FOR 3"DRAINVAL	
all	2	96D35B0D	BODY & BALL FOR 3" DRAIN VALVE (VLV HOUSING ONLY)	
all	3	96D35C0V	MTRCOVER 2-PCFOR 3"DRAINVAL-DEPENDO #90016105	
all	4	96D35PIN	DRIVE PIN KIT FOR 3" DRAIN VAL	



## Cool Down Components and Installation

2 Sheets

**Table 38. Parts List—Cool Down Components and Installation**

Find the assembly for your machine and the letter shown in the "Item" column. The components for your machine will show this letter or the word "all" in the "Used In" column. The numbers shown in the "Item" column are those shown in the illustrations.				
Used In	Item	Part Number	Description/Nomenclature	Comments
Reference Assemblies				
	A	AVC30X001	COOLDOWN ASSMBLY 3022X	
Components				
all	1	5S0KBEA	NPT TEE 1/2" BRASS 125#	
all	2	5N0K03KB42	NPT NIP 1/2X3.5 TBE BRASS STD	
all	3	5SL0KBEA	NPTEL B 90DEG 1/2 BRASS 125#	
all	4	5N0KCLSBE2	NPT NIP 1/2XCLS TBE BRASS STD	
all	5	96P057A71	1/2"NPT X 1/2"ORIFICE 240V 5/6 - BURKERT	
all	6	5N0K03ABE2	NPT NIP 1/2X3 TBE BRASS STD	
all	7	96D034	BALL VLV - BONOMI 1/2" 171S SS BALL/STEM	
all	8	51E509	HOSESTEM BRASS 1/2MPX1/2HOSEID	

Electric Heat

3022X, 3626X, 4226X, 4232X

1 Sheet




Table 39. Parts List—Electric Heat


Find the assembly for your machine and the letter shown in the "Item" column. The components for your machine will show this letter or the word "all" in the "Used In" column. The numbers shown in the "Item" column are those shown in the illustrations.				
Used In	Item	Part Number	Description/Nomenclature	Comments
Components				
all	1	98CMCR3605	ELECTRIC HEATER PROBE, 3KW 240V UL	

# 10 Control and Sensing

Water Level Switch & Temperature Sensor

2 Sheets

3022X8J, 3022X8R



## Water Level Switch & Temperature Sensor

2 Sheets

3022X8J, 3022X8R

**Table 40. Parts List—Water Level Switch & Temperature Sensor**

Find the assembly for your machine and the letter shown in the "Item" column. The components for your machine will show this letter or the word "all" in the "Used In" column. The numbers shown in the "Item" column are those shown in the illustrations.				
Used In	Item	Part Number	Description/Nomenclature	Comments
Reference Assemblies				
	A	ALL30211	ASSY=3022H7J AIR CHAMBER	
Components				
all	1	5N0K04AG42	NPT NIP 1/2X4 TBE GALSTL SK40	
all	2	5SL0KNFK	NPTELB 45DEG 1/2 GALMAL 150#	
all	3	5SR0K0ENF	NPT RED 1/2X1/4 GALMAL 150#	
all	4	51E507	HOSESTEM BRASS 1/4MPX1/2HOSEID	
all	5	60E006C	PVC TUBING NYL.REINF.5IDX.75OD	
all	6	27A040	HOSECLAMP 7/16-25/32SS W/SCREW	
all	7	12P01410SZ	TUBE CLAMP 5/8 ZC	
all	8	5SCC0EBE	NPT COUP 1/4 BRASS 150#PSI W/HEX	
all	9	51E502B	HOSESTEM BRASS 1/4MPX1/8HOSEID	
all	10	27A047	HOSECLMP 1/8HOSEID CLIP	
all	11	60E004NT	TUBING (NYL.)CLR.1/4"ODX1/8"	
all	12	30R0043PB	TEMPERATURE PROBE ASSY=BRASS	

# 11 Recirculation



This page intentionally blank

BPWXAW08 / 2021055


BPWXAW08.1 0000334868 B.2 F.4 8/29/23, 4:58 PM Released

## Reuse Tank, Recirculation Pump, and Piping

4 Sheets

30022X8W, 30022X8R

Figure 64. Tank



### Legend


A . . . Recirculation to the door

## Reuse Tank, Recirculation Pump, and Piping

4 Sheets

30022X8W, 30022X8R

Figure 65. Recirculation Pump






## Reuse Tank, Recirculation Pump, and Piping

4 Sheets

30022X8W, 30022X8R

Figure 66. Recirculation Piping



# Reuse Tank, Recirculation Pump, and Piping









4 Sheets

30022X8W, 30022X8R

**Table 41. Parts List—Reuse Tank, Recirculation Pump, and Piping**

Find the assembly for your machine and the letter shown in the "Item" column. The components for your machine will show this letter or the word "all" in the "Used In" column. The numbers shown in the "Item" column are those shown in the illustrations.				
Used In	Item	Part Number	Description/Nomenclature	Comments
Components				
all	1	W2 03115	WLMT+OUTERWEAR REUSE TANK	
all	2	W2 03120	COVER REUSE TANK 3022X	
all	3	02 02947	3022X RECIRC PUMP MNT	
all	4	06 20730	SPACER = MOTOR TO BRKT	
all	5	27E955M96	3/4HP 3P PMP 240/420/480 5/6C	
all	6	W2 13546B	TUBE WELD RECIRC 3022X	
all	7	5SL1ENFA	NPT ELB 90DEG 1.25 GALMAL 150#	
all	8	5N1ECLSG42	NPT NIP 1.25XCLS TBE GALSTLS40	
all	9	51E098ASS	KINGREDNIP1.5IDX1.25MP#RST2015	
all	10	60E098	HOSE 1.5" WATER SUCTION HOSE	
all	11	27A066A	T-BOLT HOSECLAMP 1.66-1.97"	
all	12	5S1ENFA	NPT TEE 1.25" GALMAL 150#	
all	13	96D087WE	ANGBODVLV 1.5"N/C H2O BURK BRZ	
all	14	5N1E05AG42	NPT NIP 1.25X5 TBE GALSTL SK40	
all	15	5N1E06AS41	NPT NIP 1.25X6 TOE 304SS SK40	
all	16	5SL1ESFA	NPT ELB 90DEG 1.25 304SS 150#	
all	17	5N1E09AS41	NPT NIP 1.25X9 TOE 304SS SK40	
all	18	5SB1K1ESFO	NPTHEXBUSH 1.5X1.25 SS304 150#	
all	19	5SL1KSFA	NPT ELB 90DEG 1.5 304SS 150#	
all	20	5N1K07AS42	NPT NIP 1.5X7 TBE 304SS SK40	
all	21	5N1K06AS42	NPT NIP 1.5X6 TBE 304SS SK40	
all	22	27E971D	VICT COUP 1.5"GALV #75	
all	23	5N1KCLSS42	NPT NIP 1.5XCLS TBE 304SS SK40	
all	24	96D087FBA	1.5"BALVAL+ACT BRS N/C BONOMI	
all	25	5N1K03AS41	NPT NIP 1.5X3 TOE 304SS SK40	
all	25	5N2KCLSS42	NPT NIP 2.5XCLS TBE 304SS SK40	
all	27	5SL2KSFA	NPT ELBOW 90DEG 2.5 304SS 150#	
all	28	5N2K04AS41	NPT NIP 2.5X4 TOE 304SS SK40	
all	29	60E303F	HOSE 3"ID LAYFLAT HOSE	

# 12 Dimensional Drawings








W3	COLD WATER INLET, 3/4" GARDEN HOSE, MALE THREAD.
W2	HOT WATER INLET, 3/4" GARDEN HOSE, MALE THREAD.
W1	HOT WATER FOR SUPPLY, 3/4" NPT CONNECTION, PRESSURE REGULATOR ASSEMBLY, REMOVED FOR SHIPPING, MUST BE ADDED AT INSTALLATION.
L2	STANDARD LIQUID SUPPLY INLETS. SEE NOTE 10.
L1	STANDARD SOAP CHUTE
F4	DRAIN HOLES
F3	GROUT HOLES
F2	(4) 1-1/16" DIAMETER ANCHOR BOLT HOLES, USE 5/8" X 6" BOLTS MINIMUM.
F1	BASEPADS, SEE NOTE 8.
E4	MAIN ELECTRICAL CONTROL BOX
E3	SECONDARY (240 VOLT) CONTROL PANEL
E2	MillTouch-EX™ TOUCH SCREEN CONTROLLER (3022X8R); E-P PLUS™ CONTROLLER (3022X8J)
E1	MAIN ELECTRICAL CONNECTION
D1	DRAIN TO REAR, 3" PIPE SOCKET JOINT.
A2	VENT FOR LIQUID SUPPLY
A1	VENT 3"Ø
ITEM	LEGEND

NOTES	
11	12" [305] MINIMUM CLEARANCE IS RECOMMENDED FOR SERVICE TO MACHINE ON SIDES NOT REQUIRING OPERATOR ACCESS. 16" [406] MINIMUM IS RECOMMENDED FOR OPERATOR ACCESS TO SOAP SUPPLY. SEE LOCAL ELECTRIC CODES FOR REQUIRED CLEARANCES.
10	STANDARD LIQUID SUPPLY INLETS COMES WITH THREE SETS OF FIVE FITTINGS. ONE SET OF 3/8" FITTINGS, ONE SET OF 1/2" FITTINGS, AND ONE SET OF PLUGS WHICH ARE SHIPPED ON MACHINE.
9	SHIM TO LEVEL THE MACHINE AND ALLOW FOR 1" [25] MINIMUM GROUT. ANCHOR ALL LABELED ANCHOR BOLT HOLES. USE 5/8" X 6" BOLTS MINIMUM. SEE INSTALLATION MAINTENANCE MANUAL FOR FURTHER INSTRUCTIONS.
8	SHADED AREA DENOTES BASE PADS WHICH MUST BE CONTINUOUSLY SUPPORT.
7	DO NOT PRE-PIPE ANY CLOSER THAN 60 [1524].
6	AS OF THIS WRITING, THE MINIMUM CLEARANCE REQUIRED BY U.S. NATIONAL ELECTRIC CODES, FROM ELECTRIC BOX TO ANY OBJECT IS: 36 [914] IF OBJECT IS AN UNGROUNDED (INSULATED) WALL. 42 [1067] IF OBJECT IS A GROUNDED WALL (i.e. BARE CONCRETE, BRICK, ETC.) 48 [1219] IF OBJECT IS ANY LIVE PART. CHECK LOCAL ELECTRIC CODES FOR FURTHER RESTRICTIONS.
5	CUSTOMER TO SUPPLY CIRCUIT BREAKER OR FUSED BRANCH CIRCUIT DISCONNECT (SAFETY) SWITCHES WITH LAG TYPE FUSES FROM POWER SOURCE TO MACHINE. A SEPARATE GROUND WIRE MUST BE CONNECTED FROM DISCONNECT TO EQUIPMENT.
4	BASELINE "Z" IS THE SAME FOR ALL MILLNOR MACHINES AND IS SHOWN ON ALL DIMENSIONAL DRAWINGS. THE DISTANCE BETWEEN BASELINE "Z" AND THE FINISHED FLOOR MAY VARY (WITH CHANGES IN FLOOR HEIGHT) AS REQUIRED TO INSURE THAT BASELINE "Z" IS HORIZONTAL AND ALL COMPONENTS REQUIRING GROUT ARE SET ON A MINIMUM 1" [25] THICK GROUT BED.
3	USE REFERENCE LINES "X", "Y", AND "Z" TO LOCATE ALL SERVICE CONNECTIONS.
2	NUMBERS IN BRACKETS [ ] DENOTE DIMENSIONS IN MILLIMETERS.
1	ALL DIMENSIONS SHOWN ARE APPROXIMATE, SUBJECT TO NORMAL MANUFACTURING TOLERANCES, AND TO OCCASIONAL CHANGES WITHOUT NOTICE THROUGH REDESIGN AND/OR RELOCATION OF COMPONENTS, ETC. DO NOT USE FOR CONSTRUCTION UNLESS CERTIFIED, AND IN NO EVENT PRE-PIPE CLOSER THAN FIVE FEET FROM MACHINE. FACTORY MUST BE CONSULTED FOR DIMENSIONS IF MACHINE IS TO BE MOVED THROUGH NARROW OR LOW CORRIDORS OR OPENINGS.
<b>ATTENTION</b>	
MOST REGULATORY AUTHORITIES (INCLUDING OSHA IN THE USA) HOLD THE OWNER/USER ULTIMATELY RESPONSIBLE TO MAINTAIN A SAFE WORKING ENVIRONMENT. ACCORDINGLY, THE OWNER/USER MUST RECOGNIZE ALL FORESEEABLE SAFETY HAZARDS, FURNISH SAFETY INSTRUCTIONS AND GUIDANCE TO ALL PERSONNEL WHO MAY COME IN CONTACT WITH THE INSTALLATION, AND PROVIDE ALL NECESSARY ADDITIONAL SAFETY GUARDS, FENCES, RESTRAINTS, DEVICES, ETC., NOT FURNISHED BY THE EQUIPMENT MANUFACTURER OR VENDOR.	
<b>ATTENTION</b>	
THE FLOOR AND/OR OTHER SUPPORT COMPONENTS MUST HAVE SUFFICIENT STRENGTH (AND RIGIDITY WITH DUE CONSIDERATION FOR NATURAL OR RESONANT FREQUENCY THEREOF) TO WITHSTAND THE FULLY LOADED WEIGHT OF THE MACHINE INCLUDING THE GOODS, THE WATER, AND ANY REPEATED SINUSOIDAL (ROTATING) FORCES GENERATED DURING ITS OPERATION. WRITE THE FACTORY FOR ADDITIONAL MACHINE DATA FOR USE BY A COMPETENT SOIL AND/OR STRUCTURAL ENGINEER.	

30022X8R, 30022X8J

BD3022X8CE  
2025262D

**MILLNOR** PELLERIN MILLNOR CORPORATION  
P.O. Box 400 Kenner, LA 70063, USA, Phone 504/487-8591,  
FAX 504/488-1849, Email: millnorinfo@millnor.com



W5	OPTIONAL AIROP REUSE (IF STEAM SUPPLIED), 1/2" NPT, (PART OF OPTIONAL DUAL DRAIN).
W4	OPTIONAL AIROP REUSE (IF NO STEAM), 1/2" NPT, (PART OF OPTIONAL DUAL DRAIN).
T2	OVERFLOW, 3" ID HOSE SUPPLIED
T1	OPTIONAL REUSE TANK, 3022X8W ONLY.
S1	OPTIONAL STEAM, 1/2" NPT
L4	5 COMPARTMENT SUPPLY
L3	ADDITIONAL LIQUID SUPPLY INLETS FOR 15 PORT PERISTALTIC
D2	DUAL DRAIN (REUSE), 3" PIPE SOCKET JOINT
D1	DRAIN DRAIN (SEWER), 3" PIPE SOCKET JOINT
A1	AIR CONNECTION 1/4" NPT, FOR REUSE WATER INLET(AIROP) (PART OF OPTIONAL DUAL DRAIN).
ITEM	LEGEND




NOTES	
6	AS OF THIS WRITING, THE MINIMUM CLEARANCE REQUIRED BY U.S. NATIONAL ELECTRIC CODES, FROM ELECTRIC BOX TO ANY OBJECT IS: 36 [914] IF OBJECT IS AN UNGROUNDED (INSULATED) WALL. 42 [1067] IF OBJECT IS A GROUNDED WALL (i.e. BARE CONCRETE, BRICK, ETC.). 48 [1219] IF OBJECT IS ANY LIVE PART. CHECK LOCAL ELECTRIC CODES FOR FURTHER RESTRICTIONS.
5	CUSTOMER TO SUPPLY CIRCUIT BREAKER OR FUSED BRANCH CIRCUIT DISCONNECT (SAFETY) SWITCHES WITH LAG TYPE FUSES FROM POWER SOURCE TO MACHINE. A SEPARATE GROUND WIRE MUST BE CONNECTED FROM DISCONNECT TO EQUIPMENT.
4	BASELINE "Z" IS THE SAME FOR ALL MILNOR MACHINES AND IS SHOWN ON ALL DIMENSIONAL DRAWINGS. THE DISTANCE BETWEEN BASELINE "Z" AND THE FINISHED FLOOR MAY VARY (WITH CHANGES IN FLOOR HEIGHT) AS REQUIRED TO INSURE THAT BASELINE "Z" IS HORIZONTAL AND ALL COMPONENTS REQUIRING GROUT ARE SET ON A MINIMUM 1" [25] THICK GROUT BED.
3	USE REFERENCE LINES "X", "Y", AND "Z" TO LOCATE ALL SERVICE CONNECTIONS.
2	NUMBERS IN BRACKETS [ ] DENOTE DIMENSIONS IN MILLIMETERS.
1	ALL DIMENSIONS SHOWN ARE APPROXIMATE, SUBJECT TO NORMAL MANUFACTURING TOLERANCES, AND TO OCCASIONAL CHANGES WITHOUT NOTICE THROUGH REDESIGN AND/OR RELOCATION OF COMPONENTS, ETC. DO NOT USE FOR CONSTRUCTION UNLESS CERTIFIED, AND IN NO EVENT PRE-PIPE CLOSER THAN FIVE FEET FROM MACHINE. FACTORY MUST BE CONSULTED FOR DIMENSIONS IF MACHINE IS TO BE MOVED THROUGH NARROW OR LOW CORRIDORS OR OPENINGS.
ATTENTION	
MOST REGULATORY AUTHORITIES (INCLUDING OSHA IN THE USA) HOLD THE OWNER/USER ULTIMATELY RESPONSIBLE TO MAINTAIN A SAFE WORKING ENVIRONMENT. ACCORDINGLY, THE OWNER/USER MUST RECOGNIZE ALL FORESEEABLE SAFETY HAZARDS, FURNISH SAFETY INSTRUCTIONS AND GUIDANCE TO ALL PERSONNEL WHO MAY COME IN CONTACT WITH THE INSTALLATION, AND PROVIDE ALL NECESSARY ADDITIONAL SAFETY GUARDS, FENCES, RESTRAINTS, DEVICES, ETC., NOT FURNISHED BY THE EQUIPMENT MANUFACTURER OR VENDOR.	
ATTENTION	
THE FLOOR AND/OR OTHER SUPPORT COMPONENTS MUST HAVE SUFFICIENT STRENGTH (AND RIGIDITY WITH DUE CONSIDERATION FOR NATURAL OR RESONANT FREQUENCY THEREOF) TO WITHSTAND THE FULLY LOADED WEIGHT OF THE MACHINE INCLUDING THE GOODS, THE WATER, AND ANY REPEATED SINUSOIDAL (ROTATING) FORCES GENERATED DURING ITS OPERATION. WRITE THE FACTORY FOR ADDITIONAL MACHINE DATA FOR USE BY A COMPETENT SOIL AND/OR STRUCTURAL ENGINEER.	

30022X8J, X8R OPTIONS





# 13 Dimensional Drawings: Pedestals

This page intentionally blank



6 W 20 RECOMMENDED



F2	FOUR, 1-1/4" [32] ANCHOR BOLT HOLES BOLT TO FLOOR
F1	FOUR, 1-1/4" [32] ANCHOR BOLT HOLES BOLT TO MACHINE

ITEM	LEGEND
------	--------

NOTES	
3	WHEN INSTALLING MACHINE AND PEDESTAL BASE, IT IS RECOMMENDED TO LAY THE PEDESTAL ON A MINIMUM 1 [25] THICK GROUT BED AND BOLT THE MACHINE TO IT. ALTERNATELY, THE MACHINE MAY BE WELDED TO THE BASE, PROVIDED IT IS SHIMMED AS REQUIRED TO INSURE THERE IS NO DISTORTION OF THE MACHINE BASE PLATES OR FRAME.
2	THIS BASE MUST BE FABRICATED LOCALLY AND SHOULD BE MADE SQUARE AND LEVEL. IT IS NOT SUPPLIED BY PELLERIN MILNOR CORP. THIS DRAWING CONVEYS NO EXPRESS OR IMPLIED WARRANTY WITH REGARD TO THE CONSTRUCTION AND/OR SUITABILITY OF THIS ASSEMBLY.
1	NUMBERS IN BRACKETS [ ] DENOTE DIMENSIONS IN MILLIMETERS.

ATTENTION	
MOST REGULATORY AUTHORITIES (INCLUDING OSHA IN THE USA) HOLD THE OWNER/USER ULTIMATELY RESPONSIBLE TO MAINTAIN A SAFE WORKING ENVIRONMENT. ACCORDINGLY, THE OWNER/USER MUST RECOGNIZE ALL FORESEEABLE SAFETY HAZARDS, FURNISH SAFETY INSTRUCTIONS AND GUIDANCE TO ALL PERSONNEL WHO MAY COME IN CONTACT WITH THE INSTALLATION, AND PROVIDE ALL NECESSARY ADDITIONAL SAFETY GUARDS, FENCES, RESTRAINTS, DEVICES, ETC., NOT FURNISHED BY THE EQUIPMENT MANUFACTURER OR VENDOR.	

ATTENTION	
THE FLOOR AND/OR OTHER SUPPORT COMPONENTS MUST HAVE SUFFICIENT STRENGTH (AND RIGIDITY WITH DUE CONSIDERATION FOR NATURAL OR RESONANT FREQUENCY THEREOF) TO WITHSTAND THE FULLY LOADED WEIGHT OF THE MACHINE INCLUDING THE GOODS, THE WATER, AND ANY REPEATED SINUSOIDAL (ROTATING) FORCES GENERATED DURING ITS OPERATION. WRITE THE FACTORY FOR ADDITIONAL MACHINE DATA FOR USE BY A COMPETENT SOIL AND/OR STRUCTURAL ENGINEER.	

PEDESTAL BASE 30022X8J, X8R

SCALE: 1" = 1' 0"

PELLERIN MILNOR CORPORATION  
P.O. Box 400 Kenner, LA 70063, USA, Phone 504/467-8591,  
FAX 504/468-1849, Email: milnorinfo@milnor.com