

Published Manual Number/ECN: MNTDVMSTAE/2001324N

- Publishing System: TPAS
- Access date: 08/08/2001
- Document ECN's: Latest Available



Technical Reference— Device Master



PELLERIN MILNOR CORPORATION POST OFFICE BOX 400, KENNER, LOUISIANA 70063-0400, U.S.A.

Please Read

About the Manual Identifying Information on the Cover

The front cover displays pertinent identifying information for this manual. Most important, are the published manual number (part number) /ECN (date code). Generally, when a replacement manual is furnished, it will have the same published manual number, but the latest available ECN. This provides the user with the latest information applicable to his machine. Similarly all documents comprising the manual will be the latest available as of the date the manual was printed, **even though older ECN dates for those documents may be listed in the table of contents.**

When communicating with the Milnor factory regarding this manual, please also provide the other identifying information shown on the cover, including the publishing system, access date, and whether the document ECN's are the latest available or exact.

References to Yellow Troubleshooting Pages

This manual may contain references to "yellow pages." Although the pages containing troubleshooting procedures are no longer printed on yellow paper, troubleshooting instructions, if any, will be contained in the easily located "Troubleshooting" chapter or section. See the table of contents.

Trademarks of Pellerin Milnor Corporation

The following, some of which may be used in this manual, are trademarks of Pellerin Milnor Corporation:


Ampsaver [®]	Dye-Extractor [®]	Gear Guardian [®]	Milnet [®]	Staph-Guard [®]
Autolint [®]	Dyextractor [®]	Hands-Off [®]	Milnor [®]	System 4 [®]
Auto-Purge [®]	E-P Express [®]	Hydro-Cushion [®]	Miltrac	System 7 [®]
Autovac	E-P OneTouch [®]	Mildata [®]	Miltron	Totaltrol [®]
CBW [®]	E-P Plus [®]			

Comments and Suggestions

Help us to improve this manual by sending your comments to:

Pellerin Milnor Corporation
Attn: Technical Publications
P. O. Box 400
Kenner, LA 70063-0400

Fax: (504) 469-1849



DEVICE MASTER start screen, the number that appears in the bottom right, hand corner is the software version number.

PROGRAMMING/INITIALIZE

PROGRAMMING/INITIALIZE

DEVICE MASTER MAIN MENU

INITIALIZE

CONFIGURE

DISPLAY PAGES

NAMES

EXIT

Time & Date
Clear memory
Display Checksum

DEVICE MASTER Initialization Menu

Time & Date:

To put in current time and date.

Clear Memory:

To clear the entire memory of the DEVICE MASTER. When configuring the DEVICE MASTER for the first time, the user must clear the memory.

Display Checksum:

To display the checksum of the current data which the DEVICE MASTER holds in its memory.

ENTER TIME 15:24
ENTER DATE 10/30/90

Enter the current time for the DEVICE MASTER in hh-mm format. (Hour-Min)

Enter the current date for the DEVICE MASTER in mm-dd-yy format. (Month-
Date-Year)

CLEAR MEMORY

WARNING !!

This menu selection will clear all the data in Device Master memory and then reload with the default values. It will also erase all the names.

Do you want to continue? (Y/N)

This screen is to confirm with the user before the DEVICE MASTER clears the memory.

CONFIGURE CHECKSUM 72F9

Display the total sum of all data currently held in memory.

PROGRAMMING/CONFIGURE

PROGRAMMING/CONFIGURE

DEVICE MASTER MAIN MENU

INITIALIZE

CONFIGURE

DISPLAY PAGES

NAMES

EXIT

General
Devices

DEVICE MASTER Configuration Menu

Configure: General: To configure the DEVICE MASTER.

Devices: To configure the devices controlled by the DEVICE MASTER.

DEVICE MASTER CONFIGURATION

General Configuration		Remote Displays	
MILTRAC ADDRESS	000	NUMBER OF REMOTE DISPLAYS	1
BYTES IN NETWORK STRING	30	PAGE FOR REMOTE #1	11
TOTAL NUMBER OF DEVICES	7	PAGE FOR REMOTE #2	00
ENABLE SIGNAL OPTION	1	PAGE FOR REMOTE #3	00
ENABLE FLAG OPTION	0	PAGE FOR REMOTE #4	00
SIGNAL BELT XFER STATUS	0		
RESET ON BELT LOAD ERROR	0		

Delay assignments for

filled data passing

FORMULA 0

TRY CODE 0

DESTINATION 0

CUSTOMER 0

GOODS CODE 0

TAKE NUMBER 0

This is the starting address for the first device on Device Master. All subsequent devices will add one to this number. Example: If the Device Master address is 003 and two devices are enabled, then Device 0 = 003, Device 1 = 004.

DEVICE MASTER General Configuration:

MILTRAC Address:

This is the starting address for the first belt on the DEVICE MASTER. All subsequent devices will add one to this number. Example: If the DEVICE MASTER address is 003 and two belts are enabled, the Belt 0 = 003, Belt 1 = 004.

Bytes In Network String:

Enter number of bytes for Network string (24 or 30 bytes).

Total Number Of Devices:

Enter total number of devices controlled by the DEVICE MASTER (1-8).

Enable Signal Option:

This board supplies 2 signals per device: Load waiting and Goods different from last. If the device desires to discharge and cannot, the Load waiting signal will be enabled. If Goods on the device are different than the previous batch, the Goods different from last signal would be enabled (0=NO 1=YES).

Enable Flag Option:

In general, this is a "Have been allowed to load signal". It can be used to drop a target if a movable device is loading it (0=NO 1=YES).

Signal Belt Xfer Status:

This option enables a board that provides a signal for each device to say "Finished discharging" (0=NO 1=YES).

Reset On Belt Load Error:

If desired, this option will allow the DEVICE MASTER to reset a loading error automatically (0=NO 1=YES).

Allied Data Relay Assignments:

(Total no more than 16 relays):

Formula	--->	Enter number of relays assigned for Formula to pass to allied device.
Dry Code	--->	Enter number of relays assigned for Dry code to pass to allied device.
Destination	--->	Enter number of relays assigned for Destination to pass to allied device.
Customer	--->	Enter number of relays assigned for Customer to pass to allied device.
Goods Code	--->	Enter number of relays assigned for Goods code to pass to allied device.
Cake Number	--->	Enter number of relays assigned for Cake number to pass to allied device.

Number Of Remote Displays:

Enter the number of remote monitors connected to the DEVICE MASTER. If your system has only the main monitor, the number is 0. DEVICE MASTER supports a maximum of 4 monitors.

Page For Remote #?:

Enter the page number to display on this monitor.

10 = Data page
11 = Status page
12 = Input page

DEVICE MENU	0 UNLOADER
	1 STORAGE
	2 NON STORG
	3 ALLIED DRY
	4 A.HAND LDR
	5 FEEDER
	6 SEQUENCING

This is a belt device menu which lists the name of all the devices which exist in the DEVICE MASTER and allows the user to select a particular device to configure.

CONFIGURE DEVICE

DEVICE #0

DEVICE TYPE

DRYER UNLOADER
STORAGE BELT
NON STORAGE BELT
ALLIED DRYER
ALLIED HAND LOADER
FEEDER BELT
SEQUENCING BELT

NAME UNLOADER

Discharge data

DISCHARGE TYPE

0

ALLIED DATA PASSING

0

DISCHARGE DIRECTION

0

WORK WITH SEQUENCING BELT

0

SEQUENCING ON TIME

000

Others

SEQUENCING OFF TIME

000

CLEAR BELT TIME

010

RUN TIME AFTER DISCHARGE

000

FLAG DOWN END

0

Loading data

LOADING LEVEL

0

LOADING DIRECTION

0

LOADING ON TIME

010

LOADING OFF TIME

010

NUMBER OF LOAD SEQUENCES

15

DELAY BEFORE RUN

000

Enter the name desired
for this device. Maximum
length of name is 10
characters.

CONFIGURE DEVICE

DEVICE #1

DEVICE TYPE

DRYER UNLOADER
STORAGE BELT
NON STORAGE BELT
ALLIED DRYER
ALLIED HAND LOADER
FEEDER BELT
SEQUENCING BELT

NAME STORAGE

Discharge data

DISCHARGE TYPE

0

ALLIED DATA PASSING

0

RUN TIME AFTER DISCHARGE

000

Others

CLEAR BELT TIME

010

FLAG DOWN END

0

Loading data

LOADING LEVEL

0

LOADING DIRECTION

0

LOADING ON TIME

005

LOADING OFF TIME

008

NUMBER OF LOAD SEQUENCES

10

DELAY BEFORE RUN

000

Enter the name desired
for this device. Maximum
length of name is 10
characters.

CONFIGURE DEVICE

DEVICE #2

DEVICE TYPE

DRYER UNLOADER
STORAGE BELT
NON STORAGE BELT
ALLIED DRYER
ALLIED HAND LOADER
FEEDER BELT
SEQUENCING BELT

NAME NON STORG

Discharge data

DISCHARGE TYPE

0

ALLIED DATA PASSING

0

DISCHARGE DIRECTION

0

WORK WITH SEQUENCING BELT

0

Others

SEQUENCING ON TIME

000

CLEAR BELT TIME

010

SEQUENCING OFF TIME

000

Loading data

LOADING LEVEL

0

LOADING DIRECTION

0

Enter the name desired
for this device. Maxia
unlength of name is 10
characters.

CONFIGURE DEVICE

DEVICE #3

DEVICE TYPE

DRYER UNLOADER
STORAGE BELT
NON STORAGE BELT
ALLIED DRYER
ALLIED HAND LOADER
FEEDER BELT
SEQUENCING BELT

NAME ALLIED DRY

Discharge data

DISCHARGE TYPE

0

ALLIED DATA PASSING

0

Others

NUMBER OF STORAGE POSITIONS 1

Loading data

LOADING TYPE

0

LOADING LEVEL

0

LOADING DIRECTION

0

Enter the name desired
for this device. Maxia
unlength of name is 10
characters.

CONFIGURE DEVICE

DEVICE #4

DEVICE TYPE

DRYER UNLOADER
STORAGE BELT
NON STORAGE BELT
ALLIED DRYER
ALLIED HAND LOADER
FEEDER BELT
SEQUENCING BELT

NAME A.HAND LDR:
Discharge data
DISCHARGE DIRECTION

0

Others

CLEAR BELT TIME 010

Loading data
LOADING LEVEL

0

Enter the name desired
for this device. Maximum
length of name is 10
characters.

CONFIGURE DEVICE

DEVICE #5

DEVICE TYPE

DRYER UNLOADER
STORAGE BELT
NON STORAGE BELT
ALLIED DRYER
ALLIED HAND LOADER
FEEDER BELT
SEQUENCING BELT

NAME FEEDER

Others

CLEAR BELT TIME 010

Enter the name desired
for this device. Maximum
length of name is 10
characters.

CONFIGURE DEVICE

DEVICE #6	DEVICE TYPE	DRYER UNLOADER STORAGE BELT NON STORAGE BELT ALLIED DRYER ALLIED HAND LOADER FEEDER BELT SEQUENCING BELT
NAME	SEQUENCING	
Others		
CLEAR BELT TIME	010	

Enter the name desired for this device. Maximum length of name is 10 characters.

Device Configuration:

Device Name:

Enter the name desired for this device.
Maximum length of name is 10 characters.

Discharge Type:

Enter how this device will discharge:
0 = to a MILTRAC device.
1 = to an Allied device.

Allied Data Passing:

Enter a 0 if NOT Allied data passing.
Otherwise, enter a 1.

Discharge Direction:

Enter a 0 for Forward, a 1 for Backward.

Run Time After Discharge:

If this time is set to zero, then the device will run "Clear Belt Time". If a time other than zero is entered, the Belt will decrement this time while the eye is clear. If the eye is blocked before the time is zeroed, the timer will be reset (0-255 secs).

Work With Sequencing Belt:

If this belt discharges in conjunction with a Sequencing belt in the system, enter a 1. Otherwise, enter a 0.

Sequencing On Time:

Enter the time desired to have this device running after the Sequencing eye is blocked (0-255 seconds).

Sequencing Off Time:

Enter the time desired to have this device stop after the Sequencing eye is cleared (0-255 seconds).

Loading Type:

Enter how this device will load:
0 = from a MILTRAC device.
1 = from an Allied device.

Loading Level:

Enter receive level for the device (0-7).

Loading Direction:

Enter a 0 for Forward, enter a 1 for Backward.

Loading On Time:

Enter the jog ON time (0-255 seconds).

Loading Off Time:

Enter the jog OFF time (0-255 seconds).

Number Of Load Sequences:

Enter number of jogging sequences desired. The belt can have a jogging sequence to space out the goods without bunching (0-255 seconds).

Delay Before Run:

Enter the desired delay time before running the device. This allows the goods to be bunched together (not spread out). This is useful when a belt is loading a shuttle (0-255 seconds).

Clear Belt Time:

This time should be set to completely clear the belt (0-255 seconds).

Number Of Storage Positions:

Enter the maximum number of storage positions for this device.

Flag Down End:

If FLAG DOWN OPTION is enabled, then specify which end it will drop the target:

0 = Load end.

1 = Discharge end.

PROGRAMMING/DATA PAGE

PROGRAMMING/DATA PAGE

DEVICE MASTER MAIN MENU

INITIALIZE

CONFIGURE

DISPLAY PAGES

NAMES

EXIT

Data page

This menu is to set up run time data display page.

DATA PAGE

Enter a 1 to display this data in each window on the page. You may display up to 7 items.

DATA TO DISPLAY	
FORMULA	1
DRYCODE	1
DESTINATION CODE	1
CUSTOMER	1
GOODS CODE	1
WEIGHT	1
CAKE NUMBER	1

DEVICE #0 UNLOADER	DEVICE #1 STORAGE	DEVICE #2 NON STORG	DEVICE #3 ALLIED DRY
DEVICE #4 A.HAND LDR	DEVICE #5 FEEDER	DEVICE #6 SEQUENCING	DEVICE #7

First, enter the type of data the user desires to display on the Data page at run time. The user can select up to 7 types of data to display in the Data page.

Secondly, enter the device number in the appropriate window which the user desires to display data in the Data page at run time.

PROGRAMMING/NAMES

PROGRAMMING/NAMES

DEVICE MASTER MAIN MENU

INITIALIZE

CONFIGURE

DISPLAY PAGES

NAMES

EXIT

Formulas
Dry codes
Dest codes
Customer codes
Goods codes
Erase names
Download names from Miltrac

Programming Name Menu

Formulas:

To program all formulas names.

Dry Codes:

To program all dry codes names.

Dest Codes:

To program all destinations names.

Customer Codes:

To program all customer codes names.

Goods Codes:

To program all goods codes names.

Erase Names:

To erase all the names currently used in the DEVICE MASTER..

Download Names From MILTRAC:

To copy the names programmed in MILTRAC.

FORMULA NAMES

00	01	02	03	04	05	06	07	08	09	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40	41	42	43	44	45	46	47	48	49	50	51	52	53	54	55	56	57	58	59	60	61	62	63
00	01	02	03	04	05	06	07	08	09	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40	41	42	43	44	45	46	47	48	49	50	51	52	53	54	55	56	57	58	59	60	61	62	63

This screen is to program all 64 formula names. Each formula name can have up to 8 characters.

DRYCODE NAMES	
00	???????
01	???????
02	???????
03	???????
04	???????
05	???????
06	???????
07	???????
08	???????
09	???????
10	???????
11	???????
12	???????
13	???????
14	???????
15	???????

This screen is to program all 16 dry code names. Each dry code name can have up to 8 characters.

DESTINATION NAMES					
00		22		44	
01		23		45	
02		24		46	
03		25		47	
04		26		48	
05		27		49	
06		28		50	
07		29		51	
08		30		52	
09		31		53	
10		32		54	
11		33		55	
12		34		56	
13		35		57	
14		36		58	
15		37		59	
16		38		60	
17		39		61	
18		40		62	
19		41		63	
20		42			
21		43			

This screen is to program all 64 destination names. Each destination name can have up to 8 characters.

SELECT CUSTOMER RANGE TO EDIT

000-063
064-127
128-191
192-255

This screen shows a sub menu which allows the user to select the range of Customer names which he wishes to program.

CUSTOMER NAMES		
00		
01		
02		
03		
04		
05		
06		
07		
08		
09		
10		
11		
12		
13		
14		
15		
16		
17		
18		
19		
20		
21		
22		
23		
24		
25		
26		
27		
28		
29		
30		
31		
32		
33		
34		
35		
36		
37		
38		
39		
40		
41		
42		
43		
44		
45		
46		
47		
48		
49		
50		
51		
52		
53		
54		
55		
56		
57		
58		
59		
60		
61		
62		
63		

This screen is to program Customer names 0 through 63. Each customer name can have up to 8 characters.

CUSTOMER NAMES

064	086	108
065	087	109
066	088	110
067	089	111
068	090	112
069	091	113
070	092	114
071	093	115
072	094	116
073	095	117
074	096	118
075	097	119
076	098	120
077	099	121
078	100	122
079	101	123
080	102	124
081	103	125
082	104	126
083	105	127
084	106	
085	107	

This screen is to program Customer names 64 through 127. Each customer name can have up to 8 characters.

CUSTOMER NAMES

128	*****	150	*****	172	*****
129	*****	151	*****	173	*****
130	*****	152	*****	174	*****
131	*****	153	*****	175	*****
132	*****	154	*****	176	*****
133	*****	155	*****	177	*****
134	*****	156	*****	178	*****
135	*****	157	*****	179	*****
136	*****	158	*****	180	*****
137	*****	159	*****	181	*****
138	*****	160	*****	182	*****
139	*****	161	*****	183	*****
140	*****	162	*****	184	*****
141	*****	163	*****	185	*****
142	*****	164	*****	186	*****
143	*****	165	*****	187	*****
144	*****	166	*****	188	*****
145	*****	167	*****	189	*****
146	*****	168	*****	190	*****
147	*****	169	*****	191	*****
148	*****	170	*****		
149	*****	171	*****		

This screen is to program Customer names 128 through 191. Each customer name can have up to 8 characters.

192	193	194	195	196	197	198	199	200	201	202	203	204	205	206	207	208	209	210	211	212	213
214	215	216	217	218	219	220	221	222	223	224	225	226	227	228	229	230	231	232	233	234	235
236	237	238	239	240	241	242	243	244	245	246	247	248	249	250	251	252	253	254	255		

This screen is to program Customer names 192 through 255. Each customer name can have up to 8 characters.

SELECT GOODS CODE RANGE TO EDIT

000-063
064-127
128-191
192-255

This screen shows a sub menu which allows the user to select the range of Goods code names which he wishes to program.

GOODS CODE NAMES

00	*****	22	*****	44	*****
01	*****	23	*****	45	*****
02	*****	24	*****	46	*****
03	*****	25	*****	47	*****
04	*****	26	*****	48	*****
05	*****	27	*****	49	*****
06	*****	28	*****	50	*****
07	*****	29	*****	51	*****
08	*****	30	*****	52	*****
09	*****	31	*****	53	*****
10	*****	32	*****	54	*****
11	*****	33	*****	55	*****
12	*****	34	*****	56	*****
13	*****	35	*****	57	*****
14	*****	36	*****	58	*****
15	*****	37	*****	59	*****
16	*****	38	*****	60	*****
17	*****	39	*****	61	*****
18	*****	40	*****	62	*****
19	*****	41	*****	63	*****
20	*****	42	*****		
21	*****	43	*****		

This screen is to program Goods code names 0 through 63. Each goods code name can have up to 8 characters.

GOODS CODE NAMES

064	086	108
065	087	109
066	088	110
067	089	111
068	090	112
069	091	113
070	092	114
071	093	115
072	094	116
073	095	117
074	096	118
075	097	119
076	098	120
077	099	121
078	100	122
079	101	123
080	102	124
081	103	125
082	104	126
083	105	127
084	106	
085	107	

This screen is to program Goods code names 64 through 127. Each goods code name can have up to 8 characters.

GOODS CODE NAMES

128	*****	150	*****	172	*****
129	*****	151	*****	173	*****
130	*****	152	*****	174	*****
131	*****	153	*****	175	*****
132	*****	154	*****	176	*****
133	*****	155	*****	177	*****
134	*****	156	*****	178	*****
135	*****	157	*****	179	*****
136	*****	158	*****	180	*****
137	*****	159	*****	181	*****
138	*****	160	*****	182	*****
139	*****	161	*****	183	*****
140	*****	162	*****	184	*****
141	*****	163	*****	185	*****
142	*****	164	*****	186	*****
143	*****	165	*****	187	*****
144	*****	166	*****	188	*****
145	*****	167	*****	189	*****
146	*****	168	*****	190	*****
147	*****	169	*****	191	*****
148	*****	170	*****		
149	*****	171	*****		

This screen is to program Goods code names 128 through 191. Each goods code name can have up to 8 characters.

GROUPS CODE NAMES		
192	*****	214 *****
193	*****	215 *****
194	*****	216 *****
195	*****	217 *****
196	*****	218 *****
197	*****	219 *****
198	*****	220 *****
199	*****	221 *****
200	*****	222 *****
201	*****	223 *****
202	*****	224 *****
203	*****	225 *****
204	*****	226 *****
205	*****	227 *****
206	*****	228 *****
207	*****	229 *****
208	*****	230 *****
209	*****	231 *****
210	*****	232 *****
211	*****	233 *****
212	*****	234 *****
213	*****	235 *****
		236 *****
		237 *****
		238 *****
		239 *****
		240 *****
		241 *****
		242 *****
		243 *****
		244 *****
		245 *****
		246 *****
		247 *****
		248 *****
		249 *****
		250 *****
		251 *****
		252 *****
		253 *****
		254 *****
		255 *****

ERASE NAMES

Devices	0
Formulas	0
Dry codes	0
Dest codes	0
Customer codes	0
Goods codes	0

Enter a 1 to erase these
names. Otherwise, enter
a 0.

This is the erase names screen. Enter a 1 for the names which the user wishes to erase. Otherwise, enter a 0.

DOWNLOAD NAMES FROM MILTRAC

This menu selection will allow
Device Master to receive the data
names downloaded from Miltrac. All
the data names in Device Master
will be overwritten.
Do you want to continue? (Y/N)

This screen is to confirm with the user before the DEVICE MASTER starts to download the names from MILTRAC.

DOWNLOAD NAMES FROM MILTRAC

This menu selection will allow
Device Master to receive the data
names downloaded from Miltrac. All
the data names in Device Master
will be overwritten.
Do you want to continue? (Y/N) Y

Downloading... 0000

This screen shows the memory locations where names are being downloaded from MILTRAC.

PROGRAMMING/EXIT

PROGRAMMING/EXIT

DEVICE MASTER MAIN MENU

INITIALIZE

CONFIGURE

DISPLAY PAGES

NAMES

EXIT

Exit

Exit Menu

Exit: To leave programming menu.

TURN PROGRAM KEY TO EXIT

**This screen instructs the user to turn the program key to run position so the
DEVICE MASTER can proceed the run mode.**

OPERATION/INITIALIZE

OPERATION/INITIALIZE

INITIALIZE 01234567
STATE 0110011

This screen appears when the DEVICE MASTER is in initialization mode. The number on the top line (0-7) shows the Device number. The numbers below it show the status of the device's run forward output (0 = OFF 1 = ON).

IS UNLOADER
LOADED? 0=NO 1=YES 1

FORMULA = 000
DRY CODE = 000
DESTINATION = 000
CUSTOMER CODE = 000
GOODS CODE = 000
WEIGHT = 000
CAKE NUMBER = 000

**This screen allows the user to enter the data after the DEVICE MASTER
initializes**

OPERATION/RUN PAGE

OPERATION/RUN PAGE

	0 - UNLOADER	1 - STORAGE	2 - NON STORG	3 - ALLIED DRY	
FORMULA	00 #####				DATA PAGE
DRY CODE	00 #####				
DESTINATION	00 #####				
CUSTOMER CODE	00 #####				
GOODS CODE	64 #####				
WEIGHT	00				DATE 10-30-1990
CAKE NUMBER	00				
	LOADED 00:08	EMPTY 00:08	EMPTY 00:09	EMPTY 00:09	
	4 - A.HAND LDR	5 - FEEDER	6 - SEQUENCING		
FORMULA		00 #####	00 #####		TIME 16:08:38
DRY CODE		00 #####	00 #####		
DESTINATION		00 #####	00 #####		
CUSTOMER CODE		00 #####	00 #####		
GOODS CODE		64 #####	64 #####		TOTAL DEVICES
WEIGHT		00	00		
CAKE NUMBER		00	00		7
	EMPTY 00:09	LOADED 00:09	LOADED 00:09		

CONTROL-B=MANUAL

RETURN=STATUS PAGE

This screen is the Data page at run time. The two left top and bottom windows show the meaning of the data. The remaining windows show the name and the data of the configured device. The bottom line shows the key instructions.

0 UNLOADER	1 STORAGE	2 NON STORG	3 ALLIED DRY	STATUS PAGE
RECEIVE STATUS =HOLDING COMMAND=DO NOTHING	RECEIVE STATUS =WAITING COMMAND=DO NOTHING	RECEIVE STATUS =HOLDING COMMAND=DO NOTHING	RECEIVE STATUS =HOLDING COMMAND=DO NOTHING	
DISCHARGE STATUS =WAITING COMMAND=DO NOTHING	DISCHARGE STATUS =HOLDING COMMAND=DO NOTHING	DISCHARGE STATUS =HOLDING COMMAND=DO NOTHING	DISCHARGE STATUS =HOLDING COMMAND=DO NOTHING	DATE 10-30
STATE = 4	STATE = 0	STATE = 0	STATE = 0	
4 A.HAND LDR	5 FEEDER	6 SEQUENCING		TIME 16:10
RECEIVE STATUS =HOLDING COMMAND=DO NOTHING	RECEIVE STATUS =WAITING COMMAND=DO NOTHING	RECEIVE STATUS =HOLDING COMMAND=DO NOTHING		
DISCHARGE STATUS =HOLDING COMMAND=DO NOTHING	DISCHARGE STATUS =HOLDING COMMAND=DO NOTHING	DISCHARGE STATUS =HOLDING COMMAND=DO NOTHING		TOTAL DEVICES
STATE = 0	STATE = 0	STATE = 0		7

CONTROL-B=MANUAL

RETURN=INPUTS PAGE

This screen is the Status page at run time. Each window shows the name, receive and transfer statuses of the DEVICE MASTER, receive and transfer commands from MILTRAC, receive and transfer levels. The bottom line shows the key instructions.

OPERATION/INPUTS

OPERATION/INPUTS

UNLOADER	1 STORAGE	2 NON STORG	3 ALLIED DRY	INPUTS PAGE
LOAD ALLOWED = +	LOAD ALLOWED = +	LOAD ALLOWED = -	LOAD ALLOWED = -	
DISCH ALLOWED = +	DISCH ALLOWED = +	DISCH ALLOWED = +	DISCH ALLOWED = -	
FORWARD EYE = +	FORWARD EYE = -		LOAD DESIRED = -	
BACKWARD EYE = -	BACKWARD EYE = -		DISCH DESIRED = -	
			LOAD DOOR OPEN = -	
			LOAD DOOR SHUT = -	
			DISCH DOOR OPEN = -	DATE
			DISCH DOOR SHUT = -	10-30
			MANUAL = -	
A. HAND LDR	5 FEEDER	6 SEQUENCING		TIME 16:11
DISCH ALLOWED = -	FORWARD EYE = -	LOAD ALLOWED = -		
FORWARD EYE = -	BACKWARD EYE = -	FORWARD EYE = -		
DASH CODE = 01		BACKWARD EYE = -		
DATA VALID = -		SEQUENCING EYE = -		
FEELT LOADED = -		AUTO MANUAL = -		TOTAL DEVICES
MANUAL = -				7

CONTROL-B=MANUAL

RETURN=DATA PAGE

-=NOT MADE

+ =MADE

This screen is the Input page. This page shows statuses of all the inputs of the DEVICE MASTER (- = Input is not made. + = Input is made). The bottom line shows the key instructions.

OPERATION/OUTPUTS

OPERATION/OUTPUTS

0 UNLOADER +=ON --OFF	1 STORAGE +=ON --OFF	2 NON STORG +=ON --OFF	3 ALLIED DRY +=ON --OFF	MANUAL PAGE
0=FORWARD - 1=BACKWARD -	0=FORWARD - 1=BACKWARD -	0=FORWARD - 1=BACKWARD -	0=ALLOW LOAD - 1=LOADED - 2=DRY CODE 00 3=PARTIAL LOAD - 4=ALLOW DISCH -	
6=LOAD WAITING 7=DIFFERENT	6=LOAD WAITING - 7=DIFFERENT -	6=LOAD WAITING - 7=DIFFERENT -	6=LOAD WAITING - 7=DIFFERENT -	DATE 10-30
4 A.HAND LDR +=ON --OFF	5 FEEDER +=ON --OFF	6 SEQUENCING +=ON --OFF		TIME 16:13
0=FORWARD - 1=BACKWARD - 2=DESIRE LOAD - 3=DISCH DONE - 4=TARGET -	0=FORWARD - 1=BACKWARD -	0=FORWARD - 1=BACKWARD -		
6=LOAD WAITING - 7=DIFFERENT -	6=LOAD WAITING - 7=DIFFERENT -	6=LOAD WAITING - 7=DIFFERENT -		TOTAL DEVICES 7

ESCAPE=EXIT DEVICE	>.<=SELECT DEVICE	0-9=ENABLE OUTPUTS
--------------------	-------------------	--------------------

ESCAPE=EXIT DEVICE),<=SELECT DEVICE 0-9=ENABLE OUTPUTS

This screen is the DEVICE MASTER Auto Manual screen. The Auto Manual mode in the DEVICE MASTER allows the user to enable and disable one individual output at a time. The bottom line shows the key instructions of how to exit or turn on an output.

Memory Download Box Applications

Document..... BICUDC01
Specified Date..... 20010807
As-of Date..... 20010807
Access Date..... 20010807

Applicability..... YUD CUD
Language Code..... ENG01

The memory download box is used to store configuration and formula data for most current models of Milnor® machines. Two types of download boxes (Figure 1) are available: one with a *Transmit* button on the front panel, and one without the button. The *Transmit* button is not required for machines—usually CBW® controllers and similar devices—which are capable of initiating the data transfer.

Figure 1: Download Box Identification





Figure 2: Rear View of Circuit Board



Supplement 1

Interpreting the DIP Switch Settings

Use the following codes and their definitions to set the DIP switch positions for the equipment, as shown in Table 1.

- A. All switch positions are OFF.
- B. Switch position 4 is ON; all other switch positions are OFF.
- C. Switch position 5 is ON; all other switch positions are OFF.
- D. Switch positions 1 and 5 are ON; all other switch positions are OFF.

Note 1: If necessary, a memory download box with the *Transmit* button may be used to store configuration and formula data from any machine that's capable of downloading. When using a button-equipped download box to store data from one of the devices listed in Table 1 as requiring the *Transmit* button, ignore the button. The download will begin when commanded from the device control panel.

Table 1: DIP Switch Positions

Processor Board	Software Version	DIP Switch Setting	Processor Board	Software Version	DIP Switch Setting
Uses Memory Download Box WITH Transmit Button			Uses Memory Download Box WITHOUT Transmit Button		
Washer-extractor Models			Milttron Controller for CBW System		
8088	All	C	8088	All	A
80186	98000-98003	C	80186	All	B
	98004-99004	not supported	Miltrac		
	99005-9900B	D	8088	All	A
	20000-20003	D	80186	All	B
FxW, FxP, and FxS Washer-extractor models			Milrail Rail Controller		
8088	All	C	8088	All	A
80186	98000-98003	C	80186	All	B
	98004-98009	not supported	Device Master		
	9800A-9800H	D	8085	All	not supported
	20000-2000B	D	8088	All	not supported
Textile and Dye Machine Models			80186	94000-94017	not supported
8088	All	C		94018	B
80186	95000-95305M	C		20000-present	B
	95305N-95306	D	Linear Costo Master		
80186	20000-20004	D	8085	All	not supported
	Dryer Models		8088	All	not supported
8088	All	C	80186	94000-94011	not supported
80186	All	C		20000-present	B
Centrifugal Extractor Models			Key: A All switch positions OFF B Position 4 ON; all others OFF C Position 5 ON; all others OFF D Positions 1 and 5 ON; all others OFF		
8088	All	C			
80186	All	C			
Single-station Press Models					
8088	All	C			

HOW TO CHANGE EPROMS IN MICROPROCESSORS AND WHERE TO CHECK THE DC VOLTAGES

Occasionally, software enhancements become available. Depending upon the software change, the new software EPROMs (Erasable, Programmable, Read-Only Memory) may be offered for sale or for no charge to the customer. When a set of EPROMs is changed in the field, ensure that the software version being installed matches the machine hardware and that EPROMs are installed in the proper socket positions and orientation.

How To Change EPROMs

⚠ WARNING ⚠



SHOCK HAZARD—Electrical components on the machine conduct high voltage that will kill or seriously injure you on contact.

☞ **Lock OFF** and tag out electrical power at the main (wall) disconnect before beginning this procedure.

1. Make sure all power to the machine is *off*.
2. Locate the EPROMs as described in “Location of EPROMs on Processor Board” in this section. Note the orientation of the EPROMs as shown in FIGURES 3, 5, 7, and 9.
3. Slip a small flat tool underneath the EPROM, and carefully remove each old EPROM from its base, taking note of their numerical order (see FIGURES 3 and 7) and orientation to the key notch on the socket.
4. Install new EPROMs, making sure the key notch on the EPROM is properly oriented and that all pins enter the proper holes in the socket (FIGURE 1). If necessary, slightly bend the pins on the EPROMs to align them in the socket. After inserting each EPROM, verify that all pins are seated in the socket.




FIGURE 1 (MSSM0217AE)
Properly Seating the EPROM

⚠ CAUTION ⚠



COMPONENT DAMAGE HAZARD—Incorrectly installing any EPROM may cause EPROM burn out, machine failure, or display error.

☞ **Match** each EPROM with its corresponding socket. Each EPROM will *work* in only one socket, although it may physically *fit* in others.

☞ **Align** EPROM so every pin mates with the correct hole in the socket.

Verifying Proper EPROM Installation—After installing new EPROMs, apply power to the machine and turn the machine *on*. If the EPROMs are properly installed, the display will continue with the normal display sequence when powering up. If the display is blank or appears unusual, turn the machine *off* at once and check the orientation of the EPROMs.

Location of EPROMs on Processor Board

Depending on machine model and type, the CPU chip can be an Intel 8085 or an Intel 8088. Each microprocessor board requires at least one EPROM for proper operation, but the EPROMs are located differently, depending upon the type of board. This information describes the location and arrangement of the EPROM chips on each type of board. It also describes where to check the voltages required by the processor board.

8085 Processor Boards, *NOT Coin Machine*—See FIGURE 3. Install EPROM #1 at the end of the row, then #2, #3, and #4. Chip #4 goes next to the two soldered chips on the board. See FIGURE 2 for where to check voltages.




FIGURE 2 (MSSM0217AE)
MTA-31 on 8085 Processor Board
(wires not shown for clarity)




FIGURE 3 (MSSM0217AE)
8085 Processor Board (NOT Coin Machine)

8085 Coin Machine Processor Boards—See FIGURE 5. Install the single EPROM in socket IC7 below connector W34. These boards have no battery.




FIGURE 4 (MSSM0217AE)
MTA-1 in 8085 Coin Machine
(wires not shown for clarity)




FIGURE 5 (MSSM0217AE)
8085 Coin Machine Processor Board

8088 Processor Boards Without Memory Expansion Board—See the table of EPROM locations (below) and FIGURE 7. If the set consists of only one EPROM, install it in socket A of FIGURE 7. If two EPROMs comprise the set, install EPROM #2 in socket A and EPROM #1 in socket B. **Always install highest numbered EPROM in socket A.** If the set consists of more than two EPROMs, a Memory Expansion Board must be present in the machine along with the processor board.

8088 Processor Boards With Memory Expansion Board—See the table of EPROM locations below and FIGURE 7. If the EPROM set consists of three or more EPROMs, install the two highest numbered EPROMs (e.g., EPROMs #3 and #4 of a four-chip set) *on the processor board*, with the highest numbered E-PROM (EPROM #4 of a four-chip set) in socket A, and the EPROM with the second highest number (EPROM #3 of a four-chip set) in socket B. *Install the remaining EPROM(s) on the Memory Expansion Board* with the highest numbered of the remaining EPROMs (e.g., EPROM #2 of a four-chip set) in socket IC-1 on the Memory Expansion Board and EPROM #1 in socket IC-2.

EPROM Locations on 8088 Processor Board and Memory Expansion Board				
EPROMS in Set	E-PROM Location by Socket (see FIGURE 4)			
	A	B	IC-1	IC-2
4-chip set	4	3	2	1
3-chip set	3	2	1	—
2-chip set	2	1	—	—
1-chip set	1	—	—	—




FIGURE 6 (MSSM0217AE)
1MTA-31 on 8088 Board (wires not shown for clarity)




FIGURE 7 (MSSM0217AE)
8088 Processor Board and Optional Memory Expansion Board

80186 Processor Boards—This processor board is used on all Milnor system controllers (Miltron, Mildata, etc.) equipped with a color monitor, and on textile processing machines with software versions 95000 and later. The single EPROM on this board is located in socket IC-2.




FIGURE 8 (MSSM0217AE)
1MTA-31 on 80186 Board (wires not shown for clarity)




FIGURE 9 (MSSM0217AE)
80186 Processor Board

NOTICE

As this manual was being printed, Pellerin Milnor Corporation began a manufacturing change which may affect how this manual applies to your machine. The six-position DIP switch on each printed circuit board is being replaced with two sixteen-position rotary switches. The switches (DIP and rotary) are used to set the logical address for each board that communicates with the microprocessor in the machine, or with a higher-level control system (e.g., a Mildata network).

Because the change to rotary switches corresponds so closely to the release of this manual, we are supplying you with documentation on how to set both types of switches.

If your machine uses printed circuit boards containing one DIP switch, refer to MSFDA401DE to set the address on replacement boards. If your machine uses printed circuit boards containing rotary switches, refer to MSFDA401EE.

THE HARDWARE IN SERIAL-TYPE MICROPROCESSORS

General

Milnor[®] serial microprocessor controls are designed specifically for Milnor[®] machines and systems. Along with certain external electromechanical relay logic and sensing devices, they control all machine and system functions. **Not every microprocessor includes all the components described in this section.**

The Microprocessor Components

This is a list of all components for Milnor[®] microprocessor controllers. Not every Milnor[®] microprocessor controller includes all the following components.

1. Keypad or Keyboard—Depending upon the model/type, the keypad may have 12, 30, or 58 buttons. The different keypads are not interchangeable.

2. Keyswitch—Selects run/program modes. The key may be removed only in *run*. **Never leave the key accessible to unauthorized personnel.**

3. Display—Depending upon the model/type, the display may be either liquid crystal, fluorescent, or CRT. The different displays are not interchangeable.

4a. Power Supply (NOT for CBW[®] System)—Converts control circuit AC voltage to +12VDC, -12VDC, and +5VDC for the CPU board. On dryers and some other machines, a second, identical power supply performs the same function for all the peripheral boards, which are mounted in an enclosure separate from the CPU.

A *minimum 14AWG ground wire* must be connected between the grounds on the CPU and the peripheral board(s). This ground is installed at the factory when both enclosures are mounted on the same machine, as in washer-extractors. The ground wire must be provided during installation when the CPU enclosure and its associated peripheral board enclosures are remote from one another as in dryers.

Although the +12VDC and -12VDC are not adjustable, the +5VDC for the CPU is very sensitive. The power supply must be adjusted most accurately, **so the actual voltage at the CPU board is between 4.95VDC and 5.1VDC as measured by an accurate digital voltmeter.**

4b. Power Supply (CBW[®] System Only)—The Milnor[®] CBW[®] System utilizes two discrete power supplies to convert control circuit AC voltage to +12 VDC, -12 VDC, and +5VDC for the CPU board and peripheral boards.

One power supply (ESPS) is a 40-watt power supply located in the Miltron cabinet. It powers the peripheral boards in the Miltron cabinet, including the optional load cell interface board and A/D board for a weighing conveyor, the CPU board and the memory expansion board, and the monitor interface board.

Although the +12VDC and -12VDC are not adjustable, the +5VDC for the CPU is very sensitive. The power supply must be adjusted accurately, **so the actual voltage at the CPU board is between 4.95VDC and 5.1VDC as measured by an accurate digital voltmeter.**

The second power supply (PSO) is a 120-watt power supply which provides +12VDC, -12VDC, and +5VDC to the peripheral boards located on the tunnel. This power supply provides for the adjustment of the +12VDC voltage, the -12VDC voltage, and the +5VDC voltage. If these voltages require adjustment, set the +5VDC to provide no less than +4.8VDC at the module electric box farthest from the power supply, as measured by an accurate digital voltmeter. If necessary, adjust the +12VDC to 12.00VDC and the -12VDC to -12.00VDC as measured by an accurate digital voltmeter.

G If the +5VDC at the peripheral board nearest PSO is at least +5.25VDC when the voltage at the peripheral board farthest from PSO is +4.8VDC or less, suspect loose MTA connections or inadequate wiring somewhere between the nearest and farthest peripheral boards.

5. CPU (Processor) Board—The Central Processing Unit (CPU) processes data received from the various inputs, stores information, and responds to each keypad entry with the appropriate action. It may be mounted in an enclosure separate from its peripheral boards. The CPU contains E-PROMs programmed by the Milnor[®] factory with fixed instructions (software) that determine how the machine functions. Depending upon machine model/type, the CPU chip can be either an Intel 8085 or an Intel 8088.

Although the E-PROMs do not require battery backup, the CPU board utilizes a battery which normally assures that the user-programmable memory will be retained for two to three months without external power. See below and “IMPORTANT OWNER/USER INFORMATION . . .” (see Table of Contents).

6. Memory Expansion Board—Increases memory space available to the processor. This board is used with 8088 CPU board in some applications.

D G 7. Battery—Provides memory retention backup when power is *off*. The battery is mounted directly on 8085 CPU boards, and mounted separately for 8088 CPU boards. A capacitor on the 8088 CPU board provides enough power to retain memory for several hours after the battery has been disconnected. Once fully charged (see “IMPORTANT OWNER/USER INFORMATION . . .”), the battery backup is reliable for 90 days with no power applied.

8. Opto-Isolator Board—Optically isolates inputs to the CPU for electronic noise immunity. Opto-Isolators are incorporated into the 8088 CPU board; thus this separate board is only required for 8085 CPUs.

9. I/O Board—16/8 input-output contains 16 solid-state signal input devices and eight output relays. The input devices are capable of faithfully conducting a low VA 12VDC ground signal to the CPU. The output relays are socket-mounted SPDT, 12VDC electromechanical relays with contacts capable of faithfully conducting a *maximum* of 25VA at 110/120VAC (0.2 ampere or 200 milliamperes at 110/120VAC) or 12.5 VA at 24VAC (0.5 ampere or 500 milliamperes at 24VAC). The output will be either 24VAC or 110/120VAC depending on the machine model/type.

These outputs and their power source are intended only to drive another relay with higher contact ratings, that in turn may drive a pump, valve, solenoid, etc., from a separate power source. **Never use these outputs to directly drive a pump, valve, or solenoid unless the maximum current required never exceeds the above values. Higher ampere or VA loads will burn out traces on the printed circuit board or possibly overload and damage the control circuit transformer.**

H **Standard I/O board**—Used in all devices requiring I/O boards except those listed below.
High-speed I/O board—Used only in the following devices and configurations: E6N, J6N, and T6N washer-extractors equipped and configured for **both variable basket speed and electronic balancing**; Milrail configured for high-speed boards; and all configurations of the M7E centrifugal extractor.

10. Output Board—A 16-output board contains 16 output relays, the same type as those described above.

D G 11. A/D Board (Analog to Digital Convertor)—Converts analog voltage signals, such as temperature, to a digital signal that can be utilized by the CPU. Up to a maximum of eight A/D channels may be provided on a single board. Although seemingly identical, the A/D boards used to sense air temperature in the dryer, water temperature in washer-extractors and dye machines, water temperature in the tunnel, and weight for a weighing conveyor are all different. **The different types are clearly marked with different part numbers, which are mentioned in the wiring diagram set and are not interchangeable.**

D 12. D/A Board (Digital to Analog Convertor)—Converts digital signals from the processor to an analog voltage between 0 and 5VDC (e.g., provides the analog signal to the dryer gas valve position actuator and dye machine steam position actuator).

13. CRT Board—Receives display instructions from the processor and generates the signals to the CRT to create the desired displays; used in controllers such as the Miltron and Miltrac controllers and Device Master systems.

⚠ CAUTION ⚠

The CRT board can be plugged in backwards, even though the cabinet/bracketry makes this difficult to do and labeling on the parent board states the proper orientation. Use care to orient the board properly, otherwise microprocessor components may burn out.

14. Resistor Boards—Although seemingly identical, resistor boards are quite different. **The different types are clearly marked with different part numbers, which are mentioned in the wiring diagram set and are not interchangeable.**

- a. **For Temperature-Sensing System**—Used with A/D board in washer-extractors and Dye-Extractors[®] as part of temperature-sensing system; not required on continuous batch washers because necessary circuitry is included on other (standard) CBW[®] printed circuit boards.
- b. **For Gas Valve**—Used with D/A board in temperature control circuit of gas dryers; converts 0-5VDC to 4-20 milliamperes for modulating gas valve.
- c. **For Steam Valve**—Used with D/A board in temperature control circuit of older steam dryer models; converts 0-5VDC to 4-20 milliamperes for modulating steam valve. See “4-20MA Output Board” in this section.

15. Signal Conditioner for Thermocouple—Amplifies the output from a thermocouple so an A/D board can use the signal.

16. Rotation Safety Board—Used in dryers. Reads rotational safety proximity switch to confirm that the basket is turning.

17. Temperature Probes—Two types of temperature probes are used, depending on equipment type:

Thermistor temperature probes—A temperature-sensitive resistor whose resistance changes with respect to temperature; uses include washer-extractors, textile machines, and continuous batch washers.

Thermocouple temperature probes—A connection of dissimilar metals which produces a voltage with respect to its temperature; uses include dryers.

18. Weigh Scale Interface Board—Regarding machine logic, this is located between the load cell of the weighing conveyor (CONWA) and the weighing conveyor A/D board. It interprets data from the conveyor load cell to the A/D board.

19. 4-20MA Output Board—Used on newer dye machines and steam dryers with temperature control. See “Resistor Boards/c. For Steam Valve” in this section.

The Serial Communications Port

All Milnor[®] serial microprocessors have a serial port with a nine-pin receptacle and plug to pass data to other devices via one of several special serial cables to *Download* or to *Print data* when their software supports these functions (e.g., see programming information). For more information on the various separate serial cables required for these functions, see external serial link cable information in this manual (see Table of Contents), if applicable.

Which Boards Are Used in Various Devices

Board Device	8088 CPU	I/O	OUTPUT	A/D	D/A	CRT	Opto- Isolator	Temp Sensing Resistor	Gas Valve Resistor	Steam Valve 4-20MA	Signal Condi- tioner	Rotation Safety	Weigh Scale Interface
COSHA	1	2 ¹	—	—	—	—	—	—	—	—	—	—	—
COBUC	1	2 ¹	— ¹	—	—	—	—	—	—	—	—	—	—
DEVICE MASTER	1	2 ¹	— ¹	—	—	1	—	—	—	—	—	—	—
DRYER	1	1 ¹	1	1 ⁴	1 ²	—	—	—	1 ²	— ²	1	1	—
DYE	1	2	2	1 ⁴	1	—	—	1	—	1	—	—	—
LINEAR COSTA	1	1 ¹	—	—	—	—	—	—	—	—	—	—	—
LINK MASTER	1	—	—	—	—	—	—	—	—	—	—	—	—
MILTRAC	1	—	—	—	—	1	—	—	—	—	—	—	—
PRESS	1	2 ¹	1 ¹	1	—	—	—	—	—	—	—	—	—
EXTRACTO R	1	1 ¹	1 ¹	—	—	—	—	—	—	—	—	—	—
VERTSTO	1	2	—	—	—	1	—	—	—	—	—	—	—
W/E (MARK I)	NOTE 7	1 ¹	1 ¹	1 ^{3,4}	— ¹	—	1	1	—	—	—	—	—
W/E (MARK II)	1	1 ¹	1 ¹	1 ^{3,4}	— ¹	—	—	1	—	—	—	—	—
CBW [®] System	1	2+1 per mod- ule	— ¹	1 per 8 ⁴ mod- ules 1,5,6	—	1	—	—	—	—	—	—	1 ⁵

- Boards can be added for options
- For gas dryers and steam dryers with temperature control
- For washer-extractors with temperature option
- Although seemingly identical, the A/D boards for sensing air temperature in dryers, water temperature in washer-extractors and dye machines, water temperature in tunnels and weight for weighing conveyors are all different. **The different types have different part numbers, are clearly marked, and are not interchangeable.**
- Required for CBW[®] system with weighing conveyor
- Required for Reuse/Cooldown and/or Overhead Fill tanks
- The Mark I washer-extractor control used an 8085 CPU

NOTE: Additional boards may be required for certain other options.

[illegible]

THE HARDWARE IN SERIAL-TYPE MICROPROCESSORS FOR MARK IV AND V MACHINES

General

Milnor[®] serial microprocessor controls are designed specifically for Milnor[®] machines and systems. Along with certain external electromechanical relay logic and sensing devices, they control all machine and system functions. **Not every microprocessor includes all the components described in this section.**

The Microprocessor Components

This is a list of all components for Milnor[®] microprocessor controllers. Not every Milnor[®] microprocessor controller includes all the following components.

1. Keypad or Keyboard—Depending upon the model/type, the keypad may have 12, 30, or 58 buttons. The different keypads are not interchangeable.

2. Keyswitch—Selects run/program modes. The key may be removed only in *run*. **Never leave the key accessible to unauthorized personnel.**

3. Display—Depending upon the model/type, the display may be either liquid crystal, fluorescent, or CRT. The different displays are not interchangeable.

4a. Power Supply (NOT for CBW[®] System)—Converts control circuit AC voltage to +12VDC, -12VDC, and +5VDC for the CPU board. On dryers and some other machines, a second, identical power supply performs the same function for all the peripheral boards, which are mounted in an enclosure separate from the CPU.

A minimum 14AWG ground wire must be connected between the grounds on the CPU and the peripheral board(s). This ground is installed at the factory when both enclosures are mounted on the same machine, as in washer-extractors. The ground wire must be provided during installation when the CPU enclosure and its associated peripheral board enclosures are remote from one another as in dryers.

Although the +12VDC and -12VDC are not adjustable, the +5VDC for the CPU is very sensitive. The power supply must be adjusted most accurately, **so the actual voltage at the CPU board is between 4.95VDC and 5.1VDC as measured by an accurate digital voltmeter.**

4b. Power Supply (CBW[®] System Only)—The Milnor[®] CBW[®] System utilizes two discrete power supplies to convert control circuit AC voltage to +12 VDC, -12 VDC, and +5VDC for the CPU board and peripheral boards.

One power supply (ESPS) is a 40-watt power supply located in the Miltron cabinet. It powers the peripheral boards in the Miltron cabinet, including the optional load cell interface board and A/D board for a weighing conveyor, the CPU board and the memory expansion board, and the monitor interface board.

Although the +12VDC and -12VDC are not adjustable, the +5VDC for the CPU is very sensitive. The power supply must be adjusted accurately, **so the actual voltage at the CPU board is between 4.95VDC and 5.1VDC as measured by an accurate digital voltmeter.**

The second power supply (PSO) is a 120-watt power supply which provides +12VDC, -12VDC, and +5VDC to the peripheral boards located on the tunnel. This power supply provides for the adjustment of the +12VDC voltage, the -12VDC voltage, and the +5VDC voltage. If these voltages require adjustment, set the +5VDC to provide no less than +4.8VDC at the module electric box farthest from the power supply, as measured by an accurate digital voltmeter. If necessary, adjust the +12VDC to 12.00VDC and the -12VDC to -12.00VDC as measured by an accurate digital voltmeter.

If the +5VDC at the peripheral board nearest PSO is at least +5.25VDC when the voltage at the peripheral board farthest from PSO is +4.8VDC or less, suspect loose MTA connections or inadequate wiring somewhere between the nearest and farthest peripheral boards.

5. CPU (Processor) Board—The Central Processing Unit (CPU) processes data received from the various inputs, stores information, and responds to each keypad entry with the appropriate action. It may be mounted in an enclosure separate from its peripheral boards. The CPU contains EPROMs programmed by the Milnor[®] factory with fixed instructions (software) that determine how the machine functions. Depending upon machine model/type, the CPU chip can be an Intel 8085, an Intel 8088, or an Intel 80186.

Although the EPROMs do not require battery backup, the CPU board utilizes a battery which normally assures that the user-programmable memory will be retained for two to three months without external power. See below and “IMPORTANT OWNER/USER INFORMATION . . .” (see Table of Contents).

6. Memory Expansion Board—Increases memory space available to the processor. This board is used with 8088 CPU board in some applications.

7. Battery—Provides memory retention backup when power is *off*. The battery is mounted directly on 8085 CPU boards, and mounted separately for 8088 and 80186 CPU boards. A capacitor on the 8088 and 80186 CPU board provides enough power to retain memory for several hours after the battery has been disconnected. Once fully charged (see “IMPORTANT OWNER/USER INFORMATION . . .”), the battery backup is reliable for 90 days with no power applied.

8. Opto-Isolator Board—Optically isolates inputs to the CPU for electronic noise immunity. Opto-Isolators are incorporated into the 8088 and 80186 CPU board; thus this separate board is only required for 8085 CPUs.

9. I/O Board—16/8 input-output contains 16 solid-state signal input devices and eight output relays. The input devices are capable of faithfully conducting a low VA 12VDC ground signal to the CPU. The output relays are socket-mounted SPDT, 12VDC electromechanical relays with contacts capable of faithfully conducting a *maximum* of 25VA at 110/120VAC (0.2 ampere or 200 milliamperes at 110/120VAC) or 12.5 VA at 24VAC (0.5 ampere or 500 milliamperes at 24VAC). The output will be either 24VAC or 110/120VAC depending on the machine model/type.

These outputs and their power source are intended only to drive another relay with higher contact ratings, that in turn may drive a pump, valve, solenoid, etc., from a separate power source. **Never use these outputs to directly drive a pump, valve, or solenoid unless the maximum current required never exceeds the above values. Higher ampere or VA loads will burn out traces on the printed circuit board or possibly overload and damage the control circuit transformer.**

This board has 25 status lights. One light blinks when the board is sending signals. Each of the 24 remaining lights represent an input (green lights) or output (red lights) on that board, and illuminates when the corresponding input or outputs is made. This board has two rotary dials which must be adjusted to set the board's address (see “Rotary Switches and How to Set Them” in this section). This board also has convenient test points that can be used to test voltage to the board.

Standard I/O board—Used in all devices requiring I/O boards except those listed below.

High-speed I/O board—Used only in the following devices and configurations: E6N, J6N, and T6N washer-extractors equipped and configured for **both variable basket speed and electronic balancing**; Milrail configured for high-speed boards; and all configurations of the M7E centrifugal extractor.

10. Output Board—A 24-output board contains 24 output relays, the same board and relays as described above.

11. A/D Board (Analog to Digital Converter)—Converts analog voltage signals, such as temperature, to a digital signal that can be utilized by the CPU. Up to a maximum of eight A/D channels may be provided on a single board. Although seemingly identical, the A/D boards used to sense air temperature in the dryer, water temperature in washer-extractors and textile machines, water temperature in the tunnel, and weight for a weighing conveyor are all different. **The different types are clearly marked with different part numbers, which are mentioned in the wiring diagram set and are not interchangeable.**

This board has one status light. This light blinks when the board is communicating. This board has two rotary dials which must be adjusted to set the board's address (see "Rotary Switches and How to Set Them"). This board also has convenient test points that can be used to test voltage to the board.

12. D/A Board (Digital to Analog Converter)—Converts digital signals from the processor to an analog voltage between 0 and 5VDC (e.g., provides the analog signal to the dryer gas valve position actuator and dye machine steam position actuator).

This board has one status light. This light blinks when the board is communicating. This board has two rotary dials which must be adjusted to set the board's address (see "Rotary Switches and How to Set Them"). This board also has convenient test points that can be used to test voltage to the board.

13. CRT Board—Receives display instructions from the processor and generates the signals to the CRT to create the desired displays; used in controllers such as the Miltron and Miltrac controllers and Device Master systems.

▲ CAUTION ▲

The CRT board can be plugged in backwards, even though the cabinet/bracketry makes this difficult to do and labeling on the parent board states the proper orientation. Use care to orient the board properly, otherwise microprocessor components may burn out.

14. Resistor Boards—Although seemingly identical, resistor boards are quite different. **The different types are clearly marked with different part numbers, which are mentioned in the wiring diagram set and are not interchangeable.**

- a. **For Temperature-Sensing System**—Used with A/D board in washer-extractors and Dye-Extractors[®] as part of temperature-sensing system; not required on continuous batch washers because necessary circuitry is included on other (standard) CBW[®] printed circuit boards.
- b. **For Gas Valve**—Used with D/A board in temperature control circuit of gas dryers; converts 0-5VDC to 4-20 milliamperes for modulating gas valve.
- c. **For Steam Valve**—Used with D/A board in temperature control circuit of older steam dryer models; converts 0-5VDC to 4-20 milliamperes for modulating steam valve. See "4-20MA Output Board" in this section.

15. Signal Conditioner for Thermocouple—Amplifies the output from a thermocouple so an A/D board can use the signal.

16. Rotation Safety Board—Used in dryers. Reads rotational safety proximity switch to confirm that the basket is turning.

17. Temperature Probes—Two types of temperature probes are used, depending on equipment type:

Thermistor temperature probes—A temperature-sensitive resistor whose resistance changes with respect to temperature; uses include washer-extractors, textile machines, and continuous batch washers.

Thermocouple temperature probes—A connection of dissimilar metals which produces a voltage with respect to its temperature; uses include dryers.

18. Weigh Scale Interface Board—Regarding machine logic, this is located between the load cell of the weighing conveyor (CONWA) and the weighing conveyor A/D board. It interprets data from the conveyor load cell to the A/D board.

19. 4-20MA Output Board—Used on newer textile machines and steam dryers with temperature control. See “Resistor Boards/c. For Steam Valve” in this section.

20. 8 Out/16 In Chemical Flow Meter Board—This board is used with the metered chemical injection option on textile machines. Eight outputs and eight counters are respectively assigned to chemical valves and chemical flow meters. Two of the counters are non-isolated direct inputs to the microprocessor *on this board* and are capable of counting pulses of 0 to 5 VDC at a frequency of up to 10kHz. the remaining six counters are optically isolated from the peripheral board microprocessor and are capable of counting pulses from 0 to 12 VDC at a frequency up to 150 Hz.

The Serial Communications Port

All Milnor[®] serial microprocessors have a serial port with a nine-pin receptacle and plug to pass data to other devices via one of several special serial cables to *Download* or to *Print data* when their software supports these functions (e.g., see programming information). For more information on the various separate serial cables required for these functions, see external serial link cable information in this manual (see Table of Contents), if applicable.

Which Boards Are Used in Various Devices

Board Device	CPU	I/O	Output	A/D	D/A	CRT	Opto- Isolator	Temp Sensing Resistor	Gas Valve Resistor	Steam Valve 4-20MA	Signal Condi- tioner	Chem Flow Meter	Rotation Safety	Weigh Scale Interfac e
COSHA	1	2 ¹	—	—	—	—	—	—	—	—	—	—	—	—
COBUC	1	2 ¹	— ¹	—	—	—	—	—	—	—	—	—	—	—
DEVICE MASTER*	1	2 ¹	— ¹	—	—	1	—	—	—	—	—	—	—	—
DRYER	1	2	1	1 ⁴	1 ²	—	—	—	1 ²	— ²	1	—	1	—
TEXTILE*	1	1	2	1 ⁴	1	—	—	1	—	1	—	0 ¹	—	—
LINEAR COSTA	1	1 ¹	—	—	—	—	—	—	—	—	—	—	—	—
LINK MASTER	1	—	—	—	—	—	—	—	—	—	—	—	—	—
MILTRAC*	1	—	—	—	—	1	—	—	—	—	—	—	—	—
PRESS	1	2 ¹	1 ¹	1	—	—	—	—	—	—	—	—	—	—
EXTRACTO R	1	2	1 ¹	—	—	—	—	—	—	—	—	—	—	—
VERTSTO	1	2	—	—	—	1	—	—	—	—	—	—	—	—
W/E (MARK I)	NOTE 7	1 ¹	1 ¹	1 ^{3,4}	— ¹	—	1	1	—	—	—	—	—	—
W/E (MARK II)	1	1 ¹	1 ¹	1 ^{3,4}	— ¹	—	—	1	—	—	—	—	—	—
CBW [®] System*	1	2+1 per mod- ule	— ¹	1 per 8 ⁴ mod- ules 1,5,6	—	1	—	—	—	—	—	—	—	1 ⁵

*80186 CPU

1. Boards can be added for options
2. For gas dryers and steam dryers with temperature control
3. For washer-extractors with temperature option
4. Although seemingly identical, the A/D boards for sensing air temperature in dryers, water temperature in washer-extractors and dye machines, water temperature in tunnels and weight for weighing conveyors are all different. **The different types have different part numbers, are clearly marked, and are not interchangeable.**
5. Required for CBW[®] system with weighing conveyor
6. Required for Reuse/Cooldown and/or Overhead Fill tanks
7. The Mark I washer-extractor control used an 8085 CPU

NOTE: Additional boards may be required for certain other options.

Rotary Switches and How To Set Them

The Input/Output board, the Output board, the A/D board, and the D/A board each have two rotary switches which establish the address for each board. This allows the boards to communicate serially with its own CPU, as though on a “party line,” while sending and receiving its own messages. In a battery of machines, the rotary switches are identical for each identical peripheral board in each identical machine (e.g., each first I/O board (I/O-1) in each washer-extractor has the identical rotary switch setting). When a CPU must communicate with a higher level control (e.g., when all dryers communicate with the Milnet[®] system), the higher level control must know the address of each CPU. For 8088 CPUs, the high level control knows the address of each CPU because that information was established during configuration (e.g., see Miltrac Address configure decision in the programming manual for any device that communicates with Miltrac).

Rotary Switch Settings

[illegible]