



Published Manual Number/ECN: MNTVTSTOAE/2000304N

- **Publishing System: TPAS**
- **Access date: 07/19/2000**
- **Document ECN's: Latest Available**

Technical Reference— VERTSTO

Please Read

About the Manual Identifying Information on the Cover

The front cover displays pertinent identifying information for this manual. Most important, are the published manual number (part number) /ECN (date code). Generally, when a replacement manual is furnished, it will have the same published manual number, but the latest available ECN. This provides the user with the latest information applicable to his machine. Similarly all documents comprising the manual will be the latest available as of the date the manual was printed, **even though older ECN dates for those documents may be listed in the table of contents.**

When communicating with the Milnor factory regarding this manual, please also provide the other identifying information shown on the cover, including the publishing system, access date, and whether the document ECN's are the latest available or exact.

References to Yellow Troubleshooting Pages

This manual may contain references to "yellow pages." Although the pages containing troubleshooting procedures are no longer printed on yellow paper, troubleshooting instructions, if any, will be contained in the easily located "Troubleshooting" chapter or section. See the table of contents.

Trademarks of Pellerin Milnor Corporation

The following, some of which may be used in this manual, are trademarks of Pellerin Milnor Corporation:

Ampsaver [®]	CBW [®]	Gear Guardian [®]	Milnet [®]	Staph-Guard [®]
Autolint [®]	Dye-Extractor [®]	Hands-Off [®]	Milnor [®]	System 4 [®]
Auto-Purge [®]	Dyextractor [®]	Hydro-Cushion [®]	Miltrac	System 7 [®]
Autovac	E-P Plus [®]	Mildata [®]	Miltron	Totaltrol [®]

Comments and Suggestions

Help us to improve this manual by sending your comments to:

Pellerin Milnor Corporation
Attn: Technical Publications
P. O. Box 400
Kenner, LA 70063-0400

Fax: (504) 469-1849

PROGRAMMING/INITIALIZE

MAIN MENU/INITIALIZE

VERTSTO MAIN MENU

INITIALIZE

CONFIGURE

DISPLAY PAGES

NAMES

EXIT

Time & Date
Clear memory
Display Checksum

VERTSTC Initialization Menu

- Time & Date: To put in current time and date.
- Clear Memory: To clear the entire memory of the VERTSTO. When configuring the VERTSTO for the first time, the user must clear the memory.
- Display Checksum: To display the checksum of the current data which the VERTSTO holds.

ENTER TIME 14:42
ENTER DATE 10/30/90

Enter the current time for the VERTSTO in hh-mm format. (Hour-Min)

Enter the current date for the VERTSTO in mm-dd-yy format. (Month-Date-Year)

CLEAR MEMORY

WARNING !!

This menu selection will clear all the data in the Vertsto memory and then reload with the default values. It will also erase all the names.

Do you want to continue? (Y/N)

This screen is to confirm with the user before the VERTSTO clears the memory.

CONFIGURE CHECKSUM F5C0

Display the total sum of all data currently held in memory.

PROGRAMMING/CONFIGURE

MAIN MENU/CONFIGURE

VERTSTO MAIN MENU

INITIALIZE

CONFIGURE

DISPLAY PAGES

NAMES

EXIT

Configure Vertsto
Name belts
Name positions

VERTSTC Configuration Menu

Configure VERTSTO: To configure the VERTSTO.

Name Belts: To name all the belts of the VERTSTO.

Name Positions: To name all the storage positions of the belts on the VERTSTO.

VERTSTO CONFIGURATION			
General Configuration		Remote Displays	
MILTRAC ADDRESS	000	NUMBER OF REMOTE DISPLAYS	1
BYTES IN NETWORK STRING	30	PAGE FOR REMOTE #1	11
MILDATA ADDRESS	001	PAGE FOR REMOTE #2	00
TOTAL NUMBER OF BELTS	5	PAGE FOR REMOTE #3	00
ELEVATOR INSTALLED	1	PAGE FOR REMOTE #4	00
HOW MANY DISCHARGE LEVELS	1		
TIME TO REACH BOTTOM-TOP	50		
WEIGHT UNITS (0=LBS 1=KGS)	0		
PERIPHERAL BOARDS CHECK	1		
Belt configuration		<div style="border: 1px solid black; padding: 5px;"> MILTRAC ADDRESS <hr/> <p>This is the starting address for the first belt on the Vertsto. All subsequent belts will add one to this number. Example: If the Vertsto address is 003 and two belts are enabled, then Belt 0 = 003, Belt 1 = 004.</p> </div>	
CLEAR BELT TIME	10		
TRAILING TIME	10		
NUMBER OF CAKES PER BELTS	2		
OPTIMUM NUMBER OF CAKES	2		
OPTIMUM DISCH WAIT TIME	00		
Valid Data			
FORMULA	1 GOODS CODE	1	
DRYCODE	1 WEIGHT	1	
DESTINATION	1 CAKE NUMBER	1	
CUSTOMER	1		

VERTSTO Configuration:

MILTRAC Address:

This is the starting address for the first belt on the VERTSTO. All subsequent belts will add one to this number. Example: If the VERTSTO address is 003 and two belts are enabled, then Belt 0 = 003, Belt 1 = 004.

Bytes In Network String:

Enter number of bytes for Network string (24 or 30 bytes).

MILDATA Address:

Enter the address you wish to assign to the VERTSTO for the MILDATA network (0-255).

Total Number of Belts: Enter total number of belts controlled by VERTSTO (1-8).

Elevator Installed: Enter a 0 if the VERTSTO can NOT elevate. Otherwise, enter a 1.

How Many Discharge Levels: Enter number of different levels which the VERTSTO will discharge the cakes (1-4).
Example: If the VERTSTO discharges to 2 LCOSTAS which have different heights, then number of discharge levels is 2.

Time To Reach Bottom-Top: Enter the time (in seconds) it takes for the VERTSTO to move from the bottom to the top (5-75).

Weight Units (0=lbs 1=kgs): Enter the number (0 or 1) for the unit of measure appropriate to your country.

Peripheral Test: Enter a 0 if peripheral boards check is NOT desired. Otherwise, enter a 1.

Clear Belt Time: This time should be set to completely clear the belt (5-25 seconds).

Number Of Cakes Per Belts: Enter number of storages on each belt (1-8).

Trailing Time: Enter the time (in 10th sec) desired to stop the belt after the cake passes the load eye when loading (0-99).

Optimum Number Of Cakes: Enter the optimum number of cakes for the belt to discharge (1-Number of cakes per belt).

Optimum Disch Wait Time: Enter the time (in minutes) desired to discharge the cake(s) on the belt if optimum number of cakes is not met (0-99).

Valid Data: Enter a 0 if this type of data is not being passed in your system. Enter a 1 otherwise. This decision tells VERTSTO what data is actually valid in your system such that false data is not displayed.

Number of Remote Displays: Enter the number of remote monitors connected to VERTSTO. If your system has only the main monitor, the number is 0. VERTSTO supports a maximum of 4 remote monitors.

Page For Remote #?: Enter the page number to display on the appropriate monitor.
0 - 9 = Cake Pages 0 - 9
10 = Main Page
11 = State Page
12 = Monitor inputs
13 = Monitor outputs

NAME BELTS		
BELT #	NAME	BORDER COLOR
0	BELT 0	03
1	BELT 1	04
2	BELT 2	05
3	BELT 3	06
4	BELT 4	07

BELT NAME

Enter a name for the belt. The name can be up to 10 characters long.

Enter belt names and belt border colors.

Belt Name: Enter a name for the belt. The name can be up to 10 characters long.

Border Color: Enter color for device border lines:

01=Blue	02=Green	03=Cyan
04=Red	05=Magenta	06=Brown
07=Lt grey	08=Dark grey	09=Lt blue
10=Lt green	11=Lt cyan	12=Lt red
13=Lt magenta	14=Yellow	15=White

BELT MENU	0 BELT 0
	1 BELT 1
	2 BELT 2
	3 BELT 3
	4 BELT 4

This is a belt sub menu which lists the name of all the belts which exist in the VERTSTO and allows the user to select a particular belt to program its position names.

NAME POSITIONS

BELT #0 NAME: BELT 0

Position	Position name	Short name
0	BELT 0-0	B0-0
1	BELT 0-1	B0-1

POSITION NAME

Enter a name for the position. The name can be up to 8 characters long.

Enter the position names and position short names for the belt.

Position Name: Enter a name for the position. The name can be up to 8 characters long.

Position Short Name: Enter a SHORT name for the position. The name can be up to 4 characters long.

PROGRAMMING/DISPLAY PAGES

MAIN MENU/DISPLAY PAGES

VERTSTO MAIN MENU

INITIALIZE

CONFIGURE

DISPLAY PAGES

NAMES

EXIT

Main page
Cake pages

Set Up Run Time Display Menu

Main Page: To set up run time Main page display.

Cake Page: To set up run time Cake data page display.

CONFIGURE
MAIN PAGE

Enter 1 to display this
data in each window on the
page. You may display up to
2 items

DATA TO DISPLAY	
FORMULA	1
DRYCODE	1
DESTINATION	0
CUSTOMER	0
GOODS CODE	0
WEIGHT	0
CAKE NUMBER	0

Enter the type of data the user desires to display on the Main page at run time.
The user can select up to 2 types of data to display in the Main page.

CONFIGURE MAIN PAGE D = BELT NUMBER P = POSITION NUMBER
ENTER 5 TO CLEAR WINDOW

B 5 P 0	B 5 P 0	B 5 P 0	B 5 P 0	B 5 P 0	B 5 P 0	B 5 P 0	B 5 P 0	B 5 P 0	B 5 P 0	B 5 P 0	B 5 P 0
------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------

B 0 P 0 B0-0	B 1 P 0 B1-0	B 2 P 0 B2-0	B 3 P 1 B3-1	B 4 P 0 B4-0	B 5 P 0	B 5 P 0	B 5 P 0	B 5 P 0	B 5 P 0	B 5 P 0	B 5 P 0
--------------------	--------------------	--------------------	--------------------	--------------------	------------	------------	------------	------------	------------	------------	------------

B 0 P 1 B0-1	B 1 P 1 B1-1	B 2 P 1 B2-1	B 3 P 0 B3-0	B 4 P 1 B4-1	B 5 P 0	B 5 P 0	B 5 P 0	B 5 P 0	B 5 P 0	B 5 P 0	B 5 P 0
--------------------	--------------------	--------------------	--------------------	--------------------	------------	------------	------------	------------	------------	------------	------------

B 5 P 0	B 5 P 0	B 5 P 0	B 5 P 0	B 5 P 0	B 5 P 0	B 5 P 0	B 5 P 0	B 5 P 0	B 5 P 0
------------	------------	------------	------------	------------	------------	------------	------------	------------	------------

Enter the belt and position number in the appropriate window which the user desires to display data in the Main page at run time.

SELECT PAGE TO CONFIGURE

PAGE 0
PAGE 1
PAGE 2
PAGE 3
PAGE 4
PAGE 5
PAGE 6
PAGE 7
PAGE 8
PAGE 9

This is a cake page sub menu which allows the user to select 1 out of 10 cake pages to set up the cake page run time display.

PAGE 0

Enter a 1 to display this
data in each window on the
page. You may display up to
5 items.

DATA TO DISPLAY	
FORMULA	1
DRYCODE	1
DESTINATION	1
CUSTOMER	1
GOODS CODE	0
WEIGHT	1
CAKE NUMBER	0

WINDOW #00	WINDOW #01	WINDOW #02	WINDOW #03	WINDOW #04	WINDOW #05
BELT #0	BELT #0	BELT #1	BELT #1	BELT #2	BELT #2
POSITION #0	POSITION #1	POSITION #0	POSITION #1	POSITION #0	POSITION #1
BELT 0-0	BELT 0-1	BELT 1-0	BELT 1-1	BELT 2-0	BELT 2-1
WINDOW #06	WINDOW #07	WINDOW #08	WINDOW #09	WINDOW #10	WINDOW #11
BELT #3	BELT #3	BELT #4	BELT #4	BELT #5	BELT #5
POSITION #0	POSITION #1	POSITION #0	POSITION #1	POSITION #0	POSITION #0
BELT 3-0	BELT 3-1	BELT 4-0	BELT 4-1		
WINDOW #12	WINDOW #13	WINDOW #14	WINDOW #15	WINDOW #16	WINDOW #17
BELT #5	BELT #5	BELT #5	BELT #5	BELT #5	BELT #5
POSITION #0	POSITION #0	POSITION #0	POSITION #0	POSITION #0	POSITION #0

First, enter the type of data the user desires to display on the Cake page at run time. The user can select up to 5 types of data to display in the Cake page.

Secondly, enter the belt and position number in the appropriate window which the user desires to display data in the Cake page at run time.

PROGRAMMING/NAMES

MAIN MENU/NAMES

VERTSTO MAIN MENU

INITIALIZE

CONFIGURE

DISPLAY PAGES

NAMES

EXIT

Formulas
Dry codes
Dest codes
Customer codes
Goods codes
Erase names
Download names from Miltrac

Programming Name Menu

Formulas:	To program all formulas names.
Dry Codes:	To program all dry codes names.
Dest Codes:	To program all destination names.
Customer Codes:	To program all customer code names.
Goods Codes:	To program all goods codes names.
Erase Names:	To erase all the names currently used in the VERTSTO.
Download Names From MILTRAC:	To copy the names programmed in MILTRAC.

FORMULA NAMES

00 FORM 00	22	44
01 FORM 01	23	45
02	24	46
03	25	47
04	26	48
05	27	49
06	28	50
07	29	51
08	30	52
09	31	53
10	32	54
11	33	55
12	34	56
13	35	57
14	36	58
15	37	59
16	38	60
17	39	61
18	40	62
19	41	63
20	42	
21	43	

This screen is to program all 64 formula names. Each formula name can have up to 8 characters.

DRYCODE NAMES	
00	DRY 00
01	DRY 01**
02	*****
03	*****
04	*****
05	*****
06	*****
07	*****
08	*****
09	*****
10	*****
11	*****
12	*****
13	*****
14	*****
15	*****

This screen is to program all 16 dry code names. Each dry code name can have up to 8 characters.

DESTINATION NAMES

00 DEST 00	22	44
01 DEST 01	23	45
02	24	46
03	25	47
04	26	48
05	27	49
06	28	50
07	29	51
08	30	52
09	31	53
10	32	54
11	33	55
12	34	56
13	35	57
14	36	58
15	37	59
16	38	60
17	39	61
18	40	62
19	41	63
20	42	
21	43	

This screen is to program all 64 destination names. Each destination name can have up to 8 characters.

SELECT CUSTOMER RANGE TO EDIT

000-063
064-127
128-191
192-255

This screen shows a sub menu which allows the user to select the range of Customer names which he wishes to program.

CUSTOMER NAMES

00 CUST 00	22	44
01 CUST 01	23	45
02	24	46
03	25	47
04	26	48
05	27	49
06	28	50
07	29	51
08	30	52
09	31	53
10	32	54
11	33	55
12	34	56
13	35	57
14	36	58
15	37	59
16	38	60
17	39	61
18	40	62
19	41	63
20	42	
21	43	

This screen is to program Customer names 0 through 63. Each customer name can have up to 8 characters

CUSTOMER NAMES

064	086	108
065	087	109
066	088	110
067	089	111
068	090	112
069	091	113
070	092	114
071	093	115
072	094	116
073	095	117
074	096	118
075	097	119
076	098	120
077	099	121
078	100	122
079	101	123
080	102	124
081	103	125
082	104	126
083	105	127
084	106	
085	107	

This screen is to program Customer names 64 through 127. Each customer name can have up to 8 characters.

CUSTOMER NAMES

128	*****	150	*****	172	*****
129	*****	151	*****	173	*****
130	*****	152	*****	174	*****
131	*****	153	*****	175	*****
132	*****	154	*****	176	*****
133	*****	155	*****	177	*****
134	*****	156	*****	178	*****
135	*****	157	*****	179	*****
136	*****	158	*****	180	*****
137	*****	159	*****	181	*****
138	*****	160	*****	182	*****
139	*****	161	*****	183	*****
140	*****	162	*****	184	*****
141	*****	163	*****	185	*****
142	*****	164	*****	186	*****
143	*****	165	*****	187	*****
144	*****	166	*****	188	*****
145	*****	167	*****	189	*****
146	*****	168	*****	190	*****
147	*****	169	*****	191	*****
148	*****	170	*****		
149	*****	171	*****		

This screen is to program Customer names 128 through 191. Each customer name can have up to 8 characters.

CUSTOMER NAMES

192	*****	214	*****	236	*****
193	*****	215	*****	237	*****
194	*****	216	*****	238	*****
195	*****	217	*****	239	*****
196	*****	218	*****	240	*****
197	*****	219	*****	241	*****
198	*****	220	*****	242	*****
199	*****	221	*****	243	*****
200	*****	222	*****	244	*****
201	*****	223	*****	245	*****
202	*****	224	*****	246	*****
203	*****	225	*****	247	*****
204	*****	226	*****	248	*****
205	*****	227	*****	249	*****
206	*****	228	*****	250	*****
207	*****	229	*****	251	*****
208	*****	230	*****	252	*****
209	*****	231	*****	253	*****
210	*****	232	*****	254	*****
211	*****	233	*****	255	*****
212	*****	234	*****		
213	*****	235	*****		

This screen is to program Customer names 192 through 255. Each customer name can have up to 8 characters.

SELECT GOODS CODE RANGE TO EDIT

000-063
064-127
128-191
192-255

This screen shows a sub menu which allows the user to select the range of Goods code names which he wishes to program.

GOODS CODE NAMES

00 3000 00	22 ???????	44 ???????
01 3000 01	23 ???????	45 ???????
02 ???????	24 ???????	46 ???????
03 ???????	25 ???????	47 ???????
04 ???????	26 ???????	48 ???????
05 ???????	27 ???????	49 ???????
06 ???????	28 ???????	50 ???????
07 ???????	29 ???????	51 ???????
08 ???????	30 ???????	52 ???????
09 ???????	31 ???????	53 ???????
10 ???????	32 ???????	54 ???????
11 ???????	33 ???????	55 ???????
12 ???????	34 ???????	56 ???????
13 ???????	35 ???????	57 ???????
14 ???????	36 ???????	58 ???????
15 ???????	37 ???????	59 ???????
16 ???????	38 ???????	60 ???????
17 ???????	39 ???????	61 ???????
18 ???????	40 ???????	62 ???????
19 ???????	41 ???????	63 ???????
20 ???????	42 ???????	
21 ???????	43 ???????	

This screen is to program Goods code names 0 through 63. Each goods code name can have up to 8 characters.

GOODS CODE NAMES

064	086	108
065	087	109
066	088	110
067	089	111
068	090	112
069	091	113
070	092	114
071	093	115
072	094	116
073	095	117
074	096	118
075	097	119
076	098	120
077	099	121
078	100	122
079	101	123
080	102	124
081	103	125
082	104	126
083	105	127
084	106	
085	107	

This screen is to program Goods code names 64 through 127. Each goods code name can have up to 8 characters.

GOODS CODE NAMES

128	*****	150	*****	172	*****
129	*****	151	*****	173	*****
130	*****	152	*****	174	*****
131	*****	153	*****	175	*****
132	*****	154	*****	176	*****
133	*****	155	*****	177	*****
134	*****	156	*****	178	*****
135	*****	157	*****	179	*****
136	*****	158	*****	180	*****
137	*****	159	*****	181	*****
138	*****	160	*****	182	*****
139	*****	161	*****	183	*****
140	*****	162	*****	184	*****
141	*****	163	*****	185	*****
142	*****	164	*****	186	*****
143	*****	165	*****	187	*****
144	*****	166	*****	188	*****
145	*****	167	*****	189	*****
146	*****	168	*****	190	*****
147	*****	169	*****	191	*****
148	*****	170	*****		
149	*****	171	*****		

This screen is to program Goods code names 128 through 191. Each goods code name can have up to 8 characters.

GOODS CODE NAMES

192	*****	214	*****	236	*****
193	*****	215	*****	237	*****
194	*****	216	*****	238	*****
195	*****	217	*****	239	*****
196	*****	218	*****	240	*****
197	*****	219	*****	241	*****
198	*****	220	*****	242	*****
199	*****	221	*****	243	*****
200	*****	222	*****	244	*****
201	*****	223	*****	245	*****
202	*****	224	*****	246	*****
203	*****	225	*****	247	*****
204	*****	226	*****	248	*****
205	*****	227	*****	249	*****
206	*****	228	*****	250	*****
207	*****	229	*****	251	*****
208	*****	230	*****	252	*****
209	*****	231	*****	253	*****
210	*****	232	*****	254	*****
211	*****	233	*****	255	*****
212	*****	234	*****		
213	*****	235	*****		

This screen is to program Goods code names 192 through 255. Each goods code name can have up to 8 characters.

ERASE NAMES

Belts	0
Positions	0
Position Short Names	0
Formulas	0
Dry codes	0
Dest codes	0
Customer codes	0
Goods codes	0

Enter a 1 to erase these
names. Otherwise, enter
a 0.

This is the erase names screen. Enter a 1 for the names which the user wishes to erase. Otherwise, enter a 0.

DOWNLOADED NAMES FROM MILTRAC

This menu selection will allow
the Vertsto to receive the data
names downloaded from Miltrac. All
the data names in the Versto will
be overwritten.
Do you want to continue? (Y/N)

This screen is to confirm with the user before the VERTSTO starts to download the names from MILTRAC.

DOWNLOAD NAMES FROM MILTRAC

This menu selection will allow
the Versto to receive the data
names downloaded from Miltrac. All
the data names in the Versto will
be overwritten.

Do you want to continue? (Y/N) Y

Downloading... 0000

This screen shows the memory locations where names are being downloaded from MILTRAC.

PROGRAMMING/EXIT

MAIN MENU/EXIT

VERTSTO MAIN MENU

INITIALIZE

CONFIGURE

DISPLAY PAGES

NAMES

EXIT

Exit

Exit Menu

Exit: To leave programming menu.

OPERATION/INITIALIZE

VERTSTO BARE MANUAL

TO RETURN TO AUTOMATIC, TURN ON AUTO SWITCH THEN PRESS RETURN

This screen is to inform the user that the VERTSTO is in Bare manual mode:
(Contact Auto is not made).

POWER UP TEST	
STEP 1	Moving up
STEP 2	Taut chain
STEP 3	Moving down

INITIALIZE BELTS			
	REARWARD	LOAD EYE	FORWARD
Belt 0	ON	-	OFF
Belt 1	ON	-	OFF
Belt 2	ON	-	OFF
Belt 3	ON	-	OFF
Belt 4	ON	-	OFF
Belt 5	NOT APPLIED		
Belt 6	NOT APPLIED		
Belt 7	NOT APPLIED		

This screen appears when you power up the VERTSTO. The small window shows the actions being taken to test the Taut chain and Slack contacts of the VERTSTO. The larger window shows the actions being taken to initialize all the belts on the VERTSTO (ON =Output is enable. OFF = Output is disabled. - = Input is not made. + = Input is made).

INITIALIZE BELTS			
	REARWARD	LOAD EYE	FORWARD
Belt 0	OFF	-	OFF
Belt 1	OFF	+	ON
Belt 2	OFF	-	OFF
Belt 3	OFF	+	ON
Belt 4	OFF	-	OFF
Belt 5	NOT APPLIED		
Belt 6	NOT APPLIED		
Belt 7	NOT APPLIED		

This screen appears when the VERTSTO initializes its belts (ON =Output is enabled. OFF =Output is disabled. - = Input is not made. + = Input is made).

DATA ENTRY	
DOES BELT	#1 - BELT 1
POSITION #0	HAVE A CAKE (Y/N) ? Y
ENTER DATA FOR THIS CAKE	
FORMULA	00
DRYCODE	00
DESTINATION	00
CUSTOMER	000
GOODS CODE	000
WEIGHT	000
CAKE NUMBER	000
SINGLE CAKE	0

This screen allows the user to enter the data after the VERTSTO initializes.

OPERATION/MAIN PAGE

MAIN PAGE

10-0	B1-0	B2-0	B3-0	B4-0
	01		02	
	01		02	

10-1	B1-1	B2-1	B3-1	B4-1
	01		02	
	01		02	

[---- KEY ----]

NAME->	xxx
FORMULA->	xxx
DRYCODE->	xxx

MAIN PAGE · DATE 10/31 - TIME 08:26:07 RETURNING HOME
 RETURN=Cake size CONTROL->A=BELT DATA, B=MANUAL, H=HELP SPACE BAR=More

This screen is the Main page at run time. Each window shows the name and the data of the configured position. The bottom line shows the key instructions. The line right above it shows the page title, date, time and the action being taken by the VERTSTO.

CAKE PAGE

00 BELT 0-0	00 BELT 0-1	01 BELT 1-0	01 BELT 1-1	02 BELT 2-0	02 BELT 2-1
		01 FORM 01	01 FORM 01		
		01 DRY 01**	01 DRY 01**		
		01 DEST 01	01 DEST 01		
		01 CUST 01	01 CUST 01		
		110.0 LBS	250.0 LBS		
03 BELT 3-0	03 BELT 3-1	04 BELT 4-0	04 BELT 4-1		
02 *****	02 *****				
02 *****	02 *****				
02 *****	02 *****				
02 *****	02 *****				
155.0 LBS	210.0 LBS				

CAKE PAGE 0 - DATE 11/31 - TIME 08:29:27 WAITING FOR LOAD OR DISCHARGE DEVICE
RETURN=STATE PAGE (-9=CAKE PAGE NUMBER CONTROL-> B=MANUAL SPACE BAR=More

This screen is the Cake page at run time. Each window shows the name and the data of the configured position. The bottom line shows the key instructions. The line right above it shows the page title, date, time, and the action being taken by the VERTSTO.

0 BELT 0	1 BELT 1	2 BELT 2	3 BELT 3
RS CAN'T RECEIVE	CAN'T RECEIVE	CAN'T RECEIVE	CAN'T RECEIVE
RC DO NOTHING	DO NOTHING	DO NOTHING	DO NOTHING
RL 04	03	02	01
TS CAN'T TRANSFER	CAN'T TRANSFER	CAN'T TRANSFER	CAN'T TRANSFER
TC DO NOTHING	DO NOTHING	DO NOTHING	DO NOTHING
TL 00	00	00	00
4 BELT 4	5 *****	6 *****	7 *****
RS CAN'T RECEIVE	CAN'T RECEIVE	CAN'T RECEIVE	CAN'T RECEIVE
RC DO NOTHING	DO NOTHING	DO NOTHING	DO NOTHING
RL 00	00	00	00
TS CAN'T TRANSFER	CAN'T TRANSFER	CAN'T TRANSFER	CAN'T TRANSFER
TC DO NOTHING	DO NOTHING	DO NOTHING	DO NOTHING
TL 00	00	00	00

STATE PAGE - DATE 10/31 - TIME 08:28:04 RETURNING HOME
RETURN=MAIN PAGE CONTROL-> B=MANUAL, I=INPUTS, O=OUTPUTS SPACE BAR=more

This screen is the Status page at run time. Each window shows the name, receive and transfer statuses of the VERTSTO, receive and transfer commands from MILTRAC, receive and transfer levels. The bottom line shows the key instructions. The line right above it shows the page title, date, time, and the action being taken by the VERTSTO.

OPERATION/INPUTS-OUTPUTS

MONITOR INPUTS/OUTPUTS

MONITOR INPUTS (+ = Made / - = Not made)				
Disch levels	Others			
Level 0 -	Program key -	Three wire +	Slack cable -	
Level 1 -	Signal cancel -	Automatic +	Home level +	
Level 2 -				
Level 3 -				
Belt 0 BELT 0	Belt 1 BELT 1	Belt 2 BELT 2	Belt 3 BELT 3	
Load allowed -	Load allowed -	Load allowed -	Load allowed -	
Disch allowed -	Disch allowed -	Disch allowed -	Disch allowed -	
Load end eye -	Load end eye -	Load end eye -	Load end eye -	
Disch end eye -	Disch end eye -	Disch end eye -	Disch end eye -	
Belt 4 BELT 4	Belt 5	Belt 6	Belt 7	
Load allowed -	NOT APPLIED	NOT APPLIED	NOT APPLIED	
Disch allowed -				
Load end eye -				
Disch end eye -				

RETURN=MAIN PAGE CONTROL-B=MANUAL, I=OUTPUTS, P=PRINT SCREEN

This screen is the Input page. This page shows statuses of all the inputs of the VERTSTO (- = Input is not made. + = Input is made). The bottom line shows the key instructions.

MONITOR OUTPUTS (+ = ON / - = OFF)			
Genera. Move up - Load flag down - Bare manual - Signal - Move down - Disch flag down - Manual inter. -			
Belt 0 BELT 0 Run forward - Run rearward -	Belt 1 BELT 1 Run forward - Run rearward -	Belt 2 BELT 2 Run forward - Run rearward -	Belt 3 BELT 3 Run forward - Run rearward -
Belt 4 BELT 4 Run forward - Run rearward -	Belt 5 NOT APPLIED	Belt 6 NOT APPLIED	Belt 7 NOT APPLIED

RETURN=MAIN PAGE CONTROL: M=MANUAL, I=INPUTS, P=PRINT SCREEN

This screen is the Output page. This page shows statuses of all the outputs of the VERTSTO. (+ = Output is enabled. - = Output is disabled). The bottom line shows the key instructions.

OPERATION/MANUAL

MANUAL OPERATION

<div data-bbox="451 694 704 764">VERTSTO AUTO MANUAL</div> <div data-bbox="462 828 690 996">Return to Auto mode Moving VERTSTO Control boxes Other outputs Monitor inputs</div>	
---	--

This screen is the VERTSTO Auto Manual screen. The Auto Manual mode in the VERTSTO allows the user to enable and disable one individual output at a time. The window below the title is a sub menu in Auto Manual mode which allows the user to select the type of outputs to enable.

VERTSTO AUTO MANUAL	MOVING VERTSTO
Return to auto mode	Move up ON
Moving Vertsto	Move down OFF
Control belts	
Other outputs	
Monitor inputs	

This screen shows the Auto Manual mode in which the Moving VERTSTO sub menu is selected.

<div>VERTSTO AUTO MANUAL</div> <div>Return to auto mode Moving Vertsto Control belts Other outputs Monitor inputs</div> <div>CONTROL BELTS</div> <div>0 BELT 0 1 BELT 1 2 BELT 2 3 BELT 3 4 BELT 4</div>	<div>BELT 0</div> <div>Move forward OFF Move rearward ON</div>
--	--

This screen shows the Auto Manual mode in which the Control belts sub menu, belt #0 is selected.

VERTSTO AUTO MANUAL	OTHER OUTPUTS
Return to auto mode	Signal ON
Moving Vertsto	Bare manual OFF
Control belts	Manual interv. ON
Other outputs	Load flag down OFF
Monitor inputs	Disch flag down OFF

This screen shows the Auto Manual mode in which the Other outputs sub menu is selected.

HOW TO CHANGE EPROMS IN MICROPROCESSORS AND WHERE TO CHECK THE DC VOLTAGES

Occasionally, software enhancements become available. Depending upon the software change, the new software EPROMs (Erasable, Programmable, Read-Only Memory) may be offered for sale or for no charge to the customer. When a set of EPROMs is changed in the field, ensure that the software version being installed matches the machine hardware and that EPROMs are installed in the proper socket positions and orientation.

How To Change EPROMs

⚠ WARNING ⚠



SHOCK HAZARD—Electrical components on the machine conduct high voltage that will kill or seriously injure you on contact.

☞ **Lock OFF** and tag out electrical power at the main (wall) disconnect before beginning this procedure.

1. Make sure all power to the machine is *off*.
2. Locate the EPROMs as described in “Location of EPROMs on Processor Board” in this section. Note the orientation of the EPROMs as shown in FIGURES 3, 5, 7, and 9.
3. Slip a small flat tool underneath the EPROM, and carefully remove each old EPROM from its base, taking note of their numerical order (see FIGURES 3 and 7) and orientation to the key notch on the socket.
4. Install new EPROMs, making sure the key notch on the EPROM is properly oriented and that all pins enter the proper holes in the socket (FIGURE 1). If necessary, slightly bend the pins on the EPROMs to align them in the socket. After inserting each EPROM, verify that all pins are seated in the socket.




FIGURE 1 (MSSM0217AE)
Properly Seating the EPROM

⚠ CAUTION ⚠



COMPONENT DAMAGE HAZARD—Incorrectly installing any EPROM may cause EPROM burn out, machine failure, or display error.

☞ **Match** each EPROM with its corresponding socket. Each EPROM will *work* in only one socket, although it may physically *fit* in others.

☞ **Align** EPROM so every pin mates with the correct hole in the socket.

Verifying Proper EPROM Installation—After installing new EPROMs, apply power to the machine and turn the machine *on*. If the EPROMs are properly installed, the display will continue with the normal display sequence when powering up. If the display is blank or appears unusual, turn the machine *off* at once and check the orientation of the EPROMs.

Location of EPROMs on Processor Board

Depending on machine model and type, the CPU chip can be an Intel 8085 or an Intel 8088. Each microprocessor board requires at least one EPROM for proper operation, but the EPROMs are located differently, depending upon the type of board. This information describes the location and arrangement of the EPROM chips on each type of board. It also describes where to check the voltages required by the processor board.

8085 Processor Boards, *NOT Coin Machine*—See FIGURE 3. Install EPROM #1 at the end of the row, then #2, #3, and #4. Chip #4 goes next to the two soldered chips on the board. See FIGURE 2 for where to check voltages.




FIGURE 2 (MSSM0217AE)
MTA-31 on 8085 Processor Board
(wires not shown for clarity)




FIGURE 3 (MSSM0217AE)
8085 Processor Board (NOT Coin Machine)

8085 Coin Machine Processor Boards—See FIGURE 5. Install the single EPROM in socket IC7 below connector W34. These boards have no battery.




FIGURE 4 (MSSM0217AE)
MTA-1 in 8085 Coin Machine
(wires not shown for clarity)




FIGURE 5 (MSSM0217AE)
8085 Coin Machine Processor Board

8088 Processor Boards Without Memory Expansion Board—See the table of EPROM locations (below) and FIGURE 7. If the set consists of only one EPROM, install it in socket A of FIGURE 7. If two EPROMs comprise the set, install EPROM #2 in socket A and EPROM #1 in socket B. **Always install highest numbered EPROM in socket A.** If the set consists of more than two EPROMs, a Memory Expansion Board must be present in the machine along with the processor board.

8088 Processor Boards With Memory Expansion Board—See the table of EPROM locations below and FIGURE 7. If the EPROM set consists of three or more EPROMs, install the two highest numbered EPROMs (e.g., EPROMs #3 and #4 of a four-chip set) *on the processor board*, with the highest numbered E-PROM (EPROM #4 of a four-chip set) in socket A, and the EPROM with the second highest number (EPROM #3 of a four-chip set) in socket B. *Install the remaining EPROM(s) on the Memory Expansion Board* with the highest numbered of the remaining EPROMs (e.g., EPROM #2 of a four-chip set) in socket IC-1 on the Memory Expansion Board and EPROM #1 in socket IC-2.

EPROM Locations on 8088 Processor Board and Memory Expansion Board				
EPROMS in Set	E-PROM Location by Socket (see FIGURE 4)			
	A	B	IC-1	IC-2
4-chip set	4	3	2	1
3-chip set	3	2	1	—
2-chip set	2	1	—	—
1-chip set	1	—	—	—




FIGURE 6 (MSSM0217AE)
1MTA-31 on 8088 Board (wires not shown for clarity)




FIGURE 7 (MSSM0217AE)
8088 Processor Board and Optional Memory Expansion Board

80186 Processor Boards—This processor board is used on all Milnor system controllers (Miltron, Mildata, etc.) equipped with a color monitor, and on textile processing machines with software versions 95000 and later. The single EPROM on this board is located in socket IC-2.




FIGURE 8 (MSSM0217AE)
1MTA-31 on 80186 Board (wires not shown for clarity)




FIGURE 9 (MSSM0217AE)
80186 Processor Board

THE EXTERNAL SERIAL LINK CABLES AND HOW TO CONSTRUCT THEM

General

Only three wires (two signal wires plus a ground, referred to in this section as a *serial link*) are required to transfer data from one Milnor[®] device to another. However, because the two optional serial communicating functions (*Download* and *Print Data*, but not interconnected networks such as Milnet[®]/Miltrac or Mildata[®] systems) are conducted through a single external DIN-type, 9-pin connector, different *serial links* will be required for the two functions; it may be necessary to temporarily disconnect one plug from the connector and insert another to access the other optional function. *Non-optional* serial communications (as between Mildata[®] networks and a bank of washer-extractors, or as between Milnet[®]/Miltrac systems and the press, shuttle, and dryers in a CBW[®] system) are hard-wired internally either at the factory or during system installation. Thus, except for some field retrofit situations, these network systems generally do not use the external connector mentioned above.

In Mildata[®] systems, the functions of *Download* and *Print Data* are usually performed at the Mildata[®] PC itself, but each washer-extractor (and certain other machines if their software supports it) can also *Download* or *Print Data* via its external connector.

▲ CAUTION ▲

If *Download* or *Print Data* is performed from serial downloader-to-machine or machine-to-machine with machines in a Milnet[®]/Miltrac or Mildata[®] network system, **ALL** energized machines on the network will receive the downloaded data. Turn *off* power to any machines to which you do not wish to *Download*.

Pin Identification




FIGURE 1 (MSSM0227AE)
Pin Locations in the External Serial Link Connector

Pin Assignments in the External Connector

PIN NUMBER	FUNCTION	WIRES ON RECEPTACLE INSIDE ELECTRICAL ENCLOSURE	
		Number	Color
1+2	SERIAL LOW	DLL	BLUE and BLACK
3+4	SERIAL HIGH	DLH	BLUE and RED
5	CLEAR TO SEND	CTS	BLUE and ORANGE
6+9	ELECTRONIC GROUND	2G	BLUE and WHITE
7	TRANSMIT DATA	TXD	BLUE and ORANGE
8	+5DC	V1	BLUE

⚠ CAUTION ⚠

AVOID EQUIPMENT DAMAGE—Never connect pin 8 between any machines or to the printer. This pin conducts +5VDC from the machine’s power supply. Pin 8 is used only to power the SERIAL DOWNLOADER INTERFACE. If pin 8 is connected to any pin in the connector or the printer or any other machine, the two volt sources will clash and burn up expensive electronic components in both machines.

How To Construct (Wire) the Serial Link Cables

The Type of Cable Wire To Use—Use 18AWG four-conductor shielded cable. Connect the shield to the ground at one end only. See the various drawings below.

⚠ CAUTION ⚠

AVOID EQUIPMENT DAMAGE—Never connect pin 8 between any machines or to the printer. This pin conducts +5VDC from the machine's power supply. Pin 8 is used only to power the SERIAL DOWNLOADER INTERFACE. If pin 8 is connected to any pin in the connector or the printer or any other machine, the two volt sources will clash and burn up expensive electronic components in both machines.

To Download From Machine-to (from)-Serial Downloader




FIGURE 2 (MSSM0227AE)
Connections for Downloading Machine-to (from)-Serial Downloader

RECEPTACLE
(with male pins)

PLUG (with female pins)

CONNECT SHIELDS TOGETHER

SHIELD

GROUND UNUSED

GROUND

ONLY GROUND THIS END OF SHIELD

DO NOT GROUND THIS END OF SHIELD

INTERNAL JUMPERS IN RECEPTACLE SHOWN

DON'T USE PIN 8

Connect all unused wires and the shield (at this end only) to ground pin number nine as shown.

SEE "PIN ASSIGNMENTS IN THE EXTERNAL CONNECTOR" IN THIS MANUAL SECTION.

For Print Data—The connections shown in FIGURE 4 are made at the factory if the factory furnishes the printer, or by whomever provides the printer. Where applicable, see the appropriate programming section in this manual for an explanation of the Print Data feature (see Table of Contents).




FIGURE 4 (MSSM0227AE)
Machine-to-Printer Connections

NOTICE

As this manual was being printed, Pellerin Milnor Corporation began a manufacturing change which may affect how this manual applies to your machine. The six-position DIP switch on each printed circuit board is being replaced with two sixteen-position rotary switches. The switches (DIP and rotary) are used to set the logical address for each board that communicates with the microprocessor in the machine, or with a higher-level control system (e.g., a Mildata network).

Because the change to rotary switches corresponds so closely to the release of this manual, we are supplying you with documentation on how to set both types of switches.

If your machine uses printed circuit boards containing one DIP switch, refer to MSFDA401DE to set the address on replacement boards. If your machine uses printed circuit boards containing rotary switches, refer to MSFDA401EE.

THE HARDWARE IN SERIAL-TYPE MICROPROCESSORS

General

Milnor[®] serial microprocessor controls are designed specifically for Milnor[®] machines and systems. Along with certain external electromechanical relay logic and sensing devices, they control all machine and system functions. **Not every microprocessor includes all the components described in this section.**

The Microprocessor Components

This is a list of all components for Milnor[®] microprocessor controllers. Not every Milnor[®] microprocessor controller includes all the following components.

1. Keypad or Keyboard—Depending upon the model/type, the keypad may have 12, 30, or 58 buttons. The different keypads are not interchangeable.

2. Keyswitch—Selects run/program modes. The key may be removed only in *run*. **Never leave the key accessible to unauthorized personnel.**

3. Display—Depending upon the model/type, the display may be either liquid crystal, fluorescent, or CRT. The different displays are not interchangeable.

4a. Power Supply (NOT for CBW[®] System)—Converts control circuit AC voltage to +12VDC, -12VDC, and +5VDC for the CPU board. On dryers and some other machines, a second, identical power supply performs the same function for all the peripheral boards, which are mounted in an enclosure separate from the CPU.

A *minimum 14AWG ground wire* must be connected between the grounds on the CPU and the peripheral board(s). This ground is installed at the factory when both enclosures are mounted on the same machine, as in washer-extractors. The ground wire must be provided during installation when the CPU enclosure and its associated peripheral board enclosures are remote from one another as in dryers.

Although the +12VDC and -12VDC are not adjustable, the +5VDC for the CPU is very sensitive. The power supply must be adjusted most accurately, **so the actual voltage at the CPU board is between 4.95VDC and 5.1VDC as measured by an accurate digital voltmeter.**

4b. Power Supply (CBW[®] System Only)—The Milnor[®] CBW[®] System utilizes two discrete power supplies to convert control circuit AC voltage to +12 VDC, -12 VDC, and +5VDC for the CPU board and peripheral boards.

One power supply (ESPS) is a 40-watt power supply located in the Miltron cabinet. It powers the peripheral boards in the Miltron cabinet, including the optional load cell interface board and A/D board for a weighing conveyor, the CPU board and the memory expansion board, and the monitor interface board.

Although the +12VDC and -12VDC are not adjustable, the +5VDC for the CPU is very sensitive. The power supply must be adjusted accurately, **so the actual voltage at the CPU board is between 4.95VDC and 5.1VDC as measured by an accurate digital voltmeter.**

The second power supply (PSO) is a 120-watt power supply which provides +12VDC, -12VDC, and +5VDC to the peripheral boards located on the tunnel. This power supply provides for the adjustment of the +12VDC voltage, the -12VDC voltage, and the +5VDC voltage. If these voltages require adjustment, set the +5VDC to provide no less than +4.8VDC at the module electric box farthest from the power supply, as measured by an accurate digital voltmeter. If necessary, adjust the +12VDC to 12.00VDC and the -12VDC to -12.00VDC as measured by an accurate digital voltmeter.

G If the +5VDC at the peripheral board nearest PSO is at least +5.25VDC when the voltage at the peripheral board farthest from PSO is +4.8VDC or less, suspect loose MTA connections or inadequate wiring somewhere between the nearest and farthest peripheral boards.

5. CPU (Processor) Board—The Central Processing Unit (CPU) processes data received from the various inputs, stores information, and responds to each keypad entry with the appropriate action. It may be mounted in an enclosure separate from its peripheral boards. The CPU contains E-PROMs programmed by the Milnor[®] factory with fixed instructions (software) that determine how the machine functions. Depending upon machine model/type, the CPU chip can be either an Intel 8085 or an Intel 8088.

Although the E-PROMs do not require battery backup, the CPU board utilizes a battery which normally assures that the user-programmable memory will be retained for two to three months without external power. See below and “IMPORTANT OWNER/USER INFORMATION . . .” (see Table of Contents).

6. Memory Expansion Board—Increases memory space available to the processor. This board is used with 8088 CPU board in some applications.

D G 7. Battery—Provides memory retention backup when power is *off*. The battery is mounted directly on 8085 CPU boards, and mounted separately for 8088 CPU boards. A capacitor on the 8088 CPU board provides enough power to retain memory for several hours after the battery has been disconnected. Once fully charged (see “IMPORTANT OWNER/USER INFORMATION . . .”), the battery backup is reliable for 90 days with no power applied.

8. Opto-Isolator Board—Optically isolates inputs to the CPU for electronic noise immunity. Opto-Isolators are incorporated into the 8088 CPU board; thus this separate board is only required for 8085 CPUs.

9. I/O Board—16/8 input-output contains 16 solid-state signal input devices and eight output relays. The input devices are capable of faithfully conducting a low VA 12VDC ground signal to the CPU. The output relays are socket-mounted SPDT, 12VDC electromechanical relays with contacts capable of faithfully conducting a *maximum* of 25VA at 110/120VAC (0.2 ampere or 200 milliamperes at 110/120VAC) or 12.5 VA at 24VAC (0.5 ampere or 500 milliamperes at 24VAC). The output will be either 24VAC or 110/120VAC depending on the machine model/type.

These outputs and their power source are intended only to drive another relay with higher contact ratings, that in turn may drive a pump, valve, solenoid, etc., from a separate power source. **Never use these outputs to directly drive a pump, valve, or solenoid unless the maximum current required never exceeds the above values. Higher ampere or VA loads will burn out traces on the printed circuit board or possibly overload and damage the control circuit transformer.**

H **Standard I/O board**—Used in all devices requiring I/O boards except those listed below.
High-speed I/O board—Used only in the following devices and configurations: E6N, J6N, and T6N washer-extractors equipped and configured for **both variable basket speed and electronic balancing**; Milrail configured for high-speed boards; and all configurations of the M7E centrifugal extractor.

10. Output Board—A 16-output board contains 16 output relays, the same type as those described above.

D G 11. A/D Board (Analog to Digital Convertor)—Converts analog voltage signals, such as temperature, to a digital signal that can be utilized by the CPU. Up to a maximum of eight A/D channels may be provided on a single board. Although seemingly identical, the A/D boards used to sense air temperature in the dryer, water temperature in washer-extractors and dye machines, water temperature in the tunnel, and weight for a weighing conveyor are all different. **The different types are clearly marked with different part numbers, which are mentioned in the wiring diagram set and are not interchangeable.**

D 12. D/A Board (Digital to Analog Convertor)—Converts digital signals from the processor to an analog voltage between 0 and 5VDC (e.g., provides the analog signal to the dryer gas valve position actuator and dye machine steam position actuator).

13. CRT Board—Receives display instructions from the processor and generates the signals to the CRT to create the desired displays; used in controllers such as the Miltron and Miltrac controllers and Device Master systems.

⚠ CAUTION ⚠

The CRT board can be plugged in backwards, even though the cabinet/bracketry makes this difficult to do and labeling on the parent board states the proper orientation. Use care to orient the board properly, otherwise microprocessor components may burn out.

14. Resistor Boards—Although seemingly identical, resistor boards are quite different. **The different types are clearly marked with different part numbers, which are mentioned in the wiring diagram set and are not interchangeable.**

- a. **For Temperature-Sensing System**—Used with A/D board in washer-extractors and Dye-Extractors[®] as part of temperature-sensing system; not required on continuous batch washers because necessary circuitry is included on other (standard) CBW[®] printed circuit boards.
- b. **For Gas Valve**—Used with D/A board in temperature control circuit of gas dryers; converts 0-5VDC to 4-20 milliamperes for modulating gas valve.
- c. **For Steam Valve**—Used with D/A board in temperature control circuit of older steam dryer models; converts 0-5VDC to 4-20 milliamperes for modulating steam valve. See “4-20MA Output Board” in this section.

15. Signal Conditioner for Thermocouple—Amplifies the output from a thermocouple so an A/D board can use the signal.

16. Rotation Safety Board—Used in dryers. Reads rotational safety proximity switch to confirm that the basket is turning.

17. Temperature Probes—Two types of temperature probes are used, depending on equipment type:

Thermistor temperature probes—A temperature-sensitive resistor whose resistance changes with respect to temperature; uses include washer-extractors, textile machines, and continuous batch washers.

Thermocouple temperature probes—A connection of dissimilar metals which produces a voltage with respect to its temperature; uses include dryers.

18. Weigh Scale Interface Board—Regarding machine logic, this is located between the load cell of the weighing conveyor (CONWA) and the weighing conveyor A/D board. It interprets data from the conveyor load cell to the A/D board.

19. 4-20MA Output Board—Used on newer dye machines and steam dryers with temperature control. See “Resistor Boards/c. For Steam Valve” in this section.

The Serial Communications Port

All Milnor[®] serial microprocessors have a serial port with a nine-pin receptacle and plug to pass data to other devices via one of several special serial cables to *Download* or to *Print data* when their software supports these functions (e.g., see programming information). For more information on the various separate serial cables required for these functions, see external serial link cable information in this manual (see Table of Contents), if applicable.

Which Boards Are Used in Various Devices

Board Device	8088 CPU	I/O	OUTPUT	A/D	D/A	CRT	Opto- Isolator	Temp Sensing Resistor	Gas Valve Resistor	Steam Valve 4-20MA	Signal Condi- tioner	Rotation Safety	Weigh Scale Interface
COSHA	1	2 ¹	—	—	—	—	—	—	—	—	—	—	—
COBUC	1	2 ¹	— ¹	—	—	—	—	—	—	—	—	—	—
DEVICE MASTER	1	2 ¹	— ¹	—	—	1	—	—	—	—	—	—	—
DRYER	1	1 ¹	1	1 ⁴	1 ²	—	—	—	1 ²	— ²	1	1	—
DYE	1	2	2	1 ⁴	1	—	—	1	—	1	—	—	—
LINEAR COSTA	1	1 ¹	—	—	—	—	—	—	—	—	—	—	—
LINK MASTER	1	—	—	—	—	—	—	—	—	—	—	—	—
MILTRAC	1	—	—	—	—	1	—	—	—	—	—	—	—
PRESS	1	2 ¹	1 ¹	1	—	—	—	—	—	—	—	—	—
EXTRACTO R	1	1 ¹	1 ¹	—	—	—	—	—	—	—	—	—	—
VERTSTO	1	2	—	—	—	1	—	—	—	—	—	—	—
W/E (MARK I)	NOTE 7	1 ¹	1 ¹	1 ^{3,4}	— ¹	—	1	1	—	—	—	—	—
W/E (MARK II)	1	1 ¹	1 ¹	1 ^{3,4}	— ¹	—	—	1	—	—	—	—	—
CBW [®] System	1	2+1 per mod- ule	— ¹	1 per 8 ⁴ mod- ules 1,5,6	—	1	—	—	—	—	—	—	1 ⁵

- Boards can be added for options
- For gas dryers and steam dryers with temperature control
- For washer-extractors with temperature option
- Although seemingly identical, the A/D boards for sensing air temperature in dryers, water temperature in washer-extractors and dye machines, water temperature in tunnels and weight for weighing conveyors are all different. **The different types have different part numbers, are clearly marked, and are not interchangeable.**
- Required for CBW[®] system with weighing conveyor
- Required for Reuse/Cooldown and/or Overhead Fill tanks
- The Mark I washer-extractor control used an 8085 CPU

NOTE: Additional boards may be required for certain other options.

[illegible]

THE HARDWARE IN SERIAL-TYPE MICROPROCESSORS FOR MARK IV AND V MACHINES

General

Milnor[®] serial microprocessor controls are designed specifically for Milnor[®] machines and systems. Along with certain external electromechanical relay logic and sensing devices, they control all machine and system functions. **Not every microprocessor includes all the components described in this section.**

The Microprocessor Components

This is a list of all components for Milnor[®] microprocessor controllers. Not every Milnor[®] microprocessor controller includes all the following components.

1. Keypad or Keyboard—Depending upon the model/type, the keypad may have 12, 30, or 58 buttons. The different keypads are not interchangeable.

2. Keyswitch—Selects run/program modes. The key may be removed only in *run*. **Never leave the key accessible to unauthorized personnel.**

3. Display—Depending upon the model/type, the display may be either liquid crystal, fluorescent, or CRT. The different displays are not interchangeable.

4a. Power Supply (NOT for CBW[®] System)—Converts control circuit AC voltage to +12VDC, -12VDC, and +5VDC for the CPU board. On dryers and some other machines, a second, identical power supply performs the same function for all the peripheral boards, which are mounted in an enclosure separate from the CPU.

A minimum 14AWG ground wire must be connected between the grounds on the CPU and the peripheral board(s). This ground is installed at the factory when both enclosures are mounted on the same machine, as in washer-extractors. The ground wire must be provided during installation when the CPU enclosure and its associated peripheral board enclosures are remote from one another as in dryers.

Although the +12VDC and -12VDC are not adjustable, the +5VDC for the CPU is very sensitive. The power supply must be adjusted most accurately, **so the actual voltage at the CPU board is between 4.95VDC and 5.1VDC as measured by an accurate digital voltmeter.**

4b. Power Supply (CBW[®] System Only)—The Milnor[®] CBW[®] System utilizes two discrete power supplies to convert control circuit AC voltage to +12 VDC, -12 VDC, and +5VDC for the CPU board and peripheral boards.

One power supply (ESPS) is a 40-watt power supply located in the Miltron cabinet. It powers the peripheral boards in the Miltron cabinet, including the optional load cell interface board and A/D board for a weighing conveyor, the CPU board and the memory expansion board, and the monitor interface board.

Although the +12VDC and -12VDC are not adjustable, the +5VDC for the CPU is very sensitive. The power supply must be adjusted accurately, **so the actual voltage at the CPU board is between 4.95VDC and 5.1VDC as measured by an accurate digital voltmeter.**

The second power supply (PSO) is a 120-watt power supply which provides +12VDC, -12VDC, and +5VDC to the peripheral boards located on the tunnel. This power supply provides for the adjustment of the +12VDC voltage, the -12VDC voltage, and the +5VDC voltage. If these voltages require adjustment, set the +5VDC to provide no less than +4.8VDC at the module electric box farthest from the power supply, as measured by an accurate digital voltmeter. If necessary, adjust the +12VDC to 12.00VDC and the -12VDC to -12.00VDC as measured by an accurate digital voltmeter.

If the +5VDC at the peripheral board nearest PSO is at least +5.25VDC when the voltage at the peripheral board farthest from PSO is +4.8VDC or less, suspect loose MTA connections or inadequate wiring somewhere between the nearest and farthest peripheral boards.

5. CPU (Processor) Board—The Central Processing Unit (CPU) processes data received from the various inputs, stores information, and responds to each keypad entry with the appropriate action. It may be mounted in an enclosure separate from its peripheral boards. The CPU contains EPROMs programmed by the Milnor[®] factory with fixed instructions (software) that determine how the machine functions. Depending upon machine model/type, the CPU chip can be an Intel 8085, an Intel 8088, or an Intel 80186.

Although the EPROMs do not require battery backup, the CPU board utilizes a battery which normally assures that the user-programmable memory will be retained for two to three months without external power. See below and “IMPORTANT OWNER/USER INFORMATION . . .” (see Table of Contents).

6. Memory Expansion Board—Increases memory space available to the processor. This board is used with 8088 CPU board in some applications.

7. Battery—Provides memory retention backup when power is *off*. The battery is mounted directly on 8085 CPU boards, and mounted separately for 8088 and 80186 CPU boards. A capacitor on the 8088 and 80186 CPU board provides enough power to retain memory for several hours after the battery has been disconnected. Once fully charged (see “IMPORTANT OWNER/USER INFORMATION . . .”), the battery backup is reliable for 90 days with no power applied.

8. Opto-Isolator Board—Optically isolates inputs to the CPU for electronic noise immunity. Opto-Isolators are incorporated into the 8088 and 80186 CPU board; thus this separate board is only required for 8085 CPUs.

9. I/O Board—16/8 input-output contains 16 solid-state signal input devices and eight output relays. The input devices are capable of faithfully conducting a low VA 12VDC ground signal to the CPU. The output relays are socket-mounted SPDT, 12VDC electromechanical relays with contacts capable of faithfully conducting a *maximum* of 25VA at 110/120VAC (0.2 ampere or 200 milliamperes at 110/120VAC) or 12.5 VA at 24VAC (0.5 ampere or 500 milliamperes at 24VAC). The output will be either 24VAC or 110/120VAC depending on the machine model/type.

These outputs and their power source are intended only to drive another relay with higher contact ratings, that in turn may drive a pump, valve, solenoid, etc., from a separate power source. **Never use these outputs to directly drive a pump, valve, or solenoid unless the maximum current required never exceeds the above values. Higher ampere or VA loads will burn out traces on the printed circuit board or possibly overload and damage the control circuit transformer.**

This board has 25 status lights. One light blinks when the board is sending signals. Each of the 24 remaining lights represent an input (green lights) or output (red lights) on that board, and illuminates when the corresponding input or outputs is made. This board has two rotary dials which must be adjusted to set the board's address (see “Rotary Switches and How to Set Them” in this section). This board also has convenient test points that can be used to test voltage to the board.

Standard I/O board—Used in all devices requiring I/O boards except those listed below.

High-speed I/O board—Used only in the following devices and configurations: E6N, J6N, and T6N washer-extractors equipped and configured for **both variable basket speed and electronic balancing**; Milrail configured for high-speed boards; and all configurations of the M7E centrifugal extractor.

10. Output Board—A 24-output board contains 24 output relays, the same board and relays as described above.

11. A/D Board (Analog to Digital Converter)—Converts analog voltage signals, such as temperature, to a digital signal that can be utilized by the CPU. Up to a maximum of eight A/D channels may be provided on a single board. Although seemingly identical, the A/D boards used to sense air temperature in the dryer, water temperature in washer-extractors and textile machines, water temperature in the tunnel, and weight for a weighing conveyor are all different. **The different types are clearly marked with different part numbers, which are mentioned in the wiring diagram set and are not interchangeable.**

This board has one status light. This light blinks when the board is communicating. This board has two rotary dials which must be adjusted to set the board's address (see "Rotary Switches and How to Set Them"). This board also has convenient test points that can be used to test voltage to the board.

12. D/A Board (Digital to Analog Converter)—Converts digital signals from the processor to an analog voltage between 0 and 5VDC (e.g., provides the analog signal to the dryer gas valve position actuator and dye machine steam position actuator).

This board has one status light. This light blinks when the board is communicating. This board has two rotary dials which must be adjusted to set the board's address (see "Rotary Switches and How to Set Them"). This board also has convenient test points that can be used to test voltage to the board.

13. CRT Board—Receives display instructions from the processor and generates the signals to the CRT to create the desired displays; used in controllers such as the Miltron and Miltrac controllers and Device Master systems.

▲ CAUTION ▲

The CRT board can be plugged in backwards, even though the cabinet/bracketry makes this difficult to do and labeling on the parent board states the proper orientation. Use care to orient the board properly, otherwise microprocessor components may burn out.

14. Resistor Boards—Although seemingly identical, resistor boards are quite different. **The different types are clearly marked with different part numbers, which are mentioned in the wiring diagram set and are not interchangeable.**

- a. **For Temperature-Sensing System**—Used with A/D board in washer-extractors and Dye-Extractors[®] as part of temperature-sensing system; not required on continuous batch washers because necessary circuitry is included on other (standard) CBW[®] printed circuit boards.
- b. **For Gas Valve**—Used with D/A board in temperature control circuit of gas dryers; converts 0-5VDC to 4-20 milliamperes for modulating gas valve.
- c. **For Steam Valve**—Used with D/A board in temperature control circuit of older steam dryer models; converts 0-5VDC to 4-20 milliamperes for modulating steam valve. See "4-20MA Output Board" in this section.

15. Signal Conditioner for Thermocouple—Amplifies the output from a thermocouple so an A/D board can use the signal.

16. Rotation Safety Board—Used in dryers. Reads rotational safety proximity switch to confirm that the basket is turning.

17. Temperature Probes—Two types of temperature probes are used, depending on equipment type:

Thermistor temperature probes—A temperature-sensitive resistor whose resistance changes with respect to temperature; uses include washer-extractors, textile machines, and continuous batch washers.

Thermocouple temperature probes—A connection of dissimilar metals which produces a voltage with respect to its temperature; uses include dryers.

18. Weigh Scale Interface Board—Regarding machine logic, this is located between the load cell of the weighing conveyor (CONWA) and the weighing conveyor A/D board. It interprets data from the conveyor load cell to the A/D board.

19. 4-20MA Output Board—Used on newer textile machines and steam dryers with temperature control. See “Resistor Boards/c. For Steam Valve” in this section.

20. 8 Out/16 In Chemical Flow Meter Board—This board is used with the metered chemical injection option on textile machines. Eight outputs and eight counters are respectively assigned to chemical valves and chemical flow meters. Two of the counters are non-isolated direct inputs to the microprocessor *on this board* and are capable of counting pulses of 0 to 5 VDC at a frequency of up to 10kHz. the remaining six counters are optically isolated from the peripheral board microprocessor and are capable of counting pulses from 0 to 12 VDC at a frequency up to 150 Hz.

The Serial Communications Port

All Milnor[®] serial microprocessors have a serial port with a nine-pin receptacle and plug to pass data to other devices via one of several special serial cables to *Download* or to *Print data* when their software supports these functions (e.g., see programming information). For more information on the various separate serial cables required for these functions, see external serial link cable information in this manual (see Table of Contents), if applicable.

Which Boards Are Used in Various Devices

Board Device	CPU	I/O	Output	A/D	D/A	CRT	Opto- Isolator	Temp Sensing Resistor	Gas Valve Resistor	Steam Valve 4-20MA	Signal Condi- tioner	Chem Flow Meter	Rotation Safety	Weigh Scale Interfac e
COSHA	1	2 ¹	—	—	—	—	—	—	—	—	—	—	—	—
COBUC	1	2 ¹	— ¹	—	—	—	—	—	—	—	—	—	—	—
DEVICE MASTER*	1	2 ¹	— ¹	—	—	1	—	—	—	—	—	—	—	—
DRYER	1	2	1	1 ⁴	1 ²	—	—	—	1 ²	— ²	1	—	1	—
TEXTILE*	1	1	2	1 ⁴	1	—	—	1	—	1	—	0 ¹	—	—
LINEAR COSTA	1	1 ¹	—	—	—	—	—	—	—	—	—	—	—	—
LINK MASTER	1	—	—	—	—	—	—	—	—	—	—	—	—	—
MILTRAC*	1	—	—	—	—	1	—	—	—	—	—	—	—	—
PRESS	1	2 ¹	1 ¹	1	—	—	—	—	—	—	—	—	—	—
EXTRACTO R	1	2	1 ¹	—	—	—	—	—	—	—	—	—	—	—
VERTSTO	1	2	—	—	—	1	—	—	—	—	—	—	—	—
W/E (MARK I)	NOTE 7	1 ¹	1 ¹	1 ^{3,4}	— ¹	—	1	1	—	—	—	—	—	—
W/E (MARK II)	1	1 ¹	1 ¹	1 ^{3,4}	— ¹	—	—	1	—	—	—	—	—	—
CBW [®] System*	1	2+1 per mod- ule	— ¹	1 per 8 ⁴ mod- ules 1,5,6	—	1	—	—	—	—	—	—	—	1 ⁵

*80186 CPU

1. Boards can be added for options
2. For gas dryers and steam dryers with temperature control
3. For washer-extractors with temperature option
4. Although seemingly identical, the A/D boards for sensing air temperature in dryers, water temperature in washer-extractors and dye machines, water temperature in tunnels and weight for weighing conveyors are all different. **The different types have different part numbers, are clearly marked, and are not interchangeable.**
5. Required for CBW[®] system with weighing conveyor
6. Required for Reuse/Cooldown and/or Overhead Fill tanks
7. The Mark I washer-extractor control used an 8085 CPU

NOTE: Additional boards may be required for certain other options.

Rotary Switches and How To Set Them

The Input/Output board, the Output board, the A/D board, and the D/A board each have two rotary switches which establish the address for each board. This allows the boards to communicate serially with its own CPU, as though on a “party line,” while sending and receiving its own messages. In a battery of machines, the rotary switches are identical for each identical peripheral board in each identical machine (e.g., each first I/O board (I/O-1) in each washer-extractor has the identical rotary switch setting). When a CPU must communicate with a higher level control (e.g., when all dryers communicate with the Milnet[®] system), the higher level control must know the address of each CPU. For 8088 CPUs, the high level control knows the address of each CPU because that information was established during configuration (e.g., see Miltrac Address configure decision in the programming manual for any device that communicates with Miltrac).

Rotary Switch Settings

[illegible]