

Published Manual Number/ECN: MECOELT1AE/2015142A

- Publishing System: TPAS2
- Access date: 04/13/2015
- Document ECNs: Latest



**Read the  
separate  
safety  
manual  
before  
installing,  
operating,  
or servicing**

# Schematic/Electrical Parts

## CA3608PSA Loading, Extending, Elevating Conveyor with Weight Controller



## **Table of Contents**

### **MECOELT1AE/15142A**

<b>Page</b>	<b>Description</b>	<b>Document</b>
1	Component Parts List	WCG1CLTCPL/2014374N
5	Limited Standard Warranty	BMP720097/2008272A
6	How to Get the Necessary Repair Components	BIUUUD19/20081231
7	How to Use Milnor® Electrical Schematic Diagrams	BIUUUK01/20130308
20	Sample Schematic	BMP010012/2001503N
22	3 Phase Motor Connection Diagram	BMP850029/1999362B
23	3P Motor Diagram-Multivolt	W80008/2001253A
24	Coelds Motor Contactors with Standard Hoist	WCG1CLSA1/2014455B
26	Coelds Motor Contactors with Demag Hoist	WINSFDRLSA/2014455B
28	Load / Discharge Circuit	WCG1CLSB1/2015142B
30	Extend / Retract Circuit	WCG1CLSC1/2015142B
32	Allied Signals	WCG1CLSD1/2014455B
34	Motor and Incoming Voltage	WCG1CLSE/2014392B
36	Source Voltage	WCG1CLSF/2011464B
38	CBW Allied Weight Interface	W6WTCSAI/2012242B
40	Weight Controller Board Wiring 1	W6WTCSBW1/2014374B
42	Weight Controller Board Wiring 2	W6WTCSBW2/2012242B
44	Weight Controller Keypad	W6WTCSKP/2012242B
46	Weight Controller Loading LED Lights	W6WTCSLC/2014455B
48	Weight Controller Control Circuit Power	W6WTCSLV/2012242B
50	Weighing Controller Operating Instructions	W6WTCSINST/2014455A



# COMPONENT PARTS LIST

<u>COMPONENT NUMBER</u>	<u>FUNCTION OF THIS COMPONENT</u>	<u>WHERE TO FIND THIS COMPONENT</u>	<u>MILNOR P/N</u>	<u>DESCRIPTION</u>	<u>LOCATION</u>
<b>B</b>	<b>&gt;&gt;PRINTED CIRCUIT BOARDS</b>				
B024-1	BOARD-24 OUTPUT	W6WTC5A1	08BSO24AT	BD:SERIAL 24 OUTPUT->TEST	WT CNTRL BX
BAD-1	BOARD-D TO A #1	W6WTC5BW2	08BSADCLT	BD:SER A-D+LOAD CELL->TESTED	WT CNTRL BX
BAD-2	BOARD-D TO A #2	W6WTC5BW2	08BSADCLT	BD:SER A-D+LOAD CELL->TESTED	WT CNTRL BX
BAD-3	BOARD-D TO A #3	W6WTC5BW2	08BSADCLT	BD:SER A-D+LOAD CELL->TESTED	WT CNTRL BX
BAD-4	BOARD-D TO A #4	W6WTC5BW2	08BSADCLT	BD:SER A-D+LOAD CELL->TESTED	WT CNTRL BX
BBB-1	BOARD-BATTERY BACKUP	W6WTC5BW1	08BSBB1T	BOARD: SER BATT BACKUP-TEST	WT CNTRL BX
BDVFD	DISPLAY-VACUUM FLOURESCENT	W6WTC5BW1	08BSEVFD5V	BD:SER VFD 2LINE-19200B-TEST	WT CNTRL BX
BMTH-0	BOARD-8 BOARD MOTHER	W6WTC5BW2	08BS8MTHAT	BD:SERIAL 8 CARD MOTHER-TEST	WT CNTRL BX
BPB	BOARD-PROCESSOR	W6WTC5BW1	08BSPG1T	BD:ARM7 SERIAL PROCESSOR->TEST	WT CNTRL BX
CD	<b>&gt;&gt;RELAY-TIME DELAY</b>				
CDD1	DELAY-PHOTOEYE CLEAR	WCG1CLSC1	09CF016024	TDR F16S 2PDT 11PIN 24V50/60C	LOW VOLT BOX
CDD2	DELAY-DISC END PHOTOEYE BLOCKED	WCG1CLSB1	09CF002024	TDR F2S 2PDT 11PIN 24V50/60C	LOW VOLT BOX
CL	<b>&gt;&gt;RELAY-LATCH</b>				
CLB	LATCH-COELD LOADING	WCG1CLSC1	09CL2C-C24	RELAY-LATCH DPDT 24V 2-COIL	LOW VOLT BOX
CLC	LATCH-COELD LOADED	WCG1CLSB1	09CL2C-C24	RELAY-LATCH DPDT 24V 2-COIL	LOW VOLT BOX
CLC	LATCH-COELD LOADED	WCG1CLSC1	09CL2C-C24	RELAY-LATCH DPDT 24V 2-COIL	LOW VOLT BOX
CP	<b>&gt;&gt;PHOTOEYE</b>				
CPLD	PHOTOEYE-LOAD END	WCG1CLSB1	09RE004	SENSOR DARK OPERATE AC N/O-OUT	END OF BELT
CPRD	PHOTOEYE-DISCHARGE END	WCG1CLSB1	09RE004	SENSOR DARK OPERATE AC N/O-OUT	END OF BELT
CR	<b>&gt;&gt;RELAY-CONTROL</b>				
CRAM	RELAY-MANUAL DESIRED	WCG1CLSC1	09C024D24	RELAY 4PDT DIFGLD 14PIN 24V	LOW VOLT BOX
CRAMA	RELAY=MANUAL DESIRED	WCG1CLSC1	09C024D24	RELAY 4PDT DIFGLD 14PIN 24V	LOW VOLT BOX
CRB	RELAY-COELD LOADING	WCG1CLSB1	09C024D24	RELAY 4PDT DIFGLD 14PIN 24V	LOW VOLT BOX
CRBF	RELAY-RUN BELT FORWARD	WCG1CLSB1	09C024D24	RELAY 4PDT DIFGLD 14PIN 24V	LOW VOLT BOX
CRBL	RELAY COELD LOADING	WCG1CLSB1	09C024D24	RELAY-LATCH DPDT 24V 2-COIL	LOW VOLT BOX
CRBR	RELAY-RUN BELT REVERSE	WCG1CLSB1	09C024D24	RELAY 4PDT DIFGLD 14PIN 24V	LOW VOLT BOX
CRCTAR	RELAY-TARE	W6WTC5LC	09C024D37	4PDT MINITURE RELAY PT W/LED	WT CNTRL BX
CRCWH	RELAY WEIGHT IS HIGH	W6WTC5LC	09C024D37	4PDT MINITURE RELAY PT W/LED	WT CNTRL BX
CRCWL	RELAY-WEIGHT IS LOW	W6WTC5LC	09C024D37	4PDT MINITURE RELAY PT W/LED	WT CNTRL BX
CRCWO	RELAY-WEIGHT IS O.K.	W6WTC5LC	09C024D37	4PDT MINITURE RELAY PT W/LED	WT CNTRL BX
CRD	RELAY-DISCHARGE END	WCG1CLSB1	09C024D24	RELAY 4PDT DIFGLD 14PIN 24V	LOW VOLT BOX
CRDA	RELAY-DISCHARGE END	WCG1CLSB1	09C024D24	RELAY 4PDT DIFGLD 14PIN 24V	LOW VOLT BOX

# COMPONENT PARTS LIST

WCG1CTPL/2014374N

<u>COMPONENT NUMBER</u>	<u>FUNCTION OF THIS COMPONENT</u>	<u>WHERE TO FIND THIS COMPONENT</u>	<u>MILNOR P/N</u>	<u>DESCRIPTION</u>	<u>LOCATION</u>
CRDH	RELAY-COELED AT DISCHARGE HEIGHT	WCG1CLSC1	09C024D24	RELAY 4PDT DIFGLD 14PIN 24V	LOW VOLT BOX
CRDN	RELAY-COELED DOWN	WCG1CLSC1	09C024D24	RELAY 4PDT DIFGLD 14PIN 24V	LOW VOLT BOX
CRDNS	RELAY-COELED DOWN	WCG1CLSB1	09C024D24	RELAY 4PDT DIFGLD 14PIN 24V	LOW VOLT BOX
CRFE	RELAY-COELED FULLY EXTENDED	WCG1CLSC1	09C024D24	RELAY 4PDT DIFGLD 14PIN 24V	LOW VOLT BOX
CRFR	RELAY-COELED FULLY RETRACTED	WCG1CLSC1	09C024D24	RELAY 4PDT DIFGLD 14PIN 24V	LOW VOLT BOX
CRLDX	RELAY-DRYER LOAD DOOR EOEN	WCG1CLSC1	09C024D24	RELAY 4PDT DIFGLD 14PIN 24V	LOW VOLT BOX
CRLH	RELAY-COELED AT LOAD HEIGHT	WCG1CLSB1	09C024D24	RELAY 4PDT DIFGLD 14PIN 24V	LOW VOLT BOX
CRLL	RELAY-LOAD END PHOTOEYE BLOCKED	WCG1CLSB1	09C024D24	RELAY 4PDT DIFGLD 14PIN 24V	LOW VOLT BOX
CRS+	RELAY-3-WIRE	WCG1CLSB1	09C024D24	RELAY 4PDT DIFGLD 14PIN 24V	LOW VOLT BOX
CRUP	RELAY-COELED UP	WCG1CLSC1	09C024D24	RELAY 4PDT DIFGLD 14PIN 24V	LOW VOLT BOX
CS	>>CONTACTORS				
CSB	CONTACTOR-RUN BELT FORWARD+REV	WCG1CLSA1	09MR04B337	12A 3P REV+2N/C 120V5/6 IEC	HIGH VOLT BX
CSB	CONTACTOR-FORWARD/REVERSE BELT	WCG1CLSE	09MR08B337	12A 3P REV+2N/C 120V5/6 IEC	HIGH VOLT BX
CSX	CONTACTOR-UP/DOWN BELT	WCG1CLSA1	09MR04B337	12A 3P REV+2N/C 120V5/6 IEC	HIGH VOLT BX
CSX	CONTACTOR-UP/DOWN BELT	WCG1CLSE	09MR08B337	12A 3P REV+2N/C 120V5/6 IEC	HIGH VOLT BX
EB	>>BUZZER-LIGHT				
EBSG	BUZZER-OPERATOR SIGNAL	WCG1CLSA1	09H015	BUZZ:115V W/6-32 CTR+6"LEADS	HIGHT VOLT BX
EF	>>FUSES				
EF24	FUSE-24VOLT CONTROL CIRCUIT	WCG1CLSA1	09FF006AMA	XFMR 120-240,110-220/24V 150VA	HIGH VOLT BX
EF37	FUSE-120VOLT CONTROL CIRCUIT	WCG1CLSA	09FF004AHG	XFMR 200-240 PRI/120SEC 250VA	HIGH VOLT BX
EL	>>LIGHT-PILOT				
ELCTR	LIGHT-TARE	W6WTCSLC	09J080C12	LIGHTHEAD, LED, 4" ROUND CLEAR - PAR 36	LIGHT BOX
ELCWA	LIGHT-WEIGHT IS HIGH	W6WTCSLC	09J080R12	LIGHTHEAD, LED, 4" ROUND RED - PAR 36	LIGHT BOX
ELCWL	LIGHT-WEIGHT IS LOW	W6WTCSLC	09J080A12	LIGHTHEAD, LED, 4" ROUND AMBER - PAR 36	LIGHT BOX
ELCWO	LIGHT-WHEIGH IS O.K.	W6WTCSLC	09J080B12	LIGHTHEAD, LED, 4" ROUND BLUE - PAR 36	LIGHT BOX
ELD	LIGHT-BELT LOADED	WCG1CLSB	09J060A24	LAMP 1/2" AMB IDI #1090QC3-28V	SWITCH PANEL
ELS+	LIGHT-3-WIRE ON	WCG1CLSB	09J060G24	LAMP 1/2" GRN 28V IDI#1090QC5	SWITCH PANEL
ELSG	LIGHT-OPERATOR SIGNAL	WCG1CLSA	09J060WH37	LAMP 1/2" WHITE 120V TAB	SWITCH PANEL
EM	>>EMERGENCY STOP SWITCH				
EMSR1	SWITCH-EMERGENCY STOP LEFT	WCG1CLSA	09N505	SW ASSY EMER STOP	SIDE OF COELD
EMSR2	SWITCH-EMERGENCY STOP RIGHT	WCG1CLSA	09N505	SW ASSY EMER STOP	SIDE OF COELD
ESPS	POWER SUPPLY -120 TO +12,-12 AND 5V	W6WTCBSW1	08PSS3401T	40 WATT POWER SUPPLY TESTED	WT CNTRL BX
ET	>>OVERLOAD				

# COMPONENT PARTS LIST

<u>COMPONENT NUMBER</u>	<u>FUNCTION OF THIS COMPONENT</u>	<u>WHERE TO FIND THIS COMPONENT</u>	<u>MILNOR P/N</u>	<u>DESCRIPTION</u>	<u>LOCATION</u>
ETB	OVERLOAD-FORWARD/REVERSE BELT	WCG1CLSE	09F025SA	0L RELAY 3P SZ1 SQD #9065-SEO5	HIGH VOLT BX
ETH	OVERLOAD-UP/DOWN BELT	WCG1CLSE	09F025SA	0L RELAY 3P SZ1 SQD #9065-SEO5	HIGH VOLT BX
EX	>>TRANSFORMER				
EX24	TRANSFORMER-120V TO 24VAC	WCG1CLSF	09U027AB24	XFMR 120-240, 110-220/24V 150VA	HIGH VOLT BX
EX37-1	TRANSFORMER-200-240V TO 120VAC	WCG1CLSF	09U249AA37	XFMR 200-240 PRI/120SEC 250VA	HIGH VOLT BX
EX37-1	TRANSFORMER-200-240V TO 120VAC	W6WTCSLV	09U249AA37	XFMR 200-240 PRI/120SEC 250VA	WT CNTRL BX
EX37-2	TRANSFORMER-380-480V TO 120VAC	WCG1CLSF	09U200AAB	XFMR 380-480V/240-120V 250VA	HIGH VOLT BX
EX37-2	TRANSFORMER-380-480V TO 120VAC	W6WTCSLV	09UA025AAB	XFMR 380-480PRI/120-240SEC250V	WT CNTRL BX
EX37-3	TRANSFORMER-380-480V TO 120VAC	WCG1CLSF	09U251AB37	XFMR 600V/PRI/120VSC-250VA-3%RE	HIGH VOLT BX
EX37-3	TRANSFORMER-380-480V TO 120VAC	W6WTCSLV	09U251AB37	XFMR 600V/PRI/120VSC-250VA-3%RE	WT CNTRL BX
PSCL	POWER SUPPLY 12VDC	W6WTCSLC	08PSS2125T	PWRSP 25W 5/12OUT 85-264VAC/IN	WT CNTRL BX
SH	>>SWITCH-HAND OPERATED				
SH1	SWITCH-AUTO/MANUAL	WCG1CLSB	09N405M240	SWASS N2W 4NO	SWITCH PANEL
SHAM	SWITCH-AUTO/MANUAL	WCG1CLSB	09N405M240	SWASS N2W 4NO	SWITCH PANEL
SHAM	SWITCH-AUTO/MANUAL	WCG1CLSC	09N405M240	SWASS N2W 4NO	SWITCH PANEL
SHBL	SWITCH-BELT IS LOADED	WCG1CLSB	09N405PB10	SWASS PBBK 1NO	SWITCH PANEL
SHER	SWITCH-EXTEND/RETRACT	WCG1CLSC	09N405M320	SWASS M3W 2NO	SWITCH PANEL
SHFR	SWITCH-FORWARD/REVERSE	WCG1CLSB	09N405M320	SWASS M3W 2NO	SWITCH PANEL
SHKP	KEYPAD-12 BUTTON	W6WTCSKP	08ND0206N	KEYPAD-DOME-2X6 MATRIX NUME	WT CNTRL BX
SHS+	SWITCH-START	WCG1CLSB	09N405PG10	SWASS PBGN 1NO	SWITCH PANEL
SHSG	SWITCH-SIGNAL CANCEL	W6WTCBWB1	09N405PY10	SWASS PB YELLOW INO	WT CNTRL BX
SHSMA	SWITCH-MASTER	WCG1CLSA	09N405M220	SWASS M2W 2NO	SWITCH PANEL
SHSMD	SWITCH-MASTER	W6WTCBWB1	09N405M210	SWASS M2W 1NO	WT CNTRL BX
SHSO	SWITCH-STOP	WCG1CLSB	09N405PR01	SWASS PBRD 1NC	SWITCH PANEL
SHTAR	SWITCH-MANUAL TARE	W6WTCBWB1	09N405PB11	SWASS PBBK 1NO/1NC	WT CNTRL BX
SHUD	SWITCH-UP/DOWN	WCG1CLSC	09N405M320	SWASS M3W 2NO	SWITCH PANEL
SKPR	KEY SWITCH-PROGRAMMING	W6WTCBWB1	09N127C	KEYSW SPST 7A120VAC SCREW TERM	WT CNTRL BX
SM	>>SWITCH-MECHANICAL				
SMB1	SWITCH-BUMP BELT FRWRD WHEN LOAD	WCG1CLSA	09R012STDG	82026# * 09R012 +MOUNTING HDWRE+INST	SIDE OF BELT
SMB2	SWITCH-BUMP BELT FRWRD WHEN LOAD	WCG1CLSA	09R012STDG	82026# * 09R012 +MOUNTING HDWRE+INST	SIDE OF BELT
SMDH	SWITCH-COELD AT DISCHARGE	WCG1CLSC	09RM01412S	CAPSW 12ROTARY ACTUATE SILVER	SIDE OF BELT
SMDN	SWITCH-DOWN LIMIT	WCG1CLSC	09RM01412S	CAPSW 12ROTARY ACTUATE SILVER	SIDE OF BELT
SMFE	SWITCH-FULLY EXTENDED	WCG1CLSC	09RM01412S	CAPSW 12ROTARY ACTUATE SILVER	SIDE OF BELT

# COMPONENT PARTS LIST

<u>COMPONENT NUMBER</u>	<u>FUNCTION OF THIS COMPONENT</u>	<u>WHERE TO FIND THIS COMPONENT</u>	<u>MILNOR P/N</u>	<u>DESCRIPTION</u>	<u>LOCATION</u>
SMFR	SWITCH-FULLY RETRACTED	WCG1CLSC	09RM01412S	CAPSW 12"ROTARY ACTUATE SILVER	SIDE OF BELT
SMLH	SWITCH-COELD AT LOAD HEIGHT	WCG1CLSB	09RM01412S	CAPSW 12"ROTARY ACTUATE SILVER	SIDE OF BELT
SMUP	SWITCH-UP LIMIT	WCG1CLSC	09RM01412S	CAPSW 12"ROTARY ACTUATE SILVER	SIDE OF BELT
VE	>>VALVE				
VEEX	VALVE-EXTEND BELT	WCG1CLSC	96R301A24	1/8" AIRPILOT 3W NC 24V50/60	VALVE BOX
VERT	VALVE-RETRACT BELT	WCG1CLSC	96R302A24	1/8" AIRPILOT 3W NC 24V50/60	VALVE BOX



## **PELLERIN MILNOR CORPORATION LIMITED STANDARD WARRANTY**

We warrant to the original purchaser that MILNOR machines including electronic hardware/software (hereafter referred to as "equipment"), will be free from defects in material and workmanship for a period of one year from the date of shipment (unless the time period is specifically extended for certain parts pursuant to a specific MILNOR published extended warranty) from our factory with no operating hour limitation. This warranty is contingent upon the equipment being installed, operated and serviced as specified in the operating manual supplied with the equipment, and operated under normal conditions by competent operators.

Providing we receive written notification of a warranted defect within 30 days of its discovery, we will at our option repair or replace the defective part or parts, FOB our factory. We retain the right to require inspection of the parts claimed defective in our factory prior to repairing or replacing same. We will not be responsible, or in any way liable, for unauthorized repairs or service to our equipment, and this warranty shall be void if the equipment is tampered with, modified, or abused, used for purposes not intended in the design and construction of the machine, or is repaired or altered in any way without MILNOR's written consent.

Parts damaged by exposure to weather, to aggressive water, or to chemical attack are not covered by this warranty. For parts which require routine replacement due to normal wear such as gaskets, contact points, brake and clutch linings, belts, hoses, and similar parts the warranty time period is 90 days.

We reserve the right to make changes in the design and/or construction of our equipment (including purchased components) without obligation to change any equipment previously supplied.

ANY SALE OR FURNISHING OF ANY EQUIPMENT BY MILNOR IS MADE ONLY UPON THE EXPRESS UNDERSTANDING THAT MILNOR MAKES NO EXPRESSED OR IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR ANY PARTICULAR USE OR PURPOSE OR ANY OTHER WARRANTY IMPLIED BY LAW INCLUDING BUT NOT LIMITED TO REDHIBITION. MILNOR WILL NOT BE RESPONSIBLE FOR ANY COSTS OR DAMAGES ACTUALLY INCURRED OR REQUIRED AS A RESULT OF: THE FAILURE OF ANY OTHER PERSON OR ENTITY TO PERFORM ITS RESPONSIBILITIES, FIRE OR OTHER HAZARD, ACCIDENT, IMPROPER STORAGE, MIS-USE, NEGLIGENCE, POWER OR ENVIRONMENTAL CONTROL MALFUNCTIONS, DAMAGE FROM LIQUIDS, OR ANY OTHER CAUSE BEYOND THE NORMAL RANGE OF USE. REGARDLESS OF HOW CAUSED, IN NO EVENT SHALL MILNOR BE LIABLE FOR SPECIAL, INDIRECT, PUNITIVE, LIQUIDATED, OR CONSEQUENTIAL COSTS OR DAMAGES, OR ANY COSTS OR DAMAGES WHATSOEVER WHICH EXCEED THE PRICE PAID TO MILNOR FOR THE EQUIPMENT IT SELLS OR FURNISHES.

THE PROVISIONS ON THIS PAGE REPRESENT THE ONLY WARRANTY FROM MILNOR AND NO OTHER WARRANTY OR CONDITIONS, STATUTORY OR OTHERWISE, SHALL BE IMPLIED.

WE NEITHER ASSUME, NOR AUTHORIZE ANY EMPLOYEE OR OTHER PERSON TO ASSUME FOR US, ANY OTHER RESPONSIBILITY AND/OR LIABILITY IN CONNECTION WITH THE SALE OR FURNISHING OF OUR EQUIPMENT TO ANY BUYER.

## How to Get the Necessary Repair Components



This document uses Simplified Technical English.

Learn more at <http://www.asd-ste100.org>.

You can get components to repair your machine from the approved supplier where you got this machine. Your supplier will usually have the necessary components in stock. You can also get components from the Milnor® factory.

Tell the supplier the machine model and serial number and this data for each necessary component:

- The component number from this manual
- The component name if known
- The necessary quantity
- The necessary transportation requirements
- If the component is an electrical component, give the schematic number if known.
- If the component is a motor or an electrical control, give the nameplate data from the used component.

To write to the Milnor factory:

Pellerin Milnor Corporation  
Post Office Box 400  
Kenner, LA 70063-0400  
UNITED STATES

Telephone: 504-467-2787  
Fax: 504-469-9777  
Email: [parts@milnor.com](mailto:parts@milnor.com)

— End of BIUUUD19 —

BIUUUK01 (Published) Book specs- Dates: 20130308 / 20130308 / 20130308 Lang: ENG01 Applic: PCR UUU

## How to Use Milnor® Electrical Schematic Diagrams

Milnor® electrical schematic manuals contain a table of contents/component list and a set of schematic drawings. These documents are cross referenced and must be used together.

The table of contents/components list shows, for every component on every schematic in the manual, the component item number (explained in detail below), statement of function, parent schematic number, part number, description and electric box location. In older manuals, two component lists are provided: List 1 sorts the components by function, and List 2 by type of component. Newer schematic manuals include only the list sorted by component number.

The schematic drawings use symbols for each electromechanical component, and indicate the function of each. Integrated circuits are not shown, but the function of each microprocessor input and output is stated. Certain electrical components not pertinent to circuit logic, such as wire connectors, are not represented on the schematic.

Most machines require several schematics to describe the complete control system and all the options available on the included models. In most manuals there are some schematic pages that don't apply to your specific machine because certain options and configurations are mutually exclusive or are not necessary in all markets. You may find it helpful to mark or remove such pages. A schematic page that only applies to a subset of machines will normally state, in the title, which models and/or options it covers. Compare this with the nameplate on your machine and with your purchase records.

Each schematic is devoted to circuits with common functions (e.g., microprocessor inputs, motor contactors). Schematics appear in the manual in alphanumeric order.

### 1. Component Prefix Classifications and Descriptions

Component item numbers consist of up to six characters and appear as part of a component's symbol on the schematic. The first two characters indicate the general class of component, and the remaining characters are a mnemonic for the function. For example, "CD" is the code for all time delay relays, and "SR" stands for safety reset. Thus, CDSR is a time delay relay that serves as a safety reset.

The following are descriptions of electrical components used in Milnor® machines. Descriptions are in alphabetical order by the component class code (two character prefix).

**Note 1:** Some component class codes do not have a corresponding symbol, but are represented by a box and an accompanying note describing the component. Examples of such codes are BA (printed circuit board), ED (electronic display), and ES (electronic power supply).

**BA=Printed Circuit Board**—Insulating substrate on which a thin pattern of copper conductors has been formed to connect discrete electronic components also mounted on the board.


**CB=Circuit Breaker (Figure 1)**—Automatic switch that opens an electric circuit in abnormal current conditions (e.g., an overload).

**Figure 1: Circuit Breaker (CB)**




**CD=Control, Time Delay Relay (Figure 2)**—A relay whose contacts switch only after a fixed or adjustable delay, once voltage has been applied to its coil. The contacts switch back to normal (de-energized state) immediately when the voltage is removed.

**Figure 2: Time Delay Relay (CD)**




**CL=Control, Latch Relay (Figure 3)**—A relay which latches in an energized or set position when operated by one coil (the latch/set coil). The relay stays latched even though coil voltage is removed. The relay releases or unlatches when voltage is applied to a second coil (the unlatch/reset coil).

**Figure 3: Latch Relay (CL)**




**CR=Control, Relay (Figure 4)**—A relay whose contacts switch immediately when voltage is applied to its coil and revert to normal when the voltage is removed.

**Figure 4: Standard Relay (CR)**




**CP=Control, Photo-Eye (Figure 5)**—Photo-eyes sense the presence of an object without direct physical contact. Photo-eyes consist of a transmitter, receiver, and output module. These components may be housed in one assembly with the transmitter bouncing light off of a reflector to the receiver, or these components can be housed in two separate assemblies with the transmitter pointed directly at the receiver. The photo-eye can be set to turn on its output either when the light beam becomes blocked (dark operate) or when it becomes un-blocked (light operate).

Figure 5: Photo-eye (CP)



**CS=Control, Contactor/Motor Starter (Figure 6)**—A relay capable of handling heavier electrical loads, usually a motor.

Figure 6: Other Control Symbols



**EB=Electric Buzzer (Figure 6)**—An audible signaling device.

**EC=Electric Clutch (Figure 6)**—A clutch consists of a coil and a rotor. The rotor has two separate rotating plates. These plates are free to rotate independent of each other until the coil is energized. Once energized the two plates turn as one.

**ED=Electronic Display**—A visual presentation of data, such as an LCD (liquid crystal display), LED (light emitting diode) display, or VFD (vacuum florescent display).

**EF=Electric Fuse (Figure 6)**—A fuse is an over-current safety device with a circuit opening fusible member which is heated and severed by the passage of over-current through it.


**EL=Electric Light (Figure 6)**—Indicator lights may be either incandescent or fluorescent.

**EM=Electro Magnet Solenoid**—A device consisting of a core surrounded by a wire coil through which an electric current is passed. While current is flowing, iron is attracted to the core (e.g., a pinch tube drain valve solenoid).

**ES=Electronic Power Supply**—A device that converts AC (alternating current) to filtered and regulated DC (direct current). The input voltage to the power supply is usually 120 or 240 VAC. The output is +5, +12, and -12 VDC.

**ET=Thermal Overload (Figure 7)**—A safety device designed to protect a motor. A thermal overload consists of an overload block, heaters, and an auxiliary contact. The auxiliary contact is normally installed in a safety (three-wire) circuit that stops power to the motor contactor coil when a motor overload occurs.

Figure 7: Thermal Overload (ET)

Schematic Symbol	Legend
	<p>A. Heater (one per phase)</p> <p>B. Overload relay; contacts open if overload condition exists</p>

**EX=Electrical Transformer (Figure 8)**—A device that transfers electrical energy from one isolated circuit to another, often raising or lowering the voltage in the process.

**KB=Keyboard**—Device similar to a typewriter for making entries to a computer.


**MN=Electronic Monitor (CRT)**—A cathode ray tube used for visual presentation of data.

**MR=Motors (Figure 9)**—Electromechanical device that converts electrical energy into mechanical energy.

Figure 8: Transformer (EX)



Figure 9: Electric Motor (MR)




**MV=Motor (Variable Speed) Inverter**—To vary the speed of an AC motor, the volts to frequency ratio must be kept constant. The motor will overheat if this ratio is not maintained. The motor variable speed inverter converts three phase AC to DC. The inverter then uses this DC voltage to generate AC at the proper voltage and frequency for the commanded speed.

**Note 2:** Switch symbols used in the schematics and described below always depict the switch in its un-actuated state.

**PX=Proximity Switch (Figure 10)**—A device which reacts to the proximity of a target without physical contact or connection. The actuator or target causes a change in the inductance of the proximity switch which causes the switch to operate. Proximity switches can be two-wire (AC) or three-wire (DC) devices.

Figure 10: Proximity Switches (PX)



**SC=Switch, Cam Operated (Figure 11)**—A switch in which the electrical contacts are opened and/or closed by the mechanical action of a cam(s). Applications include 35-50 pound timer operated machines, Autospot, timer reversing motor assembly, and some balancing systems.

**SH=Switch, Hand Operated (Figure 12)**—A switch that is manually operated (e.g., *Start button*, *Master switch*, etc.).

Figure 11: Cam Switch (SC)





Figure 12: Hand Operated Switch (SH)



**SK=Switch, Key Lock (Figure 13)**—A switch that requires a key to operate. This prevents unauthorized personnel from gaining access to certain functions (e.g., the *Program menu*).

**SL=Switch, Level Operated (Figure 14)**—A switch connected to a float that causes the switch to open and close as the level changes.

Figure 13: Key Switch (SK)





Figure 14: Level Switch (SL)



**SM=Switch, Mechanically Operated (Figure 15)**—A switch that is mechanically operated by a part of or the motion of the machine (e.g., door closed switch, tilt limit switches, etc.)

**SP=Switch, Pressure Operated (Figure 16)**—A switch in which a diaphragm presses against a switch actuator.

Figure 15: Mechanical Switch (SM)





Figure 16: Pressure Switch (SP)



**ST=Switch, Temperature Operated (Figure 17)**—A switch that is actuated at a preset temperature (e.g., dryer safety probes) or has adjustable set points (e.g., Motometers or Combistats).

**TB=Terminal Board (Figure 18)**—A strip or block for attaching or terminating wires.

Figure 17: Temperature Switch (ST)




Figure 18: Terminal Board (TB)



**VE=Valve, Electric Operated (Figure 19)**—A valve operated by an electric coil to control the flow of fluid. The fluid can be air, water or hydraulic.

Figure 19: Electrically Operated Valve (VE)



**ZF=Rectifier (Figure 20)**—A solid state device that converts alternating current to direct current.



Figure 20: Bridge Rectifier (ZF)





Figure 21: Bridge Rectifier



**WC=Wiring Connector**—A coupling device for joining two cables or connecting a cable to an electronic circuit or piece of equipment. Connectors are male or female, according to whether they plug into or receive the mating connector.


## 2. Component Terminal Numbering



**CAUTION 1: Risk of Mis-wiring**—Due to electrical component manufacturing inconsistencies, the pin numbers imprinted on components such as connectors and relay bases used on Milnor machines often do not correspond to the pin numbers shown in the schematics.

- Ignore pin numbers imprinted on in-line connectors (e.g., Molex connectors) and relay bases.
- Use the pin identification illustrations herein to identify pins on these components.

Figure 22: Plug-in Relays



**Note 3:** Relay functional names ending with the letter "M" (e.g., CRxxM) are not discrete components but are a component of a printed circuit board. They are usually not individually replaceable.

**Figure 23: AMP Connector Pin Locations**






Figure 24: Molex Connector Pin Locations




Figure 25: Pressure Switch




Figure 26: Toggle Switch





Figure 27: Switch with Replaceable Contact Blocks



### 3. Features of Milnor® Electrical Schematic Diagrams

Document BMP010012 (following this section) is a sample schematic, based on a schematic diagram for the Milnor® gas dryer. For the purposes of this exercise, the schematic is shown gray and explanations of the items on the schematic are shown black.

The item numbers below correspond to the circled item numbers shown on the drawing.

1. The first six characters of the drawing number (W6DRYG) indicate that this is a wiring diagram (W), identify the generation of controls (6), and identify the type of machine (DRYG=Gas Dryer). These characters appear in the drawing number of every schematic in the set.

The characters following the first six are unique to each drawing. The two characters identified as the page number are an abbreviation for the function performed by the depicted

circuitry (S+=three-wire circuit) and establish the order in which the schematic occurs in the manual (schematics are arranged in alpha-numeric order in the manual).

Whenever circuitry changes are significant enough to warrant publishing a new schematic drawing, the new drawing number will be the same as the old except for the major revision letter (A in the example).

2. Included in the drawing title are the class of control system, the title of this circuit, and the circuit voltage.
3. Line numbers are provided along the bottom edge of the drawing. These permit service personnel in the field and at the Milnor® factory to quickly relate circuit locations when discussing troubleshooting over the phone. Page and line numbers are referenced on the drawing as explained in items five and six below.
4. Relay contacts show the page and line number on which the relay coil may be found. This is the type of cross referencing most frequently used in troubleshooting.
5. Relay coils show the page and line number on which its associated contacts are located.
6. Relay contacts and relay coils show the physical location of the relay.
7. The designation MTA applies to electronic circuit board connections. Typically, a control system will contain several different types of circuit boards and one or more boards of each type. A numerical suffix identifies the board type and a numerical prefix identifies which one of several boards of a given type is being depicted. For example, the designation 1MTA5 identifies this as the first I/O board (8 output, 16 input board) in the control system. As shown on the drawing, a pin number follows the board number, separated by a dash. Thus, 1MTA5-9 is pin 9 on this board. The numerical designations for board types vary from one control system to another. Some of the board types commonly encountered on the Mark V and Mark VI washer-extractor control and their designations are as follows:
  - MTM1-MTM8 = Mother board
  - MTA1-MTA5 = 8 output, 16 input (8/16) boards
  - MTA11-MTA14 = 24 output boards
  - MTA30-MTA40 = processor boards
  - MTA41-MTA43 = digital to analog (D/A) boards
  - MTA51-MTA55 = analog to digital (A/D) boards
  - MTA81-MTA85 = balance A-D board

The complete listing of the boards utilized in a given control system can be found in the component list for that system.

8. Wire numbers, as described earlier in this section, are shown at appropriate locations on the schematic drawing.
9. Where diamond symbols appear at the end of a conductor, these are match points for continuing the schematic on another drawing. The page and line number that continues the circuit is printed adjacent to the diamond symbol. Where more than one match point appears on the referenced page, match diamonds containing corresponding letters.

— End of BIUUUK01 —

This page intentionally left blank.









FIGURE	ELECTRICAL VALUES	SUFFIXES							
		B		H		M		T	
		50HZ	60HZ	50HZ	60HZ	50HZ	60HZ	50HZ	60HZ
A	1,000	208	230			200	220	220	240
B	$\sqrt{3}$			208	240	346	380	380	
C	2,000	416	460	220	240	400	440	440	480
D	$1 + \sqrt{3}$						600		
E	$2\sqrt{3}$			380					




06 07 08 09 10 11 12 13 14 15 16 17

# BMP850029

## MOTOR CONNECTION DIAGRAMS

THREE PHASE SINGLE SPEED MOTORS WITH MULTIPLE VOLTAGE RATINGS  
(ONLY FOR MOTOR SUFFIXES LISTED)


PELLERIN MILNOR CORPORATION




# W80008

THREE PHASE  
MOTOR CONNECTION DIAGRAMS  
SINGLE SPEED MOTORS WITH MULTIPLE VOLTAGE RATINGS  
PELLERIN MILNOR CORPORATION

W80008  
2001253A





# WCG1CLSA1


## COELDS EXTEND AND RETRACT (SINGLE CAKE AND SINGLE CHARGE)

### SCHEMATIC: COELDS CONTACTS


#### NON DEMAC HOIST

PELLERIN MILNOR CORPORATION







**WINSFDRLSA**  
WC1CLSA MODIFIED FOR FDR SERVICES DEMAG HOIST  
COELDS EXTEND AND RETRACT (SINGLE CAKE AND SINGLE CHARGE)  
**SCHEMATIC: COELDS CONTACTS**  
PELLERIN MILNOR CORPORATION







SC04	SC03	SC12	SA06	SA15	SA07	SD04
		SD04	SA14	SC18	SB10	SD06
		SB09				SC06





SC04  
SC07

SB09  
SC14

SC14

WCG1CLSC1  
2014455B




**WCG1CLSC1**  
COELD (SINGLE CAKE AND SINGLE CHARGE)  
SCHEMATIC: COELD 3-WIRE. LOAD &  
DISCHARGE PHOTOEYES  
PELLERIN MILNOR CORPORATION

#### NOTES:

1. NOT USED
2. REMOVE JUMPER J1 (LINE 02) AND J2 (LINE 04) WHEN LOADING AUTOMATICALLY WIRE ALLIED CONTACTS FROM LOADING DEVICE TO SAY THAT IT HAS O.K. TO DO UP OR DOWN.
3. A N.O. DRY CONTACT RATED 5 AMPS, 125 VOLTS, MUST BE SUPPLIED BY ALLIED DEVICE TO TELL COELD IT CAN UNLOAD (TBA7-1BB8) SEE WCG1CLSC LINE 11

WCG1CLSC1  
2014455B



NOTES:


1. CONTACTS BETWEEN TBC1 AND TBC2 TELL ALLIED DEVICE THAT COELDS CAN TAKE A LOAD.
2. CONTACTS FROM TBA3 TO TBA4 TELL ALLIED DEVICE COELDS IT IS READY TO DISCHARGE.
3. CONTACTS FROM TBA5 TO TBA6 TELL ALLIED DEVICE COELDS HAS FINISHED DISCHARGING.

<p>SYSTEM OPERATION</p>
<p>COELDS SINGLE CAKE</p>
<p>1. COELDS CAN BE OPERATED TO LOAD EITHER MANUALLY OR AUTOMATICALLY</p> <p>A. <u>MANUAL LOADING OPERATION.</u></p> <ol style="list-style-type: none"> <li>1. COELDS IS FULLY RETRACTED</li> <li>2. PLACE SWITCH SH1 TO "MANUAL LOADING" POSITION</li> <li>3. COELDS AT LOAD HEIGHT</li> <li>4. BUMP THE GOODS WITH BUMP SWITCHES SMB1 OR SMB2 UNTIL THE DISCHARGE END PHOTOEYE IS BLOCKED.</li> <li>5. ENTER THE DATA.</li> <li>6. PUSH THE "BELT IS LOADED" SWITCH SHBL.</li> <li>7. COELDS WILL AUTOMATICALLY LIFT TO THE DISCHARGE HEIGHT.</li> <li>8. WHEN ALLIED DEVICE ALLOWS TO BE LOADED, COELDS WILL EXTEND AND AND RUN BELT CLEAR TIME.</li> <li>9. COELDS WILL RETRACT AND RETURN TO LOAD POSITION.</li> </ol>
<p>COELDS SINGLE CHARGE</p>
<p>1. COELDS CAN BE OPERATED TO LOAD EITHER MANUALLY OR AUTOMATICALLY</p> <p>A. <u>MANUAL LOADING OPERATION.</u></p> <ol style="list-style-type: none"> <li>1. COELDS IS FULLY RETRACTED</li> <li>2. PLACE SWITCH SH1 TO "MANUAL LOADING" POSITION</li> <li>3. COELDS AT LOAD HEIGHT</li> <li>4. BELT WILL MOVE FORWARD ANYTIME LOAD END PHOTOEYE IS BLOCKED WILL STOP AS SOON AS LOAD END PHOTOEYE IS CLEAR.</li> <li>5. BELT WILL NOT RUN WHEN DISCHARGE END PHOTOEYE IS BLOCKED.</li> <li>6. ENTER THE DATA.</li> <li>7. GOODS MUST BLOCK DISCHARGE END PHOTOEYE BEFORE "BELT IS LOADED". SWITCH SHBL CAN BE ENABLED.</li> <li>8. COELDS WILL AUTOMATICALLY LIFT TO THE DISCHARGE HEIGHT.</li> <li>9. WHEN ALLIED DEVICE ALLOWS TO BE LOADED, COELDS WILL EXTEND AND BELT CLEAR TIME.</li> <li>10. COELDS WILL RETRACT AND RETURN TO LOAD POSITION.</li> </ol>

- EQUIPMENT DEFINITIONS
1. COELDS SINGLE CAKE LOADS ONE CAKE. CONFIGURATION 1-1-1
  2. COELDS SINGLE CHARGE LOADS MULTIPLE CAKES OR CONTINUOUS GOODS CONFIGURATION 1-X-1


WCG1CLSD1  
2014455B

WCG1CLSD1  
COELDS (SINGLE CAKE AND SINGLE CHARGE)  
SCHEMATIC:ALLIED SIGNALS  
PELLERIN MILNOR CORPORATION




WCG1CLSE  
COELD AND COELD S  
SCHEMATIC: MOTORS + INCOMING VOLTAGE  
PELLERIN MILNOR CORPORATION

# CONTROL CIRCUIT POWER









10 11 12 13 14 15

WCG1CLSF  
 COELD + COELDS  
 SCHEMATIC: SOURCE TO 110V50HZ/120V60HZ  
 CONTROL CIRCUIT POWER  
 PELLERIN MILNOR CORPORATION

WCG1CLSF  
 2011464B

WCG1CLSF  
 2011464B



00

01

02

03

04

05

06

07

08

09

10

ALLIED INTERFACE BOARD #1

ALLIED RELAY ASSIGNMENTS

CRA = WEIGHT = .15  
CRB = WEIGHT = .2  
CRC = WEIGHT = .4  
CRD = WEIGHT = .8  
CRE = WEIGHT = 1.6  
CRF = WEIGHT = 3.2  
CRG = WEIGHT = 6.4  
CRH = WEIGHT = 12.8  
CRJ = WEIGHT = 25.8  
CRK = WEIGHT = 51.2  
CRL = WEIGHT = 102.4  
CRM = WEIGHT = 204.8

CRQ = TARE  
CRR = WEIGHT IS HIGH  
CRS = WEIGHT IS OK  
CRT = WEIGHT IS LOW

B024-1


1

SW2

24 OUTPUT BOARD #1  
LOCATED IN RIGHT (MODULE)  
SECTION OF THE MAIN  
CONTROL BOX


1

SW1





11 12 13 14 15 16 17 18 19

W6WTCSAI  
G3 CBW SYSTEM MARK 9  
SCHEMATIC: ALLIED INTERFACE  
PELLERIN MILNOR CORPORATION





00 01 02 03 04 05 06 07 08 09 10



W6WTCSBW1  
MARK 6 WEIGHING CONTROLLER  
SCHEMATIC: BOARD WIRING  
PELLERIN MILNOR CORPORATION

11 12 13 14 15 16 17 18 19





# W6WTC5BW2

## MARK 6 WEIGHTING CONTROLLER

### SCHEMATIC: BOARD WIRING


MARK 6 WEIGHTING CO  
SCHEMATIC: BOARD WIRING

## SCHEMATIC: BOARD WIRING

PELLERIN MILNOR CORPORATION

W6WTCSBW2  
2012242B

W6WICSBWZ  
2012242B



00 01 02 03 04 05 06 07 08 09



W6WTCSKP  
MARK 6 WEIGHING CONTROLLER  
SCHEMATIC:KEYPAD  
PELLERIN MILNOR CORPORATION

W6WTCSKP  
2012242B




# W6WTCSLC

## MARK 6 WEIGHING CONVEYOR

### SCHEMATIC: LOADING LED LIGHTS

PELLERIN MILNOR CORPORATION




#### NOTES:

1. WCL IS LOCATED IN THE CONLO BOX AND THE LIGHT BOX.
2. THE LED CONTROLLER MUST BE SET TO HAVE THE LED CONTINUOUSLY ON TO CYCLE THROUGH ALL THE LED PATTERNS. APPLY +12V TO THE WHITE/VIOLET WIRE FOR LESS THAN 1 SECOND AND RELEASE TO CYCLE FORWARD. APPLY AND RELEASE +12V FOR MORE THAN 1 SECOND TO CYCLE BACKWARDS. WHEN LIGHT IS CONTINUOUSLY ON ALLOW IT TO RUN FOR MORE THAN 5 SECONDS TO SET PATTERN. TO RESET PATTERN TURN POWER OFF AND APPLY +12V TO THE WHITE/VIOLET WIRE WHILE TURNING POWER BACK ON TO LIGHT.

10 11 12 13 14 15 16 17 18 19

# CONTROL CIRCUIT POWER





## **Pellerin Milnor Weighing Controller**

Software Version WUAWS/20004

05NOV14

On power-up, the copyright/software version number is displayed, followed by the configure checksum. When the controller is turned on for the first time the user will be prompted to clear memory. To do this, turn the run/program key switch to the program position and press buttons “4”, “5” and “6” on the keypad simultaneously. Following the clear memory process, the controller automatically enters Configure Mode where the user will be prompted to set the configuration parameters for the weighing controller. Once the configure process is complete, the display shows “Program 0 Menu/Turn Key To Run”. Turn the run/program key switch to the run position and press the “NEXT” button on the keypad to return to Run Mode. If a valid configuration exists, the controller goes directly to Run Mode on power-up following the configure checksum display.

Once configured, the user must set the A/D offset and calibrate the scale. To set the A/D offset, press buttons “1” and “SKIP TO” on the keypad simultaneously to access the Manual Menu. From the Manual Menu, option “3 Set A/D Offset” is used to set the A/D offset. To return to Run Mode, select option “0 Exit Manual Menu” from the Manual Menu. In addition to setting the A/D offset, the Manual Menu can also be used to test the inputs and outputs on the machine, and to view the calibration values.

Once the A/D offset has been set, it is necessary to calibrate the scale. From the Run Mode, turn the run/program key switch to the program position to access the Program Menu. From the Program Menu, option “Program 3 Menu/Calibrate Loadcell” is used to calibrate the scale by calibrating each load cell individually. In addition to calibrating the scale, the Program Menu can also be used to clear memory and configure the weighing controller. To return to Run Mode, select option “Program 0 Menu/ OK Turn Key to Run”. Turn the run/program key switch to the run position and press the “NEXT” button on the keypad .

In Run Mode, the display shows the actual weight, as measured by the scale. The desired weight and tolerance are configured by formula in the Mentor controller. The measured weight is passed to the Mentor controller via the output relays in the Weighing Controller. When properly calibrated, the actual weight should read “000” when the scale is empty. The “Manual Tare” button on the control box may be used to manually zero the scale. As the operator loads the scale, the weight indicator lights, controlled by Mentor, signal the load weight status - yellow when the weight is low, red when the weight is high, and blue when the weight is within the configured tolerance. The operator completes the loading process by actuating the “Belt Is Loaded” pushbutton, which makes the “Lock In Weight” input on the Weighing Controller. The loaded weight is locked in, and the display changes to show the output weight as the elevator moves up to the discharge position. After the load has finished discharging, as the elevator moves down to the loading position, the “Lock In Weight” input is reset and the “Get Ready To Tare” input is made on the Weighing Controller, and the message “Get Ready To Tare” appears on the display. At the loading position, the “Get Ready To

Tare” input is reset and the “Start Tare” input is made on the Weighing Controller. Following the tare delay, as set in Configure, the controller automatically re-tares the scale. During the taring process, the message “Tare In Progress” is displayed and the white weight indicator light is illuminated. Once the tare process is complete, the scale is ready to be loaded again. The “Start Tare” input remains made while the elevator is at the loading position.

### **Alternate Displays**

Press and hold button “7” on the keypad, while in Run mode, to view the status of the microprocessor inputs. The ID designations, “A” through “L”, corresponding to the inputs identified in Table 1, below, are presented across the top row, with the respective input status, identified by a “+” or “-“, shown across the bottom row. A “+” character indicates an active (grounded) input; a “-“ character indicates an inactive (open) input.

ID	Input Name
A	---
B	PROGRAM KEY
C	SIGNAL CANCEL
D	---
E	---
F	---
G	---
H	GET READY TO TARE
I	LOCK IN WEIGHT
J	START TARE
K	---
L	---

**Table 1: View Microprocessor Inputs**

Press and hold button “8” on the keypad, while in Run mode, to view the status of the microprocessor outputs on Page 0. Press and hold buttons “8” and “1” on the keypad together to view the status of the microprocessor outputs on Page 1. The ID designations, “a” through “l”, corresponding to the outputs identified in Table 2, below, are presented across the top row, with the respective output status, identified by a “+” or “-“, shown across the bottom row. A “+” character indicates an active (energized) output; a “-“ character indicates an inactive (de-energized) output.

ID	Output Name	
	Page 0	Page 1
a	WEIGHT A	---
b	WEIGHT B	---
c	WEIGHT C	SCALE IS TARING
d	WEIGHT D	WEIGHT HIGH
e	WEIGHT E	WEIGHT OK
f	WEIGHT F	WEIGHT LOW
g	WEIGHT G	---
h	WEIGHT H	---
i	WEIGHT J	---
j	WEIGHT K	---
k	WEIGHT L	---
l	WEIGHT M	---

**Table 2: View Microprocessor Outputs**

Press and hold button “9” on the keypad, while in Run mode, to view the individual weight measurement for each load cell.

## **Program Menu**

To access the Program Menu, turn the run/program key switch to the program position. The Program Menu is used to clear program memory and to set the configuration parameters for the weighing controller. To return to Run Mode, select program menu option “0”, turn the run/program key switch to the run position, then press the “NEXT” button on the keypad.

- |                    |   |
|--------------------|---|
| 0 Turn Key to Run  | Press “0” to display this option. Turn the run/program key switch to the run position, then press “NEXT” to select this option and return to Run Mode.  |
| 1 Clear All Memory | <p>Press “1” to display this option, then press “NEXT” to select this option and access the Clear All Memory feature. Use this option to clear program memory.</p> <p>When the message “Clear Memory Now/Press 4 + 5 + 6” appears on the display, turn the run/program key switch to the program position and press the buttons “4”, “5” and “6” on the keypad simultaneously.</p> <p>Following the clear memory process, the controller automatically enters Configure Mode where the user will be prompted to set the configuration parameters for the machine.</p> |
| 2 Configure        | Press the “2” button on the keypad to display this option, then press the “NEXT” button to select this option and access the Configure feature. Use this option to set the following configuration parameters for the machine. Press “NEXT” to scroll forward. Press “SKIP TO” to scroll backwards. Once the configure process is complete, the display returns to the “Program 0 Menu/Turn Key To Run” option.   |
| Unit Weight        | Press “0” for LB or “1” for KG, then press “NEXT” to enter.   |
| Tare Delay         | Enter a two digit value from 00 to 99 for tare delay, then press “NEXT” to enter. After returning to its loading position, the controller waits for the tare delay to expire before beginning the tare process. This delay allows the scale to settle before sampling the load cell signals.  |



Sample Size	Enter a two digit value from 01 to 99 for sample size, then press “NEXT” to enter. This configuration parameter defines the number of samples from each load cell averaged together to calculate the actual weight value. A larger sample size gives a more stable weight, but a slower response time. A smaller sample size gives a quicker response time, but a less stable weight.
Number of Load Cells	Enter a value from 1 to 4 corresponding to the number of load cells, then press “NEXT” to enter. Each load cell requires its own A/D board for interfacing to the weighing controller.
3 Calibrate Loadcell	<p>Press “3” to display this option, then press “NEXT” to select this option and access the Calibrate Loadcell feature. Use this option to calibrate each load cell.</p> <p>When prompted, enter a value from 1 to 4 corresponding to the load cell being calibrated, then press “NEXT” to proceed. Empty the scale, then press “NEXT” to zero the load cell, or “SKIP TO” to cancel the function.</p> <p>When prompted, enter a three digit value from 000 to 999 corresponding to the calibration weight which will be used to calibrate the load cell, then press “NEXT” to proceed. Position the calibration weight directly over the load cell, then press “NEXT” to calibrate, or “SKIP TO” to cancel the function. The display automatically returns to the Program Menu.</p> <p>Repeat the calibration procedure for each load cell.</p>

## **Manual Menu**

To access the Manual Menu, press buttons “SKIP TO” and “1” on the keypad simultaneously. The Manual Menu is used to test outputs, test inputs, and calibrate the scale. To return to Run Mode, select manual menu option “0”, then press the “NEXT” button on the keypad.

0 Exit Manual Menu	Press “0” to display this option, then press “NEXT” to select this option and return to Run Mode.
1 Test Outputs	Press “1” to display this option, then press “NEXT” to select this option and access the Test Outputs feature. Use this option to manually actuate each available relay output as identified in Table 3, below. Enter a two digit number from 01 to 24, corresponding to the desired output, to access that

output directly. Alternatively, press buttons “SKIP TO” and “4” simultaneously to scroll forward, or buttons “SKIP TO” and “6” simultaneously to scroll backwards. Press “NEXT” to turn the selected output on. Press “SKIP TO” to turn the output off. Enter 00 to display “ABORT OUTPUTS TEST”, then press “NEXT” to select this option and return to the Manual Menu.

Item	Connections		Output Name	Output Function
	Common	Normally Open		
00	n/a	n/a	ABORT OUTPUTS TEST	Return to Manual Menu
01	1MTA13-11	1MTA13-01	WEIGHT A	Signal s binary Weight bit 0 (value = 0.1)
02	1MTA13-12	1MTA13-02	WEIGHT B	Signal s binary Weight bit 1 (value = 0.2)
03	1MTA13-13	1MTA13-03	WEIGHT C	Signal s binary Weight bit 2 (value = 0.4)
04	1MTA13-14	1MTA13-04	WEIGHT D	Signal s binary Weight bit 3 (value = 0.8)
05	1MTA13-15	1MTA13-05	WEIGHT E	Signal s binary Weight bit 4 (value = 1.6)
06	1MTA13-16	1MTA13-06	WEIGHT F	Signal s binary Weight bit 5 (value = 3.2)
07	1MTA13-17	1MTA13-07	WEIGHT G	Signal s binary Weight bit 6 (value = 6.4)
08	1MTA13-18	1MTA13-08	WEIGHT H	Signal s binary Weight bit 7 (value = 12.8)
09	1MTA13-19	1MTA13-09	WEIGHT J	Signal s binary Weight bit 8 (value = 25.6)
10	1MTA14-01	1MTA13-10	WEIGHT K	Signal s binary Weight bit 9 (value = 51.2)
11	1MTA14-02	1MTA14-11	WEIGHT L	Signal s binary Weight bit 10 (value = 102.4)
12	1MTA14-03	1MTA14-12	WEIGHT M	Signal s binary Weight bit 11 (value = 204.8)
13	1MTA14-04	1MTA14-13	OUTPUT 26	Not used
14	1MTA14-04	1MTA14-14	OUTPUT 27	Not used
15	1MTA14-10	1MTA14-05	SCALE I S TARING	Illuminates White weight indicator light
16	1MTA14-10	1MTA14-15	WEIGHT HIGH	Illuminates Red weight indicator light
17	1MTA14-10	1MTA14-06	WEIGHT OK	Illuminates Blue weight indicator light
18	1MTA14-10	1MTA14-16	WEIGHT LOW	Illuminates Amber weight indicator light
19	1MTA14-10	1MTA14-07	OUTPUT 32	Not used
20	1MTA14-10	1MTA14-17	OUTPUT 33	Not used
21	1MTA14-10	1MTA14-08	OUTPUT 34	Not used
22	1MTA14-10	1MTA14-18	OUTPUT 35	Not used
23	1MTA14-10	1MTA14-09	OUTPUT 36	Not used
24	1MTA14-10	1MTA14-19	OUTPUT 37	Not used

**Table 3: Test Microprocessor Outputs**

## 2 Test Inputs

Press “2” to display this option, then press “NEXT” to select this option and access the Test Inputs feature. Use this option to view the status of the microprocessor inputs. The item designations, A through L, corresponding to the inputs identified in Table 4, below, are presented across the top

row, with the respective input status, identified by a “+” or “-“, shown across the bottom row. A “+” character indicates an active (grounded) input; a “-“ character indicates an inactive (open) input. Press “SKIP TO” to return to the Manual Menu.

Item	Connection	Input Name	Input Function
A	1MTA38-3	INPUT 00	Not used
B	1MTA38-2	PROGRAM KEY	Enable programming function
C	1MTA38-1	SIGNAL CANCEL	Reset a fault condition
D	1MTA38-4	INPUT 03	Not used
E	1MTA38-5	INPUT 04	Not used
F	1MTA38-6	INPUT 05	Not used
G	1MTA39-5	INPUT 06	Not used
H	1MTA39-4	GET READY TO TARE	Enable the tare function
I	1MTA39-3	LOCK IN WEIGHT	Read load weight for output
J	1MTA39-8	START TARE	Initiate the tare function
K	1MTA39-7	INPUT 10	Not used
L	1MTA39-6	INPUT 11	Not used

**Table 4: Test Microprocessor Inputs**

### 3 Set A/D Offset

Press “3” to display this option, then press “NEXT” to select this option and access the Set A/D Offset feature. Use this option to set the offset adjustment pot on the load cell interface board installed on each A/D board. The display shows the 12-bit A/D counts (0000-4095) for each A/D board. Locate the adjustment pot between connectors MTA54 and MTA55 on the A/D board and set the A/D offset to approximately 1000 counts. Turn the pot clockwise to decrease the counts and counter-clockwise to increase the counts. Repeat for each A/D board. Press “SKIP TO” to return to the Manual Menu.

### 4 View Calibration

Press “4” to display this option, then press “NEXT” to select this option and access the View Calibration feature. Use this option to view the scale values for each load cell as set in the calibration procedure. Press “SKIP TO” to return to the Manual Menu.