

Published Manual Number/ECN: MAPCOINCAE/2020234A

- Publishing System: TPAS2
- Access date: 06/23/2020
- Document ECNs: Latest



Service & Mechanical Parts

COINC111,11H,11K,11Q,11R

CIFML40A,CIFMR40A

CIFEL40A, CIFER40A

COHORFPN, COHORFPM



**Read the
separate
safety
manual
before
installing,
operating,
or servicing**

Table of Contents

MAPCOINCAE/20234A

Page	Description	Document
1	Limited Standard Warranty	BMP720097/2019036
2	How to Get the Necessary Repair Components	BIUUUD19/20081231
3	Trademarks	BNUUUU02/2020152A
4	Safety—Stationary (non-Shuttling) Conveyors	BIUUUS27VA/20051111
8	Glossary of Tag Illustrations - Conveyor	MSIUSCTGAE/199449BV
12	Safety Placard Use and Placement - All Pivoting Conveyors	BMP070020/2007215V
14	Safety Placard Use and Placement ISO, All Pivoting Conveyors	BMP070021/2007215V
16	Safety Placard Use and Placement, All Fixed Conveyors	BMP070022/2007215V
18	Safety Placard Use and Placement ISO, All Fixed Conveyors	BMP070023/2007215V
20	Pull-wire Stop Switch	BMP140053/2017336A
22	Trip wire Safety Switch	BMP150006/2015062A
23	1. Service and Maintenance	
24	Conveyor Lubrication & Chain Adjustments	BMP070001/2007042B
26	Conveyor Adjustment Procedures	BMP820015/1996322V
29	Torque Requirements for Fasteners	BIUUUM04/20180109
37	2. Assemblies	
38	Conveyor Components COINC111, COINC11H, COINC11K, COINC11Q, COINC11R	BMP150002/2015042A
42	Pivoting COINCS 41x50 Bed	BMP150004/2020234A
46	Rollers, Bearings, Carriers and Torque Arm - CONVEY40, CONVEY42, CONVEY46, CONVEY48, CONVEY50	BPVAUN01/2018035A
52	Gear Reducers	BPVAUN03/2018066A
53	Bed 41"x 50"	BMP150003/2015046A
56	Bed Assemblies	BPVAUN04/2018165A

PELLERIN MILNOR CORPORATION LIMITED STANDARD WARRANTY

We warrant to the original purchaser that MILNOR machines including electronic hardware/software (hereafter referred to as "equipment"), will be free from defects in material and workmanship for a period of one year from the date of shipment (unless the time period is specifically extended for certain parts pursuant to a specific MILNOR published extended warranty) from our factory with no operating hour limitation. This warranty is contingent upon the equipment being installed, operated and serviced as specified in the operating manual supplied with the equipment, and operated under normal conditions by competent operators.

Providing we receive written notification of a warranted defect within 30 days of its discovery, we will—at our option—repair or replace the defective part or parts, EX Factory (labor and freight specifically NOT included). We retain the right to require inspection of the parts claimed defective in our factory prior to repairing or replacing same. We will not be responsible, or in any way liable, for unauthorized repairs or service to our equipment, and this warranty shall be void if the equipment is tampered with, modified, or abused, used for purposes not intended in the design and construction of the machine, or is repaired or altered in any way without MILNOR's written consent.

Parts damaged by exposure to weather, to aggressive water, or to chemical attack are not covered by this warranty. For parts which require routine replacement due to normal wear—such as gaskets, contact points, brake and clutch linings, belts, hoses, and similar parts—the warranty time period is 90 days.

We reserve the right to make changes in the design and/or construction of our equipment (including purchased components) without obligation to change any equipment previously supplied.

ANY SALE OR FURNISHING OF ANY EQUIPMENT BY MILNOR IS MADE ONLY UPON THE EXPRESS UNDERSTANDING THAT MILNOR MAKES NO EXPRESSED OR IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR ANY PARTICULAR USE OR PURPOSE OR ANY OTHER WARRANTY IMPLIED BY LAW INCLUDING BUT NOT LIMITED TO REDHIBITION. MILNOR WILL NOT BE RESPONSIBLE FOR ANY COSTS OR DAMAGES ACTUALLY INCURRED OR REQUIRED AS A RESULT OF: THE FAILURE OF ANY OTHER PERSON OR ENTITY TO PERFORM ITS RESPONSIBILITIES, FIRE OR OTHER HAZARD, ACCIDENT, IMPROPER STORAGE, MIS-USE, NEGLIGENCE, POWER OR ENVIRONMENTAL CONTROL MALFUNCTIONS, DAMAGE FROM LIQUIDS, OR ANY OTHER CAUSE BEYOND THE NORMAL RANGE OF USE. REGARDLESS OF HOW CAUSED, IN NO EVENT SHALL MILNOR BE LIABLE FOR SPECIAL, INDIRECT, PUNITIVE, LIQUIDATED, OR CONSEQUENTIAL COSTS OR DAMAGES, OR ANY COSTS OR DAMAGES WHATSOEVER WHICH EXCEED THE PRICE PAID TO MILNOR FOR THE EQUIPMENT IT SELLS OR FURNISHES.

THE PROVISIONS ON THIS PAGE REPRESENT THE ONLY WARRANTY FROM MILNOR AND NO OTHER WARRANTY OR CONDITIONS, STATUTORY OR OTHERWISE, SHALL BE IMPLIED.

WE NEITHER ASSUME, NOR AUTHORIZE ANY EMPLOYEE OR OTHER PERSON TO ASSUME FOR US, ANY OTHER RESPONSIBILITY AND/OR LIABILITY IN CONNECTION WITH THE SALE OR FURNISHING OF OUR EQUIPMENT TO ANY BUYER.

BMP720097/19036

How to Get the Necessary Repair Components



This document uses Simplified Technical English.
Learn more at <http://www.asd-ste100.org>.

You can get components to repair your machine from the approved supplier where you got this machine. Your supplier will usually have the necessary components in stock. You can also get components from the Milnor® factory.

Tell the supplier the machine model and serial number and this data for each necessary component:

- The component number from this manual
- The component name if known
- The necessary quantity
- The necessary transportation requirements
- If the component is an electrical component, give the schematic number if known.
- If the component is a motor or an electrical control, give the nameplate data from the used component.

To write to the Milnor factory:

Pellerin Milnor Corporation
Post Office Box 400
Kenner, LA 70063-0400
UNITED STATES

Telephone: 504-467-2787
Fax: 504-469-9777
Email: parts@milnor.com

— End of BIUUUD19 —

Trademarks

These words are trademarks of Pellerin Milnor[®] Corporation and other entities:

Table 1. Trademarks

AutoSpot [™]	GreenFlex [™]	MilMetrix [®]	PulseFlow [®]
CBW [®]	GreenTurn [™]	MilTouch [™]	Ram Command [™]
Drynet [™]	Hydro-cushion [™]	MilTouch-EX [™]	RecircONE [®]
E-P Express [®]	Mentor [®]	MILRAIL [™]	RinSave [®]
E-P OneTouch [®]	Mildata [®]	Miltrac [™]	SmoothCoil [™]
E-P Plus [®]	Milnor [®]	PBW [™]	Staph Guard [®]
Gear Guardian [®]			

End of document: BNUUUU02

Safety—Stationary (non-Shuttling) Conveyors

1. General Safety Requirements—Vital Information for Management Personnel [Document BIUUUS04]

Incorrect installation, neglected preventive maintenance, abuse, and/or improper repairs, or changes to the machine can cause unsafe operation and personal injuries, such as multiple fractures, amputations, or death. The owner or his selected representative (owner/user) is responsible for understanding and ensuring the proper operation and maintenance of the machine. The owner/user must familiarize himself with the contents of all machine instruction manuals. The owner/user should direct any questions about these instructions to a Milnor® dealer or the Milnor® Service department.

Most regulatory authorities (including OSHA in the USA and CE in Europe) hold the owner/user ultimately responsible for maintaining a safe working environment. Therefore, the owner/user must do or ensure the following:

- recognize all foreseeable safety hazards within his facility and take actions to protect his personnel, equipment, and facility;
- work equipment is suitable, properly adapted, can be used without risks to health or safety, and is adequately maintained;
- where specific hazards are likely to be involved, access to the equipment is restricted to those employees given the task of using it;
- only specifically designated workers carry out repairs, modifications, maintenance, or servicing;
- information, instruction, and training is provided;
- workers and/or their representatives are consulted.

Work equipment must comply with the requirements listed below. The owner/user must verify that installation and maintenance of equipment is performed in such a way as to support these requirements:

- control devices must be visible, identifiable, and marked; be located outside dangerous zones; and not give rise to a hazard due to unintentional operation;
- control systems must be safe and breakdown/damage must not result in danger;
- work equipment is to be stabilized;
- protection against rupture or disintegration of work equipment;
- guarding, to prevent access to danger zones or to stop movements of dangerous parts before the danger zones are reached. Guards to be robust; not give rise to any additional hazards; not be easily removed or rendered inoperative; situated at a sufficient distance from the danger zone; not restrict view of operating cycle; allow fitting, replacing, or maintenance by restricting access to relevant area and without removal of guard/protection device;
- suitable lighting for working and maintenance areas;
- maintenance to be possible when work equipment is shut down. If not possible, then protection measures to be carried out outside danger zones;
- work equipment must be appropriate for preventing the risk of fire or overheating; discharges of gas, dust, liquid, vapor, other substances; explosion of the equipment or substances in it.

- 1.1. **Laundry Facility**—Provide a supporting floor that is strong and rigid enough to support—with a reasonable safety factor and without undue or objectionable deflection—the weight of the fully loaded machine and the forces transmitted by it during operation. Provide sufficient clearance for machine movement. Provide any safety guards, fences, restraints, devices, and verbal and/or posted restrictions necessary to prevent personnel, machines, or other moving machinery from accessing the machine or its path. Provide adequate ventilation to carry away heat and vapors. Ensure service connections to installed machines meet local and national safety standards, especially regarding the electrical disconnect (see the National Electric Code). Prominently post safety information, including signs showing the source of electrical disconnect.
- 1.2. **Personnel**—Inform personnel about hazard avoidance and the importance of care and common sense. Provide personnel with the safety and operating instructions that apply to them. Verify that personnel use proper safety and operating procedures. Verify that personnel understand and abide by the warnings on the machine and precautions in the instruction manuals.
- 1.3. **Safety Devices**—Ensure that no one eliminates or disables any safety device on the machine or in the facility. Do not allow machine to be used with any missing guard, cover, panel or door. Service any failing or malfunctioning device before operating the machine.
- 1.4. **Hazard Information**—Important information on hazards is provided on the machine safety placards, in the Safety Guide, and throughout the other machine manuals. **Placards must be kept clean so that the information is not obscured. They must be replaced immediately if lost or damaged. The Safety Guide and other machine manuals must be available at all times to the appropriate personnel.** See the machine service manual for safety placard part numbers. Contact the Milnor Parts department for replacement placards or manuals.
- 1.5. **Maintenance**—Ensure the machine is inspected and serviced in accordance with the norms of good practice and with the preventive maintenance schedule. Replace belts, pulleys, brake shoes/disks, clutch plates/tires, rollers, seals, alignment guides, etc. before they are severely worn. Immediately investigate any evidence of impending failure and make needed repairs (e.g., cylinder, shell, or frame cracks; drive components such as motors, gear boxes, bearings, etc., whining, grinding, smoking, or becoming abnormally hot; bending or cracking of cylinder, shell, frame, etc.; leaking seals, hoses, valves, etc.) Do not permit service or maintenance by unqualified personnel.

2. Safety Alert Messages—Internal Electrical and Mechanical Hazards [Document BIUUUS11]

The following are instructions about hazards inside the machine and in electrical enclosures.



WARNING 1: Electrocution and Electrical Burn Hazards—Contact with electric power can kill or seriously injure you. Electric power is present inside the cabinetry unless the main machine power disconnect is off.

- Do not unlock or open electric box doors.
- Do not remove guards, covers, or panels.
- Do not reach into the machine housing or frame.
- Keep yourself and others off of machine.
- Know the location of the main machine disconnect and use it in an emergency to remove all electric power from the machine.



WARNING 2: Entangle and Crush Hazards—Contact with moving components normally isolated by guards, covers, and panels, can entangle and crush your limbs. These components move automatically.

- Do not remove guards, covers, or panels.
- Do not reach into the machine housing or frame.
- Keep yourself and others off of machine.
- Know the location of all emergency stop switches, pull cords, and/or kick plates and use them in an emergency to stop machine motion.

3. Safety Alert Messages—External Mechanical Hazards [Document BIUUUS12]

The following are instructions about hazards around the front, sides, rear or top of the machine.



WARNING 3: Fall, Entangle, and Strike Hazards—Machine motion can cause you to fall or become entangled in or struck by nearby objects if you stand, walk, or ride on the machine. Shuttles and conveyor belts move automatically.

- Keep yourself and others off of machine.

4. Safety Alert Messages—Unsafe Conditions [Document BIUUUS14]

4.1. Damage and Malfunction Hazards

4.1.1. Hazards Resulting from Inoperative Safety Devices



WARNING 4: Multiple Hazards—Operating the machine with an inoperative safety device can kill or injure personnel, damage or destroy the machine, damage property, and/or void the warranty.

- Do not tamper with or disable any safety device or operate the machine with a malfunctioning safety device. Request authorized service.



WARNING 5: Electrocutation and Electrical Burn Hazards—Electric box doors—Operating the machine with any electric box door unlocked can expose high voltage conductors inside the box.

- Do not unlock or open electric box doors.



WARNING 6: Entangle and Crush Hazards—Guards, covers, and panels—Operating the machine with any guard, cover, or panel removed exposes moving components.

- Do not remove guards, covers, or panels.

4.1.2. Hazards Resulting from Damaged Mechanical Devices



WARNING 7: Multiple Hazards—Operating a damaged machine can kill or injure personnel, further damage or destroy the machine, damage property, and/or void the warranty.

- Do not operate a damaged or malfunctioning machine. Request authorized service.

4.2. Careless Use Hazards

4.2.1. Careless Operation Hazards—Vital Information for Operator Personnel (see also operator hazards throughout manual)



WARNING 8: Multiple Hazards—Careless operator actions can kill or injure personnel, damage or destroy the machine, damage property, and/or void the warranty.

- Do not tamper with or disable any safety device or operate the machine with a malfunctioning safety device. Request authorized service.
- Do not operate a damaged or malfunctioning machine. Request authorized service.
- Do not attempt unauthorized servicing, repairs, or modification.
- Do not use the machine in any manner contrary to the factory instructions.
- Use the machine only for its customary and intended purpose.
- Understand the consequences of operating manually.



CAUTION 9: Goods Damage and Wasted Resources—Entering incorrect cake data causes improper processing, routing, and accounting of batches.

- Understand the consequences of entering cake data.

4.2.2. Careless Servicing Hazards—Vital Information for Service Personnel (see also service hazards throughout manuals)



WARNING 10: Electrocutation and Electrical Burn Hazards—Contact with electric power can kill or seriously injure you. Electric power is present inside the cabinetry unless the main machine power disconnect is off.

- Do not service the machine unless qualified and authorized. You must clearly understand the hazards and how to avoid them.
- Abide by the current OSHA lockout/tagout standard when lockout/tagout is called for in the service instructions. Outside the USA, abide by the OSHA standard in the absence of any other overriding standard.







WARNING 11: Entangle and Crush Hazards—Contact with moving components normally isolated by guards, covers, and panels, can entangle and crush your limbs. These components move automatically.

- Do not service the machine unless qualified and authorized. You must clearly understand the hazards and how to avoid them.
- Abide by the current OSHA lockout/tagout standard when lockout/tagout is called for in the service instructions. Outside the USA, abide by the OSHA standard in the absence of any other overriding standard.

— End of BIUUUS27 —


Glossary of Tag Illustrations— Conveyor

MSIUSCTGAE/9449BV


Illustration	Explanation
	<p>Stop! Read the manual first for complete instructions before continuing.</p>
	<p>Do not jack the machine here. Do not lift the machine here.</p>
	<p>Use three point or four point lifting as determined by the lifting eyes furnished. Rig the load using lifting cables of sufficient size and length to ensure cables are not over-stressed.</p>
	<p>Do not lift the machine from one corner or one side edge.</p>

Illustration

Explanation



Do not strike machine or components during fork lifting.



Do not start this machine until the packing materials, lifting brackets, etc. with this tag attached or behind this panel are removed. These materials are painted red. Safety stands or brackets (also painted red) may be provided with this machine. Do not discard safety stands or brackets




Do not step or stand on this machine part.




This motor or pump should rotate in the direction of the arrow.


Glossary of Tag Illustrations—
Conveyor




Do not start this machine until the part with this tag is installed on the machine.




Do not remove this component from the machine.



Install the appropriate part here before operating the machine.



Do not strap or chain over box



Replace non-vented plug with vented plug on gear reducer before operating.

Safety Placard Use and Placement

ALL PIVOTING CONVEYORS

BMP070020/2007215B
(Sheet 1 of 2)






Pellerin Milnor Corporation
P. O. Box 400, Kenner, LA 70063-0400

Litho in U.S.A.

Notes:

1. Replace placard immediately, if removed or unreadable.
2. Approximate locations of placards are shown. Mounting holes are provided on machine. Use #8 self-tapping screws.





Pellerin Milnor Corporation
P. O. Box 400, Kenner, LA 70063-0400

Litho in U.S.A.

Parts List—Safety Placard Placement

Find the correct assembly first, then find the needed components. The item letters (A, B, C, etc.) assigned to assemblies are referred to in the "Used In" column to identify which components belong to an assembly. The item numbers (1, 2, 3, etc.) assigned to components relate the parts list to the illustration.

Used In	Item	Part Number	Description	Comments
-----ASSEMBLIES-----				
none				
-----COMPONENTS-----				
all	10	01 10634A	NPLT:CONVEYOR HAZARDS-TCATA	
all	20	01 10375B	NPLT:ELEC HAZARD SMALL-TCATA	
all	30	01 10699A	NPLT:SERV HZRD-PLYEST-TCATA	

Safety Placard Use and Placement ISO

ALL PIVOTING CONVEYORS

BMP070021/2007215B
(Sheet 1 of 2)






Pellerin Milnor Corporation
P. O. Box 400, Kenner, LA 70063-0400

Litho in U.S.A.

ISO Placard shown on this page

Notes:

1. Replace placard immediately, if removed or unreadable.
2. Approximate locations of placards are shown. Mounting holes are provided on machine. Use #8 self-tapping screws.





Pellerin Milnor Corporation
P. O. Box 400, Kenner, LA 70063-0400

Litho in U.S.A.

Parts List—Safety Placard Placement

Find the correct assembly first, then find the needed components. The item letters (A, B, C, etc.) assigned to assemblies are referred to in the "Used In" column to identify which components belong to an assembly. The item numbers (1, 2, 3, etc.) assigned to components relate the parts list to the illustration.

Used In	Item	Part Number	Description	Comments
-----ASSEMBLIES-----				
none				
-----COMPONENTS-----				
all	10	01 10634X	NPLT:WARN CONVEYORS -ISO	
all	20	01 10375	NPLTE:"WARNING" 2X2	

Safety Placard Use and Placement

ALL FIXED CONVEYORS

BMP070022/2007215B
(Sheet 1 of 2)




Pellerin Milnor Corporation
P. O. Box 400, Kenner, LA 70063-0400

Litho in U.S.A.

Notes:

1. Replace placard immediately, if removed or unreadable.
2. Approximate locations of placards are shown. Mounting holes are provided on machine. Use #8 self-tapping screws.



NOTES:
*THESE PLACARDS ARE TO
BE REPEATED IF CONVEYOR
IS OVER 20 FEET (6.096
METERS) LONG



Pellerin Milnor Corporation
P. O. Box 400, Kenner, LA 70063-0400

Litho in U.S.A.

Parts List—Safety Placard Placement

Find the correct assembly first, then find the needed components. The item letters (A, B, C, etc.) assigned to assemblies are referred to in the "Used In" column to identify which components belong to an assembly. The item numbers (1, 2, 3, etc.) assigned to components relate the parts list to the illustration.


Used In	Item	Part Number	Description	Comments
-----ASSEMBLIES-----				
none				
-----COMPONENTS-----				
all	10	01 10634A	NPLT:CONVEYOR HAZARDS-TCATA	
all	20	01 10375B	NPLT:ELEC HAZARD SMALL-TCATA	



ISO Placards shown on this page

Notes:

1. Replace placard immediately, if removed or unreadable.
2. Approximate locations of placards are shown. Mounting holes are provided on machine. Use #8 self-tapping screws.



NOTES:
*THESE PLACARDS ARE TO BE
REPEATED IF CONVEYOR IS OVER
20 FEET (6.096 METERS) LONG



Pellerin Milnor Corporation
P. O. Box 400, Kenner, LA 70063-0400

Litho in U.S.A.

Parts List—Safety Placard Placement


Find the correct assembly first, then find the needed components. The item letters (A, B, C, etc.) assigned to assemblies are referred to in the "Used In" column to identify which components belong to an assembly. The item numbers (1, 2, 3, etc.) assigned to components relate the parts list to the illustration.

Used In	Item	Part Number	Description	Comments
-----ASSEMBLIES-----				
			none	
-----COMPONENTS-----				
all	10	01 10634X	NPLT:WARN CONVEYORS -ISO	
all	20	01 10375	NPLTE:"WARNING" 2X2	

Pull-wire Stop Switch


All Conveyors

Figure 1: Pull-wire Stop Switch Installation



Installation and operation:

1. Install the switch bracket, switch, and adjusting bracket to the conveyor side supports as shown. (Install pull-wire stop switch to both sides of all conveyors.)
For long spans, intermediate wire supports are required every 2 m to 5 m (6 ft to 16 ft). Sufficient space must be provided so that maximum perpendicular force on the wire to activate the switch is 200 N (45 pounds) and the maximum deflection of the wire is 400 mm (15").
2. Assemble and install the cable (pull cord), thimbles, and sleeves so that the cable is tight but does not begin to move the switch shaft.
3. Adjust the position of the threaded rod (item 8) so that the cable pulls the switch shaft out until the first of two notches on the shaft is visible but the second notch is not.
4. Tighten the nuts on the threaded rod (item 12) to hold it at this position.



5. Press the button on the switch to ARM. The button should remain depressed. If it does not, the switch shaft is not in the correct position.
6. Press the button to RE-ARM the switch after the wire has been tripped.


Pull-wire Stop Switch

All Conveyors

<p align="center">Parts List—Pull-wire Stop Switch</p> <p>Find the correct assembly first, then find the needed components. The item letters (A, B, C, etc.) assigned to assemblies are referred to in the "Used In" column to identify which components belong to an assembly. The item numbers (1, 2, 3, etc.) assigned to components relate the parts list to the illustration.</p>				
Used In	Item	Part Number	Description	Comments
			-----ASSEMBLIES-----	
	A	ALC40005E	PULL-WIRE STOP SWITCH ASSY	
			-----COMPONENTS-----	
	1	04 20066	WIREPULL SWITCH BRACKET	CONVEYORS PLUS CONWA/CONLO
	1	04 24128	SAFETY SW MTG PLATE-4232M	EXTRACTOR CONVEYORS
all	2	04 20067	WIREPULL ADJUSTING BRKT	
all	3	09RS0002	PULL-WIRE SW SCHMERSAL#ZQ 700-11	
all	4	15K022B	SOKCPSCR 10-24UNC X 1+1/2"LG SS18	
all	5	27A951	1/16" SS WIRE ROPE THIMBLE	
all	6	27A952	1/16" OVAL SLEEVE S/S	
all	7	27A953	CABLE-AIRCRAFT 1/16SS7X7REDCV	
all	8	17R015	THRD ROD 1/4-28UNFX4.5" ZNC PL	
all	9	17A004	ADJ YOKE END 1/4-28 XYLAN COAT	
all	10	17A004A	CLEVIS PIN 1/4"X3/4"DRILLED SS	
all	11	15H031	STDCOTTERPIN 3/32X3/4 SS18-8	
all	12	15G177	HXNUT 1/4-28UNF2B SAE ZINC GR2	
all	13	15K038B	1/4-20X 1/2 HEXFLANGE SCREW	
all	14	15G178	1/4"-20 HEXFLANGE NUT ZINC	
all	15	01 10749X	NPLT:PULL TO STOP+RESET>ISO	

Trip Wire Safety Switch

Conveyors and COINCS



Used on Pivoting
COINCS prior to 2008.

Parts List—Trip Wire Safety Switch

Find the correct assembly first, then find the needed components. The item letters (A, B, C, etc.) assigned to assemblies are referred to in the "Used In" column to identify which components belong to an assembly. The item numbers (1, 2, 3, etc.) assigned to components relate the parts list to the illustration.

Used In	Item	Part Number	Description	Comments
-----ASSEMBLIES-----				
	A	ALC40005	TRIP WIRE SAFETY SWITCH ASSY	
-----COMPONENTS-----				
all	1	02 22713	6836M5K FRAME LOCK-DOWN BRKT	
all	2	07 50293	SPRING.500 0DX4.00LGX.049EXT	
all	3	04 20660	BRKT=SPRING TENSION HOLD	
all	4	15G177	HXNUT 1/4-28UNF2B SAE ZINC GR2	
all	5	17R015	THRD ROD 1/4-28UNFX4.5" ZNC PL	
all	6	17A004	ADJ YOKE END 1/4-28 XYLAN COAT	
all	7	17A004A	CLEVIS PIN 1/4"X3/4"DRILLED SS	
all	8	15H031	STDCOTTERPIN 3/32X3/4 SS18-8	
all	9	27A951	1/16" SS WIRE ROPE THIMBLE	
all	10	27A952	1/16" OVAL SLEEVE S/S	
all	11	01 10544X	NPLT:PULL TO STOP-ISO	
all	12	27A953	CABLE-AIRCRAFT 1/16SS7X7REDCV	
all	13	04 23141	SAFETY TRIPWIRE SPRING COVER	

Service and Maintenance

1

Conveyor Lubrication & Chain Adjustments


Flatbelt, Load Conveyors & Extractor Conveyors

BMP070001/2007042A
(Sheet 1 of 2)




Pellerin Milnor Corporation
P. O. Box 400, Kenner, LA 70063-0400


Litho in U.S.A.



TYPICAL: FLATBELT CONVEYORS




TYPICAL: LOAD CONVEYORS



TYPICAL: UNDERDRIVE

CONVEYOR LUBRICATION:

Every three months, all **CONVEYOR ROLLER BEARINGS** should be lubricated with bearing lubricant, Shell Alvania EP2 Lithium Grease or equivalent, using a hand pressure grease gun. Lubrication fittings are located on the bearings when they are easily accessible or they are remotely located to a position on the conveyor bed frame, if the bearing cannot be reached easily.



TYPICAL: IDLER ROLLER

CHAIN LUBRICATION:


Every thirty days of operation, **CHAIN DRIVES** should be lubricated with bearing lubricant, Shell Alvania EP2 Lithium Grease or equivalent. Chain drives are covered by a safety cover and their lubrication fitting are remotely mounted where they are easily accessible.



CHAIN ADJUSTMENTS:

Every thirty days of operation, **CHAIN DRIVES** should be checked for proper adjustment.

A = 0 - .125" [0 - 3mm] New Chain
A = .125" - .25" [3mm - 6mm] After 48 hours



Conveyor Adjustment Procedures Flatbelt & Load Conveyors

BMP820015/96322V
(Sheet 1 of 3)



Pellerin Milnor Corporation
P. O. Box 400, Kenner, LA 70063-0400

BMP820015/96322V (1 of 3)

Litho in U.S.A.

Comments:

To provide optimum durability of the conveyor belt, it is essential that the conveyor is properly "squared". These instructions define the procedures to "square" the system.

Step 1: The conveyor frame must be "square".



This is accomplished by adjusting the tie rods between points "A" - "C" and "B" - "D". The frame is "square" if and only if met: distance "A" - "C" equals distance "B" - "D".

Step 2: The rollers must be parallel to the lines "A" - "D" and respectively "B" - "C".

This is accomplished by moving the rollers with the adjusting rods. Therefore distance "G" must equal distance "H".

Step 3: If step 2 is respected the rollers will be parallel to one another, therefore distance "E" will equal distance "F".

SECTION X



This configuration is shown as an example only.

* Many installations incorporate several interconnected conveyors (as shown above) which must be square to one another.

Conveyor Adjustment Procedures

Flatbelt & Load Conveyors


BMP820015/96322V
(Sheet 2 of 3)



Pellerin Milnor Corporation
P. O. Box 400, Kenner, LA 70063-0400

BMP820015/96322V (2 of 3)

Litho in U.S.A.



Step 1: At some point well back from the end of the belt, measure and carefully mark a point (C) at the exact center of the belt width.

Step 2: Measure from this centerpoint two equal lengths (k and m) and mark points (A and B) along the edges and near the end of the belt. Be sure length "k" equals length "m".

Step 3: Measure the total desired length (h) from point "B" to point "F" and mark that point.

Step 4: At some point well back from this end of the belt, mark a point (D) at the exact center of the belt width.

Step 5: Repeat step 2 to find point "E". Be sure that length "n" equals length "p".

Step 6: Cut along lines "A" - "B" and "E" - "F". Cuts must be straight so that the ends may be laced together without causing the belt material to warp.

(THIS PROCEDURE TO BE USED IF A BELT IS TO BE CUT AND LACED IN THE FIELD.)

Conveyor Adjustment Procedures Flatbelt & Load Conveyors

BMP820015/96322V
(Sheet 3 of 3)



Pellerin Milnor Corporation
P. O. Box 400, Kenner, LA 70063-0400

BMP820015/96322V (3 of 3)

Litho in U.S.A.

Step 1: Check the conveyor frame to make sure it is square in accordance with illustration 1. Make sure the ends of the belt are square and laced properly in accordance with illustration 2.

Step 2: Run the conveyor for enough revolutions to indicate what direction it tracks.

Example: If the belt tracks to the right, adjust the right side non driven end adjusting rod (for double ended drives pick one end to adjust only) by following these steps:

Step 2a: Loosen the two (2) 5/8" drive locking nuts.

Step 2b: Turn the adjusting rod so as to move the right side non-driven end out until the belt is tracking straight.

Step 2c: Retighten the locking nuts.

Step 2d: If the above procedure does not correct the problem apply the same steps on the right side driven end.


Step 3: Run the conveyor for at least 12 hours and readjust if necessary. Frequent inspection is required.

Step 4: After 72 hours operating, adjust the belt to track straight if required.

Step 5: Check the belt at least monthly, or as required, to insure straight tracking.

WARNING:

When moving conveyor, never allow frame to twist; such as would occur if one corner were raised higher than the others. Misalignment and damage to the frame may occur.



COMMENTS:

In order to insure optimum durability of Milnor conveyor belts, it is essential that the belt "tracks" straight on the conveyor frame. These instructions provide step by step procedures to insure proper belt tracking.
Drive is normally located on discharge end. Double end drives are used on reversing conveyors over 16 feet long. Drive may be located on load end of short conveyors (4 feet).

This drawing intended for use with both flat bed and loading conveyor. Loading conveyor has metal dividers on belt, not shown here.

Torque Requirements for Fasteners



This document uses Simplified Technical English. Learn more at <http://www.asd-ste100.org>.

The document about the assembly gives the torque requirements for other fasteners. **If fastener torque specifications or threadlocker requirements in an assembly document are different from this document, use the assembly document.**

Figure 1: The Bolts in Milnor® Equipment

The Marks on Bolt Heads	Legend
	<p>A. SAE Grades 1 and 2, ASTM A307, and stainless steel</p> <p>B. Grade BC, ASTM A354</p> <p>C. SAE Grade 5, ASTM A449</p> <p>D. SAE Grade 8 and ASTM A354 BD</p>

1. Torque Values

These tables give the standard dimension, grade, threadlocker, and torque requirements for fasteners frequently used on Milnor® equipment.

Note 1: Data from the Pellerin Milnor® Corporation “Bolt Torque Specification” (bolt_torque_milnor.xls/2002096).

1.1. Fasteners Made of Carbon Steel

1.1.1. Without a Threadlocker

Table 1: Torque Values for Standard Fasteners with Maximum 5/16-inch Diameters and No Lubricant

Dimension	The Grade of the Bolt							
	Grade 2		Grade 5		Grade 8		Grade BC	
	Pound-Inches	N-m	Pound-Inches	N-m	Pound-Inches	N-m	Pound-Inches	N-m
1/4 x 20	66	7	101	11	143	16	126	14
1/4 x 28	76	9	116	13	163	18	--	--
5/16 x 18	136	15	209	24	295	33	258	29
5/16 x 24	150	17	232	26	325	37	--	--

Torque Requirements for Fasteners

Table 2: Torque Values for Standard Fasteners Larger Than 5/16-inch Diameters and No Lubricant

Dimension	The Grade of the Bolt							
	Grade 2		Grade 5		Grade 8		Grade BC	
	Pound-feet	N-m	Pound-feet	N-m	Pound-feet	N-m	Pound-feet	N-m
3/8 x 16	20	27	31	42	44	59	38	52
3/8 x 24	23	31	35	47	50	68	--	--
7/16 x 14	32	43	49	66	70	95	61	83
7/16 x 20	36	49	55	75	78	105	--	--
1/2 x 13	49	66	75	102	107	145	93	126
1/2 x 20	55	75	85	115	120	163	--	--
9/16 x 12	70	95	109	148	154	209	134	182
9/16 x 18	78	106	121	164	171	232	--	--
5/8 x 11	97	131	150	203	212	287	186	252
5/8 x 18	110	149	170	231	240	325	--	--
3/4 x 10	172	233	266	361	376	510	329	446
3/4 x 16	192	261	297	403	420	569	--	--
7/8 x 9	167	226	429	582	606	821	531	719
7/8 x 14	184	249	473	641	668	906	--	--
1 x 8	250	339	644	873	909	1232	796	1079
1 x 12	274	371	704	954	994	1348	--	--
1 x 14	281	381	723	980	1020	1383	--	--
1 1/8 x 7	354	480	794	1077	1287	1745	1126	1527
1 1/8 x 12	397	538	891	1208	1444	1958	--	--
1 1/4 x 7	500	678	1120	1519	1817	2464	1590	2155
1 1/4 x 12	553	750	1241	1682	2012	2728	--	--
1 3/8 x 6	655	888	1469	1992	2382	3230	2085	2827
1 3/8 x 12	746	1011	1672	2267	2712	3677	--	--
1 1/2 x 6	869	1178	1949	2642	3161	4286	2767	3751
1 1/2 x 12	979	1327	2194	2974	3557	4822	--	--

Table 3: Torque Values for Plated Fasteners with Maximum 5/16-inch Diameters and No Lubricant

Dimension	The Grade of the Bolt							
	Grade 2		Grade 5		Grade 8		Grade BC	
	Pound-Inches	N-m	Pound-Inches	N-m	Pound-Inches	N-m	Pound-Inches	N-m
1/4 x 20	49	6	76	9	107	12	95	11
1/4 x 28	56	6	88	10	122	14	--	--
5/16 x 18	102	12	156	18	222	25	193	22
5/16 x 24	113	13	174	20	245	28	--	--

Table 4: Torque Values for Plated Fasteners Larger Than 5/16-inch Diameters and No Lubricant

Dimension	The Grade of the Bolt							
	Grade 2		Grade 5		Grade 8		Grade BC	
	Pound-feet	N-m	Pound-feet	N-m	Pound-feet	N-m	Pound-feet	N-m
3/8 x 16	15	20	23	31	33	44	29	38
3/8 x 24	17	23	26	35	37	49	--	--
7/16 x 14	24	32	37	50	52	71	46	61
7/16 x 20	27	36	41	55	58	78	--	--
1/2 x 13	37	49	56	76	80	106	70	93
1/2 x 20	41	55	64	85	90	120	--	--
9/16 x 12	53	70	81	110	115	153	101	134
9/16 x 18	59	79	91	122	128	174	--	--
5/8 x 11	73	97	113	150	159	212	139	186
5/8 x 18	83	110	127	172	180	240	--	--
3/4 x 10	129	173	200	266	282	376	246	329
3/4 x 16	144	192	223	297	315	420	--	--
7/8 x 9	125	166	322	430	455	606	398	531
7/8 x 14	138	184	355	474	501	668	--	--
1 x 8	188	250	483	644	682	909	597	796
1 x 12	205	274	528	716	746	995	--	--
1 x 14	210	280	542	735	765	1037	--	--
1 1/8 x 7	266	354	595	807	966	1288	845	1126
1 1/8 x 12	298	404	668	890	1083	1444	--	--
1 1/4 x 7	375	500	840	1120	1363	1817	1192	1590
1 1/4 x 12	415	553	930	1261	1509	2013	--	--
1 3/8 x 6	491	655	1102	1470	1787	2382	1564	2085
1 3/8 x 12	559	758	1254	1672	2034	2712	--	--
1 1/2 x 6	652	870	1462	1982	2371	3161	2075	2767
1 1/2 x 12	733	994	1645	2194	2668	3557	--	--

1.1.2. With a Threadlocker

Table 5: Threadlocker by the Diameter of the Bolt (see Note 2)

LocTite Product	Dimension			
	1/4-inch	1/4- to 5/8-inch	5/8- to 7/8-inch	1-inch +
LocTite 222	OK			
LocTite 242		OK		
LocTite 262			OK	
LocTite 272			High temperature	
LocTite 277				OK

Note 2: The acceptable bolt size ranges for various LocTite® threadlocking products is the LocTite manufacturer's **general** recommendation. Specific applications sometime require that a LocTite product is applied to a bolt size outside the ranges shown here. For example, Milnor specifies LocTite 242 for use on certain 1" bolt applications and has confirmed this usage with the LocTite manufacturer. You may see variances such as this in the documentation for specific machine assemblies.

Torque Requirements for Fasteners

Table 6: Torque Values if You Apply LocTite 222

Dimension	The Grade of the Bolt							
	Grade 2		Grade 5		Grade 8		Grade BC	
	Pound-inches	N-m	Pound-inches	N-m	Pound-inches	N-m	Pound-inches	N-m
1/4 x 20	60	7	96	11	132	15	108	12
1/4 x 28	72	8	108	12	144	16	--	--

Table 7: Torque Values if You Apply LocTite 242

Dimension	The Grade of the Bolt							
	Grade 2		Grade 5		Grade 8		Grade BC	
	Pound-feet	N-m	Pound-feet	N-m	Pound-feet	N-m	Pound-feet	N-m
5/16 x 18	11	15	17	23	25	34	22	30
5/16 x 24	13	18	19	26	27	37	27	37
3/8 x 16	20	27	31	42	44	60	38	52
3/8 x 24	23	31	35	47	50	68	--	--
7/16 x 14	32	43	49	66	70	95	61	83
7/16 x 20	36	49	55	75	78	106	--	--
1/2 x 13	49	66	75	102	107	145	93	126
1/2 x 20	55	75	85	115	120	163	--	--
9/16 x 12	70	95	109	148	154	209	134	182
9/16 x 18	78	106	121	164	171	232	--	--
5/8 x 11	97	132	150	203	212	287	186	252
5/8 x 18	110	149	170	230	240	325	--	--

Table 8: Torque Values if You Apply LocTite 262

Dimension	The Grade of the Bolt							
	Grade 2		Grade 5		Grade 8		Grade BC	
	Pound-feet	N-m	Pound-feet	N-m	Pound-feet	N-m	Pound-feet	N-m
3/4 x 10	155	210	240	325	338	458	296	401
3/4 x 16	173	235	267	362	378	512	--	--
7/8 x 9	150	203	386	523	546	740	477	647
7/8 x 14	165	224	426	578	601	815	--	--

Table 9: Torque Values if You Apply LocTite 272 (High-Temperature)

Dimension	The Grade of the Bolt							
	Grade 2		Grade 5		Grade 8		Grade BC	
	Pound-feet	N-m	Pound-feet	N-m	Pound-feet	N-m	Pound-feet	N-m
1 x 8	350	475	901	1222	1272	1725	1114	1510
1 x 12	383	519	986	1337	1392	1887	--	--
1 x 14	393	533	1012	1372	1428	1936	--	--
1-1/8 x 7	496	672	1111	1506	1802	2443	1577	2138
1-1/8 x 12	556	754	1247	1691	2022	2741	--	--
1-1/4 x 7	700	949	1568	2126	2544	3449	2226	3018
1-1/4 x 12	774	1049	1737	2355	2816	3818	--	--
1-3/8 x 6	917	1243	2056	2788	3335	4522	2919	3958
1-3/8 x 12	1044	1415	2341	3174	3797	5148	--	--
1-1/2 x 6	1217	1650	2729	3700	4426	6001	3873	5251
1-1/2 x 12	1369	1856	3071	4164	4980	6752	--	--

Table 10: Torque Values if You Apply LocTite 277

Dimension	The Grade of the Bolt							
	Grade 2		Grade 5		Grade 8		Grade BC	
	Pound-feet	N-m	Pound-feet	N-m	Pound-feet	N-m	Pound-feet	N-m
1 x 8	325	441	837	1135	1181	1601	1034	1402
1 x 12	356	483	916	1242	1293	1753	--	--
1 x 14	365	495	939	1273	1326	1798	--	--
1-1/8 x 7	461	625	1032	1399	1674	2270	1464	1985
1-1/8 x 12	516	700	1158	1570	1877	2545	--	--
1-1/4 x 7	650	881	1456	1974	2362	3202	2067	2802
1-1/4 x 12	719	975	1613	2187	2615	3545	--	--
1-3/8 x 6	851	1154	1909	2588	3097	4199	2710	3674
1-3/8 x 12	970	1315	2174	2948	3526	4781	--	--
1-1/2 x 6	1130	1532	2534	3436	4110	5572	3597	4877
1-1/2 x 12	1271	1723	2852	3867	4624	6269	--	--

1.2. Stainless Steel Fasteners

Table 11: Torque Values for Stainless Steel Fasteners 5/16-inch and Smaller

Dimension	316 Stainless		18-8 Stainless		18-8 Stainless with Loctite 767	
	Pound-Inches	N-m	Pound-Inches	N-m	Pound-Inches	N-m
1/4 x 20	79	9	76	9	45	5
1/4 x 28	100	11	94	11	56	6
5/16 x 18	138	16	132	15	79	9
5/16 x 24	148	17	142	16	85	10

Table 12: Torque Values for Stainless Steel Fasteners Larger Than 5/16-inch

Dimension	316 Stainless		18-8 Stainless		18-8 Stainless with Loctite 767	
	Pound-feet	N-m	Pound-feet	N-m	Pound-feet	N-m
3/8 x 16	21	28	20	27	12	16
3/8 x 24	23	31	22	29	13	18
7/16 x 14	33	44	31	42	19	25
7/16 x 20	35	47	33	45	20	27
1/2 x 13	45	61	43	58	26	35
1/2 x 20	47	64	45	61	27	37
9/16 x 12	59	81	57	77	34	46
9/16 x 18	66	89	63	85	38	51
5/8 x 11	97	131	93	125	56	75
5/8 x 18	108	150	104	141	62	84
3/4 x 10	132	179	128	173	77	104
3/4 x 16	130	176	124	168	75	101
7/8 x 9	203	275	194	263	116	158
7/8 x 14	202	273	193	262	116	157
1 x 8	300	406	287	389	172	233
1 x 14	271	367	259	351	156	211
1-1/8 x 7	432	586	413	560	248	336
1-1/8 x 12	408	553	390	529	234	317
1-1/4 x 7	546	740	523	709	314	425
1-1/4 x 12	504	683	480	651	288	390
1-1/2 x 6	930	1261	888	1204	533	722
1-1/2 x 12	732	992	703	953	422	572

2. Preparation



WARNING 2: Fire Hazard—Some solvents and primers are flammable.

- Use threadlocker and primers with sufficient airflow.
 - Do not use flammable material near ignition sources.
1. Clean all threads with a wire brush or a different tool.
 2. Remove the grease from the fasteners and the mating threads with solvent. Make the parts dry.

Note 3: Loctite 7649 Primer™ or standard solvents will remove grease from parts.

3. Apply a spray of Loctite 7649 Primer™ or equal on the fasteners and the mating threads. Let the primer dry for one minute minimum.

3. How to Apply a Threadlocker




CAUTION 3: Malfunction Hazard—Heat, vibration, or mechanical shocks can let the fasteners loosen if you do not apply the threadlocker correctly. Loose fasteners can cause malfunctions of the equipment.

- Read the threadlocker manufacturer's instructions and warnings. Obey these instructions.

Apply the threadlocker only to the areas where the fastener threads and the mating threads engage.

Figure 2: Blind Hole




3.1. Blind Holes

1. Apply the threadlocker down the threads to the bottom of the hole.
2. Apply the threadlocker to the bolt.
3. Tighten the bolt to the value shown in the correct table ([Table 5](#) to [Table 11](#)).

3.2. Through Holes

1. Put the bolt through the assembly.
2. Apply the threadlocker only to the bolt thread area that will engage the nut.
3. Tighten the bolt to the value shown in the correct table ([Table 5](#) to [Table 11](#)).


Figure 3: Through Hole



3.3. Disassembly—For high-strength threadlocker, apply heat for five minutes. Disassemble with hand tools while the parts are hot.

For low-strength and moderate-strength threadlocker, disassemble with hand tools.

Figure 4: Disassembly





— End of BIUUM04 —

Assemblies

2



Conveyor Components

COINC111, COINC11H, COINC11K, COINC11Q, COINC11R



Conveyor Components

COINC111, COINC11H, COINC11K, COINC11Q, COINC11R



Conveyor Components

COINC111, COINC11H, COINC11K, COINC11Q, COINC11R

Parts List—Conveyor Components COINC11				
Find the correct assembly first, then find the needed components. The item letters (A, B, C, etc.) assigned to assemblies are referred to in the "Used In" column to identify which components belong to an assembly. The item numbers (1, 2, 3, etc.) assigned to components relate the parts list to the illustration.				
Used In	Item	Part Number	Description	Comments
-----ASSEMBLIES-----				
	A		REFERENCE	COINC11H 41X50
	B		REFERENCE	COINC11K 44X62
	C		REFERENCE	COINC11Q 44X77
	D		REFERENCE	COINC11R 50X84
A	E	ALC50061	COINC BASE 10"-13"-16" LD.HT	
A	F	ALC50001B	CONV.BED ROUGH 41X50 NO EYE	
B	G	ALC50076	BED ASSY 44WX62L COINC11K	
C	H	ALC50110	BED ASSY 44WX77LG COINC11Q	
D	J	ALC50130	BED ASSY 52WX84LG COINC11R	
-----COMPONENTS-----				
A	1	04 23128	COINC BASE-RT SIDE	
A	2	04 23128A	COINC BASE-LF SIDE	
A	3	04 21026	BRACE COINC STAND	
A	4	04 23129	COINC BED MTG BRKT-RT	
A	5	04 23129A	COINC BED MTG BRKT-LF	
A	6	07 20802	HOLD DOWN BRKT	
BCD	7	04 23058	CONV ADJUSTING LEG-5.00W	
BCD	8	04 23063	CONVEY SUPPORT 4.5"WX15.5"L	
BC	9	04 23139	BED MOUNTING PLATE-COINC11Q	
D	9	04 23140	BED MOUNTING PLATE-COINC11R	
BC	10	04 21070	LEG CROSS BRACE-COINCQ	
D	10	04 21071	LEG CROSS BRACE-COINC11R	
A	11	04 20804A	BED 4ROL 42W 50L GROOVE	
B	11	04 22292	SS BED LINER-COINC11K	
C	11	04 22290	SS BED LINER-COINC11Q	
D	11	04 22291	SS BED LINER-COINC11R	
BCD	12	01 10634X	NPLT:WARN CONVEYORS -ISO	
B	13	ALC50081	BED FRAME 44WX62LG ASSEMBLY	
C	13	ALC50081A	BED FRAME 44WX77LG ASSEMBLY	
D	13	ALC50081C	BED FRAME 50WX84LG ASSEMBLY	
B	14	04 22256	SIDE UPPER 62L BED-RT	
C	14	04 22254	SIDE UPPER 77L BED-RT	
D	14	04 22864	SIDE UPPER 84L BED-RT	
B	15	04 22256A	SIDE UPPER 62L BED-LF	


Conveyor Components

COINC11H, COINC11K, COINC11Q, COINC11R

Parts List—Conveyor Components COINC11				
Find the correct assembly first, then find the needed components. The item letters (A, B, C, etc.) assigned to assemblies are referred to in the "Used In" column to identify which components belong to an assembly. The item numbers (1, 2, 3, etc.) assigned to components relate the parts list to the illustration.				
Used In	Item	Part Number	Description	Comments
C	15	04 22254A	SIDE UPPER 77L BED-LF	
D	15	04 22864A	SIDE UPPER 84L BED-LF	
BC	16	04 22283	UNLOAD BRNG COVER 44W-RT	
D	16	04 22285	ROLLER BRNG COVER 44W BED-RT	
BC	17	04 22283A	UNLOAD BRNG COVER 44W-LF	
D	17	04 22285A	ROLLER BRNG COVER 44W BED-LF	
A	18	04 20837C	CHAN TORQUE ARM MT 318BOSTON	
BD	18	04 22233	TORQUE ARM GROMET MTG BRKT	
A	19	04 20837B	BRKT =TORQUE ARM 318 BOSTON	
B	19	04 22260	TORQARM-12DEG LOWER BED	
C	19	04 20716	TORQARM COSHR LOWER BED-LF	
all	20	ALC420063	TORQUE ARM BUSHING ASSEMBLY	
ABC	21	Y4 20832E	DRVROLLER 4.50D X 53" OAL	
D	21	Y4 20832K	DRVROLLER 5.75D X 63.75"OAL	
ABC	22	Y4 20832G	IDLER ROLLER 4.50D X 44.5" OAL	
D	22	ALC50131	IDLER 50W ROLLER ASSEMBLY	
ABC	23	54AF10001	FLG BRG 1" BROWN#VF2S-116M (2BOLT FLG)	
D	23	54AF1437	FLGEBRG.HUBCITY 3-BOLT FB150URX1-7/16	
A	24	54C401000E	BELT 40W V-ROUGH TOP-114"LG	
BC	24	54C420GV	BELT 42"GREY WDGGRIP W/VGUIDE	
D	24	54C500V	BELT 51" GREY WDGGRIP W/VGUIDE	
BCD	25	54G201D	CLIPPER LACE #UX-1-36S	
B	26	54G301C	BLTLACERCONN NYSO93C EA=1FT	
CD	26	54G302C	CONNECTING PIN # NYS065C EA=1FT	
BC	27	54STB3183R	REDCR30 B#SF718-30T-B5-G +OIL	
D	27	54STB3214R	REDCR40 B#SF721-40T-B5-G +OIL	
BC	29	54JH11000A	SHAFTCOLLAR 1" CLPTYPE CFG#16A	
ABC	30	15U241MB	FLAT WASHER-1.50D 1+1/32ID 10G	
C	31	04 22281	TOP BED SIDE SUPPORT	
BCD	32	09RPE011	PHOTOEYE VALU-BEAM 10-30DC	
BCD	33	09RPE001A	REFLECTOR 3"DIA CLEAR	





Pivoting Coins 41x50 Bed

CIFML40A, CIFRL40A, CIFEL40A, CIFER40A, COHORFPN, COHORFPM



Pivoting Coins 41x50 Bed

CIFML40A, CIFRL40A, CIFEL40A, CIFER40A, COHORFPN, COHORFPM



Pivoting Coins 41x50 Bed

CIFML40A, CIFRL40A, CIFEL40A, CIFER40A, COHORFPN, COHORFPM

Parts List—Mid-Pivoting Coins 41x50 Bed

Find the correct assembly first, then find the needed components. The item letters (A, B, C, etc.) assigned to assemblies are referred to in the "Used In" column to identify which components belong to an assembly. The item numbers (1, 2, 3, etc.) assigned to components relate the parts list to the illustration.

Used In	Item	Part Number	Description	Comments
-----ASSEMBLIES-----				
	A	ALC50070	FS PIVOT COINC ASSY-CIFML40A	CIFML40A
	B	ALC50071	FS PIVOT COINC ASSY-CIFMR40A	CIFMR40A
	C	ALC50073	FS PIVOT COINC ASSY-CIFER40A	CIFER40A
	D	ALC50072	FS PIVOT COINC ASSY-CIFEL40A	CIFEL40A
	E	ALC420030	FS-PIV CONV-ASSY LEFT	COHORFPN
	F	ALC420029	FS-PIV CONV-ASSY RIGHT	COHORFPM
-----COMPONENTS-----				
A	1	W4 22563	FS POST WLMT-CIFML40A	
B	1	W4 22563A	FS POST WLMT-CIFMR40A	
C	1	W4 22576	FS POST WLMT-CIFER40A	
D	1	W4 22576A	FS POST WLMT-CIFEL40A	
E	1	W4 21255A	*FS-SUPPORT FRAME-WELDMENT LF	
F	1	W4 21255	*FS-SUPPORT FRAME-WELDMENT RT	
A	2	W4 22564	PIVOT BOX WLMT-CIFML40A	
B	2	W4 22564A	PIVOT BOX WLMT-CIFMR40A	
C	2	W4 22577	FS PIVOT BOX WLMT-CIFER40A	
D	2	W4 22577A	FS PIVOT BOX WLMT-CIFEL40A	
E	2	W4 21256	FS-PIVOTING FRAME LF WLMT	
F	2	W4 21260	FS-PIVOTING FRAME RT WLMT	
all	3	W4 21257	*FS-UPPER SHAFT WELDMENT	
all	4	04 21253	FS-UPPER SHAFT LONG SPACER	
all	5	54AF1437	FLGEBRG.HUBCITY 3-BOLT FB150URX1-7/16	
All	6	15U425	LOCKWASHER MEDIUM 1+1/4"ZINC P	
all	7	15G261A	HVYHXJAMNUT 1+1/4-8UN2B ZINC G	
all	8	15A021	CARRBOLT 3/8-16 X1.5 ZNC GR 5	
all	9	15G205	HXNUT 3/8-16UNC2B ZINC GR2	
all	10	15U255	LOCKWASHER MEDIUM 3/8 ZINCPL	
all	11	15K151	HXCAPSCR 1/2-13UNC24X1.25 GR5	
all	12	15U300	LOKWASHER REGULAR 1/2 ZINC PLT	
all	13	04 22582	LOWER BRNG TAP PLATE	
all	14	54AF10001A	FLG BRG 1"BORE NTN#UCF205-100T (4-BOLT)	
all	15	15K143C	HEXCAPSCR 7/16-14 X 1.5 GR5 ZP	
all	16	15U278	LOCKWASHER MEDIUM 7/16 ZINCPL	
all	17	27C415	AIR CYL 4"X15"X1" CLEVIS MT	
all	18	54AA00PFRE	FEM ROD END ALIN#VF-12G 3/4"	
all	19	15K240C	HEXCAPSCR 3/4-10X 3.25	
all	20	15U320P	FLATWASHER(USS STD) 3/4" ZNC P	
all	21	15U321H	FLTWASH 3/4 HARD ASTM F436	
all	22	15U493	FLTWASH 1+1/2X25/32X1/4 ZINC	
all	23	15U340	LOCKWASH MEDIUM 3/4 ZINCPL	
all	24	15G240	HXNUT 3/4-10UNC2B SAE ZINC GR2	

Pivoting Coins 41x50 Bed

CIFML40A, CIFRL40A, CIFEL40A, CIFER40A, COHORFPN, COHORFPM

Parts List—Mid-Pivoting Coins 41x50 Bed

Find the correct assembly first, then find the needed components. The item letters (A, B, C, etc.) assigned to assemblies are referred to in the "Used In" column to identify which components belong to an assembly. The item numbers (1, 2, 3, etc.) assigned to components relate the parts list to the illustration.


Used In	Item	Part Number	Description	Comments
all	25	17A045	CLEVIS PIN 3/4"X 3" DRILLED +	
all	26	04 21257A	CLEVIS PIN BRACKET	
all	27	01 10375B	NPLT:ELEC HAZARD SMALL-TCATA	
all	28	01 10634A	NPLT:CONVEYOR HAZARDS-TCATA	
all	29	ESP61EMS	* SWPNL= M6PRS EMERGENCY STOP	
all	30	09N042204	DISCON SWITCH 40A 600V 2POS 4P	
all	31	09RPS18CAU	PRXSW QK CONN 18M NO-AC UNSHLD	
all	32	09H026V37	BEACON ROTARY 90MM AMBER CE ALLEN BRADLEY	
all	33	09RPE004	PE DARK OP AC N/O-OUT 24-240V	
all	34	09RPE001A	REFLECTOR 3"DIA CLEAR	

Rollers, Bearings, Carriers and Torque Arm



CONVEY40, CONVEY42, CONVEY46, CONVEY48, CONVEY50

BPVAUN01.R01 0000170507 D.2 C.2 5/15/18 2:44 PM Released

Figure 1. Drive Roller: Bearing Carrier with Torque Arm



- Legend**
- A-A. Section view, Drive roller adjusting bolt
 - B. Reducer #726 or #732, See BPVAUNO2.
 - C. The head of this nut is inserted into the bracket's hexagonal hole with the flange to the outside.
 - D. Bearing carrier adjusting bracket



Rollers, Bearings, Carriers and Torque Arm

CONVEY40, CONVEY42, CONVEY46, CONVEY48, CONVEY50

Figure 2. Torque Arm Hardware






Figure 3. Drive Roller: Bearing Carrier with no Torque Arm (Non-Drive Side)



Rollers, Bearings, Carriers and Torque Arm

CONVEY40, CONVEY42, CONVEY46, CONVEY48, CONVEY50


Figure 4. Inclined torque arm, Isolators



Rollers, Bearings, Carriers and Torque Arm

CONVEY40, CONVEY42, CONVEY46, CONVEY48, CONVEY50

Figure 5. Idler Roller: Bearing Carrier



Legend

E-E. Section view, Idler roller adjusting bolt

F. The head of this nut is inserted into the bracket's hexagonal hole with the flange to the inside.

Rollers, Bearings, Carriers and Torque Arm

5 of 6

CONVEY40, CONVEY42, CONVEY46, CONVEY48, CONVEY50

Table 1 Parts List—

Find the assembly for your machine and the letter shown in the "Item" column. The components for your machine will show this letter or the word "all" in the "Used In" column. The numbers shown in the "Item" column are those shown in the illustrations.				
Used In	Item	Part Number	Description/Nomenclature	Comments
Assemblies				
	A		40" WIDE CONVEYOR	REFERENCE
	B		42" WIDE CONVEYOR	REFERENCE
	C		44" WIDE CONVEYOR	REFERENCE
	D		46" WIDE CONVEYOR	REFERENCE
	E		48" WIDE CONVEYOR	REFERENCE
	F		48" WIDE CONVEYOR	REFERENCE
	G		HORIZONTAL TORQUE ARM #726 GEAR REDUCER	REFERENCE
	H		HORIZONTAL TORQUE ARM #732 GEAR REDUCER	REFERENCE
	J		INCLINED TORQUE ARM #726 GEAR REDUCER	REFERENCE
	K		INCLINED TORQUE ARM #732 GEAR REDUCER	REFERENCE
	L		40" IDLER ROLLER	REFERENCE
	M		42" IDLER ROLLER	REFERENCE
	N		44" IDLER ROLLER	REFERENCE
	P		46" IDLER ROLLER	REFERENCE
	Q		48" IDLER ROLLER	REFERENCE
	R		50" IDLER ROLLER	REFERENCE
Components				
A	1	APC40001A	APC40001A *MCS 40"ONE DRV LAG=1.43INPUT	
B	1	APC42007	APC42007 MCS 42W DRV ROLLER 1.44 INPUT	
C	1	APC44002	APC44002 MCS 44W DRIVE LAGGED ROLLER	
D	1	APC46001	APC46001 46" DRIVE LAGGED 1.437 INPUT	
E	1	APC48005	APC48005 48" DRIVE LAGGED 1.437 INPUT	
F	1	APC50002	APC50002 MCS 50W DRV ROLLER 1.44 INPUT	
all	2	54AF1437	54AF1437 FLGEBRG 3-BOLT FB150URX1-7/16	
all	3	54M010	54M010 GRSFIT 1/4-28NF90 ALEMITE1911B	
all	4	54JH11437C	54JH11437C SHAFTCOLLAR 1.4375 CFG #23S	
all	5	04 21412B	04 21412B BRNGCARR-NO TORQARM-22"LG	
all	6	W4 20029B	W4 20029B *BRGCAR WITH TORQ ARM MT WLMT	
all	7	04 22714A	04 22714A BRG CARRIER ADJUSTING BKT	
all	8	17R023A05K	17R023A05K THREADED ROD 1/2-20UNFX5+1/2"L	
all	9	60B055	60B055 VIBRO ISOLATER REINFORCED 70 D	
G	10	04 20070E	04 20070E TORQUE ARM 1.438"SHAFT MT DR	
H	10	04 20070N	04 20070N TORQUE ARM 732 REDUCER	
J	10	04 20167E	04 20167E TORQUE ARM=726 INCLINE	
K	10	04 20167H	04 20167H +TORQUE ARM=732 INCLINE	
G	11	04 20070G	04 20070G TORQUE ARM END BKT 1.438SHFT	
H	11	04 20070U	04 20070U TORQUE END BRKT 732 RED=HORZ	
J	11	04 20167D	04 20167D +END BRKT=726 INCLINE	
K	11	04 20167G	04 20167G +END BRKT=732 INCLINE	
G	12	04 20070F	04 20070F TORQUE ARM BKT 1.438" SHAFT	
H	12	04 20070L	04 20070L TORQUE ARM BRKT 732 REDUCER	
J	12	04 20167F	04 20167F +MOTOR SPPT BRKT=726 INCLINE	
K	12	04 20167I	04 20167I MOTOR SUPP BRKT=732 INCLINE	
A-E	13	15E228	MACHINE KEY .375X.312X5.50LG	
F	13	15E232	SQMACHKEY 3/8X3/8X3+3/4	

Rollers, Bearings, Carriers and Torque Arm

6 of 6

CONVEY40, CONVEY42, CONVEY46, CONVEY48, CONVEY50


1 Parts List— (cont'd.)

Find the assembly for your machine and the letter shown in the "Item" column. The components for your machine will show this letter or the word "all" in the "Used In" column. The numbers shown in the "Item" column are those shown in the illustrations.				
Used In	Item	Part Number	Description/Nomenclature	Comments
all	14	27B250	27B250 SPCRROLL.5ID1.5L.062T STLZNC	
all	17	15K063	15K063 HXCPCSC 5/16 18X1 GR8 ZC	
all	18	15G196	15G196 HXFLGNUT 5/16-18 ZINC	
all	19	15A011	15A011 CARBOLT 3/8-16UNC2X1 ZINC GR2	
all	20	15A012	15A012 CARBOLT 3/8-16UNC2AX1+1/4 ZNC	
all	21	15G218	15G218 HXLOKNUT NYL 3/8-16 STL/ZNC	
all	22	15K095	15K095 HXCPCSCR 3/8-16UNC2AX1 GR5 ZINC	
all	23	15U240	15U240 FLATWASHER(USS STD) 3/8" ZNC P	
all	24	15U343	15U343 FLATWASH 1X25/64X1/8 ZINC	
all	25	15U255	15U255 LOCKWASHER MEDIUM 3/8 ZINCPL	
all	26	15G198	15G198 HXFLGNUT 3/8-16 ZINC	
all	27	15K128	15K128 HEXFLGSCR 1/2-13X1 ZN. GRD. 5	
all	28	15K129	15K129 HEXFLGSCR 1/2-13X1-1/4ZN. GR 5	
all	29	15D122C	15D122C HEXTAPSCR 1/2-13UNCK 8.5 FLTHD	
all	30	15U280	15U280 FL+WASHER(USS STD)1/2 ZNC PL+D	
all	31	15G222B	15G222B HEXFLGNUT 1/2-13 ZINC SERRATED	
all	32	15G231A	15G231A HXFINJAMNUT 1/2-20UNF2B ZINC G	
all	33	15U202	15U202 FLATWSHR.50ID1.75OD11GA ZNC	
all	34	15U490	15U490 FLTWASH 1+1/2X17/32X1/4 ZINC	
all	35	15U286	15U286 FLATWASHER 2"0DX17/32"IDX1/4"	
L	40	X4 22392	X4 22392 ROLLER 6X40W IDLER MACH	
M	40	AIC42005	AIC42005 MCS 42W IDLER ASSY	
N	40	X4 24583	X4 24583 IDLER ROLLER 6X44W-MACHINED	
P	40	X4 22449	ROLLER 6X46W IDLER MACH	
Q	40	X4 22443	X4 22443 ROLLER 6X48W IDLER MACH	
R	40	X4 21998	X4 21998 ROLLER 6X50W IDLER MACH	
all	41	W4 22389	W4 22389 BRNGCARR WLMT-LOADEND TRACKING	
all	42	04 22392	04 22392 BRG CARRIER ADJUSTING BKT	
all	43	15K226H	15K226H HXCAPSCR 5/8-11X1 1/4 GR5 ZN	
all	44	15G238N	15G238N HXLOCKNUT NYL 5/8-11UNC STL/	
all	45	15U345B	15U345B FLTWASH 101NYL 41/64IDX1.125OD	
all	46	04 20023A	04 20023A MCS MOD CONN BKT RIGHT END	
all	47	04 20023B	04 20023B MCS MOD CONN BKT LEFT END	
all	48	W4 24340	SHAFT COVER- GEAR REDUCER 726/732	SHAFT COVER , DRIVE SIDE
all	49	04 23772	CONVEY ROLLER BRNG COVER	COVER, NON-DRIVE SIDE (NOT SHOWN)

Gear Reducers

BPVAUN03.R01 0000176245 A.6 4/25/18 10:26 AM In Work

Figure 1.



Legend

- A. Gear reducer used on end drive
- B. Gear reducer used on under-drive
- C. Supply parts department with gear reducer ratio, an example shown here.
- D. Supply parts department with gear reducer serial number, an example shown here.

Table 1 Parts List—


Find the assembly for your machine and the letter shown in the "Item" column. The components for your machine will show this letter or the word "all" in the "Used In" column. The numbers shown in the "Item" column are those shown in the illustrations.

Used In	Item	Part Number	Description/Nomenclature	Comments
Assemblies				
none				
Components				
all	1	54STB32625	54STB32625 REDUCER 25:1 SF726-25T-B5-G	#726 RATIO 25:1
all	2	54STB32630	54STB32630 REDUCER 30:1 SF726-30T-B5-G	#726 RATIO 30:1
all	3	54STB32640	54STB32640 REDUCER 40:1 SF726-40T-B5-G	#726 RATIO 40:1
all	4	54STB32650	54STB32650 REDUCER 50:1 SF726-50T-B5-G	#726 RATIO 50:1
all	5	54STB32660	54STB32660 REDUCER 60:1 SF726-60T-B5-G	#726 RATIO 60:1
all	6	54STB33225	54STB33225 REDUCER 25:1 SF732-25T-B7-G	#732 RATIO 25:1
all	7	54STB3323A	54STB3323A REDUCER + 7/8-5/8 IN-ADAPTER	#732 RATIO 30:1
all	8	54STB3324A	54STB3324A REDUCER + 7/8-5/8 IN-ADAPTER	#732 RATIO 40:1
all	9	54STB3325A	54STB3325A REDUCER + 7/8-5/8 IN-ADAPTER	#732 RATIO 50:1
all	10	54STB3326A	54STB3326A REDUCER + 7/8-5/8 IN-ADAPTER	#732 RATIO 60:1

Bed 41"x50"

COINC111, COHORFPM, COHORFRN, CIFEL40A, CIFER40A, CIFML40A, CIFMR40A

Figure 1: XX



Bed 41"x50"

COINC111, COHORFPM, COHORFRN, CIFEL40A, CIFER40A, CIFML40A, CIFMR40A

Parts List—Bed 41x50				
Find the correct assembly first, then find the needed components. The item letters (A, B, C, etc.) assigned to assemblies are referred to in the "Used In" column to identify which components belong to an assembly. The item numbers (1, 2, 3, etc.) assigned to components relate the parts list to the illustration.				
Used In	Item	Part Number	Description	Comments
			-----ASSEMBLIES-----	
	A	ALC50001B	CONV.BED ROUGH 41X50 NO EYE	COINC111, COINC11H
	B	ALC50001A	CONVEYORBED 41X50, NO PHO-EYE	COHORFPN/FPM CIFEL40A, CIFER40A CIFML40A, CIFMR40A
			-----COMPONENTS-----	
all	1	54STB31830	REDUCER 30:1 SF718-30T-B5-G	
all	2	15E227	MACHINE KEY .250X.219X4.50LG	
all	3	04 20801	BRNG SUPPORT CONV	
all	4	04 20802	CONV SIDE RAIL=4 ROLLER	
all	5	04 20803	COSHA BED CROSS MEMBER	
all	6	04 20809	JOINER PLATE CONV	
all	7	04 20808	BRNG ADJ BRKT CONV	
all	8	04 20810	CORNER BRACE CONV	
all	9	04 20815	ANGLE BRKT CONV	
all	10	Y4 20832E	DRVROLLER 4.50D X 53" OAL	
all	11	Y4 20832G	IDLER ROLLER 4.50D X 44.5" OAL	
all	12	04 20837C	CHAN TORQUE ARM MT 318BOSTON	
all	13	04 20837B	BRKT =TORQUE ARM 318 BOSTON	
all	14	54AF10001	FLG BRG 1" BROWN#VF2S-116M (2BOLT FLG)	
all	15	15U240	FLATWASHER(USS STD) 3/8" ZNC P	
all	16	15K095	HXCPSCR 3/8-16UNC2AX1 GR5 ZINC	
all	17	15U255	LOCKWASHER MEDIUM 3/8 ZINCPL	
all	18	15G205	HXNUT 3/8-16UNC2B ZINC GR2	
all	19	15K203	HXTAPSCR TFL 1/2-13X5 GR5 ZINC	
all	20	15U280	FL+WASHER(USS STD)1/2 ZNC PL+D	
all	21	15U300	LOKWASHER REGULAR 1/2 ZINC PLT	
all	22	15G230	HXNUT 1/2-13UNC2B SAE ZINC GR2	
all	23	15A008C	CARRBOLT 5/16-18NCX1"ZINC GR-	
all	24	15U210	LOKWASHER MEDIUM 5/16 ZINCPL	
all	25	15G185	HXNUT 5/16-18UNC2B SAE ZINC GR	
A	26	54C401000L	BELT 40W V-ROUGH TOP-105"LG	
B	26	54C400000A	BELT 40X V-SMOOTH TOP -104"LG	
all	27	12P11PHP	HOLEPLUG 1+3/4" BLK HEYCO#2773	
all	28	04 20804A	BED 4ROL 42W 50L GROOVE	
all	29	15K144C	HEXCAPSCR 7/16-14UNC X 2.5 GR	
all	30	15U312	HARD FWASH 3/4ODX33/64IDX.115	
all	31	60B065	RUBBER MNT CTR BONDED 40 DURO	
all	32	04 20796	SLEEVE=TORQUE ARM BUSHING	
all	33	15U271	LOKWASH INTOOTH 7/16ZN	
all	34	15G222C	HEXNUT 7/16-14UNC2B ZINC GR2	

Bed 41"x50"

COINC111, COHORFPM, COHORFRN, CIFEL40A, CIFER40A, CIFML40A, CIFMR40A

Parts List—Bed 41x50


Find the correct assembly first, then find the needed components. The item letters (A, B, C, etc.) assigned to assemblies are referred to in the "Used In" column to identify which components belong to an assembly. The item numbers (1, 2, 3, etc.) assigned to components relate the parts list to the illustration.

Used In	Item	Part Number	Description	Comments
all	35	15G222	HXFINJAMNUT 7/16-14UNC2B ZINC	
all	36	04 20838	TORQUE ARM SUP CONV REAR 0	
all	37	04 20838A	TORQUE ARM SUPPORT SPACER	

Bed Assemblies

CONVEY24, CONVEY36, CONVEY40, CONVEY42, CONVEY44, CONVEY48, CONVEY50, CONVEY60





BPVAUN04.R01 0000182532 B.2 4/20/18 1:53 PM Released



- A-Z See reference bed sizes in the parts list.
- DA See Detail DA.
- DB See Detail DB.
- EE See View EE.
- FF See View FF.

Bed Assemblies

CONVEY24, CONVEY36, CONVEY40, CONVEY42, CONVEY44, CONVEY48, CONVEY50, CONVEY60



- DA View DA
- DB View DB
- EE View EE
- FF View FF

Bed Assemblies

3 of 4

CONVEY24, CONVEY36, CONVEY40, CONVEY42, CONVEY44, CONVEY48, CONVEY50, CONVEY60

Table 1 Parts List—

Find the assembly for your machine and the letter shown in the "Item" column. The components for your machine will show this letter or the word "all" in the "Used In" column. The numbers shown in the "Item" column are those shown in the illustrations.

Used In	Item	Part Number	Description/Nomenclature	Comments
Assemblies				
	A	ALC24000	REFERENCE ASSEMBLY	CONVEY24, L=24
	B	ALC24004	REFERENCE ASSEMBLY	CONVEY24, L=48
	C	ALC24002	REFERENCE ASSEMBLY	CONVEY24, L=84
	D	ALC36000	REFERENCE ASSEMBLY	CONVEY36, L=24
	E	ALC36068	REFERENCE ASSEMBLY	CONVEY36, L=48
	F	ALC36069	REFERENCE ASSEMBLY	CONVEY36, L=84
	G	ALC40000	REFERENCE ASSEMBLY	CONVEY40, L=24
	H	ALC40001	REFERENCE ASSEMBLY	CONVEY40, L=48
	J	ALC40002	REFERENCE ASSEMBLY	CONVEY40, L=84
	K	ALC420141	REFERENCE ASSEMBLY	CONVEY42, L=24
	L	ALC420142	REFERENCE ASSEMBLY	CONVEY42, L=48
	M	ALC420143	REFERENCE ASSEMBLY	CONVEY42, L=84
	N	ALC420144	REFERENCE ASSEMBLY	CONVEY42, L=108
	O	ALC48000	REFERENCE ASSEMBLY	CONVEY48, L=24
	P	ALC48001	REFERENCE ASSEMBLY	CONVEY48, L=48
	Q	ALC48002	REFERENCE ASSEMBLY	CONVEY48, L=84
	R	ALC48003	REFERENCE ASSEMBLY	CONVEY48, L=108
	S	ALC50123	REFERENCE ASSEMBLY	CONVEY50, L=24
	T	ALC50124	REFERENCE ASSEMBLY	CONVEY50, L=48
	U	ALC50125	REFERENCE ASSEMBLY	CONVEY50, L=84
	V	ALC50126	REFERENCE ASSEMBLY	CONVEY50, L=108
	W	ALC60000	REFERENCE ASSEMBLY	CONVEY60, L=24
	X	ALC60001	REFERENCE ASSEMBLY	CONVEY60, L=48
	Y	ALC60002	REFERENCE ASSEMBLY	CONVEY60, L=84
	Z	ALC60003	REFERENCE ASSEMBLY	CONVEY60, L=108
Components				
A	1	04 21185A	SS CONV BED FULL 24W X 24L	
B	1	04 21183	SS CONV BED FULL 24W X 48L	
C	1	04 21184	SS CONV BED FULL 24W X 84L	
D	1	04 23090C	SS CONV BED FULL 36WX24LG	
E	1	04 23081	CONV BED FULL 36WX48L	
F	1	04 23080	CONV BED HALF 36WX42L	
G	1	04 23090A	CONV BED FULL 40WX24L	
H	1	04 23084	CONV BED FULL 40WX48L	
J	1	04 21879A	CONV BED FULL 42WX24L	
K	1	04 21879	CONV BED FULL 42WX48L	
L	1	04 21878	CONV BED HALF 42WX42L	
M	1	04 21881	CONV BED HALF 42WX54L	
N	1	04 23090E	CONV BED FULL 48WX24LG	
P	1	04 23087	CONV BED FULL 48WX48L	
Q	1	04 23086	CONV BED HALF 48WX42L	
R	1	04 23085	CONV BED HALF 48WX54L	
S	1	04 23090F	CONV BED FULL 50WX24LG	
T	1	04 21972	CONV BED FULL 50WX48LG	

Bed Assemblies

4 of 4

CONVEY24, CONVEY36, CONVEY40, CONVEY42, CONVEY44, CONVEY48, CONVEY50, CONVEY60

1 Parts List— (cont'd.)

Find the assembly for your machine and the letter shown in the "Item" column. The components for your machine will show this letter or the word "all" in the "Used In" column. The numbers shown in the "Item" column are those shown in the illustrations.				
Used In	Item	Part Number	Description/Nomenclature	Comments
U	1	04 21973	CONV BED HALF 50WX42LG	
V	1	04 21974	CONV BED HALF 50WX54LG	
W	1	04 23090G	CONV BED FULL 60WX24LG	
X	1	04 23090	CONV BED FULL 60WX48L	
Y	1	04 23089	CONV BED HALF 60WX42L	
Z	1	04 23088	CONV BED HALF 60WX54L	
DGJNSW	2	04 23096A	CONV SIDE 3.00X1.50X24L	
EHKPTX	2	04 23093	CONV SIDE 3.00X1.50X48L	
FLQUY	2	04 23092	CONV SIDE 3.00X1.50X84L	
MRVZ	2	04 23091	CONV SIDE 3.00X1.50X108L	
ABC	3	60F125	UHMW POLYMER STRIP 1+1/2"X1/4"	
DGNSW	3	X4 24346	CONV 2FT BED UHMW STRIP-MACHINED	
EHKPTX	3	X4 24345	CONV 4FT BED UHMW STRIP-MACHINED	
FLQUY	3	X4 24344	CONV 7FT BED UHMW STRIP-MACHINED	
MRVZ	3	X4 24343	CONV 9FT BED UHMW STRIP-MACHINED	
all	4	15N176	FLATMACSCR 1/4-20NCX3/4SS18-8	
all	5	15G166A	HXLKKNUT NYL1/4-20 UNC2A STL/Z	
all	6	15A011	CARBOLT 3/8-16UNC2X1 ZINC GR2	
all	7	15P200	TRDCUT-F HXWASHD 3/8-16X3/4NIK	
all	8	15K095	HXCPSCR 3/8-16UNC2AX1 GR5 ZINC	
all	9	15U255	LOCKWASHER MEDIUM 3/8 ZINCPL	
all	10	15U240	FLATWASHER(USS STD) 3/8" ZNC P	
all	11	15G205	HXNUT 3/8-16UNC2B ZINC GR2	
all	12	15G198	HXFLGNUT 3/8-16 ZINC	
all	13	15K092	HEXFLGSCR 3/8-16X1 GR8 CS	