



Manual Number: MCWG6M01
Edition (ECN): 2023352A

Mechanical Parts and Service

60044SR2, SR3



2.2.2	How to Do a Friction Pad Replacement.....	45
2.2.3	How to Do a Caliper Overhaul.....	47
2.2.4	How to Change Hydraulic Fluid and Remove (Bleed) Air from the Brake Circuit	48
2.2.5	How to Adjust the Connection between the Brake Cylinder and the Air Cylinder.....	52
2.2.6	Operation of Brake Systems.....	54
2.2.6.1	How to Apply the Brake for Machines with a "Break Release" Output.....	54
2.2.6.2	How to Release the Brake for Machines with a "Brake Release" Output.....	55
2.2.6.3	How to Apply and then Release the Brake Quickly.....	55
2.2.6.4	How the Brake Operates on Divided Cylinder Machines	55
2.2.6.5	The Second Brake.....	56
	Drive Chart 6044SP2, 6044SP3 (Single Motor).....	57
	Drive Base 6044SP2, 6044SP3 (Single Motor).....	62
	Jackshaft 42044WR2, 42044SR2, 60044WR2, 60044SR2	70
	Single Motor Drive 60044SR2.....	72
	Drive Base Installation 60044SR2	74
	Upper Disc Brake 6044SP2, 6044SP3, 6044SR2, 6044SR3	78
2.3	Main Bearing and Seal Replacement for Divided Cylinder Machines	81
2.3.1	Removing the Bearing (Front or Rear).....	82
2.3.2	Removing the Bearing Housing (Bearing and Seal Carrier), Seal Sleeve, and Seals (Front or Rear)	83
2.3.3	Precautions for Bearing Replacement	84
2.3.4	Replacing the Bearing Housing, Seal Sleeve, and Seals (Front or Rear).....	85
2.3.5	Measuring Unmounted Clearance and Setting Bearing (Front or Rear)	87
2.3.6	Tightening Bearing(s) (Front and/or Rear).....	89
2.4	Idler Shaft Bearing Replacement	91
2.5	How to Remove the Bearings	91
2.6	How To Install New Bearings	92
	Shaft and Bearing Components	94
	AutoSpot™ 6044SP2, 6044SP3, 6044SR2, 6044SR3	98
	4" Idler Shaft Bearing Installation 6044SR2, 6044SR3	100
	Lower Disc Brake Installation 6044SR2, 6044SR3, 7244SR2	103
	Lower Disc Brake Split Bearing Parts and Assembly 6044SR2, 72044SR2/SR3	108
	Assembly Procedure	109
3	Frame & Suspension.....	113
3.1	Suspension Adjustments for Divided Cylinder Machines	113
3.1.1	How Shell Adjustments are Made.....	113
3.1.2	Shell Hanging Dimensions and Adjustment Procedures.....	114
3.1.3	Push-Down Travel Dimensions and Adjustment Procedures.....	116
3.1.3.1	42" Divided Cylinder Machines	116
3.1.3.2	60" Divided Cylinder Machines.....	117
	Hold Down Adjustment 6044SR2/SR3, 6044WR2/WR3, 72044SR2/SR3, 72044WR2/WR3	120
	Push Down 6044SP2, 6044SP3, 6044SR2, 6044SR3.....	122
	Suspension Cylinder Assemblies 42031,42044,52038,60044,72044	124

Suspension Cylinder Locations	128
4 Shell, Cylinder & Doors	130
Shell Doors 60044SR2, 60044SR3, 6044WR3	132
Door Latch	136
Cylinder Assembly and Cylinder Door Installation 6044SR2, 7244SR2.....	137
Cylinder Door Installation 6044WP3/SP3, 6044WR3, 6044SR3.....	142
Cylinder Door Assembly 6044WP3/SP3, 6044WR3, 6044SR3.....	144
5 Staph Guard®	147
Staph Barrier Cleanside 6044SR2, 72044SR2.....	148
Staphairtrol 60044SR2, 72044SR2	150
6 Control & Sensing	153
Excursion Switch 6044SR2, 6044SR3, 7244SR2	154
Air Chamber Level Switch 42044WR2,WR3,SR2,SR3; 6044WR2,WR3,SR2, SR3; 72044WR2, WR3, SR2, SR3	155
Temperature Probe 6044WR2,WR3,SR2 72044WR2,WR3,SR3	157
6.1 Vibration Safety Switch Adjustments	158
6.1.1 What the Vibration Safety Switch Does.....	158
6.1.2 Adjustments.....	158
Vibration Safety Switch	160
7 Chemical Supply Devices.....	161
Peristaltic Supply Inlet 6044SP2, 6044SP3, 6044SR2, 6044SR3.....	162
Five Compartments for Dry Chemical Supplies	164
8 Water & Steam	169
Water Inlets and Optional Siphon Breaker 60044SR2, 60044SR3	170
Siphon Breaker & Scupper	174
Steam Inlet & Sparger 4244SP2, 4244SP2 SM, 6044SP2/SP3, 6044SP2 SM	176
Burket Steam Valve	178
8"X10" Stainless Dump Valve 42044WR2/WR3/SR2/SR3; 60044WR2/WR3/SR2/SR3; 72044WR2/WR3/SR2/SR3	179
9 Pneumatic	182
9.1 Servicing Air Cylinders	182
Brake Air Cylinder	186

Figures

Figure 1	The Bolts in Milnor® Equipment.....	20
Figure 2	Apply Threadlocker in a Blind Hole.....	26
Figure 3	Apply Threadlocker in a Through Hole.....	27
Figure 4	Use heat for disassembly of fasteners with threadlocker.....	27
Figure 5	Examples of drives this instruction applies to: one or more V-belts, at- tached V-belts and tooth belts.....	33
Figure 6	Pulley Groove Condition	34
Figure 7	Pulley and Shaft Position.....	35
Figure 8	Run-out	36
Figure 9	Typical Pulley Assembly	36
Figure 10	Types of Belt Damage.....	37
Figure 11	A Tension Mechanism that will not Change the Angle of the Pulleys	39

Figure 12	Some Pairs of Tension Mechanisms that Can Change the Angle of the Pulleys.....	39
Figure 13	Use a straight edge, a string, or a laser to make sure that all pulleys are in the same plane.....	41
Figure 14	Use a level to make sure that the pulleys are at the same slope.	42
Figure 15	Dial indicator used to find the axial and radial run-out of a pulley.	42
Figure 16	A typical hydraulic brake system.....	43
Figure 17	The Caliper Components	47
Figure 18	Pumps Used to Remove Hydraulic Fluid Quickly.....	50
Figure 19	Typical Tools to Remove Air (Bleed) Brakes and Used Hydraulic Fluid	50
Figure 20	The Connection between the Brake Cylinder and the Air Cylinder	52
Figure 21	The Adjustment between the Brake Rod and the Air Cylinder	53
Figure 22	A Typical First and Second Brake on a Divided Cylinder Machine.....	55
Figure 23	Motor mount, drive shaft, and pillow back bearings	74
Figure 24	Motor mount, drive shaft, and pillow block bearings.....	75
Figure 25	Adjustable bolts	76
Figure 26	Disc	78
Figure 27	Air Cylinder and Master Cylinder	79
Figure 28	Cross Section View of Front and Rear Bearing Assemblies (Bearing Assembly for 60" and 72" WED Shown. Others similar.).....	81
Figure 29	Connection From Hydraulic Pump to Assist in Bearing Removal.....	83
Figure 30	Two Bearing Housing Guide Rods in Position.....	83
Figure 31	Bearing Housing Pulling Fixture in Position.....	83
Figure 32	Installing Seals in Bearing Housing.....	85
Figure 33	Installing Seal Sleeve in Bearing Housing	85
Figure 34	Installing the Bearing Housing Setting Fixture onto Housing (42" machine shown).....	86
Figure 35	Pushing the Bearing Housing into the Shell (60" Rapid-load machine shown).....	86
Figure 36	Tightening the Bearing Housing into the Shell (42" machine shown)	87
Figure 37	Measuring Bearing Unmounted Clearance (bridge for 42" machine shown).....	88
Figure 38	Tightening the Bearing Lock nut (42" machine shown).....	90
Figure 39	Measuring the Mounted Internal Clearance of the Bearing (42" machine shown).....	90
Figure 40	Shaft and Bearing Components	94
Figure 41	Front Bearing (Models: 6044WP2, 6044WP3, 6044WR2, 6044WR3)	94
Figure 42	Front Bearing (Models: 6044SP2, 6044SP3, 6044SR2, 6044SR3	95
Figure 43	Rear Bearing (Models: 6044WP2, 6044WP3, 6044WR2, 6044WR3 & 6044SP2, 6044SP3, 6044SR2, 6044SR3)	95
Figure 44	Bearing Components.....	108
Figure 45	Hydro-cushion™ Upper Shaft and Adjusting Nuts.....	114
Figure 46	Shell Hanging for Divided Cylinder Machines (Left side view of 60044WE shown)	115
Figure 47	Push-down Travel Adjustment: 42" Div-cyls (42" Staph Guard®)	117
Figure 48	Ring Weldments.....	118
Figure 49	Exploded Views	132

Figure 50	Detail View	133
Figure 51	Cylinder Assembly and Cylinder Door Installation	137
Figure 52	Cylinder Doors Installed.....	138
Figure 53	Detail Views.....	139
Figure 54	Exploded View	150
Figure 55	Installed View	151
Figure 56	Vibration Switch	159
Figure 57	Five Compartments for Dry Chemical Supplies.....	164
Figure 58	Right Side View (Covers), Bottom View (Hose).....	164
Figure 59	Valve Manifold	165
Figure 60	Hot Water Inlet, Pressure Regulator Assembly	166
Figure 61	Water Inlets and Optional Siphon Breaker	170
Figure 62	Inlet Pipe	171
Figure 63	Using Threaded Rods.....	183
Figure 64	Ensuring Correct Piston Cup Shape.....	183

Tables

Table 1	Trademarks	9
Table 2	Parts List—Safety Placard Use and Placement 60044SR2, 60044SR3, 72044SR2	17
Table 3	Parts List—Safety Placard Use and Placement ISO 60044SR2, 60044SR3, 72044SR2	19
Table 4	Torque Values for Standard Fasteners with Maximum 5/16-inch Diameters and No Lubricant	20
Table 5	Torque Values for Standard Fasteners Larger Than 5/16-inch Diameters and No Lubricant	21
Table 6	Torque Values for Plated Fasteners with Maximum 5/16-inch Diameters and No Lubricant	21
Table 7	Torque Values for Plated Fasteners Larger Than 5/16-inch Diameters and No Lubricant	22
Table 8	Threadlocker by the Diameter of the Bolt (see below Note)	22
Table 9	Torque Values if You Apply LocTite 222	23
Table 10	Torque Values if You Apply LocTite 242	23
Table 11	Torque Values if You Apply LocTite 262	23
Table 12	Torque Values if You Apply LocTite 272 (High-Temperature)	23
Table 13	Torque Values if You Apply LocTite 277	24
Table 14	Torque Values for Stainless Steel Fasteners 5/16-inch and Smaller	24
Table 15	Torque Values for Stainless Steel Fasteners Larger Than 5/16-inch	25
Table 16	Parts List—General Assembly 6044SP2, 6044SP3, 6044SR2, 6044SR3.....	32
Table 17	Typical Tools for Pulley and Belt Maintenance	39
Table 18	Parts List—Drive Chart 6044SP2, 6044SP3 (Single Motor).....	61
Table 19	Parts List—Drive Base 6044SP2, 6044SP3 (Single Motor).....	68
Table 20	Parts List—Jackshaft 42044WR2, 42044SR2, 60044WR2, 60044SR2	71
Table 21	Parts List—Single Motor Drive 60044SR2.....	73
Table 22	Parts List—Drive Base Installation 60044SR2	77
Table 23	Parts List—Upper Disc Brake 6044SP2, 6044SP3, 6044SR2, 6044SR3	80
Table 24	Table of Bearing Clearances	89

Table 25	Parts List—Shaft and Bearing Components	96
Table 26	Parts List—AutoSpot™ 6044SP2, 6044SP3, 6044SR2, 6044SR3	98
Table 27	Parts List—4” Idler Shaft Bearing Installation 6044SR2, 6044SR3	101
Table 28	Parts List—Lower Disc Brake Installation 6044SR2, 6044SR3, 7244SR2	106
Table 29	Parts List—Lower Disc Brake Split Bearing Parts and Assembly 6044SR2, 72044SR2/SR3	108
Table 30	Hanging Dimensions	115
Table 31	Parts List—Hold Down Adjustment 6044SR2/SR3, 6044WR2/WR3, 72044SR2/SR3, 72044WR2/WR3	121
Table 32	Parts List—Push Down 6044SP2, 6044SP3, 6044SR2, 6044SR3	123
Table 33	Parts List—Suspension Cylinder Assemblies 42031,42044,52038,60044,72044	125
Table 34	Parts List—Shell Doors 60044SR2, 60044SR3, 6044WR3	133
Table 35	Parts List—Door Latch	136
Table 36	Parts List—Cylinder Assembly and Cylinder Door Installation 6044SR2, 7244SR2	140
Table 37	Parts List—Cylinder Door Installation 6044WP3/SP3, 6044WR3, 6044SR3	143
Table 38	Parts List—Cylinder Door Assembly 6044WP3/SP3, 6044WR3, 6044SR3	146
Table 39	Parts List—Staph Barrier Cleanside 6044SR2, 72044SR2	149
Table 40	Parts List—Staphairtrol 60044SR2, 72044SR2	151
Table 41	Parts List—Excursion Switch 6044SR2, 6044SR3, 7244SR2	154
Table 42	Parts List—Air Chamber Level Switch 42044WR2,WR3,SR2,SR3; 6044WR2,WR3, SR2, SR3; 72044WR2, WR3, SR2, SR3	155
Table 43	Parts List—Temperature Probe 6044WR2,WR3,SR2 72044WR2,WR3,SR3	157
Table 44	Effect of Tripping Vibration Safety Switch	158
Table 45	Parts List—Vibration Safety Switch	160
Table 46	Parts List—Peristaltic Supply Inlet 6044SP2, 6044SP3, 6044SR2, 6044SR3	163
Table 47	Parts List—Five Compartments for Dry Chemical Supplies	166
Table 48	Parts List—Water Inlets and Optional Siphon Breaker 60044SR2, 60044SR3	171
Table 49	Parts List—Siphon Breaker & Scupper	175
Table 50	Parts List—Steam Inlet & Sparger 4244SP2, 4244SP2 SM, 6044SP2/SP3, 6044SP2 SM	177
Table 51	Parts List—Burket Steam Valve	178
Table 52	Parts List—8”X10” Stainless Dump Valve 42044WR2/WR3/SR2/SR3; 60044WR2/ WR3/SR2/SR3; 72044WR2/WR3/SR2/SR3	180
Table 53	Parts List—Brake Air Cylinder	187

1 General Service & Safety-Related Components

PELLERIN MILNOR CORPORATION LIMITED STANDARD WARRANTY

We warrant to the original purchaser that MILNOR machines including electronic hardware/software (hereafter referred to as "equipment"), will be free from defects in material and workmanship for a period of one year from the date of shipment (unless the time period is specifically extended for certain parts pursuant to a specific MILNOR published extended warranty) from our factory with no operating hour limitation. This warranty is contingent upon the equipment being installed, operated and serviced as specified in the operating manual supplied with the equipment, and operated under normal conditions by competent operators.

Providing we receive written notification of a warranted defect within 30 days of its discovery, we will—at our option—repair or replace the defective part or parts, EX Factory (labor and freight specifically NOT included). We retain the right to require inspection of the parts claimed defective in our factory prior to repairing or replacing same. We will not be responsible, or in any way liable, for unauthorized repairs or service to our equipment, and this warranty shall be void if the equipment is tampered with, modified, or abused, used for purposes not intended in the design and construction of the machine, or is repaired or altered in any way without MILNOR's written consent.

Parts damaged by exposure to weather, to aggressive water, or to chemical attack are not covered by this warranty. For parts which require routine replacement due to normal wear—such as gaskets, contact points, brake and clutch linings, belts, hoses, and similar parts—the warranty time period is 90 days.

We reserve the right to make changes in the design and/or construction of our equipment (including purchased components) without obligation to change any equipment previously supplied.

ANY SALE OR FURNISHING OF ANY EQUIPMENT BY MILNOR IS MADE ONLY UPON THE EXPRESS UNDERSTANDING THAT MILNOR MAKES NO EXPRESSED OR IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR ANY PARTICULAR USE OR PURPOSE OR ANY OTHER WARRANTY IMPLIED BY LAW INCLUDING BUT NOT LIMITED TO REDHIBITION. MILNOR WILL NOT BE RESPONSIBLE FOR ANY COSTS OR DAMAGES ACTUALLY INCURRED OR REQUIRED AS A RESULT OF: THE FAILURE OF ANY OTHER PERSON OR ENTITY TO PERFORM ITS RESPONSIBILITIES, FIRE OR OTHER HAZARD, ACCIDENT, IMPROPER STORAGE, MIS-USE, NEGLIGENCE, POWER OR ENVIRONMENTAL CONTROL MALFUNCTIONS, DAMAGE FROM LIQUIDS, OR ANY OTHER CAUSE BEYOND THE NORMAL RANGE OF USE. REGARDLESS OF HOW CAUSED, IN NO EVENT SHALL MILNOR BE LIABLE FOR SPECIAL, INDIRECT, PUNITIVE, LIQUIDATED, OR CONSEQUENTIAL COSTS OR DAMAGES, OR ANY COSTS OR DAMAGES WHATSOEVER WHICH EXCEED THE PRICE PAID TO MILNOR FOR THE EQUIPMENT IT SELLS OR FURNISHES.

THE PROVISIONS ON THIS PAGE REPRESENT THE ONLY WARRANTY FROM MILNOR AND NO OTHER WARRANTY OR CONDITIONS, STATUTORY OR OTHERWISE, SHALL BE IMPLIED.

WE NEITHER ASSUME, NOR AUTHORIZE ANY EMPLOYEE OR OTHER PERSON TO ASSUME FOR US, ANY OTHER RESPONSIBILITY AND/OR LIABILITY IN CONNECTION WITH THE SALE OR FURNISHING OF OUR EQUIPMENT TO ANY BUYER.

BMP720097/19036

BNUUUM01 / 2019342

BNUUUM01 0000250121 B.3 1/2/20, 2:14 PM Released

1.1 How to Get the Necessary Repair Components

BNUUUM01.C01 0000250120 E.2 B.3 A.3 1/2/20, 2:14 PM Released

You can get components to repair your machine from the approved supplier where you got this machine. Your supplier will usually have the necessary components in stock. You can also get components from the Milnor® factory.

Tell the supplier the machine model and serial number and this data for each necessary component:

- The component number from this manual
- The component name if known
- The necessary quantity
- The necessary transportation requirements
- If the component is an electrical component, give the schematic number if known.
- If the component is a motor or an electrical control, give the nameplate data from the used component.

To write to the Milnor® factory:

Pellerin Milnor Corporation
 Post Office Box 400
 Kenner, LA 70063-0400
 UNITED STATES

Telephone: 504-712-7775

Fax: 504-469-9777

Email: parts@milnor.com

BNUUUU02 / 2023296

BNUUUU02 0000158094 G.2 7/20/23, 10:58 AM Released

1.2 Trademarks

BNUUUU02.R01 0000158093 E.2 G.2 F.2 7/20/23, 10:57 AM Released

These words are trademarks of Pellerin Milnor® Corporation and other entities:

Table 1. Trademarks

AutoSpot™	GreenFlex™	MilMetrix®	PulseFlow®
CBW®	GearTrace™	MilTouch™	RAM Command™
Drynet™	GreenTurn™	MilTouch-EX™	RecircONE®
E-P Express®	Hydro-cushion™	MilRAIL®	RinSave®
E-P OneTouch®	Mentor®	Miltrac™	SmoothCoil™

Table 1 Trademarks (cont'd.)

E-P Plus®	Mildata®	MilVision™	Staph Guard®
Gear Guardian®	Milnor®	PBW™	

BNWVUS08 / 2020122 BNWVUS08 0000279016 A.2 3/16/20, 3:40 PM Released

1.3 Safety — Divided Cylinder and Staph Guard® Washer-Extractors

BNWVUS08.C01 0000279015 E.2 A.2 3/16/20, 3:40 PM Released

1.3.1 Safety Alert Messages—Internal Electrical and Mechanical Hazards

BNWVUS01.C03 0000235064 E.2 A.2 A.3 1/2/20, 2:19 PM Released

The following are instructions about hazards inside the machine and in electrical enclosures.



WARNING: Electrocutation and Electrical Burn Hazards — Contact with electric power can kill or seriously injure you. Electric power is present inside the cabinetry unless the main machine power disconnect is off.



- ▶ Do not unlock or open electric box doors.
- ▶ Do not remove guards, covers, or panels.
- ▶ Do not reach into the machine housing or frame.
- ▶ Keep yourself and others off of machine.
- ▶ Know the location of the main machine disconnect and use it in an emergency to remove all electric power from the machine.



WARNING: Entangle and Crush Hazards — Contact with moving components normally isolated by guards, covers, and panels, can entangle and crush your limbs. These components move automatically.



- ▶ Do not remove guards, covers, or panels.
- ▶ Do not reach into the machine housing or frame.
- ▶ Keep yourself and others off of machine.
- ▶ Know the location of all emergency stop switches, pull cords, and/or kick plates and use them in an emergency to stop machine motion.

1.3.2 Safety Alert Messages—External Mechanical Hazards

BNWVUS02.C03 0000235097 E.2 A.2 A.3 1/2/20, 2:19 PM Released

The following are instructions about hazards around the front, sides, rear or top of the machine.



WARNING: Crush Hazards — Suspended machines only—Spaces between the shell and housing can close and crush or pinch your limbs. The shell moves within the housing during operation.



- ▶ Do not reach into the machine housing or frame.
- ▶ Keep yourself and others clear of movement areas and paths.

1.3.3 Safety Alert Messages—Cylinder and Processing Hazards

BNWVUS03.C03 0000235094 E.2 A.2 A.3 1/2/20, 2:19 PM Released

The following are instructions about hazards related to the cylinder and laundering process.



WARNING: Crush Hazards — Contact with the turning cylinder can crush your limbs. The cylinder will repel any object you try to stop it with, possibly causing the object to strike or stab you. The turning cylinder is normally isolated by the locked cylinder door.



- ▶ Do not attempt to open the door or reach into the cylinder until the cylinder is stopped.
- ▶ Do not place any object in the turning cylinder.
- ▶ Do not operate the machine with a malfunctioning door interlock.
- ▶ Divided cylinder machines only—Keep yourself and others clear of cylinder and goods during inching or Autospot operation.
- ▶ Do not operate the machine with malfunctioning two-hand manual controls.



WARNING: Confined Space Hazards — Confinement in the cylinder can kill or injure you. Hazards include but are not limited to panic, burns, poisoning, suffocation, heat prostration, biological contamination, electrocution, and crushing.



- ▶ Do not attempt unauthorized servicing, repairs, or modification.



WARNING: Explosion and Fire Hazards — Flammable substances can explode or ignite in the cylinder, drain trough, or sewer. The machine is designed for washing with water, not any other solvent. Processing can cause solvent-containing goods to give off flammable vapors.



- ▶ Do not use flammable solvents in processing.
- ▶ Do not process goods containing flammable substances. Consult with your local fire department/public safety office and all insurance providers.

1.3.4 Safety Alert Messages—Unsafe Conditions

BNWVUS04.C01 0000235093 E.2 A.2 A.3 12/11/20, 8:32 AM Released

1.3.4.1 Damage and Malfunction Hazards

BNWVUS04.C02 0000235092 E.2 A.2 A.3 12/11/20, 8:32 AM Released

1.3.4.1.1 Hazards Resulting from Inoperative Safety Devices

BNWVUS04.C03 0000235091 E.2 A.2 A.4 12/11/20, 8:32 AM Released



DANGER: **Entangle and Sever Hazards** — Cylinder door interlock—Operating the machine with a malfunctioning door interlock can permit opening the door when the cylinder is turning and/or starting the cycle with the door open, exposing the turning cylinder.



- ▶ Do not operate the machine with any evidence of damage or malfunction.




WARNING: **Multiple Hazards** — Operating the machine with an inoperative safety device can kill or injure personnel, damage or destroy the machine, damage property, and/or void the warranty.

- ▶ Do not tamper with or disable any safety device or operate the machine with a malfunctioning safety device. Request authorized service.



WARNING: **Electrocution and Electrical Burn Hazards** — Electric box doors—Operating the machine with any electric box door unlocked can expose high voltage conductors inside the box.



- ▶ Do not unlock or open electric box doors.



WARNING: **Entangle and Crush Hazards** — Guards, covers, and panels—Operating the machine with any guard, cover, or panel removed exposes moving components.



- ▶ Do not remove guards, covers, or panels.

1.3.4.1.2 Hazards Resulting from Damaged Mechanical Devices

BNWVUS04.C04 0000235090 E.2 A.2 A.4 12/11/20, 8:32 AM Released



WARNING: **Multiple Hazards** — Operating a damaged machine can kill or injure personnel, further damage or destroy the machine, damage property, and/or void the warranty.

- ▶ Do not operate a damaged or malfunctioning machine. Request authorized service.



WARNING: **Explosion Hazards** — Cylinder—A damaged cylinder can rip apart during extraction, puncturing the shell and discharging metal fragments at high speed.



- ▶ Do not operate the machine with any evidence of damage or malfunction.



WARNING: Explosion Hazards — Inner door latches (divided cylinder machines)—A damaged or improperly seated latch can cause the inner door to open during operation, damaging the cylinder and shell. A damaged cylinder can rip apart during extraction, puncturing the shell and discharging metal fragments at high speed.




- ▶ Ensure that the inner door is securely latched after loading and unloading.

- ▶ Do not operate the machine with any evidence of damage or malfunction.



WARNING: Explosion Hazards — Clutch and speed switch (multiple motor machines)—A damaged clutch or speed switch can permit the low speed motor to engage during extract. This will over-speed the motor and pulleys and can cause them to rip apart, discharging metal fragments at high speed.



- ▶ Stop the machine immediately if any of these conditions occur: • abnormal whining sound during extract • skidding sound as extract ends • clutches remain engaged or re-engage during extract

1.3.4.2 Careless Use Hazards

BNWVUS04.C05 0000235127 E.2 A.2 A.3 12/11/20, 8:32 AM Released

1.3.4.2.1 Careless Operation Hazards—Vital Information for Operator Personnel (see also operator hazards throughout manual)

BNWVUS04.C06 0000235126 E.2 A.2 A.4 12/11/20, 8:32 AM Released



WARNING: Multiple Hazards — Careless operator actions can kill or injure personnel, damage or destroy the machine, damage property, and/or void the warranty.


- ▶ Do not tamper with or disable any safety device or operate the machine with a malfunctioning safety device. Request authorized service.
- ▶ Do not operate a damaged or malfunctioning machine. Request authorized service.
- ▶ Do not attempt unauthorized servicing, repairs, or modification.
- ▶ Do not use the machine in any manner contrary to the factory instructions.
- ▶ Use the machine only for its customary and intended purpose.
- ▶ Understand the consequences of operating manually.

1.3.4.2.2 Careless Servicing Hazards—Vital Information for Service Personnel (see also service hazards throughout manuals)

BNWVUS04.C07 0000235125 E.2 A.2 A.4 12/11/20, 8:32 AM Released



WARNING: Electrocutation and Electrical Burn Hazards — Contact with electric power can kill or seriously injure you. Electric power is present inside the cabinetry unless the main machine power disconnect is off.



- ▶ Do not service the machine unless qualified and authorized. You must clearly understand the hazards and how to avoid them.

- ▶ Abide by the current OSHA lockout/tagout standard when lockout/tagout is called for in the service instructions. Outside the USA, abide by the OSHA standard in the absence of any other overriding standard.



WARNING: Entangle and Crush Hazards — Contact with moving components normally isolated by guards, covers, and panels, can entangle and crush your limbs. These components move automatically.



- ▶ Do not service the machine unless qualified and authorized. You must clearly understand the hazards and how to avoid them.
- ▶ Abide by the current OSHA lockout/tagout standard when lockout/tagout is called for in the service instructions. Outside the USA, abide by the OSHA standard in the absence of any other overriding standard.



WARNING: Confined Space Hazards — Confinement in the cylinder can kill or injure you. Hazards include but are not limited to panic, burns, poisoning, suffocation, heat prostration, biological contamination, electrocution, and crushing.



- ▶ Do not enter the cylinder until it has been thoroughly purged, flushed, drained, cooled, and immobilized.

This page intentionally blank

BPWG6M01 / 2020125

BPWG6M01.1 0000278949 E.2 A.5 3/19/20, 10:13 AM Released


Safety Placard Use and Placement

2 Sheets

60044SR2, 60044SR3, 72044SR2



NOTE: Replace placard immediately, if removed or unreadable. Approximate locations of placards are shown. If aluminum placard, mounting holes are provided on machine. Use #8 self-tapping screws.



Safety Placard Use and Placement

2 Sheets

60044SR2, 60044SR3, 72044SR2

Table 2. Parts List—Safety Placard Use and Placement


Find the assembly for your machine and the letter shown in the "Item" column. The components for your machine will show this letter or the word "all" in the "Used In" column. The numbers shown in the "Item" column are those shown in the illustrations.				
Used In	Item	Part Number	Description/Nomenclature	Comments
Components				
all	10	01 10627A	NPLT:DIV-CYL/STAPH WARN-TCATA	
all	20	01 10377A	NPLT:ELEC HAZARD LG-TCATA	
all	30	01 10689A	NPLT:BELT HAZARD SM TCATA	
all	40	01 10648A	NPLT:GEAR HAZARD-TCATA	
all	50	01 10685A	NPLT:BURN HAZARD-TCATA	
all	60	01 10699B	NPLT:SERV HZRD-ALUM-TCATA	

Safety Placard Use and Placement ISO

60044SR2, 60044SR3, 72044SR2



NOTE: Replace placard immediately, if removed or unreadable. Approximate locations of placards are shown. If aluminum placard, mounting holes are provided on machine. Use #8 self-tapping screws.



Safety Placard Use and Placement ISO

2 Sheets

60044SR2, 60044SR3, 72044SR2

Table 3. Parts List—Safety Placard Use and Placement ISO

Find the assembly for your machine and the letter shown in the "Item" column. The components for your machine will show this letter or the word "all" in the "Used In" column. The numbers shown in the "Item" column are those shown in the illustrations.				
Used In	Item	Part Number	Description/Nomenclature	Comments
Components				
all	10	01 10627X	NPLT:DIVCYL SG WARNING FRT ISO	
all	20	01 10377	NPLTE:"WARNING" 4X4	
all	30	01 10628X	NPLT:NONTILT W/E WARNING SIDE	
all	40	01 10648X	NPLT:ACTUATED VALVE WARN-ISO	
all	50	01 10649X	NPLT:HOT BEHIND CVR WARN-ISO	

1.4 Torque Requirements for Fasteners

BNUUUN02.C01 0000222451 E.2 B.3 A.3 1/2/20, 2:14 PM Released

The document about the assembly gives the torque requirements for other fasteners. **If fastener torque specifications or threadlocker requirements in an assembly document are different from this document, use the assembly document.**

Figure 1. The Bolts in Milnor® Equipment

The Marks on Bolt Heads	Legend
	<p>A . . . SAE Grades 1 and 2, ASTM A307, and stainless steel</p> <p>B . . . Grade BC, ASTM A354</p> <p>C . . . SAE Grade 5, ASTM A449</p> <p>D . . . SAE Grade 8 and ASTM A354 BD</p>

1.4.1 Torque Values

BNUUUN02.C02 0000222449 E.2 B.3 A.3 1/2/20, 2:14 PM Released

These tables give the standard dimension, grade, threadlocker, and torque requirements for fasteners frequently used on Milnor® equipment.



NOTE: Data from the Pellerin Milnor® Corporation “Bolt Torque Specification” (bolt_torque_milnor.xls/2002096).

1.4.1.1 Fasteners Made of Carbon Steel

BNUUUN02.C03 0000222448 E.2 B.3 A.3 1/2/20, 2:14 PM Released

1.4.1.1.1 Without a Threadlocker

BNUUUN02.C04 0000222447 E.2 B.3 A.3 1/2/20, 2:14 PM Released

Table 4. Torque Values for Standard Fasteners with Maximum 5/16-inch Diameters and No Lubricant

Dimension	The Grade of the Bolt							
	Grade 2		Grade 5		Grade 8		Grade BC	
	Pound-Inches	N-m	Pound-Inches	N-m	Pound-Inches	N-m	Pound-Inches	N-m
1/4 x 20	66	7	101	11	143	16	126	14
1/4 x 28	76	9	116	13	163	18	–	–
5/16 x 18	136	15	209	24	295	33	258	29
5/16 x 24	150	17	232	26	325	37	–	–

Table 5. Torque Values for Standard Fasteners Larger Than 5/16-inch Diameters and No Lubricant

Dimension	The Grade of the Bolt							
	Grade 2		Grade 5		Grade 8		Grade BC	
	Pound-Feet	N-m	Pound-Feet	N-m	Pound-Feet	N-m	Pound-Feet	N-m
3/8 x 16	20	27	31	42	44	59	38	52
3/8 x 24	23	31	35	47	50	68	–	–
7/16 x 14	32	43	49	66	70	95	61	83
7/16 x 20	36	49	55	75	78	105	–	–
1/2 x 13	49	66	75	102	107	145	93	126
1/2 x 20	55	75	85	115	120	163	–	–
9/16 x 12	70	95	109	148	154	209	134	182
9/16 x 18	78	106	121	164	171	232	–	–
5/8 x 11	97	131	150	203	212	287	186	252
5/8 x 18	110	149	170	231	240	325	–	–
3/4 x 10	172	233	266	361	376	510	329	446
3/4 x 16	192	261	297	403	420	569	–	–
7/8 x 9	167	226	429	582	606	821	531	719
7/8 x 14	184	249	473	641	668	906	–	–
1 x 8	250	339	644	873	909	1232	796	1079
1 x 12	274	371	704	954	994	1348	–	–
1 x 14	281	381	723	980	1020	1383	–	–
1 1/8 x 7	354	480	794	1077	1287	1745	1126	1527
1 1/8 x 12	397	538	891	1208	1444	1958	–	–
1 1/4 x 7	500	678	1120	1519	1817	2464	1590	2155
1 1/4 x 12	553	750	1241	1682	2012	2728	–	–
1 3/8 x 6	655	888	1469	1992	2382	3230	2085	2827
1 3/8 x 12	746	1011	1672	2267	2712	3677	–	–
1 1/2 x 6	869	1178	1949	2642	3161	4286	2767	3751
1 1/2 x 12	979	1327	2194	2974	3557	4822	–	–

Table 6. Torque Values for Plated Fasteners with Maximum 5/16-inch Diameters and No Lubricant

Dimension	The Grade of the Bolt							
	Grade 2		Grade 5		Grade 8		Grade BC	
	Pound-Inches	N-m	Pound-Inches	N-m	Pound-Inches	N-m	Pound-Inches	N-m
1/4 x 20	49	6	76	9	107	12	95	11
1/4 x 28	56	6	88	10	122	14	–	–
5/16 x 18	102	12	156	18	222	25	193	22
5/16 x 24	113	13	174	20	245	28	–	–

Table 7. Torque Values for Plated Fasteners Larger Than 5/16-inch Diameters and No Lubricant

Dimension	The Grade of the Bolt							
	Grade 2		Grade 5		Grade 8		Grade BC	
	Pound-Feet	N-m	Pound-Feet	N-m	Pound-Feet	N-m	Pound-Feet	N-m
3/8 x 16	15	20	23	31	33	44	29	38
3/8 x 24	17	23	26	35	37	49	–	–
7/16 x 14	24	32	37	50	52	71	46	61
7/16 x 20	27	36	41	55	58	78	–	–
1/2 x 13	37	49	56	76	80	106	70	93
1/2 x 20	41	55	64	85	90	120	–	–
9/16 x 12	53	70	81	110	115	153	101	134
9/16 x 18	59	79	91	122	128	174	–	–
5/8 x 11	73	97	113	150	159	212	139	186
5/8 x 18	83	110	127	172	180	240	–	–
3/4 x 10	129	173	200	266	282	376	246	329
3/4 x 16	144	192	223	297	315	420	–	–
7/8 x 9	125	166	322	430	455	606	398	531
7/8 x 14	138	184	355	474	501	668	–	–
1 x 8	188	250	483	644	682	909	597	796
1 x 12	205	274	528	716	746	995	–	–
1 x 14	210	280	542	735	765	1037	–	–
1 1/8 x 7	266	354	595	807	966	1288	845	1126
1 1/8 x 12	298	404	668	890	1083	1444	–	–
1 1/4 x 7	375	500	840	1120	1363	1817	1192	1590
1 1/4 x 12	415	553	930	1261	1509	2013	–	–
1 3/8 x 6	491	655	1102	1470	1787	2382	1564	2085
1 3/8 x 12	559	758	1254	1672	2034	2712	–	–
1 1/2 x 6	652	870	1462	1982	2371	3161	2075	2767
1 1/2 x 12	733	994	1645	2194	2668	3557	–	–

1.4.1.1.2 With a Threadlocker

BNUUUN02.C05 0000222446 E.2 B.3 A.3 1/2/20, 2:14 PM Released

Table 8. Threadlocker by the Diameter of the Bolt (see below Note)

LocTite Product	Dimension			
	1/4-inch	1/4- to 5/8-inch	5/8- to 7/8-inch	1-inch +
LocTite 222	OK			
LocTite 242			OK	
LocTite 262				OK
LocTite 272				High temperature
LocTite 277				OK



NOTE: The acceptable bolt size ranges for various LocTite® threadlocking products is the LocTite manufacturer’s **general** recommendation. Specific applications sometime require that a LocTite product is applied to a bolt size outside the ranges shown here. For example, Milnor® specifies LocTite 242 for use on certain 1" bolt applications and has confirmed this usage with the LocTite manufacturer. You may see variances such as this in the documentation for specific machine assemblies.

Table 9. Torque Values if You Apply LocTite 222

Dimension	The Grade of the Bolt							
	Grade 2		Grade 5		Grade 8		Grade BC	
	Pound-Inches	N-m	Pound-Inches	N-m	Pound-Inches	N-m	Pound-Inches	N-m
1/4 x 20	60	7	96	11	132	15	108	12
1/4 x 28	72	8	108	12	144	16	–	–

Table 10. Torque Values if You Apply LocTite 242

Dimension	The Grade of the Bolt							
	Grade 2		Grade 5		Grade 8		Grade BC	
	Pound-Feet	N-m	Pound-Feet	N-m	Pound-Feet	N-m	Pound-Feet	N-m
5/16 x 18	11	15	17	23	25	34	22	30
5/16 x 24	13	18	19	26	27	37	27	37
3/8 x 16	20	27	31	42	44	60	38	52
3/8 x 24	23	31	35	47	50	68	–	–
7/16 x 14	32	43	49	66	70	95	61	83
7/16 x 20	36	49	55	75	78	106	–	–
1/2 x 13	49	66	75	102	107	145	93	126
1/2 x 20	55	75	85	115	120	163	–	–
9/16 x 12	70	95	109	148	154	209	134	182
9/16 x 18	78	106	121	164	171	232	–	–
5/8 x 11	97	132	150	203	212	287	186	252
5/8 x 18	110	149	170	230	240	325	–	–

Table 11. Torque Values if You Apply LocTite 262

Dimension	The Grade of the Bolt							
	Grade 2		Grade 5		Grade 8		Grade BC	
	Pound-Feet	N-m	Pound-Feet	N-m	Pound-Feet	N-m	Pound-Feet	N-m
3/4 x 10	155	210	240	325	338	458	296	401
3/4 x 16	173	235	267	362	378	512	–	–
7/8 x 9	150	203	386	523	546	740	477	647
7/8 x 14	165	224	426	578	601	815	–	–

Table 12. Torque Values if You Apply LocTite 272 (High-Temperature)

Dimension	The Grade of the Bolt							
	Grade 2		Grade 5		Grade 8		Grade BC	
	Pound-Feet	N-m	Pound-Feet	N-m	Pound-Feet	N-m	Pound-Feet	N-m
1 x 8	350	475	901	1222	1272	1725	1114	1510
1 x 12	383	519	986	1337	1392	1887	–	–

Table 12 Torque Values if You Apply LocTite 272 (High-Temperature) (cont'd.)

Dimension	The Grade of the Bolt							
	Grade 2		Grade 5		Grade 8		Grade BC	
	Pound-Feet	N-m	Pound-Feet	N-m	Pound-Feet	N-m	Pound-Feet	N-m
1 x 14	393	533	1012	1372	1428	1936	–	–
1-1/8 x 7	496	672	1111	1506	1802	2443	1577	2138
1-1/8 x 12	556	754	1247	1691	2022	2741	–	–
1-1/4 x 7	700	949	1568	2126	2544	3449	2226	3018
1-1/4 x 12	774	1049	1737	2355	2816	3818	–	–
1-3/8 x 6	917	1243	2056	2788	3335	4522	2919	3958
1-3/8 x 12	1044	1415	2341	3174	3797	5148	–	–
1-1/2 x 6	1217	1650	2729	3700	4426	6001	3873	5251
1-1/2 x 12	1369	1856	3071	4164	4980	6752	–	–

Table 13. Torque Values if You Apply LocTite 277

Dimension	The Grade of the Bolt							
	Grade 2		Grade 5		Grade 8		Grade BC	
	Pound-Feet	N-m	Pound-Feet	N-m	Pound-Feet	N-m	Pound-Feet	N-m
1 x 8	325	441	837	1135	1181	1601	1034	1402
1 x 12	356	483	916	1242	1293	1753	–	–
1 x 14	365	495	939	1273	1326	1798	–	–
1-1/8 x 7	461	625	1032	1399	1674	2270	1464	1985
1-1/8 x 12	516	700	1158	1570	1877	2545	–	–
1-1/4 x 7	650	881	1456	1974	2362	3202	2067	2802
1-1/4 x 12	719	975	1613	2187	2615	3545	–	–
1-3/8 x 6	851	1154	1909	2588	3097	4199	2710	3674
1-3/8 x 12	970	1315	2174	2948	3526	4781	–	–
1-1/2 x 6	1130	1532	2534	3436	4110	5572	3597	4877
1-1/2 x 12	1271	1723	2852	3867	4624	6269	–	–

1.4.1.2 Stainless Steel Fasteners

BNUUUN02.C06 0000222445 E.2 B.3 A.3 1/2/20, 2:14 PM Released

Table 14. Torque Values for Stainless Steel Fasteners 5/16-inch and Smaller

Dimension	316 Stainless		18-8 Stainless		18-8 Stainless with Loctite 767	
	Pound-Inches	N-m	Pound-Inches	N-m	Pound-Inches	N-m
1/4 x 20	79	9	76	9	45	5
1/4 x 28	100	11	94	11	56	6
5/16 x 18	138	16	132	15	79	9
5/16 x 24	148	17	142	16	85	10

Table 15. Torque Values for Stainless Steel Fasteners Larger Than 5/16-inch

Dimension	316 Stainless		18-8 Stainless		18-8 Stainless with Loctite 767	
	Pound-Feet	N-m	Pound-Feet	N-m	Pound-Feet	N-m
3/8 x 16	21	28	20	27	12	16
3/8 x 24	23	31	22	29	13	18
7/16 x 14	33	44	31	42	19	25
7/16 x 20	35	47	33	45	20	27
1/2 x 13	45	61	43	58	26	35
1/2 x 20	47	64	45	61	27	37
9/16 x 12	59	81	57	77	34	46
9/16 x 18	66	89	63	85	38	51
5/8 x 11	97	131	93	125	56	75
5/8 x 18	108	150	104	141	62	84
3/4 x 10	132	179	128	173	77	104
3/4 x 16	130	176	124	168	75	101
7/8 x 9	203	275	194	263	116	158
7/8 x 14	202	273	193	262	116	157
1 x 8	300	406	287	389	172	233
1 x 14	271	367	259	351	156	211
1-1/8 x 7	432	586	413	560	248	336
1-1/8 x 12	408	553	390	529	234	317
1-1/4 x 7	546	740	523	709	314	425
1-1/4 x 12	504	683	480	651	288	390
1-1/2 x 6	930	1261	888	1204	533	722
1-1/2 x 12	732	992	703	953	422	572

1.4.2 Preparation

BNUUUN02.T01 0000222511 E.2 B.3 B.2 4/20/23, 9:05 AM Released



WARNING: Fire Hazard — Some solvents and primers are flammable.



- ▶ Use threadlocker and primers with sufficient airflow.
- ▶ Do not use flammable material near ignition sources.

1. Clean all threads with a wire brush or a different tool.
2. Remove the grease from the fasteners and the mating threads with solvent. Make the parts dry.



NOTE: Loctite 7649 Primer™ or standard solvents will remove grease from parts.


- Apply a spray of LocTite 7649 Primer™ or equal on the fasteners and the mating threads. Let the primer dry for one minute minimum.

1.4.3 How to Apply a Threadlocker

BNUUUN02.T02 0000222508 E.2 B.3 B.2 4/20/23, 9:09 AM Released




CAUTION: Malfunction Hazard — Heat, vibration, or mechanical shocks can let the fasteners loosen if you do not apply the threadlocker correctly. Loose fasteners can cause malfunctions of the equipment.



- Read the threadlocker manufacturer's instructions and warnings. Obey these instructions.

Apply the threadlocker only to the areas where the fastener threads and the mating threads engage.

Figure 2. Apply Threadlocker in a Blind Hole



1.4.3.1 Blind Holes

BNUUUN02.T03 0000222507 E.2 B.3 A.3 1/2/20, 2:14 PM Released

- Apply the threadlocker down the threads to the bottom of the hole.
- Apply the threadlocker to the bolt.
- Tighten the bolt to the value shown in the correct table ([Table 8: Threadlocker by the Diameter of the Bolt](#) (see below Note), page 22 to [Table 14: Torque Values for Stainless Steel Fasteners 5/16-inch and Smaller](#), page 24).


1.4.3.2 Through Holes

BNUUUN02.T04 0000222506 E.2 B.3 A.3 11/26/19, 2:51 PM Released

- Put the bolt through the assembly.
- Apply the threadlocker only to the bolt thread area that will engage the nut.

- Tighten the bolt to the value shown in the correct table ([Table 8: Threadlocker by the Diameter of the Bolt](#) (see below Note), page 22 to [Table 14: Torque Values for Stainless Steel Fasteners 5/16-inch and Smaller](#), page 24).

Figure 3. Apply Threadlocker in a Through Hole




1.4.3.3 Disassembly

BNUUUN02.C07 0000222444 E.2 B.3 A.3 11/26/19, 2:59 PM Released

For high-strength threadlocker, apply heat for five minutes. Disassemble with hand tools while the parts are hot.

For low-strength and moderate-strength threadlocker, disassemble with hand tools.

Figure 4. Use heat for disassembly of fasteners with threadlocker.




BPWG6U01 / 2020195

BPWG6U01.1 0000279421 E.2 A.10 5/7/20, 2:42 PM Released

General Assembly

5 Sheets

6044SP2, 6044SP3, 6044SR2, 6044SR3




Legend

- A . . . Shell doors, see BPWG6D01
- B . . . Steam cover (not shown)
- C . . . Foot guard (not shown)
- D . . . Belt guards

General Assembly

5 Sheets

6044SP2, 6044SP3, 6044SR2, 6044SR3




Legend

- E** . . . Cylinder doors, see BPWG6D02; BPWG6D03
- F** . . . Staphairtrol, see BPWG6P02
- G** . . . Cylinders, see BPWVUJ01
- H** . . . Lower disc break, see BPWG6I08

General Assembly

5 Sheets

6044SP2, 6044SP3, 6044SR2, 6044SR3



Legend

J . . . See BPWVUC02

K . . . Drain, see BPWVUW02

L . . . Gasket

M . . . Steam, see BPWG UW01

General Assembly

5 Sheets

6044SP2, 6044SP3, 6044SR2, 6044SR3



NOTE: The loading side (soil side) is the “Front” of the machine. Using this rule, the left and right staph barrier rubber extrusions are identified.

<p style="text-align: center;">Clean side</p>	<p style="text-align: center;">Rear View—Clean side, Staph Barrier Components</p>
	<p style="text-align: center;">Legend</p> <p>A. . . . Shell doors, see BPWG6D01 D. . . . Belt Guard N. . . . Typical secondary door switch P. . . . 62 instances Q. . . . Left side R. . . . Right side S. . . . Upper disc break, see BPWG6I07 T. . . . Drive base, see BPWG6I05</p>

General Assembly

5 Sheets

6044SP2, 6044SP3, 6044SR2, 6044SR3

Table 16. Parts List—General Assembly

Find the assembly for your machine and the letter shown in the "Item" column. The components for your machine will show this letter or the word "all" in the "Used In" column. The numbers shown in the "Item" column are those shown in the illustrations.				
Used In	Item	Part Number	Description/Nomenclature	Comments
Components				
all	1	AD 28 079	BLTGUARD ASSY-SOILSIDE=60"SG	
all	2	03 06533A	FOOTGUARD=60SGU LOWER Y)	
all	3	AD 28 111	SIGHT GLASS ASSY=WED + WEH	
all	4	02 18980	MARKER LEVEL INDICATOR INCH	
all	5	02 175071	MARKER LEVEL INDICATOR CM	
all	6	02 18835	COVER=STEAM ASSY 6044 SP2	
all	7	03 01448A	COV=CONT BOX NAVY	
all	8	02 18824B	COVER=BRAKE ASSY LF SIDE 6049	
all	9	02 18742	EXTENSION=FRAME 6036/6044SGH	
all	10	02 03344	TRIM=REAR CONSOLE TOP 7FT/PC	
all	11	02 18743	BRACKET=FRAME EXT 6036/44SGH	
all	12	02 18744	RT BRACKET FRM EXT 6036/44SG	
all	13	AD 28 078	BLTGUARD ASSY-CLNSIDE=60" SG	
all	17	02 18824C	COVER=UPPER SUP INJ 6044SG	
all	18	02 18824D	COVER=SUP INJ LO SUP 6044SG	
all	19	05 20296E	COVER=RGHT REAR 6044 SG	
all	20	03 06532	SPLASH COVER=MASTERCYL 72SG	
all	21	02 18107	GASKET=8"FLANGED DUMP VALVE	
all	22	E28 01200S	* DOOR INTERLK SW=60SGU-SOILE	
all	23	09R030STDG	09R030 + SCREWS+ SCREW SEAL	
all	24	E28 01200C	* DOOR INTERLK SWT=60SGU-CLEA	
all	25	09RM01212S	CAPSW 12' 180DEG ROLLER SILVER	
all	26	AD 15 090A	AIRCHAMBER PRESWITCH INSTALL	
all	27	02 18781E	EXTRUSION SHELL CS LF 60SG	
all	28	02 18781F	EXTRUSION SHELL CS RT 60SG	
all	29	02 18781G	EXTRUSION FRAME CS LF 60SG	
all	30	02 18781H	EXTRUSION FRAME CS RT 60SG	
all	31	15U320	FLATWASHER(USS STD) 3/4" UNPLT	
all	32	02 175032	CLAMP BOOT 60142 +60SG	
all	33	15P175	TRDCUT-F HXHD 1/4-20UNC2AX1/2	
all	34	02 18767	BOOT ASSEMBLY 60SGH	

2 Drive Assemblies


BNUUUM02 / 2023344

BNUUUM02 0000274599 B.2 8/23/23, 9:52 AM Released

2.1 Drive Pulley and Belt Maintenance

BNUUUM02.C01 0000274598 E.2 B.2 A.2 2/4/20, 8:08 AM Released

Figure 5. Examples of drives this instruction applies to: one or more V-belts, attached V-belts and tooth belts



NOTICE: "Remove power from the machine" means use the necessary safety procedure for your location. In the USA, this is the OSHA lockout/tagout (LOTO) procedure. More local requirements can also apply.



WARNING: Risk of Injury or death — A machine in operation without safety guards is dangerous. Drive belts can pull in your body or clothing.



- ▶ Remove power from the machine when you do work on the mechanisms.
- ▶ Stay out of the machine frame when you do a test on the machine.
- ▶ Replace all covers before you put the machine into operation.



TIP: Read these documents from the Gates Corporation (www.gates.com) to know more about pulley and belt maintenance: "Belt Drive Preventive Maintenance & Safety Manual" and "Preserve your investment - Check Engine Belts Often."

2.1.1 Pulley Requirements

BNUUUM02.C02 0000274597 E.2 B.2 A.2 2/4/20, 8:08 AM Released

- Keep pulleys free of dirt, oil and other contamination.
- Replace pulleys with groove damage.
- Align pulleys and shafts.
- Keep run-out in tolerance.


2.1.1.1 Condition of Grooves on Pulleys

BNUUUM02.C03 0000274611 E.2 B.2 A.2 2/4/20, 8:08 AM Released

Replace a pulley if:

- the grooves have burrs, cracks, or worn areas that can cause damage to the belts.
- the belts touch the bottom of the groove at any point (Figure 6, page 34).

Figure 6. Pulley Groove Condition




2.1.1.2 Pulley and Shaft Position

BNUUUM02.C04 0000274609 E.2 B.2 A.2 2/4/20, 8:08 AM Released

Align To adjust parts until they are in a correct position to other parts.

- Always align components when you replace a motor, bearing housing, pulley, or belt.
- The belts must not twist or make unusual noises or show vibration.

Figure 7. Pulley and Shaft Position



2.1.1.3 Keep Run-Out in Tolerance

BNUUUM02.C05 0000274606 E.2 B.2 A.2 2/4/20, 8:08 AM Released

Axial run-out The difference between the minimum and maximum distance between the face of a pulley and a plane perpendicular to the pulley shaft (Figure 8, page 36, item 1). Incorrect installation or damage can cause a pulley to be not at a 90 degree angle to the shaft.

Radial run-out The difference between the minimum and maximum diameter in one turn (Figure 8, page 36, item 2). If a force causes damage to a pulley, it can bend. It will not have a circular shape.

Figure 8. Run-out





Figure 9. Typical Pulley Assembly



2.1.2 Belt Requirements


BNUUUM02.C06 0000274605 E.2 B.2 A.2 2/4/20, 8:08 AM Released

- Replace damaged belts.
- The pulleys must stay aligned when you adjust the belt tension.
- Do not use belts made from cut belts.

- For a drive with more than one belt:
 - Replace all of the belts together.
 - Do not mix new and used belts.
 - Do not mix belts from more than one manufacturer.



CAUTION: Risk of damage — A screwdriver or metal tool can cause damage to the belt.



- ▶ Do not push the belt on with a tool.

2.1.2.1 Condition of Belts

BNUUUM02.C07 0000274604 E.2 B.2 A.2 2/4/20, 8:08 AM Released

Slippage when the pulley turns more quickly than the belt can move

Slippage occurs if belts are not aligned (see [Section 2.1.1.2](#), page 34) or by incorrect tension explained in [Section 2.1.1.2](#), page 34. Slippage can cause belts to become too hot. Belts must not have a temperature more than than 140F (60° C).




TIP: The belt storage area must be cool and dry with no sun light.



TIP: New and used belts can look the same. These belts will have different strength properties and a small difference in length.

Figure 10. Types of Belt Damage



2.1.2.2 Tension of Belts

BNUUUM02.C08 0000274657 E.2 B.2 A.2 2/4/20, 8:08 AM Released

This data does not apply to belts where a spring holds the correct belt tension. Manual tension adjustment is not necessary for this type of drive.

The correct belt tension is the lowest tension that prevents belt slippage with a full load condition. If the belt is too tight, this can cause damage to the belt, the pulleys, bearings, and other drive components. If the belt is too loose, this can cause belt slippage. Incorrect belt tension or belt slippage can cause components to make an unusual noise.

When you install a new belt, use these rules to get the correct belt tension:

- Set the tension of the belt when you replace a motor, bearing housing, pulley, or belt.
- Replace all belts on a pair of pulleys when you replace one of them.
- After adjustment, operate the machine in all of its standard conditions to make sure that the belt operates correctly. For example, operate a washer-extractor in its full speed range with a full load of wet goods.
- Adjust the tension when you first install a belt. Do the adjustment again after 24 and 48 hours of operation. All belts will become longer after a short time. A V-belt will move down in the grooves of the pulleys. These conditions will cause the tension to decrease.

When you do scheduled maintenance, examine the belts for correct tension. With operation, belts become longer.

2.1.3 The pulleys must stay aligned when you adjust the belt tension


BNUUUM02.C09 0000274654 E.2 B.2 A.2 2/4/20, 8:08 AM Released

Some tension mechanisms do not have an effect on pulley and shaft requirements. Pulleys will stay aligned when you adjust them. [Figure 11, page 39](#) is an example of these. Where tension mechanisms are a pair of threaded rods, you must adjust the nut, on each rod carefully. If not, the pulleys will not stay aligned. Examples of this type are shown in [Figure 12, page 39](#).

Figure 11. A Tension Mechanism that will not Change the Angle of the Pulleys



Figure 12. Some Pairs of Tension Mechanisms that Can Change the Angle of the Pulleys



2.1.4 How to Do Maintenance on Pulleys and Belts

BNUUUM02.C10 0000274653 E.2 B.2 8/23/23, 9:45 AM Released

Table 17. Typical Tools for Pulley and Belt Maintenance

Tool	Function	Related Data
Torque wrench	Make the bushing bolts the same torque to get the minimum axial run-out.	Figure 9, page 36 , item 2
Laser, straight edge, or string	Align pulleys	Tools are listed in order of preference. Section 2.1.1.2 , page 34 and Figure 13, page 41
Bubble level	Align shafts	Section 2.1.1.2 , page 34 and Figure 14, page 42
Dial indicator	Measure run-out	Section 2.1.1.3 , page 35 and Figure 15, page 42

Table 17 Typical Tools for Pulley and Belt Maintenance (cont'd.)

Tool	Function	Related Data
Sheave (pulley) gage	Examine pulley wear	Figure 6, page 34.
Infrared thermometer	Examine belt temperature	Section 2.1.2.1 , page 37.

2.1.4.1 Typical Steps to Replace Pulleys and Belts

BNUUUM02.C11 0000274652 E.2 B.2 A.2 2/4/20, 8:08 AM Released

Preparation Remove power from the machine.

Belt removal Use the belt tension mechanism to decrease the distance between the pulleys until you have sufficient clearance. [Figure 11, page 39](#) and [Figure 12, page 39](#) show typical belt tension mechanisms.

Pulley removal On the typical type of pulley and bushing shown in [Figure 9, page 36](#), use the push-off holes to remove the pulley easily. On special types of pulleys (example: large drive pulley and cone), look at the parts document in the maintenance manual for more data. Some pulleys are too heavy for only one person to hold.

Pulley installation [Figure 9, page 36](#) shows the typical pulley and bushing components. Make sure that you keep run-out tolerances when you assemble and tighten the components.

Belt installation Decrease the distance between the pulleys to put the belt on easily. Assemble the components carefully. Make sure that the components are aligned. Adjust the belt tension so the belt is tight.

Test Before you connect power again, make sure that you remove all tools. Operate the machine with a full load. If the belts slip, increase belt tension with the machine shut down and power removed. Then test again. Make sure that the machine is safe before you put it into regular operation.

2.1.4.2 Examples of Procedures Used at the Milnor® Factory to Align Pulleys

BNUUUM02.C12 0000274686 E.2 B.2 A.3 3/6/20, 4:49 PM Released

Figure 13. Use a straight edge, a string, or a laser to make sure that all pulleys are in the same plane.




Figure 14. Use a level to make sure that the pulleys are at the same slope.





Figure 15. Dial indicator used to find the axial and radial run-out of a pulley.



BNWUUM03 / 2020125

BNWUUM03 0000277540 A.7 3/19/20, 8:51 AM Released

2.2 Disk Brake Maintenance

BNWUUM03.C01 0000277539 E.2 A.7 A.2 2/27/20, 1:48 PM Released



NOTICE: "Remove power from the machine" means use the necessary safety procedure for your location. In the USA, this is the OSHA lockout/tagout (LOTO) procedure. More local requirements can also apply.

You can do these types of maintenance on the disk brake:

- do an inspection of the brake as specified in the maintenance schedule,
- replace the friction pads,

- do an overhaul on the calipers,
- replace the hydraulic fluid,
- adjust the connection between the brake cylinder and the air cylinder.

For the first four types of maintenance, you must remove air from (bleed) the hydraulic circuit.

[Section 2.2.6 : Operation of Brake Systems, page 54](#) tells how to operate the disk brakes. You can use it in some of the types of maintenance in this procedure.



WARNING: Risk of injury or death — A machine in operation without safety guards is dangerous.




- ▶ You must be an approved maintenance technician.
- ▶ Use special caution when this instruction tells you to do work with electrical power on. Remove power from the machine for all other maintenance. Obey safety codes.
- ▶ Replace all guards and covers.




TIP: During parts of this procedure when you open up the calipers or hydraulic lines, put a cloth under the calipers to catch hydraulic fluid and parts that will fall. For safety, fully remove spilled hydraulic fluid after brake maintenance. This will help you easily identify leaks.

Figure 16. A typical hydraulic brake system



A typical hydraulic brake system (cont'd.)



2.2.1 The Inspection of the Brake

BNWUUM03.T01 0000277536 E.2.A.7 A.3 3/17/20, 11:57 AM Released



NOTE: The brakes shown in this document can look different from your equipment.



NOTE: Do this inspection when the maintenance schedule tells it is necessary. Do this inspection after you replace friction pads or do a caliper overhaul.

1. Examine the fluid in the reservoir. Change the hydraulic fluid if it smells, has contamination, or has an unusual color. See [Section 2.2.4 : How to Change Hydraulic Fluid and Remove \(Bleed\) Air from the Brake Circuit](#) , page 48.



NOTE: Brake fluid can become defective from heat in the brake system. Brake fluid absorbs water from air. Water in the brake system causes corrosion.

If necessary, add new DOT 3 fluid to 0.25 inch (6.35 millimeters) from the top of the reservoir. Follow the precautions on the container.

2. Examine the rotor disk surface ([Figure 16: A typical hydraulic brake system, page 43](#) , item 5). Replace the disk if it is worn or if it is not flat.
3. Examine the brake pads ([Figure 17: The Caliper Components, page 47](#) , item 4). To do this, you will remove/replace the calipers and bleed the hydraulic system. See [Section 2.2.3 : How](#)

to [Do a Caliper Overhaul, page 47](#) and [Section 2.2.4 : How to Change Hydraulic Fluid and Remove \(Bleed\) Air from the Brake Circuit , page 48](#).

- a. **Remove power from the machine (see above notice).**
 - b. Remove the bolts ([Figure 16, page 43, item 9](#)) that attach the caliper halves ([Figure 16, page 43, item 7](#)).
 - c. Remove the caliper halves.
 - d. Replace the pads as told in [Section 2.2.2 : How to Do a Friction Pad Replacement, page 45](#) if
 - the pads make an unusual noise when you apply the brake
 - if the rotor is worn or damaged
 - if the pad thickness is less than 1/16 inches (2 mm) ([Figure 17, page 47, item 14](#)) above the mounting screw ([Figure 17, page 47, item 3](#)). Always replace the two brake pads at the same time.
 - e. Put the caliper halves in their positions on the brake assembly. Tighten the mounting bolts to 30 foot-pounds (41 Newton-meters).
 - f. Bleed the hydraulic systems as told in [Section 2.2.4 : How to Change Hydraulic Fluid and Remove \(Bleed\) Air from the Brake Circuit , page 48](#).
 - g. Supply electrical power to the machine.
4. Examine the condition of all of the brake system.
- a. Make sure that brake mounting components are tightly installed.
 - b. Make sure that fittings are tight. Make sure that there are no leaks.

2.2.2 How to Do a Friction Pad Replacement

BNWUUM03.T02 0000277566 E.2 A.7 A.5 3/17/20, 11:57 AM Released

You must have the necessary replacement friction pads for your machine. Refer to the brake parts document in your machine manual. You will find part numbers for components or overhaul/repair kits. The overhaul/repair kit contains O-rings, pads, and other components.

1. **Remove power from the machine (see above notice).**
2. Remove the used fluid. See [Section 2.2.4 : How to Change Hydraulic Fluid and Remove \(Bleed\) Air from the Brake Circuit , page 48](#).
3. Remove the two bolts that attach the caliper ([Figure 16, page 43, item 9](#)) and the two caliper halves ([Figure 16, page 43, item 3](#)) to get access to the friction pads. Do not disconnect the hydraulic line ([Figure 16, page 43, item 6](#)).
4. If there are leaks, see [Section 2.2.3 : How to Do a Caliper Overhaul, page 47](#) before you continue.
5. Replace each friction pad:
 - a. Remove the brass screw ([Figure 17, page 47, item 3](#)) that attaches the pad to the piston.
 - b. Attach the new pad to the piston. Tighten the screw.
 - c. Make sure that the screw head is fully in the recess in the pad.

6. Make sure that the connection o-rings are clean and in their positions ([Figure 17, page 47, item 7](#)).
7. Put the caliper halves in their positions on the brake assembly. Tighten the mounting bolts to 30 foot-pounds (41 Newton-meters).
8. Bleed the brake. See [Section 2.2.4 : How to Change Hydraulic Fluid and Remove \(Bleed\) Air from the Brake Circuit , page 48](#).
9. Supply electrical power to the machine.

2.2.3 How to Do a Caliper Overhaul

BNWUUM03.T03 0000277561 E.2 A.7 A.3 3/17/20, 11:57 AM Released

Figure 17. The Caliper Components

<p>The Expanded View (Shows the Piston and the O-rings)</p> 	<p>Legend</p> <ol style="list-style-type: none"> 1. The bolts to attach the caliper (Figure 16, page 43, item 9) 2. Caliper body halves (Figure 16, page 43, item 3) 3. Brass screw 4. Friction pad 5. Piston 6. The Piston O-ring 7. The connection O-ring and its position 8. Plug for the hydraulic inlet 9. A hydraulic inlet (connected on one caliper, a plug (item 8) on the other) 10. The hole in the spacer 11. Washer 12. One of the four valves to bleed the fluid 13. Nut 14. The pad thickness must be more than than 1/16 inches (2 mm) above item 3
<p>The Caliper and the Pad</p> 	<p>Look at the pad thickness above the top of the screw</p> 
<p>Fittings for the Hydraulic Inlet</p> 	



TIP: Hydraulic fluid flows from one caliper to the other caliper. Fluid flows through the connection O-rings (Figure 17, page 47, item 7) and the hole in the spacer (Figure 17, page 47, item 10). When you disconnect the calipers, hydraulic fluid can flow from the hole at the connection O-rings. Air can get in the line. After you connect the calipers, you must bleed the system.

You must have the necessary kit for the overhaul of your machine. Refer to the brake parts document in your machine's manual.

1. **Remove power from the machine (see above notice).**
2. Get access to the caliper halves (see [Section 2.2.2 : How to Do a Friction Pad Replacement, page 45](#)).
3. Do an overhaul on each caliper:
 - a. Remove and discard the connection O-rings ([Figure 17, page 47](#), item 7) on the caliper bodies.
 - b. Apply compressed air to the fitting for the hydraulic inlets (see [Figure 17, page 47](#), item 8) to push the pistons out.
 - c. Replace the piston O-rings ([Figure 17, page 47](#), item 6).
 - d. Put the pistons in the caliper body. Carefully tap the pistons with a wood or rubber hammer to install it.
 - e. Replace the connection O-rings. ([Figure 17, page 47](#), item 7)
 - f. Replace the friction pads (see [Section 2.2.2 : How to Do a Friction Pad Replacement, page 45](#)).
4. Replace the caliper halves as specified in [Section 2.2.2 : How to Do a Friction Pad Replacement, page 45](#).
5. Bleed the brake circuit (see [Section 2.2.4 : How to Change Hydraulic Fluid and Remove \(Bleed\) Air from the Brake Circuit , page 48](#)).
6. Supply electrical power to the machine.

2.2.4 How to Change Hydraulic Fluid and Remove (Bleed) Air from the Brake Circuit

BNWUUM03.T04 0000277589 E.2 A.7 A.3 3/17/20, 11:57 AM Released

Risks and Precautions



WARNING: Risk of injury — Machine power must be on for these procedures.



- ▶ Stay away from operating mechanisms.




CAUTION: Risk of injury and damage — This procedure releases pressurized brake fluid.



- ▶ Keep brake fluid out of your eyes and mouth. Wear eye protection.
- ▶ Follow procedures carefully to prevent damage to the face of the disk or the pistons.



CAUTION: **Risk of malfunction** — Air in hydraulic fluid will compress. Compressed air in the brake line will cause brake malfunctions.



► Remove (bleed) air from the brake circuit before you operate the machine.

Requirements—These personnel and items are necessary for this procedure:

- Two technicians
- An 8-ounce container of new brake fluid
- Alternative procedures to remove air and used brake fluid:
 - a suction pump (faster procedure) (see [Figure 18: Pumps Used to Remove Hydraulic Fluid Quickly, page 50](#))
 - with pressure in the hydraulic cylinder and gravity (see [Figure 19: Typical Tools to Remove Air \(Bleed\) Brakes and Used Hydraulic Fluid, page 50](#))



TIP: The Vacula suction pump can do the work more quickly than by gravity and pressure in the hydraulic cylinder. It is also cleaner because all of the hydraulic fluid goes into the container supplied. It helps you not spill the hydraulic fluid.

- If you use a suction pump as shown in [Figure 18, page 50](#), follow the manufacturer's instructions.
- If you use the tools as shown in [Figure 19, page 50](#), follow the instructions in [Section 2.2.4 : How to Change Hydraulic Fluid and Remove \(Bleed\) Air from the Brake Circuit , page 48](#).

Figure 18. Pumps Used to Remove Hydraulic Fluid Quickly





Figure 19. Typical Tools to Remove Air (Bleed) Brakes and Used Hydraulic Fluid



1. Use the tools in [Figure 19: Typical Tools to Remove Air \(Bleed\) Brakes and Used Hydraulic Fluid, page 50](#) to remove the used hydraulic fluid and clean the line. Do these steps:
 - a. Use a suction tool ([Figure 19, page 50](#), item 4) to remove the used fluid from the reservoir. Clean the contamination.
 - b. Connect the tubing ([Figure 19, page 50](#), item 2) and container ([Figure 19, page 50](#), item 1) to the valve on the caliper ([Figure 16, page 43](#), item 7).
 - c. Open the valve.
 - d. Add new fluid to flush out the lines.
 - e. Apply/release the brake (see [Section 2.2.6 : Operation of Brake Systems, page 54](#)) approximately 5 to 15 times. This will flush the used fluid out of the lines.
 - f. Close the valve.



NOTE: These steps will cause air to go into the line.

2. Add new hydraulic fluid and remove (bleed) air from the brake circuit.



NOTE: This procedure uses pressure in the hydraulic cylinder and the tools in [Figure 19: Typical Tools to Remove Air \(Bleed\) Brakes and Used Hydraulic Fluid, page 50](#).

- a. Fill the reservoir with new DOT 3 brake fluid. When you do the remaining steps, continue to add new fluid to the reservoir. Do not let the reservoir become more than half empty. You must make sure that the reservoir has fluid to prevent air flow into the system from the reservoir
- b. Apply electrical power to the machine. Release the brake.
- c. See the part of the machine reference manual that tells how to operate the outputs manually.
- d. Put a small quantity of new brake fluid (approximately inches (50 mm)) in the 12 ounce container ([Figure 19, page 50](#), item 1).
- e. Do these steps for each bleed valve ([Figure 16, page 43](#), item 1). Two technicians are necessary. This will move the fluid in one direction and push air out of the line:
 - Attach a clean tube to the valve. Put the other end in the container ([Figure 19, page 50](#), item 1) below the fluid.
 - Make sure that the reservoir is full of fluid.
 - Apply the brake (See [Section 2.2.6 : Operation of Brake Systems, page 54](#)).
 - Open the bleed valve. ([Figure 17, page 47](#), item 12)
 - Look for air bubbles in the container when you push the air and fluid out through the tube.
 - Close the valve.
 - Release the brake.
 - Continue the steps above until no more air comes out of the line.

- f. Add fluid to the top of the reservoir. Replace the cap.
- g. Operate the brake many times. Make sure that it operates correctly.

2.2.5 How to Adjust the Connection between the Brake Cylinder and the Air Cylinder

BNWUUM03.T05 0000277686 E.2 A.7 A.4 3/17/20, 2:24 PM Released

If you removed the brake cylinder or the air cylinder, you must adjust this connection.

Figure 20. The Connection between the Brake Cylinder and the Air Cylinder





Figure 21. The Adjustment between the Brake Rod and the Air Cylinder



1. Adjust for maximum rod travel.
 - a. Operate the master switch to energize control power.
 - b. Make sure that the air pressure that releases the brake ([Figure 22: A Typical First and Second Brake on a Divided Cylinder Machine, page 55](#) , item 1) is 85 -100 PSI (5.95 - 07.0 kg/cm-cm).
 - c. Make sure that the nuts that lock the rods together ([Figure 20, page 52, item 5](#)) are loose.
 - d. Release the brake (see [Section 2.2.6 : Operation of Brake Systems, page 54](#)). Let the air cylinder rod fully retract into the air cylinder as shown in [Figure 21, page 53, item A](#).
 - e. Turn the brake rod into the air cylinder rod until the brake rod comes out of the brake cylinder fully. See [Figure 21, page 53, item B](#).
 - f. Lock the brake rod ([Figure 20, page 52, item 2](#)) to the air cylinder rod ([Figure 20, page 52, item 3](#)) with two nuts ([Figure 20, page 52, item 5](#)).
2. Make sure that the brake will continue to operate while the pads wear.
 - a. Release the brake. On the view slot, put a mark at the position of the lock nuts. ([Figure 21, page 53, item M1](#)).
 - b. Apply the brake. See [Section 2.2.6 : Operation of Brake Systems, page 54](#).
 - c. Put a mark at the position of the lock nuts when the brake is applied. This can be at position M2a, M2b, or between M2a and M2b. When the pads wear, this position will move.
 - d. Make sure that the distance the rod moves when you apply the brake is 0.75 to 1.0 inches (19-25 mm). If the travel is more than this, the brake piston can hit the mechanical stop before the brake engages fully. This condition is shown in [Figure 21, page 53, item E](#) (dimension TT).

2.2.6 Operation of Brake Systems

BNWUUM03.T06 0000277789 E.2 A.7 A.3 3/17/20, 11:57 AM Released

Look at the electrical schematics of your machine to find how your brake is controlled. Some machines release the brake when you close the door. Some machines have a control relay to release or apply the brake.

2.2.6.1 How to Apply the Brake for Machines with a "Break Release" Output

BNWUUM03.T07 0000279004 E.2 A.7 A.2 3/17/20, 11:57 AM Released

1. Turn the "brake release" control output off to de-energize the air valve to remove air pressure to the air cylinder ([Figure 16: A typical hydraulic brake system, page 43](#) , item 1).
2. With no air pressure, a spring in the air cylinder will apply force to the hydraulic cylinder ([Figure 16: A typical hydraulic brake system, page 43](#) , item 8). This will apply pressure to the brake pads ([Figure 17: The Caliper Components, page 47](#) , item 4) against the rotor disk ([Figure 16: A typical hydraulic brake system, page 43](#) , item 5). ([Figure 21: The Adjustment between the Brake Rod and the Air Cylinder, page 53](#) , item C,D)



NOTE: If electrical power or compressed air is missing, hydraulic pressure will apply the brake.

2.2.6.2 How to Release the Brake for Machines with a "Brake Release" Output

BNWUUM03.T08 0000279003 E.2 A.7 A.2 3/17/20, 11:57 AM Released

1. Turn the control output called "brake release" on to energize the air cylinder valve.
2. Air pressure compresses the spring and releases the brake. ([Figure 21: The Adjustment between the Brake Rod and the Air Cylinder, page 53](#) , item B)

2.2.6.3 How to Apply and then Release the Brake Quickly

BNWUUM03.T09 0000279002 E.2 A.7 A.2 3/17/20, 11:57 AM Released


There are two air tubes at ([Figure 16: A typical hydraulic brake system, page 43](#) , item 1). One supplies compressed air from an air valve. The other sends this compressed air to a pressure switch. If you remove one of the two tubes when compressed air is there, you will apply the brake.

1. Disconnect the air tubing ([Figure 16: A typical hydraulic brake system, page 43](#) , item 1).
2. Turn the "brake release" output on. The air valve will supply compressed air to one of the tubes. ([Figure 16: A typical hydraulic brake system, page 43](#) , item 1).
3. Quickly move one of the compressed air tubes ([Figure 16: A typical hydraulic brake system, page 43](#) , item 1) on and off the air cylinder.
4. After you complete this procedure, connect the air tubing.

2.2.6.4 How the Brake Operates on Divided Cylinder Machines

BNWUUM03.T10 0000279001 E.2 A.7 A.2 3/17/20, 11:57 AM Released

Figure 22. A Typical First and Second Brake on a Divided Cylinder Machine



- On divided cylinder machines, two pair of air tubes connect to different ends of the air cylinder.
- When the cylinder turns, air pressure at [Figure 22: A Typical First and Second Brake on a Divided Cylinder Machine, page 55](#) , item 1 compresses the spring and releases the brake.
- When you operate the stop control, air pressure at 1 is removed. Then the spring in the air cylinder applies the brake.
- If you open the door, the 2nd brake is applied. Then the air pressure at [Figure 22: A Typical First and Second Brake on a Divided Cylinder Machine, page 55](#) , item 2 and the spring apply the brake.

2.2.6.5 The Second Brake

BNWUUM03.T11 0000279000 E.2 A.7 A.2 3/17/20, 11:57 AM Released

If your machine has a second brake which uses air pressure and spring pressure, it will have a pressure regulator. Make sure that you adjust the air pressure of the second brake ([Figure 22: A Typical First and Second Brake on a Divided Cylinder Machine, page 55](#) , item 2) to 10 – 12 PSI (0.7-0.84 kg/cm-cm).


BPWG6I04 / 2020136

BPWG6I04.1 0000279578 E.2 A.5 3/27/20, 5:15 PM Released

Drive Chart

5 sheets

6044SP2, 6044SP3 (Single Motor)




Legend

- A . . . Front jackshaft pulley
- B . . . Rear jackshaft pulley
- C . . . Motor pulley

Drive Chart

6044SP2, 6044SP3 (Single Motor)

5 sheets




Legend

- A . . . Front jackshaft pulley
- D . . . Front main pulley
- E . . . Main shaft
- F . . . Idler shaft
- G . . . Front idler pulley
- H . . . Rear idler pulley
- J . . . Rear main pulley

Drive Chart

6044SP2, 6044SP3 (Single Motor)

5 sheets




Legend

- A.** . . . Front jackshaft pulley
- D.** . . . Front main pulley
- G.** . . . Front idler pulley
- K.** . . . 3 instances

Drive Chart

6044SP2, 6044SP3 (Single Motor)

5 sheets



J 24,25,26

H 21,22

Legend

H . . . Rear idler pulley
J . . . Rear main pulley

Drive Chart

5 sheets

6044SP2, 6044SP3 (Single Motor)

Table 18. Parts List—Drive Chart

Find the assembly for your machine and the letter shown in the "Item" column. The components for your machine will show this letter or the word "all" in the "Used In" column. The numbers shown in the "Item" column are those shown in the illustrations.				
Used In	Item	Part Number	Description/Nomenclature	Comments
Reference Assemblies				
	A	D29 00960S	*DVECHRT=6044SP2 50/60 SGL MTR	6044SP2, 6044SP3 Single Motor Prior to 4/12/16
Components				
all	1	56060B8SF	VPUL 8B6.0 (SF) TYPE QD	USES 3
all	2	56Q1RSF	1+7/8" BUSH VPUL QD TYPE SF	
all	3	02 15794	KEY-1/2X2+1/2 4231-4244SGH	
all	4	56VB062XB3	VBAND 3RBX62 EACH=1	
all	5	5608B110	PULLEY 8B11.0 TYPE E	
all	6	56Q2PE	2+3/4" BUSHING VPUL QD TYPE E	
all	7	15E241	SQMACHKEY 5/8X2+1/2	
all	8	56080C6E	VPUL 6C8.0 (E) TYPE QD	
all	9	56Q2HE	2+7/16" BUSH VPUL QD TYPE E	
all	10	02 175121	KEY=5/8SQ	
all	11	X3 06330D	VPUL=6GR 7PDX14.5PD=60SG	
all	12	54V400	BUSHING=3-15/16=SPECIAL	
all	13	15E250	STRSQMACHKEY 1X6 C1018	
all	14	03 06445	WEDGE=SHEAVE+SHAFT=60+72SGU	
all	15	15K235A	HEXCAPSCR 3/4-10X2.5 GR 8	
all	16	15U340	LOCKWASH MEDIUM 3/4 ZINCPL	
all	17	15U320	FLATWASHER(USS STD) 3/4" UNPLT	
all	18	15K226C	SOKCAPSCR 5/8-11X3 BLK	
all	19	15U315	LOKWASHER MEDIUM 5/8 ZINCPL	
all	20	56VC173XBA	SET OF TWO 3RCX173 VBANDS	
all	21	56070C6R2	VPUL 6C7.0 (R2) SPECIAL	
all	22	56Q3DR2S	3+3/16" SPLIT BUSH B#R2	
all	23	56VC107XBA	SET OF FOUR 3RCX107 VBANDS	
all	24	56130C6F	VPUL 6C13.0 (F) TYPE QD	
all	25	56Q2TF	2+15/16" BUSH VPUL QD TYPE F	
all	26	02 175021	KEY-3/4"SQX6+1/2"LONG-60WE	

BPWG6I05 / 2020145

BPWG6I05.1 0000279741 E.2 A.6 4/2/20, 8:48 AM Released

Drive Base

7 Sheets

6044SP2, 6044SP3 (Single Motor)





NOTE: This drawing represents 60044SP2 and 60044SP3 models produced prior to 4/12/2016



Drive Base

6044SP2, 6044SP3 (Single Motor)

7 Sheets




Legend

- E** . . . 4 instances
- F** . . . 2 instances
- G** . . . 6 instances

Drive Base

6044SP2, 6044SP3 (Single Motor)

7 Sheets





Legend

- A-A** . . See view A-A
- E** . . . 4 instances
- H** . . . See detail C
- J** . . . See detail B


Drive Base

6044SP2, 6044SP3 (Single Motor)

7 Sheets



B



C




Legend

- A-A** . . . Detail view A-A
- B** . . . Detail view B
- C** . . . Detail view C
- K** . . . As required
- L** . . . Uses 3

Drive Base

6044SP2, 6044SP3 (Single Motor)


7 Sheets



Drive Base

6044SP2, 6044SP3 (Single Motor)

7 Sheets



Drive Base

6044SP2, 6044SP3 (Single Motor)

Table 19. Parts List—Drive Base

Find the assembly for your machine and the letter shown in the "Item" column. The components for your machine will show this letter or the word "all" in the "Used In" column. The numbers shown in the "Item" column are those shown in the illustrations.				
Used In	Item	Part Number	Description/Nomenclature	Comments
Reference Assemblies				
	A	SA 28 106S	*DRIVE BASE ASSY 60SPU SGL MTR	6044SP2, 6044SP3 PRIOR TO 4/1216
	B	GBJ28001S	JKSHFT ASSY 60W3 1 MOTOR	
Components				
all	1	05 20131E	MTRPLATE 6044SG 1 MOTOR	
all	2	02 19577	ADJ ANGLE MOTOR	
all	3	15K221	HEXCAPSCR 5/8-11 UNC2X2GR5 ZIN	
all	4	15U320P	FLATWASHER(USS STD) 3/4" ZNC	
all	5	15U314	FLATWASHER(USS STD) 5/8" ZNC P	
all	6	15G238	HXNUT 5/8-11UNC2B SAE ZINC GR2	
all	7	02 19283	NUT=1/2-13UNCX1+1/2SQ SPEC	
all	8	15K173A	HXCAPSCR 1/2-13UNC2AX1.75 GR5	
all	9	15U300	LOKWASHER REGULAR 1/2 ZINC PLT	
all	10	15B186	HEXTAPBLT FLT 5/8-11UNCX7	
all	11	W2 18717D	DRIVE BASE 6044SG 1 MOTOR	
all	13	54M025	HYDFIT 1/8"-90 ALEMITE 1613-B	
all	14	5SCC0CBE	NPT COUP 1/8 BRASS 125# 103A-A	
all	15	5N0C03AG42	NPT NIP 1/8X3 TBE GALSTL SK40	
all	16	02 19383	BEARHOUSE MT PLATE FRONT	
all	17	02 11603A	WASHER DBLR=2" W/CUTOFF SIDE	
all	18	15U355A	28GA ADJWASH=BRGHOUS ZINC PL	
all	19	54AF22215	PILLOW BLOCK BRG 2-3/4"=DODGE P2B-1P	
all	20	15K235A	HEXCAPSCR 3/4-10X2.5 GR 8	
all	21	15U340	LOCKWASH MEDIUM 3/4 ZINCPL	
all	22	15U300	LOKWASHER REGULAR 1/2 ZINC PLT	
all	23	02 18733	BRACE=SWAY 60"SGH	
all	24	03 25626	FORK=MTR MNT ADJ SCREW 52	
all	25	02 18702	FORK=ADJ SCREW-MOTOR MT-FRT	
all	26	17R125A15K	STUD=DRIVEBASEADS 1+1/4X15.5	
all	27	15G261	HVHXNUT 1+1/4-8UNC2B ZINC GR2H	
all	28	17W125	1+1/4"SPHERICAL WASHER SET	
all	29	15P200	TRDCUT-F HXWASHD 3/8-16X3/4NIK	
all	30	15K227	HXCAPSCR 5/8-11UNC2AX4 GR5 ZIN	
all	31	02 18706	REINFORCEMENT=HINGE PINCLAMP	

Drive Base

7 Sheets

6044SP2, 6044SP3 (Single Motor)

Table 19 Parts List—Drive Base (cont'd.)

Find the assembly for your machine and the letter shown in the "Item" column. The components for your machine will show this letter or the word "all" in the "Used In" column. The numbers shown in the "Item" column are those shown in the illustrations.				
Used In	Item	Part Number	Description/Nomenclature	Comments
all	32	X2 18634	CLAMP=MACHINED DR HINGPIN	
all	33	15G236	SQNUT 5/8-11UNC2B SAE ZINC GR2	
all	34	02 175257	GREASE RELIEF=DRIP SHIELD	


BPWG6I03 / 2023164A

BPWG6I03.1 0000279524 E.2 C.2 4/19/23, 10:25 AM Released

Jackshaft

2 Sheets

42044WR2, 42044SR2, 60044WR2, 60044SR2



Jackshaft

2 Sheets

42044WR2, 42044SR2, 60044WR2, 60044SR2

Table 20. Parts List—Jackshaft


Find the assembly for your machine and the letter shown in the "Item" column. The components for your machine will show this letter or the word "all" in the "Used In" column. The numbers shown in the "Item" column are those shown in the illustrations.				
Used In	Item	Part Number	Description/Nomenclature	Comments
Reference Assemblies				
	A	ABJ25006B	JACKSHAFT-PILLOW BLK BRG	2.75" SHAFT 6044WR2 EFFECTIVE 2015193 (5/5/2015) 6044SR2, 4233WR2, & 4244SR2 EFFECTIVE 2016163 (4/12/2016)
Components				
all	1	X2 18711M	6044WP JACKSHAFT: PILLOW BLOCK/SPHRCL 2.75 BORE	
all	2	56S22217A	SPHEROLBRG 22217EK/C3 SAF517 PILLOW BLK 3.346"ID	

Single Motor Drive

60044SR2



NOTE: This design, effective 2016163 (4/12/2016), uses a 2.75" diameter jackshaft with no housing and 2 pillow block bearings.



Legend

- A . . . Pillow block bearings
- B . . . Jackshaft
- C . . . Load
- D . . . Unload
- E . . . Balanced set includes pulley and bushing. Key comes with motor.
- F . . . One set of three belts.
- G . . . Main shaft
- H . . . Key
- J . . . Balanced set includes pulley and bushing.
- K . . . Two sets of four belts.
- L . . . Idler shaft
- M . . . See Idler Shaft Bearing installation.

Single Motor Drive

2 Sheets

60044SR2

Table 21. Parts List—Single Motor Drive

Find the assembly for your machine and the letter shown in the "Item" column. The components for your machine will show this letter or the word "all" in the "Used In" column. The numbers shown in the "Item" column are those shown in the illustrations.				
Used In	Item	Part Number	Description/Nomenclature	Comments
Reference Assemblies				
	A	D29 00960S	*DVECHRT=6044SP2 50/60 SGL MTR	REFERENCE
	B	SA 28 106S	*DRIVE BASE ASSY 60SPU SGL MTR	EFFECTIVE 4/12/2016
Components				
all	1	56060B9SF	BALANCED SET - VPUL 9B6.0 (SF) TYPE QD/(56Q1RSF) 1+7/8" BUSH VPUL QD TYPE SF	
all	2	56VB062XB3	VBAND 3RBX62 EACH=1	
all	3	56110B9E	BALANCED SET - VPUL 9B11.0 (E) TYPE QD/(56Q2PE) 2-3/4" BUSHING VPUL QD TYPE E	
all	4	02 175121	KEY=5/8SQ	
all	5	56080C6E	VPUL 6C8.0 (E) TYPE QD	
all	6	56Q2HE	2+7/16" BUSH VPUL QD TYPE E	
all	7	56VC173XBA	SET OF TWO 3RCX173 VBANDS (WT =24 LBS)	
all	8	X3 06330D	VPUL=6GR 7PDX14.5PD=60SG	
all	9	54V400	BUSHING=3-15/16=SPECIAL	
all	10	15E250	STRSQMACHKEY 1X6 C1018	
all	11	03 06445	WEDGE=SHEAVE+SHAFT=60+72SGU	
all	12	56070C6R2	VPUL 6C7.0 (R2) SPECIAL	
all	13	56Q3DR2S	3+3/16" SPLIT BUSH #R2	
all	14	56VC107XBA	SET OF FOUR 3RCX107 VBANDS=30LB	(1 SET OF 4 BELTS)
all	15	56130C6F	VPUL 6C13.0 (F) TYPE QD	
all	16	56Q2TF	2+15/16" BUSH VPUL QD TYPE F	
all	17	02 175021A	KEY-3/4"SQX3+1/4"LONG	

Drive Base Installation


4 Sheets

60044SR2



NOTE: This design effective 4/12/16, jackshaft is 2.75” in diameter with 2 pillow block bearings. For prior design, see BPWG6I05.

Figure 23. Motor mount, drive shaft, and pillow back bearings



Legend

A . . . Jackshaft, see BPWG6I03


B . . . Two instances per bearing

Drive Base Installation

4 Sheets

60044SR2

Figure 24. Motor mount, drive shaft, and pillow block bearings




Drive Base Installation

4 Sheets

60044SR2

Figure 25. Adjustable bolts



Drive Base Installation

4 Sheets

60044SR2

Table 22. Parts List—Drive Base Installation

Find the assembly for your machine and the letter shown in the "Item" column. The components for your machine will show this letter or the word "all" in the "Used In" column. The numbers shown in the "Item" column are those shown in the illustrations.				
Used In	Item	Part Number	Description/Nomenclature	Comments
Reference Assemblies				
	A	SA 28 106A	6044SP DRIVE BASE & JACKSHAFT ASSY	EFFECTIVE 04/12/2016
Components				
all	1	W2 18717E	6044SP DR BASE WLMT-PILLOW BLK BRG	
all	2	ABJ25006B	PILLOW BLOCK JACKSHAFT BRG	
all	3	15K235AB	HXCAPSCR 3/4-10UNC2AX3"GR8 ZIN	
all	4	15U320	FLATWASHER(USS STD) 3/4" UNPLT	
all	5	15U340	LOCKWASH MEDIUM 3/4 ZINCPL	
all	6	X2 18634	CLAMP=MACHINED DR HINGPIN	
all	7	02 18706	REINFORCEMENT=HINGE PINCLAMP	
all	8	15K227	HXCAPSCR 5/8-11UNC2AX4 GR5 ZIN	
all	9	15U315	LOKWASHER MEDIUM 5/8 ZINCPL	
all	10	15G236	SQ NUT 5/8-11UNC2B SAE ZINC GR2	
all	11	05 20131E	MTRPLATE 6044SG 1 MOTOR	
all	12	02 19577	ADJ ANGLE MOTOR	
all	13	15K211	HXCAPSCR 5/8-11UNC2AX1 GR5 ZIN	
all	14	15G238	HXNUT 5/8-11UNC2B SAE ZINC GR2	
all	15	15K151	HXCAPSCR 1/2-13UNC2AX1.25 GR5	
all	16	15U300	LOKWASHER REGULAR 1/2 ZINC PLT	
all	17	02 19283	NUT=1/2-13UNCX1+1/2SQ SPEC	
all	18	15B186	HEXTAPBLT FLT 5/8-11UNCX7	
all	19	15P200	TRDCUT-F HXWASHD 3/8-16X3/4NIK	
all	20	03 25626	FORK=MTR MNT ADJ SCREW 52	
all	21	17R125A15K	STUD=DRIVEBASEADS 1+1/4X15.5 8UN	
all	22	15G261	HVHXNUT 1+1/4-8UNC2B ZINC GR2H	
all	23	17W125	1+1/4"SPHERICAL WASHER SET	

BPWG6I07 / 2020155


BPWG6I07.1 0000280105 E.2 A.3 4/9/20, 9:00 AM Released

Upper Disc Brake

3 Sheets

6044SP2, 6044SP3, 6044SR2, 6044SR3

Figure 26. Disc




Upper Disc Brake

3 Sheets

6044SP2, 6044SP3, 6044SR2, 6044SR3

Figure 27. Air Cylinder and Master Cylinder



Upper Disc Brake

3 Sheets

6044SP2, 6044SP3, 6044SR2, 6044SR3

Table 23. Parts List—Upper Disc Brake

Find the assembly for your machine and the letter shown in the "Item" column. The components for your machine will show this letter or the word "all" in the "Used In" column. The numbers shown in the "Item" column are those shown in the illustrations.				
Used In	Item	Part Number	Description/Nomenclature	Comments
Reference Assemblies				
	A	GBR28002	INST=DISC BRAKE 60SG2/3 1-MOTO	
Components				
all	1	AAC65002	2006292 AIRCYL BRAKE SINGLE MOTOR	
all	2	02 21859B	BRAKE TORQUE ARM 60SG 1 MOTO	
all	3	W3 65238	*WLMT=MASTER BRAKE CYL BRKT	
all	4	54KMC1125U	MASTER CYL TILTON 74-1125U	
all	5	52XY0ER004	STRADTUN3/16MJX1/8FP#2405-3-2	
all	6	54KC7961BG	BRAKE HOSE=1/8"X18"OAL # 50612	
all	7	52AY0ER003	STR.1/4"MJICX1/8"MP#2404-4-2	
all	8	X2 04454	MACH=BRK CALPR MNT PLT,6836	
all	9	X2 04458	BRAKE ROTOR HUB-6836E	
all	10	X2 04459	BRAKE ROTOR-6836E	
all	11	56Q1RE	1+7/8" BUSH VPUL QD TYPE E	
all	12	54KC7975	CALIPER HYD D/A 1/2" H200DERG 4004-0111	
all	13	15K173A	HXCAPSCR 1/2-13UNC2AX1.75 GR5	
all	14	15G230	HXNUT 1/2-13UNC2B SAE ZINC GR2	
all	15	15U490	FLTWASH 1+1/2X17/32X1/4 ZINC	
all	16	15U300	LOKWASHER REGULAR 1/2 ZINC PLT	
all	17	02 11603C	WASHER DBLR=1.5W/CUTOFF SIDE	
all	18	15K214E	HXCAPSCR 5/8-11UNC2AX1.5 GR5 Z	
all	19	15U315	LOKWASHER MEDIUM 5/8 ZINCPL	
all	20	15P200	TRDCUT-F HXWASHD 3/8-16X3/4NIK	
all	21	15K065	HEXCAPSCR 5/16-18UNC2AX1 GR5 Z	
all	22	15U210	LOKWASHER MEDIUM 5/16 ZINCPL	
all	23	15G185	HXNUT 5/16-18UNC2B SAE ZINC GR	
all	24	15G195	HXNUT 5/16-24UNF2B SAE ZINC GR	

2.3 Main Bearing and Seal Replacement for Divided Cylinder Machines


BNWVUM02.C01 0000278612 E.2 A.5 A.3 3/12/20, 11:54 AM Released

This section applies to the front and rear cylinder shaft bearings of all divided cylinder machines (Rapid Load, Staph Guard®, dye machines, etc.). It does not apply to jackshaft bearings, idler shaft bearings or bearings on open pocket machines.

The bearings covered by this section are double row, spherical roller, self aligning bearings; Koya, SKF, FMC, Torrington or equal. Referring to [Figure 28, page 81](#), the rear (clean side on Staph Guard® models) bearing is firmly held in the bearing housing (bearing and seal carrier) by the shaft seal holder, preventing axial movement. The front (soil side on Staph Guard® models) bearing is free to move axially in the bearing housing to accommodate thermal expansion of the shaft during operation and is thus the “floating” bearing. Both bearings are held in place on the tapered portion of the shaft by a bearing lock washer and lock nut.

The front and rear bearings are each protected from contamination from wash water by three spring loaded, lip type seals and a shaft seal leak off cavity (that carries off any water that leaks past the main water seals) as shown in [Figure 28, page 81](#).

Figure 28. Cross Section View of Front and Rear Bearing Assemblies (Bearing Assembly for 60" and 72" WED Shown. Others similar.)



Access to the bearings and seals for lubrication is provided by the various grease passages. Excess lubricant is excreted through the bearing and seal cavity leak offs as shown on [Figure 28, page 81](#). The bearings and seals must be lubricated regularly and the leak off cavities flushed out

periodically through the plugged cleanout connections, in strict accordance with the preventive maintenance procedures elsewhere.

If bearing replacement becomes necessary due to wear, it is essential that the bearings **and seals** are replaced. Seal replacement requires removal of the bearing housing and seal sleeve. (In rare instances where the seals are known to be in good condition, it is not necessary to remove the bearing housing, seals or seal sleeve when a bearing is replaced.) **A pulling fixture is required to remove the bearing housing. A set of guide rods, a seal sleeve setting fixture and a bearing setting fixture are required for reinstallation of the housing.** These tools are available for rental or purchase from the Milnor® factory and are pictured elsewhere in this section. Contact the factory two weeks in advance of repairs, when ordering these tools.

This maintenance is performed in the following order:


1. Remove old bearing(s). When removing both bearings, remove the front (soil side) bearing first.
2. Remove bearing housings, seal sleeves, and seals.
3. If both bearings were removed, install the bearing housing, seal sleeve, seals, and new bearing on the rear (clean side).
4. Install the bearing housing, seal sleeve, seals, and new bearing on the front (soil side).
5. Tighten bearing(s).

See the Main Bearing Assembly drawing for your machine for bearing component part numbers.

2.3.1 Removing the Bearing (Front or Rear)

BNWVUM02.T01 0000278621 E.2 A.5 A.3 3/12/20, 11:54 AM Released

1. Loosen, then remove the main drive belts and cylinder shaft pulley (if applicable) by lowering the drive base with the jacking bolts. Do not attempt to pry belts off with a pry bar or by rolling the sheave. Remove the bearing cover (or shaft seal holder) to expose the bearing.
2. Bend back the locking tang on the bearing lock washer then remove the lock nut and lock washer.
3. The center tapped hole in the shaft end is an oil passage through which oil may be forced between the tapered shaft and the bearing inner race. Install a pipe fitting into this tapped hole as shown in [Figure 29: Connection From Hydraulic Pump to Assist in Bearing Removal, page 83](#) . Using a “Porta Power” or similar hand operated hydraulic pump, force fluid into the passage. Pump hard to build up fluid pressure. This pressure will cause the inner race to expand slightly; just enough to free the tapered surfaces and allow the bearing to slip off easily. If the bearing is not readily removed, remove the front water level inspection plate and use a timber to pry up the cylinder to remove cylinder weight from the bearings. Once the bearing is removed, the cylinder drops only approximately 1/32" before the shaft comes to rest on the shaft support.
4. Slide the bearing off of the shaft and if it is to be reused, place it on a clean surface and cover with a clean, lint free cloth.



Figure 29. Connection From Hydraulic Pump to Assist in Bearing Removal

2.3.2 Removing the Bearing Housing (Bearing and Seal Carrier), Seal Sleeve, and Seals (Front or Rear)

BNWVUM02.T02 0000278618 E.2 A.5 A.3 3/12/20, 11:54 AM Released

These procedures require the use of a pulling fixture and guide rods available from the Milnor[®] factory. With the bearing cover (or shaft seal holder) and the bearing removed, proceed as follows:

1. Remove the three bearing housing cap bolts and the grease lines from the bearing housing front plate. Install guide rods in two of the bolt holes, as shown in [Figure 30, page 83](#).
2. Install the pulling fixture as shown in [Figure 31, page 83](#), by placing each of the four threaded rods through a hole in the steel plate with hexnuts to the outside of the plate then screwing each rod into the appropriate tapped hole in the bearing housing (same holes as used to mount the bearing cover or shaft seal holder).

Figure 30. Two Bearing Housing Guide Rods in Position**Figure 31. Bearing Housing Pulling Fixture in Position**



NOTE: Step 2a or 2b below will cause the bearing housing to slide away from the shell. Shims were placed under one or more of the three bearing housing pads during factory assembly to align the housing and insure its being exactly parallel with the shaft. **When removing the bearing housing, be sure to keep these shims separate and identified so that they may be returned to their proper location, otherwise the bearing and seal will be out of line and may be damaged after a short operating period.** As a precaution in case the shims are lost during disassembly, you will find stamped next to the bearing housing the proper thickness of shims required (if any) under each adjacent bearing housing pad. The stamped number indicates the shim thickness in thousandths of an inch. For example, the number “38” indicates that 38/1000 (.038”) shims would be required under this pad.

- a. Tighten all four hex nuts on the threaded rods such that the pulling fixture plate is pressed against the shaft end. With an impact wrench, tighten down on the center bolt until the housing slides out, or
 - b. If no impact wrench is available, simply continue to tighten down on each of the four hex nuts behind the pulling fixture plate, alternately and progressively, until the housing slides out. It may be necessary to place a spacer (approx. two inches long) between the plate and the shaft to provide enough clearance between the plate and the bearing housing.
3. Once the bearing housing is free of the shell, carefully slide it off of the guide rods and place on a clean work surface.
 4. The seal sleeve will almost always remain on the shaft when the housing is removed. Remove the seal sleeve **taking care not to damage or scar it** and place it on a clean work surface.

2.3.3 Precautions for Bearing Replacement

BNWVUM02.C02 0000278703 E.2 A.5 A.4 3/16/20, 8:35 AM Released

The most important ingredient in successful bearing and seal installation is **cleanliness**. The bearing housing must be free of all **foreign** matter. The grease and leak off passages must be blown clear and all **foreign** matter removed. You must have a clean work area. Keep your hands and tools free from grit and grime. Wash your hands before starting and as required during these procedures. **Foreign** matter is, without doubt, the most frequent cause of bearing failure, and one over which the manufacturer has no control.

Where cleaning is required, bearings, bearing housings and seal sleeves may be cleaned with the following solvents or cleaning agents (in strict accordance with the manufacturer’s recommendations as such substances are generally toxic and/or explosive under certain conditions):

Benzene	Gasoline	Naptha
Chlorethane	Kerosene	Trichlorethylene
Freons	Mineral Spirts	

Do not, however, expose any components to the above substances for more than 24 hours and only use at room temperature. Never use the following solvents or cleaning agents: alcohols, cresols, phenols, flouro propanols, or other similar chemicals or mixtures.



NOTE: Hammer blows, overheating, or improper use of force can damage precision parts.

2.3.4 Replacing the Bearing Housing, Seal Sleeve, and Seals (Front or Rear)

BNWVUM02.T03 0000278713 E.2 A.5 A.3 3/12/20, 11:54 AM Released

1. With the seal sleeve removed, press all old seals out of the bearing housing. Remove the large o-ring from the outside of the housing. Thoroughly clean the bearing housing and flush out all grease passages to make certain they are unblocked. Remove the o-rings from the inside of the seal sleeve and clean the seal sleeve.
2. While the bearing housing is disassembled, charge all grease passages with grease. This will assure that there are no blockages.
3. Replace the o-rings in the seal sleeve and the large o-ring on the outside of the bearing housing. Replace with new o-rings if the old ones are worn.
4. Press new seals into the bearing housing. You may gently work the seals in with a mallet and metal drift as shown in [Figure 32, page 85](#).




CAUTION: Each seal must be of the proper material and face the proper direction. The type of material and direction the seal faces may differ from one seal to another within the same bearing housing and also from one type of machine to another. It is essential to consult the Main Bearing Assembly drawing for your machine for the proper part number and direction to face each seal.

5. Slip the seal sleeve into the bearing housing as shown in [Figure 33, page 85](#), using care not to damage or fold under any of the seal lips. Be sure to insert the sleeve in the proper direction (see Bearing Assembly drawing).

Figure 32. Installing Seals in Bearing Housing



Figure 33. Installing Seal Sleeve in Bearing Housing






NOTE: If both housings are being installed, install the rear housing first.

6. With two of the three temporary guide rods in position on the shell, place the bearing housing onto the guide rods and install the seal sleeve setting fixture on to the bearing housing as shown in [Figure 34, page 86](#). The seal sleeve setting fixture prevents the seal sleeve from being pushed out of the housing as the housing is inserted into the shell. Note that the seal sleeve setting fixture and the bearing setting fixture are very similar, but the seal sleeve setting fixture has a longer hub.
7. With a clean, lint free cloth, apply a coating of light machine oil to the outside of the housing, to assist in installation. Push the housing into the shell as shown in [Figure 35, page 86](#). Once the housing is far enough into the shell to support itself, place any shims back into position between the housing and the shell. Remove, then replace guide rods if required to place shims under bearing housing pads.

Figure 34. Installing the Bearing Housing Setting Fixture onto Housing (42" machine shown)




Figure 35. Pushing the Bearing Housing into the Shell (60" Rapid-load machine shown)



8. Install the third guide rod, spacers if required, and hex nuts, using these to seat the housing fully, as shown in [Figure 36, page 87](#). Remove the seal sleeve setting fixture.

Figure 36. Tightening the Bearing Housing into the Shell (42" machine shown)



9. Remove the guide rods and install the bearing housing cap bolts. See “Bolt Torque Requirements” elsewhere, for proper torques.
10. With the grease gun, pump grease into the inner portion of the bearing cavity, such that when the bearing is installed, the space between the bearing and the seals will be approximately 1/3 full of grease.
11. Proceed to [Section 2.3.5 : Measuring Unmounted Clearance and Setting Bearing \(Front or Rear\)](#), page 87, even if both the front and rear bearings are being replaced. Once the rear bearing is installed, the bearing housing replacement procedures may then be repeated for the front (soil side) bearing housing.

2.3.5 Measuring Unmounted Clearance and Setting Bearing (Front or Rear)

BNWVUM02.T04 0000278712 E.2 A.5 A.3 3/12/20, 11:54 AM Released

The bearings used on Milnor® washer and dye extractors are the very best anti-friction devices available for these applications. However, the anti-frictional characteristics of the bearings will be reduced if they are not properly installed. It is of critical importance when installing these tapered roller bearings, to accomplish the following (A step by step procedure follows this synopsis):

1. Accurately measure the unmounted internal clearance of the bearing (gap between the rollers and outer race before the bearing is installed). This is an essential quality control measure.
2. Calculate the final internal clearance by subtracting the specified clearance reduction (amount that the internal clearance must be reduced when the bearing is tightened onto the tapered shaft) from the unmounted clearance.
3. Tighten the bearing onto the shaft until the final internal clearance as calculated is achieved and verified by measurement.

These measurements are taken in thousandths of an inch. Although this requires precise work, attention to detail and a good set of feeler gauges, it is the only way to insure that the bearing will be tightened onto the shaft to precisely the right tension. If you have any questions on performing the measurements or adjustments described below, your local bearing supplier or the Milnor® factory can assist you. Although these procedures require precision over and above that normally required for laundry room maintenance, they are standard in bearing installation and absolutely essential:



NOTE: Step 4 requires a good set of feeler gauges including .001" through .010" in thousandths of an inch increments. Contact your local bearing supplier.

4. When you are ready to proceed (and not before), remove the new bearing from its box or protective wrapping. Do not attempt to clean the bearing or wash out the preservative coating. On a clean work surface, stand the bearing on edge and insert a .003 feeler gauge into the bearing as shown in [Figure 37, page 88](#). The gauge should be inserted just inside the outer race between two rollers and worked through to the opposite row of rollers. Rotate the inner race of the opposite row so that the end of the feeler gauge is caught between a roller and the outer race.

Figure 37. Measuring Bearing Unmounted Clearance (bridge for 42" machine shown)



5. Try to pull the gauge straight out. If it comes out, increase the size of the gauge by .001". If it does not come out, decrease the gauge by .001". The thickest feeler gauge that will come out is the unmounted internal clearance of the bearing.
6. Compare the measured clearance with the "Unmounted Clearance" in [Table 24: Table of Bearing Clearances, page 89](#). If the measured clearance is not within the range shown, do not use the bearing. Contact your bearing supplier for an exchange.



NOTE: The clearances listed in the chart are industry standards and therefore apply to all brands of bearings supplied by Milnor®. If other sources of bearings are used, refer to the manufacturer's instructions for proper clearances.



NOTE: To locate your bearing on the chart, match the first five characters of the manufacturer's part number (**not the Milnor® part number**) with those in the chart. For example, for a manufacturer's part number 22217LBK, find under "Manufacturer Part Number" the line "22217 . . ."

Table 24. Table of Bearing Clearances

Manufacturer Part Number	Unmounted Clearance		Clearance Reduction	
	Minimum	Maximum	Minimum	Maximum
22330...	.0071	.0091	.002	.003
22213...	.0030	.0039	.001	.002
22216...	.0028	.0037	.001	.002
22217...	.0044	.0057	.0015	.0025
22312...	.0030	.0039	.001	.002
22316...	.0037	.0049	.001	.002
22320...	.0044	.0057	.0015	.0025
22328...	.0063	.0081	.002	.003
23220...	.0044	.0057	.0015	.0025

- Calculate and record the final internal clearance by deducting the "Clearance Reduction" for your bearing (see [Table 24, page 89](#)) from the measured clearance. For example, if you measured .004 and the clearance reduction is .001 to .002, then the final internal clearance should be between .002 and .003.
- Hand pack the bearing with grease by rotating the inner race and rollers, forcing grease between all rollers.



NOTE: The bearing will be set into position in Step 9. If both front and rear bearings are being installed, the rear (clean side on Staph Guard® models) bearing should be set in position first because it is the fixed bearing.

- Set the bearing into the housing (with the taper facing the proper direction) and seat the bearing using the bearing setting fixture. This fixture is installed in similar fashion to the seal sleeve setting fixture. If you have just set the rear bearing and the front bearing housing is yet to be installed, leave the bearing setting fixture in place for now.
- If you have just set the rear bearing and the front bearing housing is yet to be installed, repeat all steps in bearing housing installation, measuring unmounted clearance and setting bearing, for the front bearing and housing. The bearing setting fixture should not be removed from the rear housing until it is needed to seat the front bearing. This will prevent rear bearing components from being pushed out of position by the shaft as the front housing components are seated. Remove the bearing setting fixture from the front housing once the bearing is seated.

2.3.6 Tightening Bearing(s) (Front and/or Rear)

BNWVUM02.T05 0000278718 E.2 A.5 A.3 3/12/20, 11:54 AM Released

- Once both bearings are seated, or if only one bearing was replaced, install the bearing lock washer(s) and lock nut(s). Use a hammer and a metal drift as shown in [Figure 38, page 90](#), to tighten the lock nut. **It is imperative to only tap lightly and to assure that metal chips from the drift or lock nut do not fall off and contaminate the bearing.** If both bearings are

being tightened, work between the front and rear bearings and turn the basket by hand periodically, while tightening the lock nut(s).

2. After tightening the bearing(s) onto the tapered shaft, check the internal clearance as pictured in Figure 39, page 90, by working a feeler gauge between the outer race and a roller of the outer row then between the outer race and a roller of the inner row.



NOTE: Sometimes, when setting the bearings, all the load is taken by only one row of rollers (although the load would quickly equalize on both rows after the machine has run for only a few minutes). If all the load is taken by one row, you will get an erroneous clearance reading. It is therefore, necessary to use the feeler gauge to measure the **clearance of both rows of rollers**. With the bearing in place on the machine it is admittedly rather difficult to get a feeler gauge back past the first row of rollers to measure the second **but it must be done**.

3. If one row of rollers is tight but the other has measurable clearance, tap lightly on the end of the shaft nearest the tight row of rollers to cause the shaft to shift axially and equalize the roller loading. Adjust the bearing tightness to achieve the internal clearance previously calculated.
4. When the proper internal clearance has been attained, lock the nut by bending over the matching tang on the lock washer, making sure that all unused tangs are bent as near the nut as possible so that they will not rub against the bearing roller cage.



NOTE: Check each unused tab individually to insure this.

Figure 38. Tightening the Bearing Lock nut (42" machine shown)



Figure 39. Measuring the Mounted Internal Clearance of the Bearing (42" machine shown)



5. With the grease gun, fill the space between the bearing and the front of the housing 1/3 full of grease.
6. Install the bearing cover plate or shaft seal holder, as appropriate. When installing the shaft seal holder, take care not to damage the seal as it is gently pushed over the shaft. Cover the keyway on the end of the shaft with tape to prevent the sharp corners of the keyway from cutting the seal lip. Also, make sure that the seal lip does not turn over as it passes over rough areas.

BNWG4M01 / 2020126

BNWG4M01 0000279245 A.2 3/20/20, 10:26 AM Released

2.4 Idler Shaft Bearing Replacement

BNWG4M01.C01 0000279244 E.2 A.2 3/20/20, 10:26 AM Released

The bearings used on the idler shaft are double-row spherical roller self-aligning bearings, SKF, Link-Belt, Torrington, or equal. Bearings are attached to the shaft with locknuts and tapered adapters. The idlershaft is designed with one bearing “fixed” and the other bearing “floating”. Lubrication is provided by grease passages that are tubed to two grease fittings located on the lower right cross brace. Grease is retained in the bearing housings by close-fitting covers.

2.5 How to Remove the Bearings

BNWG4M01.T01 0000279243 E.2 A.2 3/20/20, 10:26 AM Released

1. Remove the idler shaft pulleys on both ends of the shaft.
 - a. Remove the bearing caps.
 - b. Loosen the set screws which lock the bearings for the brake assembly to the idler shaft (total of four (4) setscrews).
2. Remove the soil side bearing.
 - a. Screw a 1/4"-18NPT pipe fitting into the hole in the soil side end of the idlers haft.
 - b. Loosen the bearing locknut.
 - c. Using a hand operated hydraulic pump, force fluid into the hydraulic removal passage.

Pump hard to build up fluid pressure. This pressure will be transferred to the bearing inner race causing the race to expand slightly, just enough to free the tapered surface and allow the bearing to slip off easily.
3. Remove the clean side bearing.
 - a. Loosen the bearing locknut on the bearing adapter, backing the nut about 1/8" from the bearing. DO NOT take the locknut off of the adapter.
 - b. Slip a piece of pipe (approx. 15" long) over the shaft.
 - c. Place one end of the pipe against the locknut and adapter.
 - d. Strike the other end of the pipe with a 5 lb. hammer, gently at first, then harder until the adapter snaps loose.

Hitting a block placed over the end of the pipe helps to inflict an even impact on the bearing adapter; this should prove helpful in bearing removal.
 - e. After the bearing has been snapped loose, remove the pipe, bearing locknut, and washer; now the bearing will come out of the housing with a little assistance.

Be sure not to remove the bearing locknut from the adapter when trying to snap the bearing loose; otherwise, the bearing and bearing adapter may come apart violently. Also, there is a chance of damaging the adapter which may be used again if it is not damaged during disassembly.

When it is known that only the soil side bearing is bad, it may be changed by the above mentioned hydraulic method without damaging the clean side bearing.

If only the clean side bearing must be changed, however, the soiled-side bearing should be removed first (hydraulically) before the clean side bearing is mechanically removed. If it is not removed first, minute indentations, invisible in most cases, will be formed on the inner and outer races of the soil side bearing rendering it unserviceable.

When both bearings must be changed the order of bearing removal is not critical.

2.6 How To Install New Bearings

BNWG4M01.T02 0000279242 E.2 A.2 3/20/20, 10:26 AM Released



NOTICE: The most important ingredient in successful bearing and seal installation is **cleanliness**. The bearing housing must be free of all **foreign** matter. The grease and leak-off passages must be blown clear and all **foreign** matter removed. You must have a clean work area. Keep your hands and tools free from grit and grime. (Wash your hands before actually inserting the bearing in the housing.) **Foreign** matter is, without doubt, the most frequent cause of bearing failure, and one over which the manufacturer has no control.

Before installing bearings, use a feeler gauge to measure the internal clearance in the bearing. Read the section “Measuring Unmounted Clearance and Setting Bearing (Front or Rear)” before installing the bearings in the housing, found in “Main Bearing and Seal Replacement for Divided Cylinder Machines”. (This section describes adjustment of the main bearings which also applies to the idler shaft bearing.)

1. The “fixed” bearing is always installed first.
 - a. Install the bearing housings in the take-up units with three mounting bolts. Don’t put the bearing covers on the housings; however, make sure the mounting bolts are tight.
 - b. Pass the idler shaft through the housings.
 - c. Slip the bearing adapters on the shaft with the threaded end of the adapter near the end of the shaft.
 - d. Next, pass the bearing over the shaft and onto the tapered adapters.
 - e. Hand tighten the locknut on the adapter, and adjust the location of the end of the idler shaft assembly drawing.
2. With both bearings on the shaft and in the housing, measure the distance from the center of the main shaft to the center of the idler shaft on both ends of the machine. If the center distances are different, loosen the take-up units and adjust the position of the shaft.

It is important that the idler shaft be parallel to the main shaft before setting the bearings, so that the plane of rotation of the rollers is approximately in the same plane with the bearing races; further, if the shaft is cocked, the floating bearing will not be located accurately from the face of the bearing housing as shown on the assembly drawing.

3. Tighten the bearing locknuts to the proper internal clearance using the procedure explained in section entitled “How To Adjust The Bearing”.
4. Loosen the three bearing housing mounting bolts, and put the covers on the bearings as shown on the idler shaft assembly. Check to make sure bearing housing mounting bolts are tight.
5. Lubricate the bearing before operation. Follow the instructions for bearing lubrication as outlined in section “Tightening Bearing(s) (Front and/or Rear)” found in “Main Bearing and Seal Replacement for Divided Cylinder Machines”.

This page intentionally blank

Shaft and Bearing Components

Figure 40. Shaft and Bearing Components





Figure 41. Front Bearing (Models: 6044WP2, 6044WP3, 6044WR2, 6044WR3)



Shaft and Bearing Components

4 Sheets

Figure 42. Front Bearing (Models: 6044SP2, 6044SP3, 6044SR2, 6044SR3)





Figure 43. Rear Bearing (Models: 6044WP2, 6044WP3, 6044WR2, 6044WR3 & 6044SP2, 6044SP3, 6044SR2, 6044SR3)



Shaft and Bearing Components

4 Sheets

Table 25. Parts List—Shaft and Bearing Components

Find the assembly for your machine and the letter shown in the "Item" column. The components for your machine will show this letter or the word "all" in the "Used In" column. The numbers shown in the "Item" column are those shown in the illustrations.				
Used In	Item	Part Number	Description/Nomenclature	Comments
Reference Assemblies				
	A	AD 29 032	Installation Group, Bearing housing	60044WP2/WP3, 6044WR2/WR3
	B	AD 29 032V	Installation Group, Bearing housing, Viton	60044WP2/WP3(Viton), 6044WR2/WR3(Viton)
	C	G28 15700	Installation Group, Bearing housing	6044SP2/SP3, 6044SR2/SR3
Components				
all	1	X2 175008	Shaft support, Front	
all	2	X2 175009	Shaft support, Rear	
AB	3	X3 06005	Bearing housing, Front	
C	3	X2 175005	Bearing housing, Front	
all	4	X2 175007	Bearing housing, Rear	
all	5	02 18618A	Cover	
AB	6	X2 18190	Seal holder	
C	6	X2 175053	Seal holder	
all	7	X3 06006	Seal sleeve	
all	8	02 18219	Washer, lock	
all	9	02 18928	Grease shield	
all	10	56S22316T	Bearing	
all	11	56AHN16	Bearing Locknut	
all	12	56AHW16	Washer	
AC	13	24S114	Seal, 4.5X5.5X.50	
B	13	24S114V	Seal, 4.5X5.5X.50, Viton	
A	15	60C161	O-ring, 6"X1/4	
B	15	60C161V	O-ring, 6"X1/4, Viton	
C	16	60C172	O-ring, 8"X1/4	
B	16	60C172V	O-ring, 8"X1/4, Viton	
AC	17	60C154	O-ring, 3+7/8X3/16	
B	17	60C154V	O-ring, 3+7/8X3/16, Viton	
all	18	24S111	Seal, 3X4.00X.437	
all	19	60C160J	O-ring, 6+1/4X1/8	
all	20	5SCC0CBE	Coupling, 1/8	
all	21	54M029	Pipe Fitting, 1/8	
all	22	5N0C03AG42	Pipe nipple, 1/8X3	
all	23	5SCC0EBE	Coupling, 1/4	

Shaft and Bearing Components

4 Sheets

Table 25 Parts List—Shaft and Bearing Components (cont'd.)

Find the assembly for your machine and the letter shown in the "Item" column. The components for your machine will show this letter or the word "all" in the "Used In" column. The numbers shown in the "Item" column are those shown in the illustrations.				
Used In	Item	Part Number	Description/Nomenclature	Comments
all	24	5N0E02KG42	Pipe nipple, 1/4X2.5	
all	25	5SB0E0CBEO	Hexbrush, 1/4X1/8	
all	26	5N0CCLSB42	Pipe nipple, 1/8XCLS	
all	27	5SL0CBEA	Elbow, 1/8	
all	28	15B243	Bolt, 1-8X2+1/2	
all	29	15U400	Washer, Lock 1"	
all	30	15K145	Bolt, 1/2-13X3/4	
all	31	15U300	Washer, Lock, 1/2	
all	32	15B236	Bolt, 1-8X3	
all	33	15K236	Bolt, 1-8X2.75	
all	34	15K162	Bolt, 1/2-13X1.5	
all	34	15K147C	Bolt, 1/2-13X1	
all	35	02 18870	Gasket	
all	36	02 18768D	Gasket	
all	37	02 18105	Gasket	
all	38	54M015	Pipe fitting, Lubricant	
all	39	5SP0CFESSV	Plug, 1/8	
all	40	53A039B	Elbow, 5/16X1/8	
all	41	53A508	Flexible tubing, Adapter, 5/16"	
all	42	53A509	Flexible tubing, Adapter, 5/16" X .53"	
all	43	53A019B	Pipe Fitting, 5/16X1/8	
all	44	5N0E01KBE2	Pipe nipple, 1/4X1.5	
all	45	51P008B	Plug, 1/4"	
all	46	53A060A	Nut, 5/16"	


BPWG6B01 / 2020163

BPWG6B01.1 0000288408 E.2 A.5 4/21/21, 3:27 PM Released

AutoSpot™

2 Sheets

6044SP2, 6044SP3, 6044SR2, 6044SR3



Legend

- A . . . Clean pocket 1
- B . . . Speed sensor
- C . . . Clean side
- D . . . Soil pocket 2
- E . . . Clean pocket 2
- F . . . Soil pocket 1
- G . . . Rear main bearing, see BPWVUB01
- H . . . Rear main pulley (see Drive Chart)
- J . . . Typical 12 places
- K . . . Target
- L . . . Typical 5 places

Table 26. Parts List—AutoSpot™

Find the assembly for your machine and the letter shown in the "Item" column. The components for your machine will show this letter or the word "all" in the "Used In" column. The numbers shown in the "Item" column are those shown in the illustrations.

Used In	Item	Part Number	Description/Nomenclature	Comments
Reference Assemblies				
	A	G28 15700	BEARASY MAIN(L+C)W/AUTO 60SG	
Components				
all	1	02 19197	60" S/G AUTOSPOT TIMING PLT	
all	2	02 19179	SWITCH MNT PLATE INNER	

AutoSpot™

2 Sheets

6044SP2, 6044SP3, 6044SR2, 6044SR3

Table 26 Parts List—AutoSpot™ (cont'd.)

Find the assembly for your machine and the letter shown in the "Item" column. The components for your machine will show this letter or the word "all" in the "Used In" column. The numbers shown in the "Item" column are those shown in the illustrations.				
Used In	Item	Part Number	Description/Nomenclature	Comments
all	3	02 19179A	SWITCH MNT PLATE OUTER	
all	4	09RPS07RDS	7MM SENSING RECTANGULAR SHLD	
all	5	X2 175054	SEAL HOLDER=AUTOSPOT SGL MTR	
all	6	X2 19190	COLLAR=60" S/G AUTOSPOT	
all	7	02 19186C	TARGET=60" S/G AUTOSPOT	
all	8	15K018	SKCPSCR 10-24 UNC 3X3/8 BLK	


4 inch Idler Shaft Bearing Installation

2 Sheets

6044SR2, 6044SR3



NOTE: For instructions on removing and installing idler bearings, see BNWG4M01.



4" Idler Shaft Bearing Installation

2 Sheets

6044SR2, 6044SR3

Table 27. Parts List—4" Idler Shaft Bearing Installation

Find the assembly for your machine and the letter shown in the "Item" column. The components for your machine will show this letter or the word "all" in the "Used In" column. The numbers shown in the "Item" column are those shown in the illustrations.				
Used In	Item	Part Number	Description/Nomenclature	Comments
Reference Assemblies				
	A	ABI28002	95041# BEARASSY=IDLERSHAFT NOBRAKE	
Components				
all	1	02 19023	94353A DRIVE BASE ADJ. SCREW 13.5LG	
all	2	15G250	HXNUT 1-8UNC2B SAE ZNC GR2	
all	3	15U400	LOCKWASHER MEDIUM 1" ZINCPL	
all	4	15K225	05Z HEXCAPSCR 5/8-11X2+1/2	
all	5	15G238	HXNUT 5/8-11UNC2B SAE ZINC GR2	
all	6	15U315	LOKWASHER MEDIUM 5/8 ZINCPL	
all	7	15U180	LOCKWASHER MEDIUM 1/4 ZINCPL	
all	8	15K030	HEXCAPSCR 1/4-20UNC2X1/2 GR5 ZINC	
all	9	15P010	12Z PHILPAN TRDCUTSCR TYP10-24X1/2S	
all	10	15U314	FLATWASHER(USS STD) 5/8" ZNC PLT	
all	11	15U450	FLATWASH.1345X3.25X1+11/16 ZINCPLTD	
all	12	15G268	HXFINJAMNUT 1+1/2-12UNF2B ZINC GR2	
all	13	15K235A	03Z HXCPCSC 3/4-10X2.5 GR 8	
all	14	15U340	LOCKWASH MEDIUM 3/4 ZINCPL	
all	15	15U320	FLATWASHER(USS STD) 3/4" UNPLT	
all	16	56S22220T	SPHEROLBRGNTN#22220BL1KD/C3	
all	17	56AHS20	SNW20 BRG ADAPT 3.5" CYL BORE	
all	18	56S22220S	SPHEROLBRG NTN#22220BL1D1C3	
all	19	W2 18747E	92257C*TAKE-UP WLMT=4"IDLER SHAFTCS	
all	20	03 06444A	79337C CAP=BEARING IDLERSHAFT C.S.	
all	21	X2 18763A	92236D IDLER SHAFT 4"DIA 6036SGU	
all	22	X3 06154A	92236# IDLER SHAFT 4"DIA 60+72SGU	
all	23	X2 18697A	79277C BEARHOUSE IDLER SHAFT FLOAT	
all	24	X2 18696A	94283C BEARHOUSE IDLER SHAFT LOCKED	
all	25	X2 18744C	92137# MACH=TAKEUP=4"IDLER 60SG SS	
all	26	03 06444	79507C CAP=BEARING 4"IDLERSHAFT	
all	27	03 06445	94251B WEDGE=SHEAVE+SHAFT=60+72SGU	
all	28	53A005B	BODYMALCON1/4X1/8COMP #B68A-4A	
all	29	53A059A	NUT 1/4"BR.HOLYOKE AND #61A-4	
all	30	53A501	TUBE INSERT .170"OD	
all	31	53A500	1/4" SLEEVE-DELRIN	

4" Idler Shaft Bearing Installation

2 Sheets

6044SR2, 6044SR3

Table 27 Parts List—4" Idler Shaft Bearing Installation (cont'd.)

Find the assembly for your machine and the letter shown in the "Item" column. The components for your machine will show this letter or the word "all" in the "Used In" column. The numbers shown in the "Item" column are those shown in the illustrations.				
Used In	Item	Part Number	Description/Nomenclature	Comments
all	32	54M020	GREASEFIT 30DEG 1611-B ALEMITE	
all	34	53A007B	BODYFEMCON.25X.25COMP#B66A-4B	
all	35	53A031B	BODY-EL90MALE.25X1/8 #269C-42B	



BPWG6I08 / 2021314A

BPWG6I08.1 0000289364 E.2 B.2 7/28/21, 12:00 PM Released

Lower Disc Brake Installation

5 Sheets

6044SR2, 6044SR3, 7244SR2






Legend
 B . . . See BPWVUP01
 C . . . 4 instances
 D . . . See BPWG6B02

Lower Disc Brake Installation

5 Sheets


6044SR2, 6044SR3, 7244SR2



Legend

A . . . See detail A


E . . . Adapter includes bearing locknut & washer



Lower Disc Brake Installation

5 Sheets

6044SR2, 6044SR3, 7244SR2



Lower Disc Brake Installation

6044SR2, 6044SR3, 7244SR2

Table 28. Parts List—Lower Disc Brake Installation

Find the assembly for your machine and the letter shown in the "Item" column. The components for your machine will show this letter or the word "all" in the "Used In" column. The numbers shown in the "Item" column are those shown in the illustrations.				
Used In	Item	Part Number	Description/Nomenclature	Comments
Reference Assemblies				
	A	GBR28001	INST=DISC BRAKE=60SG	6044SR2/SR3
	B	GBR36001	INST=DISC BRAKE=72SG	7244SR2
Components				
all	1	ABR28002A	ASSY=DISC BRAKE SPLIT BRNG	
all	2	ABR28003	DISC ASSY +BALANCE=60+725G	
all	3	54KC7961	CALIPER HYD FIXMT 12/20 ROTOR	
all	4	03 65203	DISC BRAKE PAD DAMPENER 1/8T	
all	5	15C098	HXSOKSTRPBLT 3/4X5+1/2X5/8-11	
all	6	01 09294	RETAIN RING-FLANGE(STEEL)+\$4S	
all	7	56AHS22	SNW22 BRG ADAPTER 4" CYL BORE	
all	8	15E260	KEY-DISC BRAKE	
all	9	W2 19569	*WELD TORQUE ARM 60+72SG	
A	10	02 19570	BRKT=TORQUE ARM MOUNT	
B	10	03 06531	BRACKET=TORQUE ARM MT 72SG	
all	11	X4 22046C	7/8" DIA. SPACER=COBUCK	
all	12	15C095	HXSOKSTRPBLT 3/4X1+3/4X5/8-11	
all	13	15G238N	HXLOCKNUT NYL 5/8-11UNC STL/	
all	14	54AA00PBB	BUSH BALL 3/4 RBC-B12L	
A	15	02 19573	CHANNEL=TORQUE ARM MT	
B	15	03 06530	CHANNEL=TORQUE ARM MT 72SG	
all	16	17B132	INDUSTRIAL RETAIN.RING 4000-12	
all	17	02 19572A	RT BRKT=DISCBRAKE HOLDER FRNT	
all	18	02 19572	LT BRKT=DISCBRAKE HOLDER FRNT	
all	19	15K054	HXCAPSCR 5/16-18X3/4 GR5 XYLAN	
all	20	15U185	FLATWASHER(USS STD) 1/4" ZNC P	
all	21	15U210	LOKWASHER MEDIUM 5/16 ZINCPL	
all	22	54KC7961B0	O-RING 08-11070 BRAKE 2-660	
all	23	54KC7961H2	BRAKEHOSE #W2511 1/8X32" OAL	
all	24	52LY0CR001	HEXPIP NIP 1/8"XCLOSE#5404-2-2	
all	25	52JY0CR001	ELBOW 1/8"FEM.#5504-02-02	
all	26	5N0C03AS82	NPT NIP 1/8X3 TBE 304SS SK80	
all	27	52AY0ER003	STR.1/4"MJICX1/8"MP#2404-4-2	
all	28	54KMC1125U	MASTER CYL TILTON 74-1125U	

Lower Disc Brake Installation

5 Sheets

6044SR2, 6044SR3, 7244SR2

Table 28 Parts List—Lower Disc Brake Installation (cont'd.)

Find the assembly for your machine and the letter shown in the "Item" column. The components for your machine will show this letter or the word "all" in the "Used In" column. The numbers shown in the "Item" column are those shown in the illustrations.				
Used In	Item	Part Number	Description/Nomenclature	Comments
all	29	W3 65238	*WLMT=MASTER BRAKE CYL BRKT	
all	30	AAC65002	2006292 AIRCYL BRAKE SINGLE MOTOR	
all	31	02 19576	SPLASH SHIELD=DISC BRAKE	
all	32	15K154A	HEXCAPSCR 1/2-13X1.5 G8 ZN	
all	33	15G230	HXNUT 1/2-13UNC2B SAE ZINC GR2	
all	34	15U280	FL+WASHER(USS STD)1/2 ZNC PL+D	
all	35	15U300	LOKWASHER REGULAR 1/2 ZINC PLT	
all	36	15K223A	HEXCAPSCR 5/8-11X2 GR8 ZIN	
all	37	15U315	LOKWASHER MEDIUM 5/8 ZINCPL	
all	38	54KC7961BG	BRAKE HOSE=1/8"X18"OAL # 50612	
all	39	54KC7961BH	BRAKE HOSE #W2261 1/8X18"OAL	
all	40	54KC7961BP	BRAKEFLUID/PISTON KIT #98-1198	Caliper repair part
all	41	54KC7961B0	O-RING 08-11070 BRAKE 2-660	Caliper repair part
all	42	54KC7961BS	BLEEDERSCREW#10-07721 #2-660	Caliper repair part
all	43	54KC7961RK	BRAKE PADS W/SENSOR #98-13982	Caliper repair part
all	44	54KC7961CT	CROSSOVERTUBEKIT HAY#B98-11700	Caliper repair part

Lower Disc Brake Split Bearing Parts and Assembly

5 Sheets

6044SR2, 72044SR2/SR3

Figure 44. Bearing Components




Table 29. Parts List—Lower Disc Brake Split Bearing Parts and Assembly

Find the assembly for your machine and the letter shown in the "Item" column. The components for your machine will show this letter or the word "all" in the "Used In" column. The numbers shown in the "Item" column are those shown in the illustrations.

Used In	Item	Part Number	Description/Nomenclature	Comments
	A	ABR28002A	ASSY=DISK BRAKE SPLIT BRNG	
Components				
all	1	X2 19577	SPLIT BUSHNG=DISK BRAKE BRNG	
all	2	X2 19578	FRONT FLANGE=DISK BRAKE BRNG	
all	3	X2 19579	REAR FLANGE=DISK BRAKE BRNG	
all	4	02 10426B	WASH=SEAL RETAIN+LOCK+SPLIT	
all	5	15K142	HXCAPSCR 3/8-16X6 GR8ZC	
all	6	15G205	HXNUT 3/8-16UNC2B ZINC GR2	
all	7	24S126	SEAL 4X5X.5 JM#R-0400-10175RUP	
all	8	54M029	RELIEFFIT 1/8STR ALEMITE 47200	
all	9	53A031B	BODY-EL90MALE.25X1/8 #269C-42B	
all	10	15G218	HXLOKNUT NYL 3/8-16 STL/ZNC	
all	11	X2 19580	SPACER=DISC BRAKE BRNG	

BPWG6B02 / 2020174

BPWG6B02.1 0000288467 E.2 A.9 4/22/20, 4:56 PM Released

Assembly Procedure


5 Sheets

6044SR2, 72044SR2/SR3


Use "Antiseize" lubricant on all threads.

Refer to the illustrations next to each step. Item numbers shown refer to the parts list.

1. Slide the front and rear flanges (Items 2 & 3) onto the shaft. Bore chamfers (large arrows) must face inward. Assemble spacers (Item 11) and ensure bolts are loose. (Only for new installation and complete replacement.)



2. Apply a thin bead of high temperature RTV silicone to the bronze bushing (Item 1) seams. Large arrows show surfaces on which to apply silicon.




Assembly Procedure


5 Sheets

6044SR2, 72044SR2/SR3


3. Put the two halves of the bronze bushing around the shaft. Ensure alignment by matching alignment marks (large arrow).



4. Push the front and rear flanges (Item 2 & 3) onto the bronze bushing (Item 1). Use only a hard rubber mallet. Ensure spacers are loose.
5. Rotate the bushing so the seams are approximately 90 degrees to the flange openings.



6. Insert the seals (Item 7) in two locations (large arrows). Use only hard rubber or plastic mallet.




Assembly Procedure


5 Sheets

6044SR2, 72044SR2/SR3

7. Install the seal retainers (Item 4) so they overlap the seams. Ensure the six bolts (Items 5 & 6) are loose.



8. Refer to the illustration below. Tighten the spacers (Item 11) until they no longer rotate. Constantly check assembly rotation around the shaft. Use only hand wrenches.




Assembly Procedure

5 Sheets


6044SR2, 72044SR2/SR3

9. Refer to the illustration above. Ensure that the edges of the retainers (Item 4) meet but do not overlap. Tighten the bolts (Item 5) in an alternate pattern. Constantly check assembly rotation. Use only hand wrenches. If binding occurs, loosen the bolts and repeat.

10. With all bolts tightened rotate the assembly. Bend the star tabs (large arrow) on the retainers. The assembly should continue to rotate freely.



11. Assemble fittings (Item 8) and tubing for grease supply line. Refer to document BPWG6I08 for the lower disk brake shown in this illustration.



3 Frame & Suspension

BNWVUM01 / 2020106

BNWVUM01 0000277899 B.2 2/5/21, 9:25 AM Released

3.1 Suspension Adjustments for Divided Cylinder Machines

BNWVUM01.C01 0000277938 E.2 B.2 2/5/21, 9:25 AM Released

The suspension system on Milnor® Hydro-cushion™ machines is adjusted and thoroughly tested at the factory. It should not require subsequent adjustment unless the machine is distorted during shipment or installation or unless some component of the system, such as a Hydro-cushion™ cylinder is replaced.

There are two primary objectives when adjusting the suspension system on any Hydro-cushion™ machine model:

1. To position the shell in the proper location within the frame (hanging dimensions) to maximize freedom of movement of the shell and to insure proper draining, and
2. To adjust the length of up and down travel at each of the push-down locations (push down travel) so that the shell will not be distorted (racked) when pushed down.

All Milnor® Hydro-cushion™ machines contain the following suspension system components:

1. Hydro-cushion™ cylinder—which suspend the shell and cylinder within the frame and provide vibration damping during extraction.
2. Pneumatic push down devices (air bags)—which when inflated, force the shell downward where it is held against rigid pads during loading, unloading, washing, and draining.
3. Metal or rubber pads—some rigidly fixed to the shell and some rigidly fixed to the frame, which come in contact when the shell is pushed down.

The actual configuration of these components varies from model to model.

3.1.1 How Shell Adjustments are Made

BNWVUM01.T01 0000278202 E.2 B.2 A.2 3/3/20, 4:33 PM Released

Regardless of machine model, repositioning of the shell is always accomplished by adjusting the nuts at the top of the upper Hydro-cushion™ shafts. To move the shell up or down at the location of any Hydro-cushion™, see [Figure 45: Hydro-cushion™ Upper Shaft and Adjusting Nuts, page 114](#) and proceed as follows:




CAUTION: These procedures should be accomplished with power to the machine locked off.

1. Straighten the tongues on the keyed lock washer using pliers, screw driver, etc.
2. Loosen the lock nut (upper hex nut) and move it all the way up to the top of the shaft, but do not remove it.

3. Use the adjusting nut (lower hex nut) to “crank” the shaft up or down as required.
4. Once final adjustment is made, while holding the adjusting nut to prevent it from turning, re-tighten the lock nut against the adjusting nut (with the lock washer between).
5. Rebend the tongues on the lockwasher as before, to prevent movement of the nuts.

Figure 45. Hydro-cushion™ Upper Shaft and Adjusting Nuts



3.1.2 Shell Hanging Dimensions and Adjustment Procedures

BNWVUM01.T02 0000278201 E.2 B.2 2/5/21, 9:25 AM Released

To adjust the shell of a divided cylinder machine, proceed as follows:

1. Locate the shell hanging dimension for your machine in [Table 30: Hanging Dimensions, page 115](#) and adjust your machine accordingly. Take measurements on the left and right sides of the shell, to assure that the shell is horizontal, left to right.
2. The shell and cylinder should be level front to back. Check this with a bubble level, as shown in [Figure 46: Shell Hanging for Divided Cylinder Machines \(Left side view of 60044WE shown\), page 115](#).
3. If further adjustment is required in order to level the cylinder, make small adjustments at all four corners. For example, if the cylinder slopes down to the front, try raising the two front corners by 1/16" (2mm) and lowering the two rear corners by 1/16" (2mm). Always split the difference.



NOTE: Only slight deviations from the dimensions shown should be used to level the shell. If large deviations are required, this may indicate that the frame is out of level. If so, this condition must be corrected before attempting to level the shell.

Figure 46. Shell Hanging for Divided Cylinder Machines (Left side view of 60044WE shown)




Table 30. Hanging Dimensions

Machine Model	Dimension A
42031WE	4 1/8" (105)
42031SG	4 1/8" (105)
44044WE	4 1/8" (105)
42044SG	4 1/8" (105)
60031WE	3 5/8" (92)
60031SG	3 5/8" (92)
60044WE	3 5/8" (92)
60044SG	3 5/8" (92)
72044SG	3 3/4" (95)
72044WE	3 3/4" (95)

3.1.3 Push-Down Travel Dimensions and Adjustment Procedures

BNWVUM01.C02 0000278454 E.2 B.2 A.2 3/5/20, 1:08 PM Released



CAUTION: Some of the following procedures require power to the machine. Take the necessary precautions to assure that no one operates the machine controls while personnel are adjusting the push-down components.

3.1.3.1 42" Divided Cylinder Machines

BNWVUM01.T03 0000278453 E.2 B.2 A.3 3/6/20, 9:06 AM Released


The push-down stops on these machines consist of brackets attached to the shell and rubber rest pads, mounted atop the base pads (see [Figure 47: Push-down Travel Adjustment: 42" Div-cyls \(42" Staph Guard®\), page 117](#)) which make contact when the shell pushes down. The rubber rest pads sit in metal pans and are raised or lowered by adding metal shims to or removing the shims from inside the pans. Extra shims and adhesive for securing the shims were supplied with your machine.

There is no specific push-down travel dimension for these machines; however, length of travel must be adjusted as follows:

1. With the **Master switch** set to **off**, and the shell hanging free, measure the gap between each bracket and base pad.
2. Add or remove shims from the appropriate pads as required to make all four gaps equal and to insure that no rest pad protrudes completely from its metal pan.

Test for equal length of travel at all four locations as follows:

3. With four sheet metal shims of **equal** thickness, set one shim **on top of** each rubber rest pad, such that at least a one inch length of the shim overhangs the outside edge of the pad.
4. Set the **Master switch** to **manual**, causing the shell to push-down.

Figure 47. Push-down Travel Adjustment: 42" Div-cyls (42" Staph Guard®)

5. With the shell pushed down, attempt to pull each test shim out from between the bracket and rubber pad. The test shims should all be tight. If any shim(s) are not pinched tightly between the bracket and pad, take note of which one(s) are not.

Make final adjustments as follows:

6. Set the **Master switch** to **off**, remove the test shims and make the necessary changes to the shims below the rubber pads as indicated by the above test.
7. Repeat Steps 3 through 6 as required, until this test is successful.
8. Once the adjustments are completed, secure all shims and rubber rest pads with the adhesive provided.

3.1.3.2 60" Divided Cylinder Machines


BNWVUM01.T04 0000278485 E.2 B.2 5/15/20, 10:18 AM Released

These machines have push-down stops on the four corners of the frame which appear as shown in [Figure 48: Ring Weldments, page 118](#) . When pushed down, the ring weldments (which move with the shell) must seat firmly onto the plugs which are mounted atop the base pads. The push-down travel dimension must assure that 1) the ring weldments and plugs are far enough apart when the shell is not pushed down, so as not to interfere with the free movement of the shell, and 2) that all four stops are in solid contact when the shell is pushed down. To accomplish this, proceed as follows:

1. With the **Master switch** set to **off** and the shell hanging free, remove the bolts securing the ring weldments to the mounting brackets. Set each ring weldment on top of its respective plug, removing any shims which may have been used and placing them next to the ring weldment.

2. Measure the gap between the top of the ring weldment and the bottom of the mounting bracket, at each location.

Figure 48. Ring Weldments



3. Stack shims on top of the ring weldment as required to make each gap **exactly 2 inches** as shown in the left side of [Figure 48: Ring Weldments, page 118](#) . If the gap at any location is less than 2 inches without shims, the shell must then be raised in the frame, using the procedures previously described.
4. Once the proper arrangement of shims is made, remount the ring weldment and shims to the mounting bracket (see the right side of [Figure 48: Ring Weldments, page 118](#)). Any extra shims may be stacked on the top side of the mounting bracket plate to which the ring weldment is attached.


This page intentionally blank

Hold Down Adjustment

6044SR2/SR3, 6044WR2/WR3, 72044SR2/SR3, 72044WR2/WR3



NOTE: For instruction: push down travel dimensions and adjustment procedures, see BNWVUM01



Hold Down Adjustment

2 Sheets

6044SR2/SR3, 6044WR2/WR3, 72044SR2/SR3, 72044WR2/WR3

Table 31. Parts List—Hold Down Adjustment

Find the assembly for your machine and the letter shown in the "Item" column. The components for your machine will show this letter or the word "all" in the "Used In" column. The numbers shown in the "Item" column are those shown in the illustrations.				
Used In	Item	Part Number	Description/Nomenclature	Comments
none				
Components				
all	2	03 06216A	SHIM=HOLDOWN 1/4"THICK	
all	3	03 06216B	SHIM=HOLDOWN 10GA THICK	
all	4	03 06216C	SHIM=HOLDOWN 16GA THICK	
all	5	W3 06406	*RING=HOLD DOWN CENT-STAMPED	
all	6	15G238	HXNUT 5/8-11UNC2B SAE ZINC GR2	
all	7	15U315	LOKWASHER MEDIUM 5/8 ZINCPL	
all	8	15D125	HXTAPSCR 5/8-11X4-FLTHRD GR5	
all	9	15K300	HXCAPSCR 1-8UNC2A X4.5 SAE GR5	


BPWG6J02 / 2020174

BPWG6J02.1 0000289722 E.2 A.3 4/22/20, 4:43 PM Released

Push Down

2 Sheets

6044SP2, 6044SP3, 6044SR2, 6044SR3



Push Down

2 Sheets

6044SP2, 6044SP3, 6044SR2, 6044SR3


Table 32. Parts List—Push Down

Find the assembly for your machine and the letter shown in the "Item" column. The components for your machine will show this letter or the word "all" in the "Used In" column. The numbers shown in the "Item" column are those shown in the illustrations.				
Used In	Item	Part Number	Description/Nomenclature	Comments
Reference Assemblies				
	A	G29 05200	XBRACE ASSY-LOWER RT 6044 SG	
	B	G29 05100M	XBRACE ASSY-LOW LF 6044SP213	
Components				
all	1	W2 175087	*WLDMNT BRACKET-PUSH DOWN=TOP	
all	2	02 19149	XBRACE,LO-RT 6044W BEND@PRNT	
all	3	02 19148M	BRACE=LOW LF CROSS 6044SP2/3	
all	4	02 19246B	XBRACE-STIFFENER 6044WP2/WP3	
all	5	60B120	AIRMT S-20 2CONV F#W013586910	
all	6	69C050A	POLYETHYLENE BAG 9X6X13X.005	
all	7	5N0E02KG42	NPT NIP 1/4X2.5 TBEGALSTL SK40	
all	8	27A005	MUFFLER 3/8" BANTAM B38	
all	9	96M055	DELTROL QUICK EXHAUST VLV.1/4"	
all	10	51V015	TEE 1/4 FGDBRASS 101T7-444	
all	11	53A040B	BODY=EL90MALE5/16X.25#B69A-5B	
all	12	53A020B	BODYMALECON5/16X.25COM#B68A-5B	
all	13	53A509	TUBE INSERT 5/16"OD X .53"LG.	
all	14	53A508	SLEEVE DELRIN 5/16"OD#60PT-5	
all	15	53A060A	NUT BRASS 5/16 COMP#61A-5	
all	16	60E006	TUBING BLK.POLY.5/160DX3/16ID	
all	18	15G238	HXNUT 5/8-11UNC2B SAE ZINC GR2	
all	19	15U315	LOKWASHER MEDIUM 5/8 ZINCPL	
all	20	15K214E	HXCAPSCR 5/8-11UNC2AX1.5 GR5 Z	
all	21	15U314	FLATWASHER(USS STD) 5/8" ZNC P	
all	22	15U240	FLATWASHER(USS STD) 3/8" ZNC P	
all	23	15U255	LOCKWASHER MEDIUM 3/8 ZINCPL	
all	24	15K095	HXCPCSCR 3/8-16UNC2AX1 GR5 ZINC	
all	25	02 19149A	PLT REINFPSHDWN=60SP2+3	

Suspension Cylinder Assemblies

3 Sheets

42031,42044,52038,60044,72044



Suspension Cylinder Assemblies

3 Sheets

42031,42044,52038,60044,72044

Table 33. Parts List—Suspension Cylinder Assemblies

Find the assembly for your machine and the letter shown in the "Item" column. The components for your machine will show this letter or the word "all" in the "Used In" column. The numbers shown in the "Item" column are those shown in the illustrations.				
Used In	Item	Part Number	Description/Nomenclature	Comments
Reference Assemblies				
	B	SA 16 039	*HYDROCUSHION CYL ASSY-"B"	CYLINDER ASSY B
	C	SA 16 038	*HYDROCUSHION CYL ASSY-"C"	CYLINDER ASSY C
	D	SA 28 091	*HYDROCUSHION CYL ASSY-"D"	CYLINDER ASSY D
	F	SA 36 021	*HYDROCUSHION CYL ASSY-"F"	CYLINDER ASSY F
	G	SA 36 023	*HYDROCUSHION CYL ASSY-"G"	CYLINDER ASSY G
	H	SA 36 047	*HYDROCUSHION CYL ASSY-"H"	CYLINDER ASSY H
	K	SA 29 031K	*HYDROCUSHION CYL ASSY-"K"	CYLINDER ASSY K
(To identify which cylinder is supplied with your machine, see BPWVUJ02 which should be located in the manual next to this document. Once you know which cylinder assembly you have, "B-K" listed above, identify your parts by referencing the "Used In" coding.)				
Components				
ABCDK	1	02 18244	BOLT=HYDCYL 27+7/8LG+KEYWAY	
K	1	02 18244A	BOLT=HYDCYL 28+7/8LG+KEYWAY	
FGH	1	03 06201	BOLT=HYDCYL 41+7/8LG+KEYWAY	
all	2	02 18840A	UPCAP=HYDROCYL 42+52+60	
all	4	5SP0KGFSS	NPT PLUG 1/2 SOSOLID GALSTL	
BC	5	X2 15356	PISTON=HYDROCYL 6"- 6 NOTCH	
DFGHK	5	X2 18228	PISTON=HYDROCYL 6"- 3 NOTCH	
all	6	5SP0GHFKM	NPT PLUG 3/8"-HEXCSMAGNETIC ZN	
FG	7A	03 06139	SPRING=IN HYDRO CYL 331LB/IN	FULL SPRING (PURPLE)
G	7B	03 06139A	SPRING=IN HYDRO CYL	PLUS 1/2 SPRING "G" ONLY (PURPLE)
H	7C	03 06338	SPRING INNER-GOLD 14"LONG	GOLD
B	8	02 16068	MAIN SPRING 212LB/IN RED	RED
C	8	02 16125	MAIN SPRING 300LB/IN BLACK	BLACK
D	8	02 19039	MAIN SPRING 480LB/IN GREEN	GREEN
FG	8	03 06138	SPRING=OUT HYDROCYL 667LB/IN	ORANGE
G	8	03 06138A	SPRING=OUT HYDRO CYL	ORANGE
H	8	03 06337	SPRING-OUTER-GOLD 14.5"LONG	GOLD
K	8	03 09016	MAIN SPRING 1035LB/IN BLUE	BLUE
ABCDFG-K	9	02 18619	BUSHING RETAINER + CAD	
H	9	03 06358	BUSHING RETAINER.CAD	
all	10	15B237	HXCAPSCR 1-8UNC2AX5.5 SAEGR5 Z	

Suspension Cylinder Assemblies

3 Sheets

42031,42044,52038,60044,72044


Table 33 Parts List—Suspension Cylinder Assemblies (cont'd.)

Find the assembly for your machine and the letter shown in the "Item" column. The components for your machine will show this letter or the word "all" in the "Used In" column. The numbers shown in the "Item" column are those shown in the illustrations.				
Used In	Item	Part Number	Description/Nomenclature	Comments
all	11	15G255A	SQNUT 1-8UNC2B SAE ZINC GR2	
all	12	15U400	LOCKWASHER MEDIUM 1" ZINCPL	
all	13	60C159A	ORING 5.475ID 1/4CS BN70 #433	
all	14	24S040	SEAL URETHNE 1-7/16 2.25 13/32	
GH	15	M2 18690	LOWER CAP=HYDROCYL	
all	16	02 18839A	MACHBUSH HYDRCYL CAP #433-OR	
BC	17	SA 15 084	*HYDCUSH CYL WLDMT (18"X12")	
DI	17	SA 28 090	*HYDCUSH CYL WLDMT (18"/23")	
FGH	17	W3 06203	*HYDCUSH CYL WLDMT (35"/12")	
K	17	W2 18233	*HYDCUSH CYL WLDMT (20"X22")	
all	18	02 175034	SHIELD-BALLBUSH-4/HYDRO MACH	
BDFGH	19	02 02230	6 WATER BARRIER (NEOPRENE)	
all	30	15G268	HXFINJAMNUT 1+1/2-12UNF2B ZINC	
all	31	02 18571A	PISTON ROD WASHER-.25"TK	
all	32	X3 06252	RETAINER-BALBUSH=4/72WEDU	
all	33	54M025	HYDFIT 1/8"-90 ALEMITE 1613-B	
all	34	27B240	SPCRROLL.5ID.813L.062T STLZNC	
all	35	02 18534	HOLDPLATE= BALLBUSH ZNC/CAD	
all	36	15G230	HXNUT 1/2-13UNC2B SAE ZINC GR2	
F	37	Y3 06200	SPACER=HYDRO-CUSHION CYL-MACH	
all	38	15K203	HXTAPSCR TFL 1/2-13X5 GR5 ZINC	
all	39	54A705	BALBRUSH 1.5 SKF#GEZ108ESAVE467	
all	40	15N037	HXCAPSCR 1/2-13UNC2AX6.5 GR5 Z	
all	41	02 18256	LOKWASH-TONGUE 8/WEH ZINC	
all	42	15K202	HEXCAPSCR 1/2-13UNC2AX5 GR5 ZIN	
all	43	15U300	LOKWASHER REGULAR 1/2 ZINC PLT	
all	44	15G231	HXFINJAMNUT 1/2-13UNC2B ZINC G	
all	45	02 18534	HOLDPLATE= BALLBRUSH ZNC/CAD	
all	46A	02 18795A	WASH-TIMING=HYDRO CYL 45DEG	USE ONE
all	46B	02 18795B	WASH-TIMING=HYDRO CYL 75DEG	USE ONE
all	47	15K191	HXCAPSCR 1/2-13UNC2AX2.5 GR5 Z	
FGH	48	AVH52001	ASSY=OILFIL SPOUT 72HYD CYL	

This page intentionally blank

Suspension Cylinder Locations

2 Sheets



Legend

- C1** . . Cylinder #1
- C2** . . Cylinder #2
- C3** . . Cylinder #3
- C4** . . Cylinder #4
- E** . . Front or soil side
- J** . . A letter is stamped on the end of the upper bolt to designate the cylinder assembly.

Suspension Cylinder Locations

2 Sheets



NOTE: See BPWVUJ01. For repair parts: hydrocushion cylinder assembly “B” through hydrocushion cylinder assembly “K”

Machine Models:									
Position	42031 CP2, NP2, WP2, WP3	42031 SP2, SP3	42044 CP2, NP2, WP2, WP3, D7P	42044 SP2/3; SR2/3	42044 WP2 SM, WP3 SM, WR2, WR3	52038 WTL, WTN, WP1	60044 WP2/3 SM, SP2/3 SM, WR2/3, SR2/3	72044 WP2, WP3, DA1	72044 SP2, SP3, SR2/SR3
Cylinder #1	B	B	C	C	C	D	K	H	G
Cylinder #2	B	C	B	C	C	D	K	H	G
Cylinder #3	B	C	B	C	C	D	K	F	G
Cylinder #4	B	C	C	C	C	D	K	F	G


4 Shell, Cylinder & Doors

This page intentionally blank

Shell Doors

60044SR2, 60044SR3, 6044WR3

Figure 49. Exploded Views



Adjust the Pressure Plate

- 1 . . . With the inner tubes deflated, tighten the tension nut (item 32), until two threads extend beyond the nut.
- 2 . . . Check the spring with air pressure applied to the inner tubes. Verify that the spring is not over compressed. If the spring height is only 3/4", it will be necessary to loosen the tension nut.



NOTE: If the spring is compressed too much, the air bags will not be able to inflate and properly seal the door.

Legend


- A** . . . Detail view A-A
- B** . . . 24 instances
- C** . . . Liner
- D** . . . Door gasket
- E** . . . Tabs. Fold gasket tabs over the edge of the door and anchor with holding strips (item 35) and screws on the final assembly.
- F** . . . Fill plate
- G** . . . Apply glue (4) to both surfaces.
- H** . . . Pressure plate

Shell Doors

4 Sheets

60044SR2, 60044SR3, 6044WR3

Figure 50. Detail View



Legend

A-A . . . Detail view A-A
E . . . Tabs. Fold gasket tabs over the edge of the door and anchor with holding strips (item 35) and screws on the final assembly.

Table 34. Parts List—Shell Doors

Find the assembly for your machine and the letter shown in the "Item" column. The components for your machine will show this letter or the word "all" in the "Used In" column. The numbers shown in the "Item" column are those shown in the illustrations.				
Used In	Item	Part Number	Description/Nomenclature	Comments
Reference Assemblies				
	A	SA 28 118	*SHELL DOOR ASY 60SG2 SOIL	6044SR2 SOIL SIDE
	B	SA 28 117	*SHELL DOOR ASY 60SG2 CLEAN	6044SR2 CLEAN SIDE
	C	SA 28 043	SHELLDOOR ASSY 60"SG3SOIL	6044SR3 SOIL SIDE
	D	SA 28 044	SHELL DOOR ASY 60SG3 CLEAN	6044SR3 CLEAN SIDE
	E	SA 28 017	SHELLDOOR ASSY 60"WE3	6044WR3
	F	SA 28 172	LINER ASSY SHELLDOOR 60SGD SS	A
	G	SA 28 171	LINER ASSY SHELLDOOR 60SGD CS	B
	H	SA 28 159	LINER ASSY=SHELLDOOR=WEH+SGH	CE
	J	SA 28 160	LINER ASSY=SHELLDOOR=SGH-CS	D
Components				
A	1	W2 18846	* SHELDOR WELD 60SG2 SOILSIDE	SR2
B	1	W2 18847	* SHELDOR WELD 60SG2 CLEANSID	SR2
C	1	W2 18316	SHELDOR WELD 60SG3 SOILSIDE	SR3
D	1	W2 18319	SHELDOR WELD 60SG3 CLEANSID	SR3
E	1	W2 18143	SHELLDOOR WELDMT 60WE3 ONLY	WR3
F	2	W2 18861C	PRESSPLT WELD SHELDR 60SGD SS	
G	2	W2 18861E	PRESSPLT WELD SHELDR 60SGD CS	

Shell Doors

60044SR2, 60044SR3, 6044WR3

Table 34 Parts List—Shell Doors (cont'd.)

Find the assembly for your machine and the letter shown in the "Item" column. The components for your machine will show this letter or the word "all" in the "Used In" column. The numbers shown in the "Item" column are those shown in the illustrations.				
Used In	Item	Part Number	Description/Nomenclature	Comments
H	2	W2 18152A	PRESPLT WELD=SHLDR60SG3SS+WE	
J	2	W2 18152B	PRESSPLT WELD=SHLDR60SG3 CS	
all	3	60A006P	PORON STRIP .25X1 1/4# W EA=FT	
all	4	20C044	RUB/GASKET ADH 3M#EC1300 PINTS	
FG	5	02 18860A	FILLER=PLATE SHELLDOOR SGD	
HJ	5	X2 18367	PLATE=DOOR FILLER	
FG	6	02 175180	GASKET=SHELLDOOR 2/60SGD	
HJ	6	02 175169	GASKET=SHELLDOOR 1/WE3	
F	7	02 18862A	LINER=SHELL DOOR RT 60SGD	
G	7	02 18862B	LINER=SHELL DOOR LT 60SGD	
HJ	7	02 18150	LINER=DOOR BACK	
all	8	15K039A	BUTSOKCPSCR 1/4-20X7/8 SS 18-8	
all	9	15G164	HX THIN LOCKNUT NYL1/4-20 SS	
all	10	02 175149	STRIP=RUBBER DOOR GASKET-SG	
all	11	15N174	HXCAPSCR 1/4-20UNC X5/8SS18-8	
all	12	15U181	LOCKWASHER MEDIUM 1/4 SS18-8	
all	13	12P016	CABLE CLMP-BLACK UL APPROVED	
ACE	14	02 18982G	DOOR TUBE-60WEHU-PRES TUB	SOIL SIDE AND WP3
BD	14	02 18981G	DOOR TUBE-60SGH-PRES TUBE	CLEAN SIDE
all	15	02 18181	FITTING-BRASS FOR INNER TUBE	
all	16	60E005	TUBING BLK.POLY.5/160DX3/16ID	
all	17	53A040B	BODY=EL90MALE5/16X.25#B69A-5B	
all	18	53A060A	NUT BRASS 5/16 COMP#61A-5	
all	19	53A060	SLEEVE 5/16 COMP IMP#60-F	
all	20	53A509	TUBE INSERT 5/16"OD X .53"LG.	
all	21	60E004TE	1/4"OD X.170"ID NYL(BLK)TUBING	
all	22	53A059A	NUT 1/4"BR.HOLYOKE AND #61A-4	
all	23	53A500	SLEEVE DELRIN 1/4"OD#60PT-4	
all	24	53A501	TUBE INSERT .163"OD #63PT-4-40	
all	25	53A031B	BODY-EL90MALE.25X1/8 #269C-42B	
all	26	SA 15 028	* DOOR LATCH ASSY-DIVCYLS	
all	27	02 15633S	ADJPLATE=DOORLATCH SS	
all	28	15U255	LOCKWASHER MEDIUM 3/8 ZINCPL	
all	29	15K085	HEXCAPSCR 3/8-16UNC2AX3/4 GR5	

Shell Doors

4 Sheets

60044SR2, 60044SR3, 6044WR3

Table 34 Parts List—Shell Doors (cont'd.)

Find the assembly for your machine and the letter shown in the "Item" column. The components for your machine will show this letter or the word "all" in the "Used In" column. The numbers shown in the "Item" column are those shown in the illustrations.				
Used In	Item	Part Number	Description/Nomenclature	Comments
all	30	02 18187	SPRING=OUTER DOOR 60 WEHU	
all	31	15U280	FL+WASHER(USS STD)1/2 ZNC PL+D	
all	32	15G234	LOKNUT 1/2-13NC CAD FLXLOC#21F	
all	33	01 10020	NPLT SMALL "MILNOR" LOGO	
all	34	15P010	TRDCUT PHILPANHDSCR 10-24X1/2S	
all	35	02 175231	PLATE=SHELL DOOR GASKET	
all	36	03 06145	HINGE PIN 60 SG2,SG3,WE2&WE3	
all	37	03 06136	WASHER,BRG BACKUP 72SG	
all	38	54A974975	TIM #L68111/L68149-1.3775"BORE	
all	39	X3 06146	BEARING ADAPTER 60&72 SG DR.	
all	40	54M021	GRSFIT 1/8PIPE X 1/4STR 1607-B	
E	40	54M015	GREASEFIT 60X36/60X44 1610BL	
all	41	54JH15500A	HINGE COL SPLIT 5.50 FL TOP	
all	42	15K045E	SKCPSCR 1/4-20X2 BLK	
all	43	15Q091	SOKSETSCR CUP1/4-20X5/8BLK	
AB	44	03 06132	BUSHING,HINGE PIN 60&72 SG	2 POCKET SR2
CDE	44	03 06148	BUSHING,HINGE PIN 60 SG3PWE3	3 POCKET WR3, SR3
all	45	15U314	FLATWASHER(USS STD) 5/8" ZNC P	
all	46	15U521	SPRINGWSHR.630ID 1.250D.051T	
all	47	15K214E	HXCAPSCR 5/8-11UNC2AX1.5 GR5 Z	
E	47	51P034	SCREWSOCSET 5/8-11X5/8 PLASTIC	

Door Latch




Table 35. Parts List—Door Latch


Find the assembly for your machine and the letter shown in the "Item" column. The components for your machine will show this letter or the word "all" in the "Used In" column. The numbers shown in the "Item" column are those shown in the illustrations.				
Used In	Item	Part Number	Description/Nomenclature	Comments
Reference Assemblies				
	A	SA 15 028	Assembly, Door latch	
Components				
all	1	02 15105	RETAINER RING	
all	2	02 15297	STRIKER	
all	3	02 15298	CYLINDER	
all	4	02 15836	SPRING	
all	5	15H090	PIN	
all	6	60C122	O-RING, 1"X1/8	
all	7	60C128	O-RING, 1+3/8X1/8	

Cylinder Assembly and Cylinder Door Installation

5 Sheets

6044SR2, 7244SR2

Figure 51. Cylinder Assembly and Cylinder Door Installation




Cylinder Assembly and Cylinder Door Installation

5 Sheets

6044SR2, 7244SR2

Figure 52. Cylinder Doors Installed




Cylinder Assembly and Cylinder Door Installation

5 Sheets

6044SR2, 7244SR2

Figure 53. Detail Views



Cylinder Assembly and Cylinder Door Installation

5 Sheets

6044SR2, 7244SR2




Table 36. Parts List—Cylinder Assembly and Cylinder Door Installation

Find the assembly for your machine and the letter shown in the "Item" column. The components for your machine will show this letter or the word "all" in the "Used In" column. The numbers shown in the "Item" column are those shown in the illustrations.				
Used In	Item	Part Number	Description/Nomenclature	Comments
	A	REFERENCE		6044SR2
	B	REFERENCE		7244SR2
Components				
A	1	ACA19SG2A	* CYL ASSY=6044SG2 WELD/SHAFT	
B	1	ACA36SG2A	* CYL ASSY=7244SG2 WELD/SHAFT	
A	3	SA 28 110	CYLDOOR LOLT 60WE2+ MIN-REIF	
B	3	SA 36 003	CYLDOOR LOLT 72WE2+ MAX-REIF	
A	4	SA 28 111	CYLDOOR UPLT 60WE2+ MIN-REIF	
B	4	SA 36 004	CYLDOOR UPLT 72WE2+ MAX-REIF	
A	5	SA 28 112	CYLDOOR LORT 60WE2+ MIN-REIF	
B	5	SA 36 001	CYLDOOR LORT 72WE2+ MAX-REIF	
all	6	SA 28 116	CYLDOR ASY,SMALL =60+72SG2	
A	7	X3 06166	KEEPER=CYL DOOR LATCH(MONEL)	
B	7	X2 15201	KEEPER=CYLDOOR LATCH(MONEL)	
all	8	02 19183	COVER-DOORLATCH KEEP-OURMATL	
all	9	03 06174	KEEPER=DOORLATCH REINFORCE	
all	10	02 18977A	SHIM=CYL DRLATCH KEEPER-11GA	
all	10	02 18977B	SHIM=CYL DRLATCH KEEPER-14GA	
all	10	02 18977C	SHIM=CYL DRLATCH KEEPER-18GA	
all	11	X3 06166	KEEPER=CYL DOOR LATCH(MONEL)	
all	12	03 06167	COVER-LARGE CYLDOOR KEEPER	
all	13	15A015	CARRSCR 3/8-16X1+1/4 18-8 SS	
all	14	15G206	HEXNUT 3/8-16 UNC2 SS 18-8	

Cylinder Assembly and Cylinder Door Installation

5 Sheets

6044SR2, 7244SR2


Table 36 Parts List—Cylinder Assembly and Cylinder Door Installation (cont'd.)

Find the assembly for your machine and the letter shown in the "Item" column. The components for your machine will show this letter or the word "all" in the "Used In" column. The numbers shown in the "Item" column are those shown in the illustrations.				
Used In	Item	Part Number	Description/Nomenclature	Comments
all	15	15U260	LOCKWASHER MEDIUM 3/8 SS18-8	
all	16	15K086	HXCAPSCR 3/8-16NCX3/4 SS18-8	
all	17	15K106E	BUTSOKCAPSCR 3/8-16NCX1+1/2 SS	
all	18	03 06156	SPRING=LARGE CYLDOOR LATCH	
all	19	X3 06152	PLATE = LARGE DOORLATCH	
all	20	03 06151	LATCHBODY-LARGE=CYLDOOR	
all	21	X3 06150	PLUNGER=LARGE CYLDOOR(CAST)	
all	22	03 06172	SHIM=DOOR LATCH-18GA	
all	23	03 06173A	SHIM=DOOR LATCH-11GA	
all	24	02 18869	SPACER-LATCH PULL BND@PRNT	
all	25	15K042	BUTSOKCAPSCR 1/4-20NCX1 SS18-8	
all	26	15U181	LOCKWASHER MEDIUM 1/4 SS18-8	
all	27	15G170	HEXNUT 1/4-20UNC2 SS18-8	
all	28	15K042K	BUTSOKCAPSCR 1/4-20UNCX1+1/4 S	
all	29	02 15040	PLUNGER=CYLDOOR LATCH(CAST)	
all	30	02 15041	BODY=CYLDOOR LATCH	
all	31	02 15077	PLATE = SMALL DOORLATCH	
all	32	02 15093	SPRING=DOOR LATCH 9.4#/INCH	
all	33	15N173	FLATMACSCR 1/4-20NCX5/8SS18-8	
all	34	15N158	HEXCAPSCR 1/4-20NCX1/2SS18-8	
all	35	02 18990	PLATE=STOP + COVER 2/60+72WD	
all	36	02 18864	PIN=LG CYL DOOR HINGE	LARGE PIN
all	37	W2 18855	WLMT=HINGE LRG CYL DR MULT	USED WITH ITEMS 3 & 5
all	37	W2 18866	WLMT=HINGE LRG CYL DR 2/60WE	USED WITH ITEM 4
all	38	02 18865	PIN=SM CYL DOOR HINGE	SMALL PIN
all	39	02 18858	HALFHINGE=60"WED CYLDOR SMAL	
all	40	02 18989	PLATE-LATCH MTG2/WED+2/SGD	

Cylinder Door Installation

2 Sheets

6044WP3/SP3, 6044WR3, 6044SR3



Cylinder Door Installation

2 Sheets

6044WP3/SP3, 6044WR3, 6044SR3


Table 37. Parts List—Cylinder Door Installation

Find the assembly for your machine and the letter shown in the "Item" column. The components for your machine will show this letter or the word "all" in the "Used In" column. The numbers shown in the "Item" column are those shown in the illustrations.				
Used In	Item	Part Number	Description/Nomenclature	Comments
Reference Assemblies				
	A	ACA19SG3A	80496D* CYL ASSY=6044SG3 WELD/SHAFT	6044SP3/SR3
	B	ACA19WE3A	* CYL ASSY=6044WE3 WELD/SHAFT	6044WP3/WR3
Components				
all	1	15G206	HEXNUT 3/8-16 UNC2 SS 18-8	
all	2	15A010	67346A CARRSCR 3/8-16 UNC2X1 SPECIAL	
all	3	X2 15201	89207A KEEPER=CYLDOOR LATCH	
all	4	X2 18677	92413C CYLEND 1/60WE3;60SG3	
all	5	15U260	LOCKWASHER MEDIUM 3/8 SS18-8	
all	6	02 19290	81201B FILLER=CYLINDER DIVIDER=60"	
all	7	SA 28 073	77422C* CYLDOOR ASSY, UP-LOAD 60WE3+	
all	8	SA 28 074	82157C* CYLDOOR ASSY, LO-LOAD 60WE3+	
all	9	SA 28 075	77422C* CYLDOOR ASSY,UP-CLEAN 60SG3	
all	10	SA 28 076	82157C* CYLDOOR ASSY, LO-CLEAN 60SG3	

Cylinder Door Assembly

3 Sheets


6044WP3/SP3, 6044WR3, 6044SR3



Cylinder Door Assembly

3 Sheets

6044WP3/SP3, 6044WR3, 6044SR3



Cylinder Door Assembly

3 Sheets

6044WP3/SP3, 6044WR3, 6044SR3

Table 38. Parts List—Cylinder Door Assembly

Find the assembly for your machine and the letter shown in the "Item" column. The components for your machine will show this letter or the word "all" in the "Used In" column. The numbers shown in the "Item" column are those shown in the illustrations.				
Used In	Item	Part Number	Description/Nomenclature	Comments
Reference Assemblies				
	A	SA 28 073	CYLDOOR ASSY,UP-LOAD 60WE3+	UP LOAD 60WP3
	B	SA 28 074	CYLDOOR ASSY,LO-LOAD 60WE3+	LOW LOAD 60WP3
	C	SA 28 075	* CYLDOOR ASSY,UP-CLEAN 60SG3	UP CLEAN 60SGS
	D	SA 28 076	* CYLDOOR ASSY,LO-CLEAN 60SG3	LOW CLEAN 60SG3
Components				
all	1	02 15040	PLUNGER=CYLDOOR LATCH(CAST)	
all	2	02 15041	BODY=CYLDOOR LATCH	
all	3	02 15077	PLATE = SMALL DOORLATCH	
all	4	02 15093	SPRING=DOOR LATCH 9.4#/INCH	
all	5	02 15255	LOCKWASHER CYLDOOR LATCH	
A,C	6	X2 18209	* HINGE=UP CYLDOR L=17+21/32"	
B,D	6	X2 18208	* HINGE=6OW CYLDOOR L=18+3/8"	
A,C	7	02 18405	DOORLOCK BOLT 6/60WEH+12/SG	
A	8	W2 18604	* CYLDOOR WLMT UP-LOAD 60WE3+	
B	8	W2 18605	CYLDOOR WLMTLOLOAD 60WE3,6HLAT	
C	8	W2 18606	* CYLDOOR WLMT UP-CLEAN 60SG3	
D	8	W2 18607	*CYLDRWLMT LO-CLN60SG3,6H-LAT	
A,C	9	02 18560	NUT=DOORLOCK SILBRO 6/60WEHU	
B,D	9	15G201	HXLKKNUT 3/8-16 NYL/SS TYPE NE	
A,C	10	15H031	STDCOTTERPIN 3/32X3/4 SS18-8	
all	11	15N186	HXCAPSCR 1/4-20X3/4 SS18-8	
all	12	15U245	FLTWASH 3/8 STD COMM 18-8 SS	
A,C	13	17B062	EXTRETRING S/S INDUST#3100-75-	
all	14	15J016	BUTTON HD RIVET 3/8 X 1+1/4" S	
all	15	03 06172	SHIM=DOOR LATCH-18GA	
all	16	03 06173A	SHIM=DOOR LATCH-11GA	
B,D	18	15K106B	BUTSOKCAPSCR 3/8-16NCX1+3/8 SS	
B	19	02 18407	DOORLATCH LOADSIDE	
D	19	02 18440	DOORLATCH CLEANSIDE	
B,D	20	02 18408	SPACER=CYLDOR SWINGLATCH	

5 Staph Guard®


BPWG6P01 / 2020192

BPWG6P01.1 0000290411 E.2 A.4 5/4/20, 11:33 AM Released

Staph Barrier Cleanside

2 Sheets

6044SR2, 72044SR2



Staph Barrier Cleanside

2 Sheets

6044SR2, 72044SR2

Table 39. Parts List—Staph Barrier Cleanside


Find the assembly for your machine and the letter shown in the "Item" column. The components for your machine will show this letter or the word "all" in the "Used In" column. The numbers shown in the "Item" column are those shown in the illustrations.				
Used In	Item	Part Number	Description/Nomenclature	Comments
Reference Assemblies				
	A	GBF60001	STAPH BARRIER CS 60SG	6044SR2
	B	GBF72001	STAPH BARRIER CS 72SG	6044SR2
Components				
all	1	02 18781T	EXTRUSION SHELL CS LF 72SG	
all	2	02 18781V	EXTRUSION SHELL CS RT 72SG	
all	3	02 18781W	EXTRUSION FRAME CS LF 72SG	
all	4	02 18781X	EXTRUSION FRAME CS RT 72SG	
all	5	03 06105	BOOT ASSEMBLY=72SGH OUR MATL	
all	6	02 175032	CLAMP BOOT 60142 +60SG	
all	7	15P175	TRDCUT-F HXHD 1/4-20UNC2AX1/2	
B	8	02 21677	CLAMP=BOOT SHLFRT SEAM 3630S	

Staphairtrol

3 Sheets

60044SR2, 72044SR2

Figure 54. Exploded View




Staphairtrol

3 Sheets

60044SR2, 72044SR2

Figure 55. Installed View



Legend

- A** . . . Exhaust, soil side
- B** . . . Intake, clean side

Table 40. Parts List—Staphairtrol

Find the assembly for your machine and the letter shown in the "Item" column. The components for your machine will show this letter or the word "all" in the "Used In" column. The numbers shown in the "Item" column are those shown in the illustrations.

Used In	Item	Part Number	Description/Nomenclature	Comments
Reference Assemblies				
	A	SA 28 126	* STAPHAIRTROL 6" #60+72SGU	
Components				
all	1	W2 18975	* WLMT,AIRTROL BODY =60+72SGU	
all	2	W2 18973	* WLMT,AIRTROL EXHAUST =60+72	
all	3	W2 18974	* WLMT,AIRTROL INTAKE=60+72SG	
all	4	02 15714	AIR TROL FLAPPER	
all	5	02 18930	PLATE-AIRTROL FLAPPER	
all	6	02 175025	PLATE-BACKUP=AIRTROL FLAPPER	
all	7	15P010	TRDCUT PHILPANHDSCR 10-24X1/2S	
all	8	15G071	MACHSCRLOKNUT 6-32 NM SER ZINC	
all	9	15U131L	FLATWASH #10L (US STD) BRASS	
all	10	15N050	RDMACSCR 6-32UNC2X1/2 SS18-8	

Staphairtrol

60044SR2, 72044SR2


Table 40 Parts List—Staphairtrol (cont'd.)

Find the assembly for your machine and the letter shown in the "Item" column. The components for your machine will show this letter or the word "all" in the "Used In" column. The numbers shown in the "Item" column are those shown in the illustrations.				
Used In	Item	Part Number	Description/Nomenclature	Comments
all	11	15N141	RDMACSCR 10-24NCX3/4 SLOTTED S	
all	12	15G130	HEXMACHSCRNUT 10-24UNC2 SS18-8	
all	13	60E320A18A	HOSE *6"ID FLEXAUST PE X 18"	
all	14	27A083	HOSECLAMP 5+1/8-7"CADSCR#HS104	
all	15	60E320A30A	HOSE *6"ID FLEXAUST PE X 30"	
all	16	03 06199A	BRT=AIRTROL+VENT MT. BD@PRT.	
all	17	W2 18496	* WLMT,AIRTROL INSCREEN=60+72	
all	18	15K039	HXCAPSCR 1/4-20UNC2AX3/4 GR5 Z	
all	19	15U185	FLATWASHER(USS STD) 1/4" ZNC P	
all	20	15G165	HXNUT 1/4-20UNC2BSAE ZC GR2	
all	21	15K153	HXCAPSCR 1/2 -13 X 1 +1/4 SS	
all	22	15U310	LOKWASHER REGULAR 1/2 SS18-8	
all	23	15G225	HEXNUT 1/2-13UNC2 SS18-8	

6 Control & Sensing

Excursion Switch

6044SR2, 6044SR3, 7244SR2



Legend

A . . . Jackshaft

Table 41. Parts List—Excursion Switch

Find the assembly for your machine and the letter shown in the "Item" column. The components for your machine will show this letter or the word "all" in the "Used In" column. The numbers shown in the "Item" column are those shown in the illustrations.

Used In	Item	Part Number	Description/Nomenclature	Comments
Reference Assemblies				
	A	E03 33100B	EXCURSION SWITCH ASSY 60SGH	6044SR2, SR3
	B	E15 04000	* EXCURSION SWITCH ASSY=SGU	7244SR2
Components				
A	1	09R008A	MICSW SPDT BZE6-2RN183	
B	1	09R008ASTD	* 09R008A+MOUNTING HDWRE+INST	
all	2	02 10391	COVER STRIP=MICRO SW #6-8	
all	3	02 15783A	*PLATE=EXCURSION SW MTG	
all	4	02 15980B	BRACKET=EXCURSION SW MT 72T	


BPWVUZ01 / 2020043

BPWVUZ01.1 0000267913 E.2 A.3 1/21/20, 10:27 AM Released

Air Chamber Level Switch

1 Sheet

42044WR2,WR3,SR2,SR3; 6044WR2,WR3,SR2, SR3; 72044WR2, WR3, SR2, SR3



Legend

- A . . . To transducer
- B . . . Transducer

Table 42. Parts List—Air Chamber Level Switch

Find the assembly for your machine and the letter shown in the "Item" column. The components for your machine will show this letter or the word "all" in the "Used In" column. The numbers shown in the "Item" column are those shown in the illustrations.

Used In	Item	Part Number	Description/Nomenclature	Comments
Reference Assemblies				
	A	AD 15 090A	AIRCHAMBER PRESWITCH INSTALL	
Components				
all	1	5SB0E0CBEO	NPTHEXBUSH 1/4X1/8 BRASS 125#	
all	2	53A047H	MALCON 5/16X1/8POLY PH#68P-5-2	
all	3	5SR1A0ENF	NPT RED 1X1/4 GALMAL 150#	
all	4	5N1A07AG42	NPT NIP 1X7 TBE GALSTL SK40	
all	5	5S0KNFA1A	NPT TEE 1/2X1/2X1" GALMAL 150#	
all	6	5N0KCLSG42	NPT NIP 1/2XCLS TBE GALSTLSK40	
all	7	5SL0PNFC0K	NPT 90D STREET 3/4X1/2 GAL150#	
all	8	96DB0PNA	HOSEBIBB 3/4" MALEINLT 45DEG. ACETAL	
all	9	60E005	TUBING BLK.POLY.5/160DX3/16ID	
all	10	51V010A	TEE 1/8"BRSEXTR BLOCTYP#2203P2	
all	11	51E502A	HOSESTEM BRASS 1/8MPT X3/16	

Air Chamber Level Switch

1 Sheet

42044WR2,WR3,SR2,SR3; 6044WR2,WR3,SR2, SR3; 72044WR2, WR3, SR2, SR3

Table 42 Parts List—Air Chamber Level Switch (cont'd.)

Find the assembly for your machine and the letter shown in the "Item" column. The components for your machine will show this letter or the word "all" in the "Used In" column. The numbers shown in the "Item" column are those shown in the illustrations.				
Used In	Item	Part Number	Description/Nomenclature	Comments
all	12	5SP0CBEHS	NPT PLUG 1/8 HXCTRSNK BRASS	
all	13	60E004NA	TUBING CLEAR PVC 3/16"IDX5/16"OD	
all	14	08BNLTT	LEVEL TRANSDUCER BD->TEST	

BPWVUZ03 / 2020195

BPWVUZ03.1 0000290654 E.2 A.3 5/7/20, 9:15 AM Released

Temperature Probe

1 Sheet

6044WR2,WR3,SR2 72044WR2,WR3,SR3




Table 43. Parts List—Temperature Probe

Find the assembly for your machine and the letter shown in the "Item" column. The components for your machine will show this letter or the word "all" in the "Used In" column. The numbers shown in the "Item" column are those shown in the illustrations.				
Used In	Item	Part Number	Description/Nomenclature	Comments
Components				
all	1	30R0043PB	TEMPERATURE PROBE ASSY=BRASS	

6.1 Vibration Safety Switch Adjustments

BNWUUM01.C01 0000250243 E.2 C.2 A.3 1/2/20, 2:19 PM Released

6.1.1 What the Vibration Safety Switch Does

BNWUUM01.C02 0000250242 E.2 C.2 A.3 1/2/20, 2:19 PM Released

The **vibration safety switch** in [Figure 56: Vibration Switch, page 159](#) is an important safety feature. If properly adjusted, the switch will momentarily actuate as a result of repeated machine movement caused by an out-of-balance condition. [Table 44, page 158](#) below illustrates the effect of the **vibration safety switch** actuation.

Table 44. Effect of Tripping Vibration Safety Switch

Machine Model	Function of Vibration Safety Switch
30015, 30020, and 30022	Disables high speed extract
All microprocessor-controlled washer-extractors not listed above, and all dye machines	De-energizes three-wire relay, effectively terminating machine operation

6.1.2 Adjustments

BNWUUM01.C03 0000250240 E.2 C.2 B.2 11/7/19, 10:43 AM Released


When the machine leaves Milnor®, the actuator arm is tie-wrapped to prevent damage (except on 30015, 30020, and 30022 models). **This tie wrap must be removed after the machine is set into position but before the machine is operated.**

Adjustment of this switch from the factory setting is not recommended; however, it should be checked for proper functioning and adjusted if its proper setting is lost.

As shown in [Figure 56: Vibration Switch, page 159](#), the unit consists of a **sensitive micro-switch** with an extended actuating arm supporting an eccentric weight. The weight may be adjusted by moving it up and down on the arm and by rotating it on the arm. In addition, the **micro-switch** itself may be tilted from side to side.

The sensitivity of the switch increases as the eccentric weight is raised on the actuating arm and decreases as the weight is lowered.

The unit should be adjusted so that the actuating arm will always reset by itself, this being accomplished by rotating either the switch or the weight to give just enough bias to cause the switch to reset. Check the adjustment by moving the arm to the left then slowly releasing it. Make sure the micro-switch clicks when the arm is **slowly** released, thus indicating that it has reset. In the released position, the arm should rest **lightly** but definitely against the stop on the **micro-switch** case that prevents any further arm movement to the left.

Figure 56. Vibration Switch

For machines with rigid mounted shells, where the machine is bolted to a very substantial foundation, very little machine movement will occur for a given degree of out-of-balance. Under such conditions it may be better to adjust the switch to be very sensitive. With less substantial foundations (e.g., ones where the sub-soil is mushy or springy or otherwise not as desirable), considerably greater machine movement will occur for a given degree of out-of-balance, in which case a less sensitive **vibration switch** setting may be indicated.

Vibration Safety Switch




Table 45. Parts List—Vibration Safety Switch

Find the assembly for your machine and the letter shown in the "Item" column. The components for your machine will show this letter or the word "all" in the "Used In" column. The numbers shown in the "Item" column are those shown in the illustrations.				
Used In	Item	Part Number	Description/Nomenclature	Comments
Reference Assemblies				
	A	SAE03 151	* ASSY-VIBRATION SWT=LG CONTR	
Components				
all	1	02 02038	PLATE INSULATING SMALL 9NOV51	
all	2	15P008	TRDCUT PANHD 6-32X1 NIKSTL +WA	
all	3	02 15119	BRACKET=VIBSW CAD	
all	4	09R020	SWITCH NC VIBR#WZ-2RW84429-P52	
all	5	03 01059	VIBSWITCH CLAMP CADSTL	
all	6	03 01058	VIBSWITCH WEIGHT-CADSTL	
all	7	15P101	TRDCUT-F PANHD 8-32X3/8 NIKSTL	

7 Chemical Supply Devices


BPWG6C01 / 2020203

BPWG6C01.1 0000291819 E.2 A.3 5/12/20, 3:35 PM Released

Peristaltic Supply Inlet

1 Sheet

6044SP2, 6044SP3, 6044SR2, 6044SR3



Peristaltic Supply Inlet

1 Sheet

6044SP2, 6044SP3, 6044SR2, 6044SR3


Table 46. Parts List—Peristaltic Supply Inlet

Find the assembly for your machine and the letter shown in the "Item" column. The components for your machine will show this letter or the word "all" in the "Used In" column. The numbers shown in the "Item" column are those shown in the illustrations.				
Used In	Item	Part Number	Description/Nomenclature	Comments
Reference Assemblies				
	A	GWL28005	INST=PARASTALTIC CONNECT 60	
Components				
all	1	03 25267E	PERISTALTIC MOUNTING BRACKET	
all	2	96TDC2AA37	1/2" N/C 2WAY 120V50/60C VALVE	
all	3	W8 01254	*ASSY=PERIST CONNECT 20 HOLES	
all	4	5SL2AP8K	NPT EL45DEG 2"PVC SH80 FPTXFPT	
all	5	27A070	T-BOLT HOSECLAMP 1.94"-2.25"	
all	6	60E255A70A	HOSE=2"ID X 70"LG(NO DWG)	
all	7	51AB2AN2AA	HOSE INSERT X MPT 2"PVC40	
all	8	02 18538	SUPPORT=SUPPLY INJ LH/RH	
all	9	02 19327B	COVER=6044 W/PERISTAL RTSIDE	

Five Compartments for Dry Chemical Supplies

4 Sheets


Figure 57. Five Compartments for Dry Chemical Supplies



Legend

A-A . . Bottom view (hose)

Figure 58. Right Side View (Covers), Bottom View (Hose)




Legend

A-A . . Bottom view (hose)

Five Compartments for Dry Chemical Supplies

4 Sheets

Figure 59. Valve Manifold



Five Compartments for Dry Chemical Supplies

4 Sheets

Figure 60. Hot Water Inlet, Pressure Regulator Assembly




Table 47. Parts List—Five Compartments for Dry Chemical Supplies

Find the assembly for your machine and the letter shown in the "Item" column. The components for your machine will show this letter or the word "all" in the "Used In" column. The numbers shown in the "Item" column are those shown in the illustrations.

Used In	Item	Part Number	Description/Nomenclature	Comments
Reference Assemblies				
	A	SA 28 085B	*ASSY,5FLUSH SUPINJ=6044WP+SP	
	B	A28 18600B	* PIPING+VALVE=SUP INJ ASSY	
	C	SA 28 084	*INLET ASSY=SUPPINJ	
	D	AD 28 059	LOCATION=SUPPINJ INLET PIPNG	
Components				
all	1	02 18538	SUPPORT=SUPPLY INJ LH/RH	
all	2	02 18824C	COVER=UPPER SUP INJ 6044SG	
all	3	02 18824D	COVER=SUP INJ LO SUP 6044SG	
all	4	02 18024	FRONT VALVE CLOZ	
all	5	02 18025	REAR VALVCLOZ YOUR MATL	
all	6	W2 18559	* SUP-CHUTE 5-FLUSH=6044W+S+ (SS)	
all	7	02 18564	ENCLOSURE=SUPPLY INJ VALVE	

Five Compartments for Dry Chemical Supplies

4 Sheets

Table 47 Parts List—Five Compartments for Dry Chemical Supplies (cont'd.)

Find the assembly for your machine and the letter shown in the "Item" column. The components for your machine will show this letter or the word "all" in the "Used In" column. The numbers shown in the "Item" column are those shown in the illustrations.				
Used In	Item	Part Number	Description/Nomenclature	Comments
all	8	SA 28 086	* COVER ASSY=SUPPINJ	
all	9	02 18777A	SUPPLY INJECTOR COVER = 6044	
all	10	60C001	RUBBER BUMPER-BLKW/WASHER #698	
all	11	15P100	#8 X 3/8 PHILPANHD TYPE B SMS	
all	12	15P010	TRDCUT PHILPANHDSCR 10-24X1/2S	
all	13	15N117	RDMACSCR 10-24UNC2X3/8SS18-8	
all	14	24G018N	ROLLED WASH.194ID NYLTITE 10W	
all	15	15G121	HXCAPNUT 10-24UNC2 #3266BR NKL	
B	17	5S0PBEA0K	NPT TEE 3/4X3/4X1/2 BRASS 125#	
B	18	5N0KCLSBE2	NPT NIP 1/2XCLS TBE BRASS STD	
B	19	96TDC2AA37	1/2"N/C2WY120V50/60C VLV(DRYVC)	
B	20	02 19307	PIPE-"U" SUPPLY INJECT BRASS	
B	21	5SCC0KBE	NPT COUP 1/2 BRASS 125#	
B	22	27A001	NOZZLE BRASS 1/2" SPRAYSYSTEMS	
B	23	5N0P06ABE2	NPT NIP 3/4X6 TBE BRASS STD	
B	24	5N0P05AB42	NPT NIPPLE 3/4X5 TBE BRASS STD	
B	25	5SL0PBEA0K	NPTLNB 90DEG 3/4X1/2 BRASS150#	
C	26	96J031D	3/4"PRESSREG SET 28# FEMXUN=WATTS#LF25AUB-ZB	
C	27	5N0PCLSG42	NPT NIP 3/4XCLS TBE GALSTL S40	
C	28	5S0PNFB	NPT SIDEOUT TEE 3/4" GALMAL	
C	29	5SB0P0CNFA	NPTHEXBUSH 3/4X1/8GALV150#CORD	
C	30	30N100	PRESSGAUGE 1/8"BACKCN.0-30PSI	
C	31	5SB0P0KNFO	NPTHEXBUSH 3/4X1/2 GALMAL 150#	
C	32	96M001	1/2X3/8" RELIEF VALVE SET31#	
C	33	5SB0G0EDEO	NPTHEXBUSH 3/8X1/4 GALC1 125#	
C	34	53A008B	BODYMALECON.25X.25COMP#B68A-4B	
C	35	5N0P10AG42	NPT NIP 3/4X10 TBE GALSTL SK4	
C	36	5SCC0PNF	NPT COUP 3/4 GALMAL 150#	
C	37	51X019	UNIONSTRADT 3/4"#0107-12-12	
D	38	27A030B	UBOLT 3/4PIPE 1/4-20 THD ZINC	
D	39	15U180	LOCKWASHER MEDIUM 1/4 ZINCPL	
D	40	15G165	HXNUT 1/4-20UNC2BSAE ZC GR2	
D	41	60E086C18K	*WATERHOSE 3/4"=18"LG+ENDS	

Five Compartments for Dry Chemical Supplies

4 Sheets

Table 47 Parts List—Five Compartments for Dry Chemical Supplies (cont'd.)

Find the assembly for your machine and the letter shown in the "Item" column. The components for your machine will show this letter or the word "all" in the "Used In" column. The numbers shown in the "Item" column are those shown in the illustrations.				
Used In	Item	Part Number	Description/Nomenclature	Comments
all	42	60E301A12A	HOSE= *2.5"ID PE X12"	
all	43	27A075	T-BOLT HOSECLAMP 2.78-3.09"	


8 Water & Steam

Water Inlets and Optional Siphon Breaker

3 Sheets

60044SR2, 60044SR3

Figure 61. Water Inlets and Optional Siphon Breaker




Water Inlets and Optional Siphon Breaker

3 Sheets

60044SR2, 60044SR3

Figure 62. Inlet Pipe



Legend

- A . . . Water inlets
- B . . . Inlet pipe
- C . . . Optional siphon breaker inlet trap
- D . . . To shell

Table 48. Parts List—Water Inlets and Optional Siphon Breaker

Find the assembly for your machine and the letter shown in the "Item" column. The components for your machine will show this letter or the word "all" in the "Used In" column. The numbers shown in the "Item" column are those shown in the illustrations.

Used In	Item	Part Number	Description/Nomenclature	Comments
Reference Assemblies				
	A	AVW28003A	H2O INLT=BONOMI COLD ONLY, 60SG	COLD
	B	AVW28010A	H2O INLT=BONOMI +1 VALVE 60SG	HOT
	C	AVW28005A	H2O INLT=BONOMI FRESH VALVE 60SG	+1 FRESH
	D	GVW28002	H2O INLTS-MTG HDWE 60SG	ADD VACUUM BREAKER
Components				
all	1	96D088FBA	2" BALVAL\$ BRS N/C BONOMI	
all	2	5SL2ANFA	NPT ELBOW 90DEG 2" GALMAL 150#	
all	3	5N2ACLSG42	NPT NIP 2XCLS TBE GALSTL SK40	
all	4	5N2A03AG42	NPT NIPPLE 2X3 TBE GALSTL SK40	
all	5	5N2A04AG42	NPT NIP 2X4 TBE GALSTL SK40	

Water Inlets and Optional Siphon Breaker

60044SR2, 60044SR3


Table 48 Parts List—Water Inlets and Optional Siphon Breaker (cont'd.)

Find the assembly for your machine and the letter shown in the "Item" column. The components for your machine will show this letter or the word "all" in the "Used In" column. The numbers shown in the "Item" column are those shown in the illustrations.				
Used In	Item	Part Number	Description/Nomenclature	Comments
all	6	5S2ANFA	NPT TEE 2" GALMAL 150#	
all	7	5N2A07AG42	NPT NIP2X7TBE GALSTL SK40	
all	8	5N2A04KG42	NPT NIP 2X4.5 TBE GALSTL SK40	
all	9	5N2A13PG42	NPT NIP 2X13.75 TBE GALSTL SK40	
all	10	51P060	PLUG PIPE SQ 2"GALCORED CI 125	
all	11	5N2A48AG42	NPT NIP 2X48 TBE GALSTL SK40	
all	12	5SCC2ANF	NPT COUP 2" GALMAL 150#	
all	13	51E098B	KINGREDNIP2.5"IDX2"NPT#STC3025	
all	14	27A075	T-BOLT HOSECLAMP 2.78-3.09"	
all	15	60E301A48A	HOSE= *2.5"2D PE X48"	
all	16	02 18995	CLAMP=2" PIPE	
all	17	27A032N	UBOLT 2"PIPE 3/8-16 ZNC4.87"LG	
all	18	15G205	HXNUT 3/8-16UNC2B ZINC GR2	
all	19	15U255	LOCKWASHER MEDIUM 3/8 ZINCPL	
all	20	60E301A12A	HOSE= *2.5"ID PE X12"	
all	21	27A084	HOSECLAMP 3+9/16-4.5CADSC#HS64	
all	22	5SU2ANF	NPT UNION 2" GALMAL 150#	
all	23	5SB3A2ADEO	NPTHEXBUSH 3X2 GALCI 125#	
all	24	SA 03 007	3"SIPHONBREAKER+SCUPPER ASSY	
all	25	W2 19278	* INLET TRAP 2.5"D=SG+VACBKR	

This page intentionally blank

Siphon Breaker and Scupper

2 Sheets



Siphon Breaker & Scupper

2 Sheets

Table 49. Parts List—Siphon Breaker & Scupper

Find the assembly for your machine and the letter shown in the "Item" column. The components for your machine will show this letter or the word "all" in the "Used In" column. The numbers shown in the "Item" column are those shown in the illustrations.				
Used In	Item	Part Number	Description/Nomenclature	Comments
Reference Assemblies				
	A	SA 03 007	3"SIPHONBREAKER+SCUPPER ASSY	
Components				
all	1	96M034	3"VAC BREAKER - WATTS#288AM2	
all	2	60C151	ORING 3+7/8ID1/8CS BUNA70#241	
all	3	03 01303	SCUPPER 3"SIPHON BREAKER	
all	4	03 01304	GASKET=RING 3"SIPHON BREAKER	
all	5	03 01305	STEM=GUIDE 3" SIPHON BREAKER	
all	6	03 01306	SPACER=BONNET 3"SIPHON BREAK	

BPWGUW01 / 2020082

BPWGUW01.1 0000274513 E.2 A.4 2/17/20, 9:57 AM Released




Steam Inlet & Sparger

2 Sheets

4244SP2, 4244SP2 SM, 6044SP2/SP3, 6044SP2 SM



NOTE: 6044SP2 Shown



Legend
A . . . Sparger

Steam Inlet & Sparger

2 Sheets

4244SP2, 4244SP2 SM, 6044SP2/SP3, 6044SP2 SM

Table 50. Parts List—Steam Inlet & Sparger

Find the assembly for your machine and the letter shown in the "Item" column. The components for your machine will show this letter or the word "all" in the "Used In" column. The numbers shown in the "Item" column are those shown in the illustrations.				
Used In	Item	Part Number	Description/Nomenclature	Comments
Reference Assemblies				
	A	AVS03001	*1+1/4BURKERT +STRAINER	4244SP2,6044SP2/SP3
	B	AVS28002	\$1.25 BURKERT STEAM=60SG2+3	6044SP2/SP3
	C	GVS28002	INSTALL=1.25STEAM 6044SG2+3	6044SP2/SP3
	D	AVS04001	\$1.25 BURKERT STEAM=42+72SG23	4244SP2
	E	GVS15001	INSTALLATION=1+1/4STEAM 42SG	4244SP2
Components				
A	1	51T060	Y-STRAINER 1+1/4" CAST IRON	
A	2	5SP0PHFSS	NPT PLUG 3/4 SQ SOLID STL/ZINC	
A	3	5N1E05AG42	NPT NIP 1.25X5 TBE GALSTL SK40	
A	4	96D0011E	1.25"NPTBRZ N/C STEAMVALANGBD	
A	5	96H018	ANGLE NEEDLE VLV 1/4" T X 1/8MP	
A	6	5SB0E0CBEO	NPTHEXBUSH 1/4X1/8 BRASS 125#	
B,D	7	5N1E05AG42	NPT NIP 1.25X5 TBE GALSTL SK40	
B	8	5SL1ENFK	NPT ELB 45DEG 1.25 GALMAL 150#	
D	8	5SL1EMFK	NPT ELB 45DEG 1.25 BLKMAL 150#	
B,D	9	5N1ECLSF42	NPT NIP 1.25XCLS TBE BLKSTLS40	
B,D	10	5SU1EMH	NPT UNION 1.25" BLKMAL 150#	
B,D	11	51E096C	MALESTEM 1.25"CADPL CAMP#IMS5	
C	12	60E096C35A	STEAMH*OSE=1.25"X35"+2ENDS=(NO	
E	12	60E096C22A	STEAMH*OSE=1.25"X22="+2ENDS=(NO	
C,E	13	5SR1E0PNF	NPT RED 1.25X3/4 GALMAL 150#	
C,E	14	5N0PCLSG42	NPT NIP 3/4XCLS TBE GALSTL S40	
C,E	15	5SL0PNFA	NPT ELB 90DEG 3/4 GALMAL 150#	
C,E	16	5N0PCLSG42	NPT NIP 3/4XCLS TBE GALSTL S40	
C,E	17	5SB1K1ADEO	NPTHEXBUSH 1.5X1 GALCI 125#	
C,E	18	W2 18801	*LMT=STEAM NOZZLE	

Burket Steam Valve




Table 51. Parts List—Burket Steam Valve

Find the assembly for your machine and the letter shown in the "Item" column. The components for your machine will show this letter or the word "all" in the "Used In" column. The numbers shown in the "Item" column are those shown in the illustrations.

Used In	Item	Part Number	Description/Nomenclature	Comments
Reference Assemblies				
	W	96D0009ER1	02Z REPAIR KIT 3/4" STEAM VALVE	KIT FOR 001A
	X	96D0011ER1	02Z REPAIR KIT 1.25" STEAM VALVE	KIT FOR 001B
	Y	96D0011ER2	ACTUATOR HOUSING FOR BURKET #251	KIT FOR 001B
	Z	96D0011ER3	REPAIR KIT MULLER 1.25" VALVE #554	KIT FOR 001B
Components				
all	1	96D0009E	03Z 3/4"NPT N/C STEAMVAL ANGLE BODY	3/4"
all	1	96D0011E	08Z 1/25"NPT N/C STEAMVAL ANGLE BODY	1-1/4"
all	2	96H018	NEEDLE VALVE	
all	3	51T030	01Z Y-STRAINER 3/4" CAST IRON	USED WITH 001A
all	3	51T060	01Z Y-STRAINER 1+1/4" CAST IRON	USED WITH 001B


BPWVUW02 / 2020264A

BPWVUW02.1 0000274870 E.2 B.2 6/24/20, 9:30 AM Released

Stainless Dump Valve

3 Sheets

42044WR2/WR3/SR2/SR3; 60044WR2/WR3/SR2/SR3; 72044WR2/WR3/SR2/SR3



8"X10" Stainless Dump Valve

3 Sheets

42044WR2/WR3/SR2/SR3; 60044WR2/WR3/SR2/SR3; 72044WR2/WR3/SR2/SR3

Table 52. Parts List—8"X10" Stainless Dump Valve

Find the assembly for your machine and the letter shown in the "Item" column. The components for your machine will show this letter or the word "all" in the "Used In" column. The numbers shown in the "Item" column are those shown in the illustrations.				
Used In	Item	Part Number	Description/Nomenclature	Comments
Reference Assemblies				
	A	SA 28 124	*8"SGL.DUMPVALVE 4244+52+60	42044WR2/WR3 42044SR2/SR3; 60044WR2/WR3; 60044SR2/SR3
	B	SA 36 015	10"SGL.DUMP VALVE 72WE+SG+WT	72044WR2/WR3; 72044SR2/SR3
	C	SA 28 158	* BONNET+AIRCYL=8"SS DUMPVALV	8" DUMP VALVE
	D	SA 36 044	* BONNET+AIRCYL=10"SS DUMPVAL	10" DUMP VALVE
Components				
CD	1	02 02101	CYLHEAD W/TAPPED HOLE	
CD	2	15U210	LOKWASHER MEDIUM 5/16 ZINCPL	
CD	3	60C132	ORING 2"IDX3/16CS BUNA70 #329	
CD	4	02 02068	AIRCYL-STAINLESS=DUMP VALVE	
CD	5	02 10585D	TIE BOLT=5/16-18X7.875 PLTD	
CD	6	03 01313	STOP=AIR CYL W/2+11/16STROKE	
CD	7	15G220	LTHX THIN LOKNUT 3/8-24 SSNTE	
CD	8	02 02194	PISTON CUP=DUMPVALVE 2+3/8"	
CD	9	02 02085	UP WASHER=2"OD=PISTON CUP	
CD	10	60C106	ORING 5/16ID 1/16CSBUNA70#011	
CD	11	02 02185	WASHER=PISTON CUP COMP LIMIT	
all	12	02 02105B	2.38"ACYL BRASS PISTONCUP WSHR	
CD	13	03 06429	SPRING=2.11ODX6.5FL 64#/"	
CD	14	60C132	ORING 2"IDX/316CS BUNA70 #329	
CD	15	24G020N	ROLLED WASH.252ID NYLTITE 25W	
CD	16	X2 02743	BONNET=2"DUMP VALVE	
CD	17	02 18931F	GASKET=DUMPVALVE-1/60+72WEHU	
CD	18	02 16021I	DUMPVAL STEM-4"+8"316SS	
CD	19	15G168	SQNUT 1/4-20UNC2 SS18-8	
all	20	15K086	HXCAPSCR 3/8-16NCX3/4 SS18-8	
CD	21	15K041S	HEXCAPSCR 1/4-20UNC2AX1 SS18-8	
CD	23	02 16021E	WASHER 3/8IDX1.250D DUMPVAL	
A	24	02 18068	9 SEAT-RESILIENT=8"DUMPVALVE	
B	24	03 06084	SEAT-RESILIENT=10"DUMPVALVE	
A	25	5SP0KGFSS	NPT PLUG 1/2 SOSOLID GALSTL	
CD	26	60C106	ORING 5/16ID 1/6CS BUNA70#011	
AC	27	02 18796	DISC-8" DUMP VALVE S/S	

8"X10" Stainless Dump Valve

3 Sheets

42044WR2/WR3/SR2/SR3; 60044WR2/WR3/SR2/SR3; 72044WR2/WR3/SR2/SR3

Table 52 Parts List—8"X10" Stainless Dump Valve (cont'd.)

Find the assembly for your machine and the letter shown in the "Item" column. The components for your machine will show this letter or the word "all" in the "Used In" column. The numbers shown in the "Item" column are those shown in the illustrations.				
Used In	Item	Part Number	Description/Nomenclature	Comments
BD	27	03 06083	DISC-10"DUMP VALVE S/S	
all	28	15U245	FLTWASH 3/8 STD COMM 18-8 SS	
A	29	02 18104	GASKET=8"DUMP VALVE BONNET	
B	29	03 06086G	GASKET=10" DUMP VALVE BONNET	
A	30	02 18931E	BONNET=8"DUMP VALVE	8" DUMP VALVE
B	30	03 06086F	BONNET=10"DUMP VALVE	10" DUMP VALVE
CD	32	02 16021C	BUMPER=DUMP VALVE BONNET	
CD	33	02 16021D	DUMP VALVE BUMPER RETAINER	
A	34	W2 18931	* BODY=8"DUMPVALV=4244,60,52	8" DUMP VALVE
B	34	W3 06086	*BODY=10"DUMP VALVE 72WE,SG,T	10" DUMP VALVE
A	35	02 18107	GASKET=8"FLANGED DUMP VALVE	8" DUMP VALVE
B	35	03 06085D	GASKET=10"FLANGEDUMP72D 8050	10" DUMP VALVE

9 Pneumatic

BNWUUM02 / 2020084

BNWUUM02 0000277470 A.3 2/19/20, 8:47 AM Released

9.1 Servicing Air Cylinders

BNWUUM02.T01 0000277469 E.2 A.3 A.2 2/18/20, 3:01 PM Released

This is the general procedure for rebuilding an air cylinder using a Milnor® furnished repair kit, once the air cylinder has been removed from the machine. See the specific air cylinder and major assembly parts drawing(s) for component identification and removal/replacement information.

Maintenance procedures require:

- Two threaded rods and nuts, twice the length of the tie bolts.
- The appropriate repair kit.



CAUTION: EXPLOSION HAZARD — Spring tension can cause air cylinder to burst apart with great force during disassembly. You can be struck by air cylinder parts.




- ▶ Follow maintenance instructions carefully.
- ▶ Wear eye protection.



NOTE: Use a new locknut when re-assembling air cylinder (see the appropriate parts drawing).


1. Replace two diagonally opposite tie bolts with threaded rods and nuts as shown in [Figure 63: Using Threaded Rods, page 183](#) .
2. Tighten nuts on the threaded rods until they contact the air cylinder.
3. Remove the other two tie bolts and the nuts, washers, clips, and actuators from the external end of piston stem.

Figure 63. Using Threaded Rods



- Loosen nuts on threaded rods evenly, permitting cylinder heads to separate. Use only a few turns on one nut before moving to the other one. Continue until springs have no tension.

Figure 64. Ensuring Correct Piston Cup Shape



- Note the position and orientation of the piston cup(s), washers, and springs. Replace the worn parts, then reassemble them in reverse order. Tighten the locknut until it is just barely possible to turn the piston cup and washer assembly on the stem. The correct piston cup shape is shown on the left side of the above figure. **Do not** overtighten the locknut, as this causes the

piston cup to deform to the shape shown on the right side of the figure and may cause the piston to bind in the cylinder.

This page intentionally blank

Brake Air Cylinder


2 Sheets



CAUTION: **Circled items are under high spring tension** — Air cylinder can burst apart with great force.



- ▶ Follow maintenance instructions BNWUUM02 carefully.



General Service & Safety-Related Components

2 Sheets

Table 53. Parts List—Brake Air Cylinder

Find the assembly for your machine and the letter shown in the "Item" column. The components for your machine will show this letter or the word "all" in the "Used In" column. The numbers shown in the "Item" column are those shown in the illustrations.				
Used In	Item	Part Number	Description/Nomenclature	Comments
Reference Assemblies				
	A	AAC65002	AIRCYL BRAKE SINGLE MOTOR	
Components				
all	1	02 18650B	STEM=2WAY AIRCYL BRAKE 7.88L	
all	2	W2 18646	*CYLINDER-AIR=DOUBLEACT BRAKE	
all	3	53A031XB	BODY-EL90MALE.25X25 #269C-4-4B	
all	4	60C132	ORING 2"IDX3/16CS BUNA70 #329	
all	5	27B250	SPCRROLL.5ID1.5L.062T STLZNC	
all	6	27B34010SS	SPACERROLL .51ID.625L.062T SS	
all	7	02 02194	PISTON CUP=DUMPVALVE 2+3/8"	
all	8	02 18651	WASHER=2 WAY BRAKE CYL	
all	9	15G220	NUTLOK THINHX 3/8-24 SS/NYL	
all	10	60C106	ORING 5/16ID 1/16CSBUNA70#011	
all	11	02 02105B	2.38"ACYL BRASS PISTONCUP WSHR	
all	12	02 02085	UP WASHER=2"OD=PISTON CUP	
all	13	06 20702E	FLOW NOT ACTUATOR CYL HEAD	
all	14	02 02101	CYLHEAD W/TAPPED HOLE	
all	15	02 17024	SPRING-SS=DUMP 1.5OD4FL40#"	
all	16	W6 20702F	*FLOW NOT VLV=AIR-CYL ROD WLD	
all	17	60C110	ORING 1/2IDX3/32CS BUNA70 #112	
all	18	02 02185	WASHER=PISTON CUP COMP LIMIT	
all	19	5N0ECLSBE2	NPT NIP 1/4XCLS TBE BRASS 125#	
all	20	51V015	TEE 1/4 FGDBRASS 101T7-444	
all	21	53A008B	BODYMALECON.25X.25COMP#B68A-4B	
all	22	5SCC0EBE	NPT COUP 1/4 BRASS 125# W/HEX	
all	23	15G185	HXNUT 5/16-18UNC2B SAE ZINC GR	
all	24	96M055	DELTROL QUICK EXHAUST VLV.1/4"	
all	25	27A005	MUFFLER 3/8" BANTAM B38	