

Published Manual Number/ECN: MPI4840MAE/2021413A

- Publishing System: TPAS2
- Access date: 10/05/2021
- Document ECNs: Latest



# Installation and Service

## 48040M7K



**Read the  
separate  
safety  
manual  
before  
installing,  
operating,  
or servicing**





## Table of Contents

### MPI4840MAE/21413A

Page	Description	Document
1	Limited Standard Warranty	BMP720097/2019036
2	How to Get the Necessary Repair Components	BIUUUD19/20081231
3	Trademarks	BNUUUU02/2021104A
<b>5</b>	<b>1. Safety</b>	
6	Safety—Tilting Washer-Extractors	BIUUUS27OT/20051111
12	Use the Red Safety Supports for Maintenance —48040M7K, 68036M5K, 72044M5K	BNWHUH02/2021344
15	Safety Stands - 48040M7K, 68036M5K, 72046M5K	BPWH4K01/2021336A
17	Safety Light Screen Components & Installation	BMP150061/2016046A
20	Installation Tag Guidelines - 48040M7K, 68036M5K, & 72046M5K (with and without Dryell)	BNWH4I01/2018333A
23	Torque Requirements for Fasteners	BIUUUM04/20180109
31	Safety Placard Use and Placement 48040M7K, 68036M5K, 72046M5K	BMP150027/2016046A
33	Safety Placard Use and Placement ISO 48040M7K, 68036M5K, 72046M5K	BMP150028/2016075A
35	Guards and Covers	BMP150029/2017282A
<b>41</b>	<b>2. Installation</b>	
42	48040H_, 68036H_, & MWF100_ Washer Extractor Installation	BIIFLI01AC/20180814
47	About the Forces Transmitted by Milnor® Washer-extractors	BIWUUU02/20001108
49	Shipping Brackets	BMP150056/2016046A
51	Service Connections	BIIFUI01FG/20130129
<b>55</b>	<b>3. Drive</b>	
56	Drive Components and Belt Installation	BIIFLM05/20151104
59	Motor Mount 48040M7K, 68036M5K	BMP150036/2015386A
62	Disc Brake Maintenance	BIEUUM01/2012266A
74	Disc Brake	BMP120026/2015435A
77	Air Cylinder Components and Installation	BIIFLM11/2015176A
79	Cylinder Installation	BIIFLM07/20160113
83	Bearing Housing Components and Installation 48040M7K	BIIFLM08/20151104
89	Air Injection Components	BIIFLM09/2018044A
<b>91</b>	<b>4. Frame and Tilt</b>	
92	Frame Pivots and Tilt Stops	BMP150038/2015386A
96	Suspension: Marshmallow Springs & Shocks	BMP150048/2015443A
<b>99</b>	<b>5. Hydraulic Assemblies</b>	
100	Hydraulic Tank 48040M7K, 68036M5K, 72046M5K	BMP150039/2015155A
102	Hydraulic Tilt Valves & Fittings	BMP150041/2015435A

## Table of Contents, continued

### MPI4840MAE/21413A

<b>Page</b>	<b>Description</b>	<b>Document</b>
106	Hydraulic Cylinder	BMP150040/2015435A
<b>109</b>	<b>6. Door Assemblies</b>	
110	Installation 38" Hydraulic Door	BMP150060/2016046A
114	Installation Manual Door	BIIFLM14/20151105
117	Components 38" Manual Door	BMP150059/2015454A
120	Door Hinge Components and Installation	BMP150058/2015454A
121	Door Latch	BIIFGM19/2010285A
122	Door Latch Small	BIHDBM04/2010476A
<b>123</b>	<b>7. Water and Steam</b>	
124	Water 48040M7K	BMP150062/2016046A
129	Steam	BMP150063/2016046A
131	Installation, Drain Valve Body With One Valve	BIIFLM21/20120503
133	Drain Valve Body with Two Valves	BIIH4M03/20120502
<b>135</b>	<b>8. Chemical</b>	
136	Soap Chute	BMP150052/2016064A
138	Eight Port Peristaltic Supply Manifold	BMP150053/2015292A
<b>141</b>	<b>9. Control and Sensing Assemblies</b>	
142	Switch Panel Pivot Arm	BMP150050/2015435A
144	Tilt Limit Switches	BMP150046/2015392A
145	Excursion Switch	BMP150047/2015155A
146	Vibration Safety Switch Adjustments	MSSMA408BE/199273BV
148	Vibration Safety Switch	BMP910038/2012383B
149	Air Chamber Level Switch with Overflow Pressure Switch	BMP180078/2018484A
151	Temperature Probe	BMP150054/2015292A
<b>153</b>	<b>10. Dimensional</b>	
155	Dimensional Drawing - 48040M7K	BD4840M7KAE/2016326D
156	Dimensional Drawing - 4840M7K Options	BD4840M7KAB/2016253D
157	Dimensional Drawing - 4840M7K with DRYELL	BD4840M7KAC/2019126D



# **PELLERIN MILNOR CORPORATION LIMITED STANDARD WARRANTY**

We warrant to the original purchaser that MILNOR machines including electronic hardware/software (hereafter referred to as "equipment"), will be free from defects in material and workmanship for a period of one year from the date of shipment (unless the time period is specifically extended for certain parts pursuant to a specific MILNOR published extended warranty) from our factory with no operating hour limitation. This warranty is contingent upon the equipment being installed, operated and serviced as specified in the operating manual supplied with the equipment, and operated under normal conditions by competent operators.

Providing we receive written notification of a warranted defect within 30 days of its discovery, we will—at our option—repair or replace the defective part or parts, EX Factory (labor and freight specifically NOT included). We retain the right to require inspection of the parts claimed defective in our factory prior to repairing or replacing same. We will not be responsible, or in any way liable, for unauthorized repairs or service to our equipment, and this warranty shall be void if the equipment is tampered with, modified, or abused, used for purposes not intended in the design and construction of the machine, or is repaired or altered in any way without MILNOR's written consent.

Parts damaged by exposure to weather, to aggressive water, or to chemical attack are not covered by this warranty. For parts which require routine replacement due to normal wear—such as gaskets, contact points, brake and clutch linings, belts, hoses, and similar parts—the warranty time period is 90 days.

We reserve the right to make changes in the design and/or construction of our equipment (including purchased components) without obligation to change any equipment previously supplied.

ANY SALE OR FURNISHING OF ANY EQUIPMENT BY MILNOR IS MADE ONLY UPON THE EXPRESS UNDERSTANDING THAT MILNOR MAKES NO EXPRESSED OR IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR ANY PARTICULAR USE OR PURPOSE OR ANY OTHER WARRANTY IMPLIED BY LAW INCLUDING BUT NOT LIMITED TO REDHIBITION. MILNOR WILL NOT BE RESPONSIBLE FOR ANY COSTS OR DAMAGES ACTUALLY INCURRED OR REQUIRED AS A RESULT OF: THE FAILURE OF ANY OTHER PERSON OR ENTITY TO PERFORM ITS RESPONSIBILITIES, FIRE OR OTHER HAZARD, ACCIDENT, IMPROPER STORAGE, MIS-USE, NEGLIGENCE, POWER OR ENVIRONMENTAL CONTROL MALFUNCTIONS, DAMAGE FROM LIQUIDS, OR ANY OTHER CAUSE BEYOND THE NORMAL RANGE OF USE. REGARDLESS OF HOW CAUSED, IN NO EVENT SHALL MILNOR BE LIABLE FOR SPECIAL, INDIRECT, PUNITIVE, LIQUIDATED, OR CONSEQUENTIAL COSTS OR DAMAGES, OR ANY COSTS OR DAMAGES WHATSOEVER WHICH EXCEED THE PRICE PAID TO MILNOR FOR THE EQUIPMENT IT SELLS OR FURNISHES.

THE PROVISIONS ON THIS PAGE REPRESENT THE ONLY WARRANTY FROM MILNOR AND NO OTHER WARRANTY OR CONDITIONS, STATUTORY OR OTHERWISE, SHALL BE IMPLIED.

WE NEITHER ASSUME, NOR AUTHORIZE ANY EMPLOYEE OR OTHER PERSON TO ASSUME FOR US, ANY OTHER RESPONSIBILITY AND/OR LIABILITY IN CONNECTION WITH THE SALE OR FURNISHING OF OUR EQUIPMENT TO ANY BUYER.

BMP720097/19036

## How to Get the Necessary Repair Components



This document uses Simplified Technical English.  
Learn more at <http://www.asd-ste100.org>.

You can get components to repair your machine from the approved supplier where you got this machine. Your supplier will usually have the necessary components in stock. You can also get components from the Milnor® factory.

Tell the supplier the machine model and serial number and this data for each necessary component:

- The component number from this manual
- The component name if known
- The necessary quantity
- The necessary transportation requirements
- If the component is an electrical component, give the schematic number if known.
- If the component is a motor or an electrical control, give the nameplate data from the used component.

To write to the Milnor factory:

Pellerin Milnor Corporation  
Post Office Box 400  
Kenner, LA 70063-0400  
UNITED STATES

Telephone: 504-467-2787  
Fax: 504-469-9777  
Email: [parts@milnor.com](mailto:parts@milnor.com)

— End of BIUUUD19 —

# Trademarks

These words are trademarks of Pellerin Milnor® Corporation and other entities:

**Table 1. Trademarks**

AutoSpot™	GreenFlex™	MilMetrix®	PulseFlow®
CBW®	GearTrace™	MilTouch™	RAM Command™
Drynet™	GreenTurn™	MilTouch-EX™	RecircONE®
E-P Express®	Hydro-cushion™	MILRAIL™	RinSave®
E-P OneTouch®	Mentor®	Miltrac™	SmoothCoil™
E-P Plus®	Mildata®	PBW™	Staph Guard®
Gear Guardian®	Milnor®		

End of document: BNUUUU02



Safety

1

## Safety—Tilting Washer-Extractors

### 1. General Safety Requirements—Vital Information for Management Personnel [Document BIUUUS04]

Incorrect installation, neglected preventive maintenance, abuse, and/or improper repairs, or changes to the machine can cause unsafe operation and personal injuries, such as multiple fractures, amputations, or death. The owner or his selected representative (owner/user) is responsible for understanding and ensuring the proper operation and maintenance of the machine. The owner/user must familiarize himself with the contents of all machine instruction manuals. The owner/user should direct any questions about these instructions to a Milnor® dealer or the Milnor® Service department.

Most regulatory authorities (including OSHA in the USA and CE in Europe) hold the owner/user ultimately responsible for maintaining a safe working environment. Therefore, the owner/user must do or ensure the following:

- recognize all foreseeable safety hazards within his facility and take actions to protect his personnel, equipment, and facility;
- work equipment is suitable, properly adapted, can be used without risks to health or safety, and is adequately maintained;
- where specific hazards are likely to be involved, access to the equipment is restricted to those employees given the task of using it;
- only specifically designated workers carry out repairs, modifications, maintenance, or servicing;
- information, instruction, and training is provided;
- workers and/or their representatives are consulted.

Work equipment must comply with the requirements listed below. The owner/user must verify that installation and maintenance of equipment is performed in such a way as to support these requirements:

- control devices must be visible, identifiable, and marked; be located outside dangerous zones; and not give rise to a hazard due to unintentional operation;
- control systems must be safe and breakdown/damage must not result in danger;
- work equipment is to be stabilized;
- protection against rupture or disintegration of work equipment;
- guarding, to prevent access to danger zones or to stop movements of dangerous parts before the danger zones are reached. Guards to be robust; not give rise to any additional hazards; not be easily removed or rendered inoperative; situated at a sufficient distance from the danger zone; not restrict view of operating cycle; allow fitting, replacing, or maintenance by restricting access to relevant area and without removal of guard/protection device;
- suitable lighting for working and maintenance areas;
- maintenance to be possible when work equipment is shut down. If not possible, then protection measures to be carried out outside danger zones;
- work equipment must be appropriate for preventing the risk of fire or overheating; discharges of gas, dust, liquid, vapor, other substances; explosion of the equipment or substances in it.

- 1.1. **Laundry Facility**—Provide a supporting floor that is strong and rigid enough to support—with a reasonable safety factor and without undue or objectionable deflection—the weight of the fully loaded machine and the forces transmitted by it during operation. Provide sufficient clearance for machine movement. Provide any safety guards, fences, restraints, devices, and verbal and/or posted restrictions necessary to prevent personnel, machines, or other moving machinery from accessing the machine or its path. Provide adequate ventilation to carry away heat and vapors. Ensure service connections to installed machines meet local and national safety standards, especially regarding the electrical disconnect (see the National Electric Code). Prominently post safety information, including signs showing the source of electrical disconnect.
- 1.2. **Personnel**—Inform personnel about hazard avoidance and the importance of care and common sense. Provide personnel with the safety and operating instructions that apply to them. Verify that personnel use proper safety and operating procedures. Verify that personnel understand and abide by the warnings on the machine and precautions in the instruction manuals.
- 1.3. **Safety Devices**—Ensure that no one eliminates or disables any safety device on the machine or in the facility. Do not allow machine to be used with any missing guard, cover, panel or door. Service any failing or malfunctioning device before operating the machine.
- 1.4. **Hazard Information**—Important information on hazards is provided on the machine safety placards, in the Safety Guide, and throughout the other machine manuals. **Placards must be kept clean so that the information is not obscured. They must be replaced immediately if lost or damaged. The Safety Guide and other machine manuals must be available at all times to the appropriate personnel.** See the machine service manual for safety placard part numbers. Contact the Milnor Parts department for replacement placards or manuals.
- 1.5. **Maintenance**—Ensure the machine is inspected and serviced in accordance with the norms of good practice and with the preventive maintenance schedule. Replace belts, pulleys, brake shoes/disks, clutch plates/tires, rollers, seals, alignment guides, etc. before they are severely worn. Immediately investigate any evidence of impending failure and make needed repairs (e.g., cylinder, shell, or frame cracks; drive components such as motors, gear boxes, bearings, etc., whining, grinding, smoking, or becoming abnormally hot; bending or cracking of cylinder, shell, frame, etc.; leaking seals, hoses, valves, etc.) Do not permit service or maintenance by unqualified personnel.

## 2. **Safety Alert Messages—Internal Electrical and Mechanical Hazards** [Document BIUUUS11]

The following are instructions about hazards inside the machine and in electrical enclosures.



**WARNING 1: Electrocution and Electrical Burn Hazards**—Contact with electric power can kill or seriously injure you. Electric power is present inside the cabinetry unless the main machine power disconnect is off.

- Do not unlock or open electric box doors.
- Do not remove guards, covers, or panels.
- Do not reach into the machine housing or frame.
- Keep yourself and others off of machine.
- Know the location of the main machine disconnect and use it in an emergency to remove all electric power from the machine.



**WARNING 2: Entangle and Crush Hazards**—Contact with moving components normally isolated by guards, covers, and panels, can entangle and crush your limbs. These components move automatically.

- Do not remove guards, covers, or panels.
- Do not reach into the machine housing or frame.
- Keep yourself and others off of machine.
- Know the location of all emergency stop switches, pull cords, and/or kick plates and use them in an emergency to stop machine motion.



**WARNING 3: Crush Hazards**—Tilting machines only—The machine housing will crush your body or limbs if it descends or falls while you are under it. Housing can descend with power off or on. Manual operation of tilting valves overrides safety interlocks. Improper operation of manual tilting valves may cause the housing to descend.

- Do not remove guards, covers, or panels.
- Do not reach into the machine housing or frame.

### 3. Safety Alert Messages—External Mechanical Hazards [Document BIUUUS12]

The following are instructions about hazards around the front, sides, rear or top of the machine.



**WARNING 4: Strike and Crush Hazards**—Machines with power operated door—The moving door can strike you or crush or pinch your limbs if caught between the door and machine. Some doors move automatically.

- Keep yourself and others clear of movement areas and paths.
- Keep both hands on the controls while operating.
- Do not operate the machine with malfunctioning two-hand manual controls.



**WARNING 5: Crush Hazards**—Tilting machines only—The machine can crush your body or limbs if you are caught between the tilting housing and a stationary object. Some machines tilt automatically.

- Keep yourself and others clear of movement areas and paths.
- Keep both hands on the controls while operating.
- Do not operate the machine with malfunctioning two-hand manual controls.



**WARNING 6: Crush Hazards**—Suspended machines only—Spaces between the shell and housing can close and crush or pinch your limbs. The shell moves within the housing during operation.

- Do not reach into the machine housing or frame.
- Keep yourself and others clear of movement areas and paths.

### 4. Safety Alert Messages—Cylinder and Processing Hazards

[Document BIUUUS13]

The following are instructions about hazards related to the cylinder and laundering process.



**DANGER 7: Entangle and Sever Hazards**—Contact with goods being processed can cause the goods to wrap around your body or limbs and dismember you. The goods are normally isolated by the locked cylinder door.



- Do not attempt to open the door or reach into the cylinder until the cylinder is stopped.
- Do not touch goods inside or hanging partially outside the turning cylinder.
- Do not operate the machine with a malfunctioning door interlock.
- Open pocket machines only—Do not jog the cylinder and pull the goods at the same time.
- Open pocket machines only—Keep yourself and others clear of cylinder and goods during jogging operation.
- Do not operate the machine with malfunctioning two-hand manual controls.
- Know the location of all emergency stop switches, pull cords, and/or kick plates and use them in an emergency to stop machine motion.
- Know the location of the main machine disconnect and use it in an emergency to remove all electric power from the machine.



**WARNING 8: Crush Hazards**—Contact with the turning cylinder can crush your limbs. The cylinder will repel any object you try to stop it with, possibly causing the object to strike or stab you. The turning cylinder is normally isolated by the locked cylinder door.

- Do not attempt to open the door or reach into the cylinder until the cylinder is stopped.
- Do not place any object in the turning cylinder.
- Do not operate the machine with a malfunctioning door interlock.
- Open pocket machines only—Keep yourself and others clear of cylinder and goods during jogging operation.
- Do not operate the machine with malfunctioning two-hand manual controls.



**WARNING 9: Confined Space Hazards**—Confinement in the cylinder can kill or injure you. Hazards include but are not limited to panic, burns, poisoning, suffocation, heat prostration, biological contamination, electrocution, and crushing.

- Do not attempt unauthorized servicing, repairs, or modification.



**WARNING 10: Explosion and Fire Hazards**—Flammable substances can explode or ignite in the cylinder, drain trough, or sewer. The machine is designed for washing with water, not any other solvent. Processing can cause solvent-containing goods to give off flammable vapors.

- Do not use flammable solvents in processing.
- Do not process goods containing flammable substances. Consult with your local fire department/public safety office and all insurance providers.

## 5. Safety Alert Messages—Unsafe Conditions [Document BIUUUS14]

### 5.1. Damage and Malfunction Hazards

#### 5.1.1. Hazards Resulting from Inoperative Safety Devices



**DANGER 11: Entangle and Sever Hazards**—Cylinder door interlock—Operating the machine with a malfunctioning door interlock can permit opening the door when the cylinder is turning and/or starting the cycle with the door open, exposing the turning cylinder.

- Do not operate the machine with any evidence of damage or malfunction.



**WARNING 12: Multiple Hazards**—Operating the machine with an inoperative safety device can kill or injure personnel, damage or destroy the machine, damage property, and/or void the warranty.

- Do not tamper with or disable any safety device or operate the machine with a malfunctioning safety device. Request authorized service.



**WARNING 13: Electrocution and Electrical Burn Hazards**—Electric box doors—Operating the machine with any electric box door unlocked can expose high voltage conductors inside the box.

- Do not unlock or open electric box doors.



**WARNING 14: Entangle and Crush Hazards**—Guards, covers, and panels—Operating the machine with any guard, cover, or panel removed exposes moving components.

- Do not remove guards, covers, or panels.



**WARNING 15: Crush Hazards**—Down limit switches (machines with front and rear tilt cylinders)—Failure of both front or both rear limit switches allows the seated tilt wheels on a tilted machine to lift from their cradles. The housing will fall and lunge forward or rearward.

- Do not operate the machine with any evidence of damage or malfunction.

#### 5.1.2. Hazards Resulting from Damaged Mechanical Devices



**WARNING 16: Multiple Hazards**—Operating a damaged machine can kill or injure personnel, further damage or destroy the machine, damage property, and/or void the warranty.

- Do not operate a damaged or malfunctioning machine. Request authorized service.



**WARNING 17: Explosion Hazards**—Cylinder—A damaged cylinder can rip apart during extraction, puncturing the shell and discharging metal fragments at high speed.

- Do not operate the machine with any evidence of damage or malfunction.



**WARNING 18: Explosion Hazards**—Clutch and speed switch (multiple motor machines)—A damaged clutch or speed switch can permit the low speed motor to engage during extract. This will over-speed the motor and pulleys and can cause them to rip apart, discharging metal fragments at high speed.

- Stop the machine immediately if any of these conditions occur:
  - abnormal whining sound during extract
  - skidding sound as extract ends
  - clutches remain engaged or re-engage during extract

## 5.2. Careless Use Hazards

### 5.2.1. Careless Operation Hazards—Vital Information for Operator Personnel (see also operator hazards throughout manual)



**WARNING 19: Multiple Hazards**—Careless operator actions can kill or injure personnel, damage or destroy the machine, damage property, and/or void the warranty.

- Do not tamper with or disable any safety device or operate the machine with a malfunctioning safety device. Request authorized service.
- Do not operate a damaged or malfunctioning machine. Request authorized service.
- Do not attempt unauthorized servicing, repairs, or modification.

- Do not use the machine in any manner contrary to the factory instructions.
- Use the machine only for its customary and intended purpose.
- Understand the consequences of operating manually.

5.2.2. Careless Servicing Hazards—Vital Information for Service Personnel (see also service hazards throughout manuals)



**WARNING 20: Electrocutation and Electrical Burn Hazards**—Contact with electric power can kill or seriously injure you. Electric power is present inside the cabinetry unless the main machine power disconnect is off.

- Do not service the machine unless qualified and authorized. You must clearly understand the hazards and how to avoid them.
- Abide by the current OSHA lockout/tagout standard when lockout/tagout is called for in the service instructions. Outside the USA, abide by the OSHA standard in the absence of any other overriding standard.



**WARNING 21: Entangle and Crush Hazards**—Contact with moving components normally isolated by guards, covers, and panels, can entangle and crush your limbs. These components move automatically.

- Do not service the machine unless qualified and authorized. You must clearly understand the hazards and how to avoid them.
- Abide by the current OSHA lockout/tagout standard when lockout/tagout is called for in the service instructions. Outside the USA, abide by the OSHA standard in the absence of any other overriding standard.



**WARNING 22: Crush Hazards**—Tilting machines only—The machine housing will crush your body or limbs if it descends or falls while you are under it. Housing can descend with power off or on. Manual operation of tilting valves overrides safety interlocks. Improper operation of manual tilting valves may cause the housing to descend.

- Secure both red safety supports in accordance with the instructions furnished, then lock out and tag out power at the main machine disconnect before working under the tilted machine.
- Do not operate the manual tilt valves with anyone under the machine.
- Do not operate the tilt controls with anyone under the machine.



**WARNING 23: Crush Hazards**—Tilting machines with front and rear tilt cylinders—The housing will fall and lunge forward or rearward if the tilt wheels on the non-tilted end lift out of their cradles, even with safety supports in place.

- Understand the consequences of operating manually.



**WARNING 24: Confined Space Hazards**—Confinement in the cylinder can kill or injure you. Hazards include but are not limited to panic, burns, poisoning, suffocation, heat prostration, biological contamination, electrocution, and crushing.

- Do not enter the cylinder until it has been thoroughly purged, flushed, drained, cooled, and immobilized.

— End of BIUUUS27 —

# Use the Red Safety Supports for Maintenance — 48040M7K, 68036M5K, 72044M5K

BNWHUH02.C02 0000373217 A.5 A.3 8/17/21 11:08 AM Released

## 1. What Safety Supports are Provided and Why

BNWHUH02.C01 0000373218 A.5 A.6 8/18/21 3:40 PM Released

These machines are provided with two, permanently attached safety stands that can be folded down from within a channel on the shell (drum) when the machine is in the wash position. If the machine has a load chute for automatic loading, it is also provided with a safety bar that can be inserted when the load chute is raised. The safety supports provide protection against the drifting down of the vertically moving portion of the machine during maintenance in the event of a leak in the hydraulic system. They are not intended to restrain the machine from coming down under power. Use the safety support(s) whenever the maintenance to be performed requires you to place any part of your body in or near the path of the vertically moving portion of the machine.



**WARNING:** **Incorrect use of the safety supports** — can cause the machine to descend and crush you.



- ▶ Never work near the path of the vertically moving portion of the machine unless the safety supports are deployed and power is removed from the machine.
- ▶ Do not use power to close a small gap between the machine and the safety supports. Use care not to lower the machine with the safety supports

deployed.

- ▶ Where a pair of safety supports is provided, always use both supports.
- ▶ Maintain the safety support(s) in good condition.
- ▶ When not in use, stow the safety support(s) in the location(s) provided on the machine or in a convenient, designated location.






### 3. How To Deploy the Safety Stands — 48040M7K

BNWHUH02.T01 0000373179 A.5 A.6 8/18/21 4:13 PM Released

1. Use the Manual mode to put the machine in the wash position (shell is horizontal).
2. Remove the clevis pins and allow the stands to pivot down completely. See the illustration below left.




3. Insert the clevis pins and secure them with the cotter pins. See the illustration above right.
4. Remove electric power from the machine.

### 4. How to Deploy the Load Chute Safety Bar

BNWHUH02.T03 0000373443 A.5 A.6 8/18/21 4:18 PM Released

1. Use the Manual mode to raise the load chute completely.
2. See the illustration at right. Insert one end of the safety bar in the holding bracket on the load chute, then the other end in the bracket on the front of the machine.
3. Remove electric power from the machine.



End of document: BNWHUH02

# Safety Stands

48040M7K, 68036M5K, 72046M5K

Figure 1. Safety Stands 68036M5K, 72046M5K





Figure 2. Safety Stands 48040M7K



# Safety Stands

48040M7K, 68036M5K, 72046M5K

**Table 1. Parts List—Safety Stands**



Find the assembly for your machine and the letter shown in the "Item" column. The components for your machine will show this letter or the word "all" in the "Used In" column. The numbers shown in the "Item" column are those shown in the illustrations.				
Used In	Item	Part Number	Description/Nomenclature	Comments
Reference Assemblies				
	A	GSB68002	6836M5K SHIPPING/SAFETY BRACKETS INSTL	68036M5K
	B	GSB72001	7246M5K SHIPPING/SAFETY BRACKETS INSTL	72046M5K
	C	GSB48004	4840M7K SHIPPING/SAFETY BRACKETS INSTL	48040M7K
Components				
AB	1	W2 25098	7246M5K KICKSTAND OUTER WLMT	
AB	2	02 25098A	7246M5K KICKSTAND INNER	
all	3	17A057	CLEVIS PIN 3/4"X6.5"	
all	4	15H062	3/4" COTTERPIN REMOVABLE	
all	5	15K203TA	HEXCAPSCR 1/2-13X6.5 GR8 ZINC	
all	6	15U300	LOKWASHER REGULAR 1/2 ZINC PLT	
all	7	15G230	HXNUT 1/2-13UNC2B SAE ZINC GR2	
C	8	W2 24074	4840M7K KICKSTAND RIGHT	
C	9	W2 24074A	4840M7K KICKSTAND LEFT	



# Safety Light Screen Components & Installation

48040M7K, 68036M5K, 72046M5K


Figure 1: Replacement parts



# Safety Light Screen Components & Installation

48040M7K, 68036M5K, 72046M5K

Figure 2: Safety Light Screen Installation



# Safety Light Screen Components & Installation

48040M7K, 68036M5K, 72046M5K

## Parts List—Safety Light Screen Components & Installation

Find the correct assembly first, then find the needed components. The item letters (A, B, C, etc.) assigned to assemblies are referred to in the "Used In" column to identify which components belong to an assembly. The item numbers (1, 2, 3, etc.) assigned to components relate the parts list to the illustration.

Used In	Item	Part Number	Description	Comments
-----COMPONENTS-----				
all	1	09RPE018LBG	STND FOR SENDER , RECEIVER, MIRROR	
all	2	09RPE018LBF	CORNER MIRROR BRACKETS	
all	3	09RPE018LBE	CORNER MIRROR FOR SAFETY BEAM	
all	4	09RPE018LBA	LITE BEAM EMITTER/RECEIVER 600MM BANNER	
all	5	09RPE018LBB	LITE BEAM CORDSET 15.3 METER	
all	6	09H025V71	BEACON ROTARY 8.5"DIA AMBER	
all	7	09RPE018LBC	LITE BEAM MUTING RELAY MODULE	NOT SHOWN
all	8	09RPE018LBD	LITE BEAM SAFETY RATING 24VDC POWER SUPPLY	NOT SHOWN
all	9	09N127C	KEYSW SPST 7A120VAC SCREW TERM	NOT SHOWN
all	10	01 10760X	NPLT:LIGHT CURTAIN BYPASS>ISO	NOT SHOWN

# Installation Tag Guidelines

BNWH4I01.R01 0000200221 A.2 8/14/18 3:58 PM Released

48040M7K

68036M5K

72046M5K

(with and without Dryell)




**NOTICE:** This information may apply to models in addition to those listed above. It applies to paper tags. It does not apply to the vinyl or metal safety placards, which must remain permanently affixed to the machine and replaced if no longer readable.

Paper tags on the machine provide installation guidelines and precautions. The tags can be tie-on or adhesive. You can remove tie-on tags and white, adhesive tags after installation. Yellow adhesive tags must remain on the machine.

The following entries explain the installation tags. Each entry includes: 1) the tag illustration, 2) the tag part number at the bottom of the tag, and 3) the meaning of the tag.

## Display or Action



## Explanation


Read the manuals before proceeding. This symbol appears on most tags. The machine ships with safety, operator, and routine maintenance guides for customer use. Milnor dealer manuals for installing, commissioning, and servicing the machine are also available from the Milnor Parts department.



B2TAG88005: This carefully built product was tested and inspected to meet Milnor performance and quality standards by (identification mark of tester).




B2TAG94078: Do not forklift here; do not jack here; do not step here—whichever applies.



B2TAG94079: Rig for crane lifting (either 3-point or 4-point, depending on the number of lifting eyes provided) using a steep angle on the chains (closer to vertical than horizontal).


B2TAG94081: Motor must rotate in this direction. On single motor washer-extractors and centrifugal extractors, the drive motor must turn in this direction during draining and extraction. This tag is usually wrapped around a motor housing. If the motor turns in the opposite direction when the machine is first tested, the electrical hookup is incorrect and must be reversed as explained in the schematic manual.




B2TAG94084: Do not lift from one corner of the machine, as this can cause the frame to rack, damaging it.



B2TAG94097: The cylinder must rotate **counterclockwise** during draining and extraction (spin) when viewed from here (rear of machine). Otherwise, reverse the electric power connections, as explained in the schematic manual.



B2TAG94118: Do not strike shipping container during fork-lifting. Fragile components inside.




B2T2001013: Hot water connection.




B2T2001014: Cold water connection.




B2T2001015: Reuse (third) water connection. (Optional)



B2T2001016: Flushing water connection. This is the water that goes into the supply compartment or pumped chemical manifold to flush chemicals into the machine.



B2T2001028: Look for tags inside the machine. These tags may identify shipping restraints to be removed or components to be installed. Do not start the machine until these actions are completed.



B2T2002013: Do not start the machine until shipping restraints are removed. This tag will appear on the outside of the machine to alert you to the presence of internal shipping restraints. A tag will also appear on the restraint to help identify it. Most, but not all shipping restraints display the color red. Some shipping restraints are also safety stands. Do not discard these.



B2T2004027: Steam connection. (Optional)

End of document: BNWH4101

## Torque Requirements for Fasteners



This document uses Simplified Technical English. Learn more at <http://www.asd-ste100.org>.

The document about the assembly gives the torque requirements for other fasteners. **If fastener torque specifications or threadlocker requirements in an assembly document are different from this document, use the assembly document.**

Figure 1: The Bolts in Milnor® Equipment

The Marks on Bolt Heads	Legend
	<p><b>A.</b> SAE Grades 1 and 2, ASTM A307, and stainless steel</p> <p><b>B.</b> Grade BC, ASTM A354</p> <p><b>C.</b> SAE Grade 5, ASTM A449</p> <p><b>D.</b> SAE Grade 8 and ASTM A354 BD</p>

### 1. Torque Values

These tables give the standard dimension, grade, threadlocker, and torque requirements for fasteners frequently used on Milnor® equipment.

**Note 1:** Data from the Pellerin Milnor® Corporation “Bolt Torque Specification” (bolt\_torque\_milnor.xls/2002096).

#### 1.1. Fasteners Made of Carbon Steel

##### 1.1.1. Without a Threadlocker

Table 1: Torque Values for Standard Fasteners with Maximum 5/16-inch Diameters and No Lubricant

Dimension	The Grade of the Bolt							
	Grade 2		Grade 5		Grade 8		Grade BC	
	Pound-Inches	N-m	Pound-Inches	N-m	Pound-Inches	N-m	Pound-Inches	N-m
1/4 x 20	66	7	101	11	143	16	126	14
1/4 x 28	76	9	116	13	163	18	--	--
5/16 x 18	136	15	209	24	295	33	258	29
5/16 x 24	150	17	232	26	325	37	--	--

Torque Requirements for Fasteners

**Table 2: Torque Values for Standard Fasteners Larger Than 5/16-inch Diameters and No Lubricant**

Dimension	The Grade of the Bolt							
	Grade 2		Grade 5		Grade 8		Grade BC	
	Pound-feet	N-m	Pound-feet	N-m	Pound-feet	N-m	Pound-feet	N-m
3/8 x 16	20	27	31	42	44	59	38	52
3/8 x 24	23	31	35	47	50	68	--	--
7/16 x 14	32	43	49	66	70	95	61	83
7/16 x 20	36	49	55	75	78	105	--	--
1/2 x 13	49	66	75	102	107	145	93	126
1/2 x 20	55	75	85	115	120	163	--	--
9/16 x 12	70	95	109	148	154	209	134	182
9/16 x 18	78	106	121	164	171	232	--	--
5/8 x 11	97	131	150	203	212	287	186	252
5/8 x 18	110	149	170	231	240	325	--	--
3/4 x 10	172	233	266	361	376	510	329	446
3/4 x 16	192	261	297	403	420	569	--	--
7/8 x 9	167	226	429	582	606	821	531	719
7/8 x 14	184	249	473	641	668	906	--	--
1 x 8	250	339	644	873	909	1232	796	1079
1 x 12	274	371	704	954	994	1348	--	--
1 x 14	281	381	723	980	1020	1383	--	--
1 1/8 x 7	354	480	794	1077	1287	1745	1126	1527
1 1/8 x 12	397	538	891	1208	1444	1958	--	--
1 1/4 x 7	500	678	1120	1519	1817	2464	1590	2155
1 1/4 x 12	553	750	1241	1682	2012	2728	--	--
1 3/8 x 6	655	888	1469	1992	2382	3230	2085	2827
1 3/8 x 12	746	1011	1672	2267	2712	3677	--	--
1 1/2 x 6	869	1178	1949	2642	3161	4286	2767	3751
1 1/2 x 12	979	1327	2194	2974	3557	4822	--	--

**Table 3: Torque Values for Plated Fasteners with Maximum 5/16-inch Diameters and No Lubricant**

Dimension	The Grade of the Bolt							
	Grade 2		Grade 5		Grade 8		Grade BC	
	Pound-Inches	N-m	Pound-Inches	N-m	Pound-Inches	N-m	Pound-Inches	N-m
1/4 x 20	49	6	76	9	107	12	95	11
1/4 x 28	56	6	88	10	122	14	--	--
5/16 x 18	102	12	156	18	222	25	193	22
5/16 x 24	113	13	174	20	245	28	--	--



**Table 4: Torque Values for Plated Fasteners Larger Than 5/16-inch Diameters and No Lubricant**

Dimension	The Grade of the Bolt							
	Grade 2		Grade 5		Grade 8		Grade BC	
	Pound-feet	N-m	Pound-feet	N-m	Pound-feet	N-m	Pound-feet	N-m
3/8 x 16	15	20	23	31	33	44	29	38
3/8 x 24	17	23	26	35	37	49	--	--
7/16 x 14	24	32	37	50	52	71	46	61
7/16 x 20	27	36	41	55	58	78	--	--
1/2 x 13	37	49	56	76	80	106	70	93
1/2 x 20	41	55	64	85	90	120	--	--
9/16 x 12	53	70	81	110	115	153	101	134
9/16 x 18	59	79	91	122	128	174	--	--
5/8 x 11	73	97	113	150	159	212	139	186
5/8 x 18	83	110	127	172	180	240	--	--
3/4 x 10	129	173	200	266	282	376	246	329
3/4 x 16	144	192	223	297	315	420	--	--
7/8 x 9	125	166	322	430	455	606	398	531
7/8 x 14	138	184	355	474	501	668	--	--
1 x 8	188	250	483	644	682	909	597	796
1 x 12	205	274	528	716	746	995	--	--
1 x 14	210	280	542	735	765	1037	--	--
1 1/8 x 7	266	354	595	807	966	1288	845	1126
1 1/8 x 12	298	404	668	890	1083	1444	--	--
1 1/4 x 7	375	500	840	1120	1363	1817	1192	1590
1 1/4 x 12	415	553	930	1261	1509	2013	--	--
1 3/8 x 6	491	655	1102	1470	1787	2382	1564	2085
1 3/8 x 12	559	758	1254	1672	2034	2712	--	--
1 1/2 x 6	652	870	1462	1982	2371	3161	2075	2767
1 1/2 x 12	733	994	1645	2194	2668	3557	--	--

## 1.1.2. With a Threadlocker

**Table 5: Threadlocker by the Diameter of the Bolt (see Note 2)**

LocTite Product	Dimension			
	1/4-inch	1/4- to 5/8-inch	5/8- to 7/8-inch	1-inch +
LocTite 222	OK			
LocTite 242		OK		
LocTite 262			OK	
LocTite 272			High temperature	
LocTite 277				OK

**Note 2:** The acceptable bolt size ranges for various LocTite® threadlocking products is the LocTite manufacturer's **general** recommendation. Specific applications sometime require that a LocTite product is applied to a bolt size outside the ranges shown here. For example, Milnor specifies LocTite 242 for use on certain 1" bolt applications and has confirmed this usage with the LocTite manufacturer. You may see variances such as this in the documentation for specific machine assemblies.

Torque Requirements for Fasteners

**Table 6: Torque Values if You Apply LocTite 222**

Dimension	The Grade of the Bolt							
	Grade 2		Grade 5		Grade 8		Grade BC	
	Pound-inches	N-m	Pound-inches	N-m	Pound-inches	N-m	Pound-inches	N-m
<b>1/4 x 20</b>	60	7	96	11	132	15	108	12
<b>1/4 x 28</b>	72	8	108	12	144	16	--	--

**Table 7: Torque Values if You Apply LocTite 242**

Dimension	The Grade of the Bolt							
	Grade 2		Grade 5		Grade 8		Grade BC	
	Pound-feet	N-m	Pound-feet	N-m	Pound-feet	N-m	Pound-feet	N-m
<b>5/16 x 18</b>	11	15	17	23	25	34	22	30
<b>5/16 x 24</b>	13	18	19	26	27	37	27	37
<b>3/8 x 16</b>	20	27	31	42	44	60	38	52
<b>3/8 x 24</b>	23	31	35	47	50	68	--	--
<b>7/16 x 14</b>	32	43	49	66	70	95	61	83
<b>7/16 x 20</b>	36	49	55	75	78	106	--	--
<b>1/2 x 13</b>	49	66	75	102	107	145	93	126
<b>1/2 x 20</b>	55	75	85	115	120	163	--	--
<b>9/16 x 12</b>	70	95	109	148	154	209	134	182
<b>9/16 x 18</b>	78	106	121	164	171	232	--	--
<b>5/8 x 11</b>	97	132	150	203	212	287	186	252
<b>5/8 x 18</b>	110	149	170	230	240	325	--	--

**Table 8: Torque Values if You Apply LocTite 262**

Dimension	The Grade of the Bolt							
	Grade 2		Grade 5		Grade 8		Grade BC	
	Pound-feet	N-m	Pound-feet	N-m	Pound-feet	N-m	Pound-feet	N-m
<b>3/4 x 10</b>	155	210	240	325	338	458	296	401
<b>3/4 x 16</b>	173	235	267	362	378	512	--	--
<b>7/8 x 9</b>	150	203	386	523	546	740	477	647
<b>7/8 x 14</b>	165	224	426	578	601	815	--	--

**Table 9: Torque Values if You Apply LocTite 272 (High-Temperature)**

Dimension	The Grade of the Bolt							
	Grade 2		Grade 5		Grade 8		Grade BC	
	Pound-feet	N-m	Pound-feet	N-m	Pound-feet	N-m	Pound-feet	N-m
<b>1 x 8</b>	350	475	901	1222	1272	1725	1114	1510
<b>1 x 12</b>	383	519	986	1337	1392	1887	--	--
<b>1 x 14</b>	393	533	1012	1372	1428	1936	--	--
<b>1-1/8 x 7</b>	496	672	1111	1506	1802	2443	1577	2138
<b>1-1/8 x 12</b>	556	754	1247	1691	2022	2741	--	--
<b>1-1/4 x 7</b>	700	949	1568	2126	2544	3449	2226	3018
<b>1-1/4 x 12</b>	774	1049	1737	2355	2816	3818	--	--
<b>1-3/8 x 6</b>	917	1243	2056	2788	3335	4522	2919	3958
<b>1-3/8 x 12</b>	1044	1415	2341	3174	3797	5148	--	--
<b>1-1/2 x 6</b>	1217	1650	2729	3700	4426	6001	3873	5251
<b>1-1/2 x 12</b>	1369	1856	3071	4164	4980	6752	--	--

**Table 10: Torque Values if You Apply LocTite 277**

Dimension	The Grade of the Bolt							
	Grade 2		Grade 5		Grade 8		Grade BC	
	Pound-feet	N-m	Pound-feet	N-m	Pound-feet	N-m	Pound-feet	N-m
<b>1 x 8</b>	325	441	837	1135	1181	1601	1034	1402
<b>1 x 12</b>	356	483	916	1242	1293	1753	--	--
<b>1 x 14</b>	365	495	939	1273	1326	1798	--	--
<b>1-1/8 x 7</b>	461	625	1032	1399	1674	2270	1464	1985
<b>1-1/8 x 12</b>	516	700	1158	1570	1877	2545	--	--
<b>1-1/4 x 7</b>	650	881	1456	1974	2362	3202	2067	2802
<b>1-1/4 x 12</b>	719	975	1613	2187	2615	3545	--	--
<b>1-3/8 x 6</b>	851	1154	1909	2588	3097	4199	2710	3674
<b>1-3/8 x 12</b>	970	1315	2174	2948	3526	4781	--	--
<b>1-1/2 x 6</b>	1130	1532	2534	3436	4110	5572	3597	4877
<b>1-1/2 x 12</b>	1271	1723	2852	3867	4624	6269	--	--

## 1.2. Stainless Steel Fasteners

**Table 11: Torque Values for Stainless Steel Fasteners 5/16-inch and Smaller**

Dimension	316 Stainless		18-8 Stainless		18-8 Stainless with Loctite 767	
	Pound-Inches	N-m	Pound-Inches	N-m	Pound-Inches	N-m
<b>1/4 x 20</b>	79	9	76	9	45	5
<b>1/4 x 28</b>	100	11	94	11	56	6
<b>5/16 x 18</b>	138	16	132	15	79	9
<b>5/16 x 24</b>	148	17	142	16	85	10

**Table 12: Torque Values for Stainless Steel Fasteners Larger Than 5/16-inch**

Dimension	316 Stainless		18-8 Stainless		18-8 Stainless with Loctite 767	
	Pound-feet	N-m	Pound-feet	N-m	Pound-feet	N-m
3/8 x 16	21	28	20	27	12	16
3/8 x 24	23	31	22	29	13	18
7/16 x 14	33	44	31	42	19	25
7/16 x 20	35	47	33	45	20	27
1/2 x 13	45	61	43	58	26	35
1/2 x 20	47	64	45	61	27	37
9/16 x 12	59	81	57	77	34	46
9/16 x 18	66	89	63	85	38	51
5/8 x 11	97	131	93	125	56	75
5/8 x 18	108	150	104	141	62	84
3/4 x 10	132	179	128	173	77	104
3/4 x 16	130	176	124	168	75	101
7/8 x 9	203	275	194	263	116	158
7/8 x 14	202	273	193	262	116	157
1 x 8	300	406	287	389	172	233
1 x 14	271	367	259	351	156	211
1-1/8 x 7	432	586	413	560	248	336
1-1/8 x 12	408	553	390	529	234	317
1-1/4 x 7	546	740	523	709	314	425
1-1/4 x 12	504	683	480	651	288	390
1-1/2 x 6	930	1261	888	1204	533	722
1-1/2 x 12	732	992	703	953	422	572

## 2. Preparation



**WARNING 2: Fire Hazard**—Some solvents and primers are flammable.

- Use threadlocker and primers with sufficient airflow.
  - Do not use flammable material near ignition sources.
1. Clean all threads with a wire brush or a different tool.
  2. Remove the grease from the fasteners and the mating threads with solvent. Make the parts dry.
 

**Note 3:** Loctite 7649 Primer™ or standard solvents will remove grease from parts.
  3. Apply a spray of Loctite 7649 Primer™ or equal on the fasteners and the mating threads. Let the primer dry for one minute minimum.

## 3. How to Apply a Threadlocker




**CAUTION 3: Malfunction Hazard**—Heat, vibration, or mechanical shocks can let the fasteners loosen if you do not apply the threadlocker correctly. Loose fasteners can cause malfunctions of the equipment.

- Read the threadlocker manufacturer's instructions and warnings. Obey these instructions.

Apply the threadlocker only to the areas where the fastener threads and the mating threads engage.

**Figure 2: Blind Hole**




### 3.1. Blind Holes

1. Apply the threadlocker down the threads to the bottom of the hole.
2. Apply the threadlocker to the bolt.
3. Tighten the bolt to the value shown in the correct table ([Table 5](#) to [Table 11](#)).

### 3.2. Through Holes

1. Put the bolt through the assembly.
2. Apply the threadlocker only to the bolt thread area that will engage the nut.
3. Tighten the bolt to the value shown in the correct table ([Table 5](#) to [Table 11](#)).


**Figure 3: Through Hole**



**3.3. Disassembly**—For high-strength threadlocker, apply heat for five minutes. Disassemble with hand tools while the parts are hot.

For low-strength and moderate-strength threadlocker, disassemble with hand tools.


Figure 4: Disassembly



— End of BIUUM04 —

# Safety Placard Use and Placement

48040M7K, 68036M5K, 72046M5K



Notes:

1. Replace placard immediately, if removed or unreadable.
2. Approximate locations of placards are shown. Mounting holes are provided on the machine. Use #8 self-tapping screws.

# Safety Placard Use and Placement

48040M7K, 68036M5K, 72046M5K

## Parts List—Safety Placard Use and Placement


Find the correct assembly first, then find the needed components. The item letters (A, B, C, etc.) assigned to assemblies are referred to in the "Used In" column to identify which components belong to an assembly. The item numbers (1, 2, 3, etc.) assigned to components relate the parts list to the illustration.

Used In	Item	Part Number	Description	Comments
-----COMPONENTS-----				
all	10	01 10583A	NPLT:64/72 W/E WARN FRT-TCATA	
all	20	01 10630A	NPLT:TILT CRUSH HAZARD-TCATA	
all	30	01 10377A	NPLT:ELEC HAZARD LG-TCATA	
all	40	01 10685A	NPLT:BURN HAZARD WARN-TCATA	
all	50	01 10648A	NPLT:GEAR HAZARD-TCATA	
all	60	01 10699A	NPLT:SERV HZRD-PLYEST-TCATA	
all	90	01 10761X	NPLT:M#K SAFETY STANDS	



# Safety Placard Use and Placement ISO

48040M7K, 68036M5K, 72046M5K



Notes:

1. Replace placard immediately, if removed or unreadable.
2. Approximate locations of placards are shown. Mounting holes are provided on the machine. Use #8 self-tapping screws.

# Safety Placard Use and Placement ISO

48040M7K, 68036M5K, 72046M5K

### Parts List—Safety Placard Use and Placement

Find the correct assembly first, then find the needed components. The item letters (A, B, C, etc.) assigned to assemblies are referred to in the "Used In" column to identify which components belong to an assembly. The item numbers (1, 2, 3, etc.) assigned to components relate the parts list to the illustration.

Used In	Item	Part Number	Description	Comments
-----COMPONENTS-----				
All	10	01 10629Z	NPLT TILT M#K WARN FRT ISO	
all	20	01 10630Y	NPLT TILT CRUSH HAZARD - ISO	
all	30	01 10377	NPLTE:"WARNING" 4X4	
all	40	01 10761X	NPLT:M#K SAFETY STANDS	

## Guards and Covers

48040M7K, 68036M5K, 72046M5K

Figure 1: Installed view



6836M5K shown


## Guards and Covers

48040M7K, 68036M5K, 72046M5K

Figure 2: Drive covers



6836M5K Drive Covers




7246M5K Drive Covers


# Guards and Covers

48040M7K, 68036M5K, 72046M5K


Figure 3: Drive covers, rear belt guard



Jackshaft Cover 7246M5K (used after 6/29/16)



48040M7K Rear Belt Guard





Torque Motor Cover




# Guards and Covers

48040M7K, 68036M5K, 72046M5K


Figure 4: Rear Belt Guard



**Detail A**  
Pivot shaft



**Detail B**  
Pivot shaft



**Detail C**  
"Locking" Belt Guard Bolts  
(4 places)

## Guards and Covers

48040M7K, 68036M5K, 72046M5K

### Parts List—Guards and Covers

Find the correct assembly first, then find the needed components. The item letters (A, B, C, etc.) assigned to assemblies are referred to in the "Used In" column to identify which components belong to an assembly. The item numbers (1, 2, 3, etc.) assigned to components relate the parts list to the illustration.

Used In	Item	Part Number	Description	Comments
-----ASSEMBLIES-----				
	A	GG568004	6836M5K HYD CYLINDER GUARDS	68036M5K
	B	GG572003	7246M5K HYD CYLINDER GUARDS	72046M5K
	C	GG548012	4840M7K HYD CYLINDER GUARDS	48040M7K
-----COMPONENTS-----				
A	1	W2 22693	6836M5K SIDEPANEL WLMT RT	
B	1	W2 25014	7246M5K SIDEPANEL WLMT RT	
C	1	W2 24044	4840M7K SIDEPANEL WLMT RT	
A	2	W2 22693A	6836M5K SIDEPANEL WLMT LT	
B	2	W2 25014A	7246M5K SIDEPANEL WLMT LT	
C	2	W2 24044A	4840M7K SIDEPANEL WLMT LT	
all	3	02 22692	6836M5K TILT FRAME PYRAMID COVER	
A	4	W2 22758	6836M5K BRAKE COVER WLMT	
B	4	W2 25118	7246M5K BRAKE COVER WLMT	
all	5	W2 25108	7246M5K MOTOR/JACKSHAFT BELTGUARD WLMT	
all	6	02 25109	7246M5K MOTOR/JACK BELTGUARD STIFFENER	
A	7	AGS68002	6836M5K REAR BELT GUARD ASSEMBLY	
B	7	AGS72001	7246M5K REAR BELT GUARD ASSY	
C	7	AGS48010	4840M7K BELTGUARD ASSY LEFT	48040 LEFT BELT GUARD
C	7	AGS48010A	4840M7K BELTGUARD ASSY RIGHT	48040 RIGHT BELT GUARD
A	8	02 22677	6836M5K BELT COVER MOUNT BRKT	
B	8	02 25106	7246M5K BELT COVER MOUNT BRK	
C	8	02 24041	4840M7K BELTGUARD MOUNT BRKT LT	48040 LEFT BRACKET
C	8	02 24041A	4840M7K BELTGUARD MOUNT BRKT RT	48040 RIGHT BRACKET
all	9	X2 22700	6836M5K BELT COVER PIVOT SHAFT	
all	10	17B012	EXTRETRING IND#1000-50-ST-ZD Z	
A	11	02 22775	6836M5K TRUCK BUMPER BRKT	
B	11	02 25107	7246M5K TRUCK BUMPER BRKT	
all	12	60B075	DFW56-33PMSP RUBB CONN.	
all	13	02 22676	6836M5K BELT COVER LOCK BRKT	
all	14	02 25121A	7246M5K BELTGUARD UPPER FILLER	
AB	15	AGS75001L	COVER=GEARTRAIN LH	
C	15	02 21968A	EXTENDED COVER=CHAIN COUPLING, 4840F	TORQUE MOTOR BELOW DOOR
all	16	15K085	HEXCAPSCR 3/8-16UNC2AX3/4 GR5	
all	17	15G198	HXFLGNUT 3/8-16 ZINC	
all	18	15U200	FLATWASHER(USS STD) 5/16"ZNC P	
all	19	15K117	HEXCAPSCR 3/8-16X1+3/4 GR 5 PL	
all	20	15U240	FLATWASHER(USS STD) 3/8" ZNC P	
all	21	15U516	FLTWSHR 2.5ODX17/32"IDX.25"THI	

## Guards and Covers

48040M7K, 68036M5K, 72046M5K

### Parts List—Guards and Covers

Find the correct assembly first, then find the needed components. The item letters (A, B, C, etc.) assigned to assemblies are referred to in the "Used In" column to identify which components belong to an assembly. The item numbers (1, 2, 3, etc.) assigned to components relate the parts list to the illustration.

Used In	Item	Part Number	Description	Comments
all	22	15G201	HXLKLNUT 3/8-16 NYL/SS TYPE NE	
all	23	15K145	HXCAPSCR 1/2-13UNC2AX3/4 GR5 P	
all	24	15U280	FL+WASHER(USS STD)1/2 ZNC PL+D	
all	25	15U300	LOKWASHER REGULAR 1/2 ZINC PLT	
all	26	15K086	HXCAPSCR 3/8-16NCX3/4 SS18-8	
all	27	15U246	FLATWASHER 1"ODX25/64IDX1/8"30	
all	28	15U260	LOCKWASHER MEDIUM 3/8 SS18-8	
all	29	15K083V	BUTSOKCAPSCR 3/8-16X3/4 SS18-8	
all	30	15P185	TRDCUT-F HXHD 1/4-20UNC2AX3/4	
C	31	02 24056	4840M7K BELTGUARD APEX	
B	32	W2 25134	7246M5K JACKSHAFT COVER WLMT	
AB	33	02 22706	6836M5K BELT COVER LIFT PLATE	



# Installation

2


## 48040H\_, 68036H\_, & MWF100\_ Washer Extractor Installation

### 1. Handling


**Note 1:** Once the machine is given to the carrier for delivery, it is solely the responsibility of the carrier to ensure that no damage occurs during transit. In addition to readily apparent damage, carriers are liable for concealed damage. Do not hesitate to file a claim with the carrier if the machine is damaged in any way during shipment. Milnor will be glad to assist you in filing your claim, but is not responsible for any shipping damage to the machine once it has been delivered to the carrier in good condition.

1. Remove the protective coverings (leaving the machine on shipping skids) and examine carefully for possible shipping damage. If the machine is damaged, notify the transportation company immediately.
2. Attach chains as shown in [Figure 2](#).

**Figure 1: Where To Lift**



**Figure 2: Rigger liable for damages**



**CAUTION 1: Machine damage hazard**—Improper placement of pickup chains can cause direct or indirect damage to machine.

- Use a 4 point pickup (as shown in [Figure 2](#))
- Use long pickup chains to prevent racking and/or twisting machine frame

### 2. Moving the Machine into Place

1. Use skids for fork lifting. If possible, leave the machine on shipping skids until it is near its final position. Once skids are removed, carefully place forks under base. Do not allow the forks to come in contact with valves, piping, motors, etc., located under the machine. Do not push or hit the shell front when uncrating or installing the machine as it may cause the door to leak.
2. Never push, pull, lift, jack, or exert pressure on any components that protrude from the machine frame (shell front, door, electric boxes, controls, guards, conduits, conveyors, piping, valves, drains, vents, tilt frames, etc.).
3. Do not pull on door conduit to help move the machine as the door switch may require readjustment.

### 3. Site Requirements

#### 3.1. Space Requirement


1. All openings and corridors through which equipment must pass during installation must be large enough to accommodate the width and the height of the machine as shown on the dimensional drawings. It is occasionally possible to reduce the overall dimensions by removing piping or other special modifications. Consult Milnor for additional information.
2. Sufficient clearance must be provided for normal operation and maintenance procedures.

#### 3.2. Operational Requirements

1. Allow sufficient ventilation for the heat and vapors of normal operation to dissipate.
2. Provide easy access to controls. Operators must be able to view all status lights and reach all controls associated with the machine (e.g., electrical power connections, water and steam shutoffs, etc.)

- 3.3. Foundation Requirement**—The floor and/or all other support components must have sufficient strength and rigidity with due consideration for the natural or resonant frequency thereof to withstand the fully loaded weight of the machine, including the wet goods and any repeated sinusoidal (rotating) forces generated during its operation. Determining the suitability of floors, foundations, and other supporting structures normally requires analysis by a qualified structural engineer.

**Figure 3: Vibration warning**



**CAUTION 2: Machine damage hazard**—Improperly installed suspension type machines can “walk” out of position during extract (Figure 3), endangering personnel and damaging equipment.

- Roughen floor. Install anchor bolts and grout under all base pads to prevent “teeter-totter” and sideways movement.
- Remove shipping restraints after machine is in place. Failure to remove all restraints (usually painted red) will cause malfunctions and damage. Restraints may be located behind access covers. These include, but are not limited to:
  - Cylinder hold-down bolts, brackets, straps and/or blocking. Replace all fasteners which are part of the machine structure.
  - Vibration safety switch restraint.

## 4. Setting Procedures

To protect against lateral creeping of the machine during operation (due to vibration), roughen the area of the floor where the grout will be applied. Anchor bolts are required.

1. With the machine near the final location, unbolt the shipping skids. Observing all precautions, lift the machine off its skids and lower the machine onto blocking. Shim the blocking until the machine is level and approximately 1" (25) clearance exists under each base pad. Install anchor bolts as shown on the dimensional drawing, but do not tighten bolts until grout is completely dry.
2. Apply grout between the existing foundation floor and the base pads, observing the following considerations:
  - Use only industrial strength non-shrinking grout. Pack or trowel by hand.
  - If the grout after mixing is too thin (causing it to flow from under the base pads) install temporary cardboard framing around pads to retain the grout until it cures.



**CAUTION 3: Vibration and Malfunction Hazard**—Voids under the base pads can magnify vibration and cause unsatisfactory operation.

- Grout must displace total clearance between base pads and existing foundation floor.
  - Voids must not exist.
3. Tighten anchor bolts evenly using only one-quarter turn on each bolt before moving to the next one. While tightening, frequently skip from front to back and right to left to insure uniform tension. After tightening all bolts, check each bolt at least twice during the first week of operation.

## 5. Before Running Machine



**CAUTION 4: Machine Damage Hazard**—Machine can be damaged if shipping restraints are improperly utilized. These include various bolts, brackets, weldments and safety stands (painted red), and the vibration safety switch (tie wrapped).

- DO NOT remove shipping restraints until installation is complete.
- DO remove all shipping restraints before operating machine.

All machines are shipped with the shell locked to the mid frame by four hold down ring weldments (two per side). Each weldment consists of a cone and cup arrangement. When shipped, the shell mounted cone and the mid-frame mounted cup are locked together using a center bolt and shims inserted under the weldment cup (Figure 4). Remove the center bolt and shims before placing machine in service. Re-install the weldment as shown in Figure 4 and store the shims underneath the mid frame as shown in Figure 5. Retain center bolts in the event that the machine is moved.

Figure 4: The hold down weldment





Figure 5: Shims stored under the mid frame



## 6. Before Tilting Machine



**WARNING** [5]: **Crush/Sever hazard**—Tilting mechanisms can crush or sever parts of your body caught in them.

- Install safety stands before performing maintenance under a tilted machine.
- NEVER test or operate (manually or automatically) any machine function with any portion of a person's body under the tilted machine - even if the safety stands are installed.




**WARNING [6]: Crush/Sever hazard**—Tilt machines with tilt wheels/cradles may lunge forward or rearward and even fall over if the non-tilted ends are raised out of their cradles - killing/injuring personnel and/or damaging property.


- NEVER manually tilt (lift) both ends of the machine at the same time. One end must always be seated in its cradle.
- ALWAYS visually inspect the tilt wheels to be sure they are all fully seated in their cradles before each manual tilt up.
- Pneumatic valve manual operation must be done by trained competent maintenance personnel who thoroughly understand the system and all the consequences of manual operations.
- ALWAYS understand beforehand all the consequences of manually operating pneumatic valves.
- NEVER permit operation with malfunctioning tilt limit switches

Tilting machines leave the factory with 4 hold-down bolts (two per side) locking the tilting mid-frame to the floor frame (Figure 7). Remove these bolts after machine is anchored and grouted, service connections are complete and all other installation steps are complete.

**Figure 6: Safety stand in place**



**Figure 7: Tilting Mid Frame to Floor Locking Bolts**



— End of BIIFLI01 —

## About the Forces Transmitted by Milnor® Washer-extractors

During washing and extracting, all washer-extractors transmit both static and dynamic (cyclic) forces to the floor, foundation, or any other supporting structure. During washing, the impact of the goods as they drop imparts forces which are quite difficult to quantify. Size for size, both rigid and flexibly-mounted machines transmit approximately the same forces during washing. During extracting, rigid machines transmit forces up to 30 times greater than equivalent flexibly-mounted models. The actual magnitude of these forces vary according to several factors:

- machine size,
- final extraction speed,
- amount, condition, and type of goods being processed,
- the liquor level and chemical conditions in the bath preceding extraction, and
- other miscellaneous factors.

Estimates of the maximum force normally encountered are available for each Milnor® model and size upon request. Floor or foundation sizes shown on any Milnor® document are only for on-grade situations based only on previous experience without implying any warranty, obligation, or responsibility on our part.

### 1. Rigid Machines

Size for size, rigid washer-extractors naturally require a stronger, more rigid floor, foundation, or other supporting structure than flexibly-mounted models. If the supporting soil under the slab is itself strong and rigid enough and has not subsided to leave the floor slab suspended without support, on grade installations can often be made directly to an existing floor slab if it has enough strength and rigidity to safely withstand our published forces without transmitting undue vibration. If the subsoil has subsided, or if the floor slab itself has insufficient strength and rigidity, a deeper foundation, poured as to become monolithic with the floor slab, may be required. Support pilings may even be required if the subsoil itself is “springy” (i.e., if its resonant frequency is near the operating speed of the machine). Above-grade installations of rigid machines also require a sufficiently strong and rigid floor or other supporting structure as described below.

### 2. Flexibly-mounted Machines

Size for size, flexibly-mounted machines generally do not require as strong a floor, foundation, or other supporting structure as do rigid machines. However, a floor or other supporting structure having sufficient strength and rigidity, as described in [Section 3](#), is nonetheless vitally important for these models as well.

### 3. How Strong and Rigid?

Many building codes in the U.S.A. specify that laundry floors must have a minimum live load capacity of 150 pounds per square foot (732 kilograms per square meter). However, even compliance with this or any other standard does not necessarily guarantee sufficient rigidity. In any event, it is the sole responsibility of the owner/user to assure that the floor and/or any other supporting structure exceeds not only all applicable building codes, but also that the floor and/or any other supporting structure for each washer-extractor or group of washer-extractors actually has sufficient strength and rigidity, plus a reasonable factor of safety for both, to support the weight of all the fully loaded machine(s) including the weight of the water and goods, and including the published 360° rotating sinusoidal RMS forces that are transmitted by the machine(s). Moreover, the floor, foundation, or other supporting structure must have sufficient

rigidity (i.e., a natural or resonant frequency many times greater than the machine speed with a reasonable factor of safety); otherwise, the mentioned 360° rotating sinusoidal RMS forces can be multiplied and magnified many times. It is especially important to consider all potential vibration problems that might occur due to all possible combinations of forcing frequencies (rotating speeds) of the machine(s) compared to the natural frequencies of the floor and/or any other supporting structure(s). A qualified soil and/or structural engineer must be engaged for this purpose.

**Figure 1: How Rotating Forces Act on the Foundation**





Figure 1 above is intended to depict both on-grade and above-grade installations and is equally applicable to flexibly-mounted washer-extractors, as well as to rigid models installed either directly on a floor slab or on a foundation poured integrally with the slab. Current machine data is available from Milnor® upon request. All data is subject to change without notice and may have changed since last printed. It is the sole responsibility of every potential owner to obtain written confirmation that any data furnished by Milnor® applies for the model(s) and serial number(s) of the specific machines.

— End of BIWUI02 —



# Shipping Brackets

48040M7K, 68036M5K, 72046M5K



# Shipping Brackets

48040M7K, 68036M5K, 72046M5K

<b>Parts List—Shipping Brackets</b>				
Find the correct assembly first, then find the needed components. The item letters (A, B, C, etc.) assigned to assemblies are referred to in the "Used In" column to identify which components belong to an assembly. The item numbers (1, 2, 3, etc.) assigned to components relate the parts list to the illustration.				
Used In	Item	Part Number	Description	Comments
-----ASSEMBLIES-----				
	A	GSB48004	4840M7K SHIPPING/SAFETY BRACKETS INSTL	48040M7K
	B	GSB68002	6836M5K SHIPPING/SAFETY BRACKETS INSTL	68036M5K
	C	GSB72001	7246M5K SHIPPING/SAFETY BRACKETS INSTL	72046M5K
-----COMPONENTS-----				
A	1	W2 24151	4840M7K SHELL HOLD DOWN WLMT-SHIPPING	48040 ONLY
BC	1	W2 22832	SHELL HOLD DOWN WLMT-SHIPPING	
A	2	02 24152	4840M7K SHELL HOLD DOWN SPACER-SHIPPING	
B	2	02 22834	SHELL HOLD DOWN SPACER-SHIPPING	
A	3	02 24153	4840M7K SHELL HOLD DOWN SHELF	
A	4	02 24050	4840M7K LOCK DOWN FRAME BRKT	
B	4	02 22710	6836M5K LOCK DOWN FRAME BRKT	
C	4	02 25120	7246M5K LOCK DOWN FRAME BRKT	
all	5	W2 22811	6836M5K SHIPPING TIE DOWN POINT WLMT	
all	6	17R031A19A	THRD ROD 1-8 X 19" GR8 ZNPL	
all	7	15U390P	FLATWASHER(USS STD) 1" ZNC P	
all	8	15G250	HXNUT 1-8UNC2B SAE ZNC GR2	
all	9	15U400	LOCKWASHER MEDIUM 1" ZINCPL	
all	10	15K255ZN	HXCPSCR1"-8UNCX1.5"L GR5 ZNPLT	
all	11	15K129	HEXFLGSCR 1/2-13X1-1/4ZN. GR 5	
all	12	15G222B	HEXFLGNUT 1/2-13 ZINC SERRATED	
all	13	15U280	FL+WASHER(USS STD)1/2 ZNC PL+D	
all	14	15G240	HXNUT 3/4-10UNC2B SAE ZINC GR2	
all	15	15U340	LOCKWASH MEDIUM 3/4 ZINCPL	
all	16	15U320P	FLATWASHER(USS STD) 3/4" ZNC P	

## Service Connections

Required service connections (depending on the machine model and optional equipment) are as follows:

1. Piped inlets and outlets are as listed in the “Table of Piped Inlets” and “Table of Piped Outlets.” The sizes and locations of piped inlets and outlets are shown on the dimensional drawings for the machine.
2. Electric power connections.

### 1. Requirements for Piped Connections

1. Inlet pressures must be within the minimum/maximum range specified. Pressures outside of the specified range may cause the machine to operate inefficiently or malfunction, and may damage machine components.



**CAUTION [1]: Machine Damage**—Valve bodies will be ruined if twisted and distorted.

- Hold the connection side of the valve with a wrench when connecting plumbing.
2. When connecting water and steam inlets, always install unions and shut-off valves at the point of connection to permit removal of the machine components for servicing, if necessary.
  3. If available, use hot water for the supply injector connection. Hot water supply must be 10 PSI minimum (0.70 kilogram/centimeter) and must not contain steam. After making the connection, set the pressure regulator for a maximum of 28 PSI (1.96 kilograms/centimeter), when there is no water flow.
  4. If valve is accidentally piped to the wrong water line, merely interchange the air tube (if valve is air operated). Never interchange any electrical connections.
  5. Some of the water inlet and/or steam valves on machines may be of the “ball valve” construction. The flow rate of a ball valve is far greater than that of an equal size globe valve. Do not use globe type shut-off valves in front of ball valves unless the globe valve is selected in accordance with the following table.



**CAUTION [2]: Machine Damage Hazards**—Pumped chemical systems, if not properly installed, can cause corrosion damage.

- See the reference manual for precautions and additional information before making any chemical connections.

**Table 1: Valve sizes and their equivalents**

Ball valve size	Equivalent globe valve size
1-1/4" normal flow	2-1/2"
1-1/2" normal flow	2-1/2"
2" normal flow	3"

### 2. Piped Inlet Specification

Piped inlet requirements are as follows (see dimension drawings for sizes and locations of connection points):

**Table 2: Table of Piped Inlets**

Description of Connections	Source Requirements	Piping Specifications, Comments
<b>Compressed air--hydraulic tilting and non-tilt models</b>	1/4" NPT, 85 - 110 PSI (5.97 - 7.73 kg.sq. cm.)	Pipe material per plumbing code
<b>Cold water inlet</b>	2" NPT 10 - 75 PSI (0.7 - 5.27 kgs.sq. cm.)	
<b>Hot water inlet</b>		
<b>Steam inlet</b>	1 - 1/4" NPT 30 - 115 PSI (2.10 - 8.08 kgs. sq. cm.)	
<b>Compressed air--air tilting models</b>	3/4" NPT 85 - 110 PSI (5.97 - 7.73 kg.sq. cm.)	
<b>Compressed air--hydraulic tilting and non-tilting models</b>	1/4" NPT 85 - 110 PSI (5.97 - 7.73 kg.sq. cm.)	

2.1. **Piped Outlet Specification**—Piped outlet requirements are as follows (see dimensional drawings for sizes and locations of connection points):

**Table 3: Table of Piped Outlets**

Description of Connections	Destination Requirements or Description	Piping Specifications
Drain	8" OD (not tilted)	Rubber hose, PVC, or other approved material per plumbing code
Vent	4" Diameter	

2.2. **Precautions for Electrical Connections**



**WARNING 3: Electrocutation Hazard**—Contact with high voltage can kill or seriously injure you.

- All electrical connections must be made by a competent electrician.
  1. Connections must be made by a competent electrician.
  2. See the fuse and wire sizing information in the schematic manual and on the machine nameplate.
  3. “Stinger leg” if any, must be connected to terminal L3, never to terminals L1 or L2.
  4. Only use BUSSMAN FUSETRON FRN (up to 250V), FRS (up to 600V), or similar lag fuses. The nameplate fuse sizes must not be applied to standard fuses.
  5. See nameplate for fuse and wire size. For wire runs more than 50 feet (15.24 meters), increase by one wire size per each additional 50 feet.
  6. Make the power and liquid supply electrical connections within junction box on the rear of the machine.
  7. Verify all motor rotation as shown in FIGURE 1 (See the operating and troubleshooting manual for more information). If the cylinder turns in the wrong direction, see note below.

**Note 1:** Before shipping, all motors are properly phased for correct rotation. It is possible to reverse the direction of rotation in a three-phase machine by interchanging the incoming power leads. Therefore, the rotation of a three-phase machine must be observed and corrected when the machine is first installed. If it is necessary to reverse the rotation, simply swap the incoming power lines to the


machine (never move L3 if L3 is a stinger leg). Never attempt to reconnect motors or the motor control devices.



**CAUTION 4: Component Damage**—Voltage fluctuations of more than 10% above or below the specified voltage for your machine can damage electrical components, especially motors.

- Any such conditions should be corrected prior to commissioning your machines.

**Figure 1: Rotation Direction during Drain and Extract**



**2.3. Electric Power Connections**—The customer must furnish a remotely mounted switch with lag type fuses, circuit breakers and wiring between the electrical service box and the junction box on the machine. The sizes of these fuses and wires, along with the motor fuses supplied with the machine, depend on the machine voltage. See the fuse and wire sizing information in the schematic manual and on the machine nameplate.

— End of BIIFUI01 —



Drive

3

BIIFLM05 (Published) Book specs- Dates: 20151104 / 20160205 / 20160205 Lang: ENG01 Applic: IFL IH4

# Drive Components and Belt Installation



This document uses Simplified Technical English.  
Learn more at <http://www.asd-ste100.org>.

## 1. Drive Components Identification

Figure 1: General View: 4840H7N, 4840H7W, 4840H7R, 4840H7K , 4840M7K








Figure 2: Detailed views



**Table 1: Parts List—Drive Components and Belt Installation**

Find the assembly for your machine and the letter shown in the "Item" column. The components for your machine will show this letter or the word "all" in the "Used In" column. The numbers shown in the "Item" column are those shown in the illustrations.				
Used In	Item	Part Number	Description/Nomenclature	Comments
Assemblies				
	A	GDB48002	Installation Group; Drive chart; 4840H7N, 4840H7W	4840H7W, 4840H7N, 4840H7R, 4840H7K, 4840M7K
Components				
all	1	X2 21925	Pulley; Cylinder	
all	2	X2 21923	Pull-up plate	
all	3	56Q1RSD	Bushing; 1+7/8"	
all	4	56044B4SD	V-pulley	
all	5	56VB147XB4	V-belt	
all	6	15K232A	Bolt; Hex head; 3/4-10X2	
all	7	15U321H	Washer; Flat; 3/4	

## 2. Belt Installation and Tension Procedure

When you install a new drive belt, the belt will increase in length when it first operates. Do this procedure again after 24, 80, and 160 hours of operation to get the correct tension.

1. Remove electrical power from the machine. Refer to applicable safety codes.
2. Install the belt loose on the pulleys, or make the belt loose, if it is tight.
3. Measure the outer diameter of the belt accurately. If this is not the first time that you did this procedure, the belt will be longer this time.
4. Calculate the correct length of the belt when it is tight, as follows:
  - If you installed a new belt this day, multiply the length by 1.003. This gives the necessary length when you make a new belt tight.

*Example: 152 inches (3861 millimeters) X 1.003 = 152.46 inches (3872 millimeters)*

- If the belt is not new (operated), multiply the length by 1.005. This gives the necessary length when you make an operated belt tight.

*Example: 152.2 inches (3866 millimeters) X 1.005 = 152.96 inches (3885 millimeters)*


5. Make a loop of the correct length with flexible wire. Attach the ends together tightly.
6. Put the wire loop around the belt.
7. Make the belt tight until there is no play in the wire loop.

— End of BIIFLM05 —

# Motor Mount

48040M5K, 6836M5K


Figure 1: 68036M5K



# Motor Mount

48040M5K, 6836M5K

Figure 2: 48040M7K



### Parts List—Motor Mount

Find the correct assembly first, then find the needed components. The item letters (A, B, C, etc.) assigned to assemblies are referred to in the "Used In" column to identify which components belong to an assembly. The item numbers (1, 2, 3, etc.) assigned to components relate the parts list to the illustration.

Used In	Item	Part Number	Description	Comments
-----ASSEMBLIES-----				
	A	GDB68001	6836M5K DRIVE BASE	68036M5K
	B	GDB48003	4840M7K DRIVE BASE	48040M7K
-----COMPONENTS-----				
all	1	02 11311B	MTR BASE PIVOT CLAMP 4226QHE	
all	2	X2 11311P	PAINT=JACKBOLT CLAMP, 6836F	
all	3	C2 11311C	CAST=JACKBOLT CLAMP, 6836F	
all	4	15K227B	HEXCAPSC 5/8-11X5.5 GR8 ZINC	
all	5	17W030	SPHERICAL WASHER SET 5/8 M/F	
all	6	15U315	LOKWASHER MEDIUM 5/8 ZINCPL	
all	7	15G238	HXNUT 5/8-11UNC2B SAE ZINC GR2	
all	8	17R031A13A	THRD ROD 1-8 X 13" GR8 ZNPL	
all	9	15G250	HXNUT 1-8UNC2B SAE ZNC GR2	
all	10	15U393	FLTWASH 1" HARD ASTM F436	
all	11	17W060	SPHERICALWASHER SET 1" M/F	
all	12	15K226L	HEXCAPSCW 5/8-11X3.5 GR8 ZINC	

# Motor Mount

48040M5K, 6836M5K

### Parts List—Motor Mount

Find the correct assembly first, then find the needed components. The item letters (A, B, C, etc.) assigned to assemblies are referred to in the "Used In" column to identify which components belong to an assembly. The item numbers (1, 2, 3, etc.) assigned to components relate the parts list to the illustration.

Used In	Item	Part Number	Description	Comments
all	13	03 17130	4840M EXTRACTOR MOTOR PLATE	
A	14	W3 17142	BRAKE TEFC MOTOR TORQARM-4840M	
B	14	02 21859C	BRAKE TORQUE ARM,4840 CAST	
all	15	15K151	HXCAPSCR 1/2-13UNC24X1.25 GR5	
all	16	15U300	LOKWASHER REGULAR 1/2 ZINC PLT	
all	17	15U490	FLTWASH 1+1/2X17/32X1/4 ZINC	
all	18	15G230	HXNUT 1/2-13UNC2B SAE ZINC GR2	

## Disk Brake Maintenance



This document uses Simplified Technical English.

Learn more at <http://www.asd-ste100.org>.

**NOTICE P1:** "Remove power from the machine" means use the necessary safety procedure for your location. In the USA, this is the OSHA lockout/tagout (LOTO) procedure. More local requirements can also apply.

You can do these types of maintenance on the disk brake:

- do an inspection of the brake as specified in the maintenance schedule,
- replace the friction pads,
- do an overhaul on the calipers,
- replace the hydraulic fluid,
- adjust the connection between the brake cylinder and the air cylinder.

For the first four types of maintenance, you must remove air from (bleed) the hydraulic circuit.

Section 6 tells how to operate the disk brakes. You can use it in some of the types of maintenance in this procedure.




**WARNING 2: Risk of injury or death** —A machine in operation without safety guards is dangerous.

- You must be an approved maintenance technician.
- Use special caution when this instruction tells you to do work with electrical power on. Remove power from the machine for all other maintenance. Obey safety codes.
- Replace all guards and covers.

**Tip:** During parts of this procedure when you open up the calipers or hydraulic lines, put a cloth under the calipers to catch hydraulic fluid and parts that will fall. For safety, fully remove spilled hydraulic fluid after brake maintenance. This will help you easily identify leaks.

Figure 1: A typical hydraulic brake system



## 1. The Inspection of the Brake

**Note 1:** The brakes shown in this document can look different from your equipment.

**Note 2:** Do this inspection when the maintenance schedule tells it is necessary. Do this inspection after you replace friction pads or do a caliper overhaul.

- 1.1. Examine the fluid in the reservoir.** —Change the hydraulic fluid if it smells, has contamination, or has an unusual color. See [Section 4](#).

**Note 3:** Brake fluid can become defective from heat in the brake system. Brake fluid absorbs water from air. Water in the brake system causes corrosion.

If necessary, add new DOT 3 fluid to 0.25 inch (6.35 millimeters) from the top of the reservoir. Follow the precautions on the container.

- 1.2. Examine the rotor disk surface (Figure 1, item 5).** —Replace the disk if it is worn or if it is not flat.
- 1.3. Examine the brake pads (Figure 2, item 4).** —To do this, you will remove/replace the calipers and bleed the hydraulic system. See [Section 3](#) and [Section 4](#).
1. **Remove power from the machine (see Notice P1).**
  2. Remove the bolts ([Figure 1](#), item 9) that attach the caliper halves ([Figure 1](#), item 7).
  3. Remove the caliper halves.
  4. Replace the pads as told in [Section 2](#) if
    - the pads make an unusual noise when you apply the brake
    - if the rotor is worn or damaged
    - if the pad thickness is less than 1/16 inches (2 mm) ([Figure 2](#), item 14) above the mounting screw ([Figure 2](#), item 3). Always replace the two brake pads at the same time.
  5. Put the caliper halves in their positions on the brake assembly. Tighten the mounting bolts to 30 foot-pounds (41 Newton-meters).
  6. Bleed the hydraulic systems as told in [Section 4.4](#).
  7. Supply electrical power to the machine.
- 1.4. Examine the condition of all of the brake system.**
1. Make sure that brake mounting components are tightly installed.
  2. Make sure that fittings are tight. Make sure that there are no leaks.

## 2. How to Do a Friction Pad Replacement

You must have the necessary replacement friction pads for your machine. Refer to the brake parts document in your machine manual. You will find part numbers for components or overhaul/repair kits. The overhaul/repair kit contains O-rings, pads, and other components.

1. **Remove power from the machine (see Notice P1).**
2. Remove the used fluid. See [Section 4.3](#).
3. Remove the two bolts that attach the caliper ([Figure 1](#), item 9) and the two caliper halves ([Figure 1](#), item 3) to get access to the friction pads. Do not disconnect the hydraulic line ([Figure 1](#), item 6).
4. If there are leaks, see [Section 3](#) “How to Do a Caliper Overhaul ” before you continue.
5. Replace each friction pad:
  - a. Remove the brass screw ([Figure 2](#), item 3) that attaches the pad to the piston.
  - b. Attach the new pad to the piston. Tighten the screw.
  - c. Make sure that the screw head is fully in the recess in the pad.
6. Make sure that the connection o-rings are clean and in their positions ([Figure 2](#), item 7).





## Disk Brake Maintenance

7. Put the caliper halves in their positions on the brake assembly. Tighten the mounting bolts to 30 foot-pounds (41 Newton-meters).
8. Bleed the brake. See [Section 4 “How to Change Hydraulic Fluid and Remove \(Bleed\) Air from the Brake Circuit”](#).
9. Supply electrical power to the machine.

### 3. How to Do a Caliper Overhaul

Figure 2: The Caliper Components

<p><b>The Expanded View (Shows the Piston and the O-rings)</b></p> 	<p><b>Legend</b></p> <ol style="list-style-type: none"> <li>1. The bolts to attach the caliper (Figure 1, item 9)</li> <li>2. Caliper body halves (Figure 1, item 3)</li> <li>3. Brass screw</li> <li>4. Friction pad</li> <li>5. Piston</li> <li>6. The Piston O-ring</li> <li>7. The connection O-ring and its position</li> <li>8. Plug for the hydraulic inlet</li> <li>9. A hydraulic inlet (connected on one caliper, a plug (item 8) on the other)</li> <li>10. The hole in the spacer</li> <li>11. Washer</li> <li>12. One of the four valves to bleed the fluid</li> <li>13. Nut</li> </ol> <p>14. The pad thickness must be more than than 1/16 inches (2 mm) above item 3</p>
<p><b>The Caliper and the Pad</b></p> 	
<p><b>Fittings for the Hydraulic Inlet</b></p> 	<p><b>Look at the pad thickness above the top of the screw</b></p> 

**Tip:** Hydraulic fluid flows from one caliper to the other caliper. Fluid flows through the connection O-rings (Figure 2, item 7) and the hole in the spacer (Figure 2, item 10). When you disconnect the calipers, hydraulic fluid can flow from the hole at the connection O-rings. Air can get in the line. After you connect the calipers, you must bleed the system.

You must have the necessary kit for the overhaul of your machine. Refer to the brake parts document in your machine's manual.

1. **Remove power from the machine (see Notice P1).**
2. Get access to the caliper halves (see [Section 2](#)).
3. Do an overhaul on each caliper:
  - a. Remove and discard the connection O-rings ([Figure 2](#), item 7) on the caliper bodies.
  - b. Apply compressed air to the fitting for the hydraulic inlets (see [Figure 2](#), item 8) to push the pistons out.
  - c. Replace the piston O-rings ([Figure 2](#), item 6).
  - d. Put the pistons in the caliper body. Carefully tap the pistons with a wood or rubber hammer to install it.
  - e. Replace the connection O-rings. ([Figure 2](#), item 7)
  - f. Replace the friction pads (see [Section 2](#)).
4. Replace the caliper halves as specified in [Section 2](#).
5. Bleed the brake circuit (see [Section 4](#)).
6. Supply electrical power to the machine.

## 4. How to Change Hydraulic Fluid and Remove (Bleed) Air from the Brake Circuit

### 4.1. Risks and Precautions



**WARNING [3]: Risk of injury** —Machine power must be on for these procedures.

- Stay away from operating mechanisms.



**CAUTION [4]: Risk of injury and damage** —This procedure releases pressurized brake fluid.

- Keep brake fluid out of your eyes and mouth. Wear eye protection.
- Follow procedures carefully to prevent damage to the face of the disk or the pistons.



**CAUTION [5]: Risk of malfunction** . —Air in hydraulic fluid will compress. Compressed air in the brake line will cause brake malfunctions.

- Remove (bleed) air from the brake circuit before you operate the machine.


### 4.2. Requirements —These personnel and items are necessary for this procedure:

- two technicians
- an 8-ounce container of new brake fluid
- Alternative procedures to remove air and used brake fluid:
  - » a suction pump (faster procedure) (see [Figure 3](#))
  - » with pressure in the hydraulic cylinder and gravity (see [Figure 4](#))


**Tip:** The Vacula suction pump can do the work more quickly than by gravity and pressure in the hydraulic cylinder. It is also cleaner because all of the hydraulic fluid goes into the container supplied. It helps you not spill the hydraulic fluid.

- If you use a suction pump as shown in [Figure 3](#), follow the manufacturer's instructions.
- If you use the tools as shown in [Figure 4](#), follow the instructions in [Section 4.3](#) and [Section 4.4](#).

**Figure 3: Pumps Used to Remove Hydraulic Fluid Quickly**



**Figure 4: Typical Tools to Remove Air (Bleed) Brakes and Used Hydraulic Fluid**



**4.3. Use the tools in Figure 4 to remove the used hydraulic fluid and clean the line.** —Do these steps:

1. Use a suction tool (Figure 4, item 4) to remove the used fluid from the reservoir. Clean the contamination.
2. Connect the tubing (Figure 4, item 2) and container (Figure 4, item 1) to the valve on the caliper (Figure 1, item 7).
3. Open the valve.
4. Add new fluid to flush out the lines.
5. Apply/release the brake (See Section 6) approximately 5 to 15 times. This will flush the used fluid out of the lines.
6. Close the valve.

**Note 4:** These steps will cause air to go into the line.

**4.4. Add new hydraulic fluid and remove (bleed) air from the brake circuit.**

**Note 5:** This procedure uses pressure in the hydraulic cylinder and the tools in Figure 4.

1. Fill the reservoir with new DOT 3 brake fluid. When you do the remaining steps, continue to add new fluid to the reservoir. Do not let the reservoir become more than half empty. You must make sure that the reservoir has fluid to prevent air flow into the system from the reservoir.
2. Apply electrical power to the machine. Release the brake.
3. See the part of the machine reference manual that tells how to operate the outputs manually.

4. Put a small quantity of new brake fluid (approximately inches (50 mm)) in the 12 ounce container (Figure 4, item 1).
5. Do these steps for each bleed valve (Figure 1, item 1) . Two technicians are necessary. This will move the fluid in one direction and push air out of the line:
  - a. Attach a clean tube to the valve. Put the other end in the container (Figure 4, item 1) below the fluid.
  - b. Make sure that the reservoir is full of fluid.
  - c. Apply the brake (See section 6).
  - d. Open the bleed valve. (Figure 2, item 12)
  - e. Look for air bubbles in the container when you push the air and fluid out through the tube.
  - f. Close the valve.
  - g. Release the brake.
  - h. Continue the steps b through g until no more air comes out of the line.
6. Add fluid to the top of the reservoir. Replace the cap.
7. Operate the brake many times. Make sure that it operates correctly.

## 5. How to Adjust the Connection between the Brake Cylinder and the Air Cylinder

If you removed the brake cylinder or the air cylinder, you must adjust this connection.

Figure 5: The Connection between the Brake Cylinder and the Air Cylinder







Figure 6: The Adjustment between the Brake Rod and the Air Cylinder



### 5.1. Adjust for maximum rod travel.

1. Operate the master switch to energize control power.
2. Make sure that the air pressure that releases the brake (Figure 7, item 1) is 85 -100 PSI ( 5.95 - 07.0 kg/cm-cm).
3. Make sure that the nuts that lock the rods together (Figure 5, item 5) are loose.
4. Release the brake (see Section 6). Let the air cylinder rod fully retract into the air cylinder as shown in Figure 6, A.
5. Turn the brake rod into the air cylinder rod until the brake rod comes out of the brake cylinder fully. See Figure 6, B.
6. Lock the brake rod (Figure 5, item 2) to the air cylinder rod (Figure 5, item 3) with two nuts (Figure 5, item 5).

### 5.2. Make sure that the brake will continue to operate while the pads wear.

1. Release the brake. On the view slot, put a mark at the position of the lock nuts. (Figure 6, item M1).
2. Apply the brake. See Section 6.
3. Put a mark at the position of the lock nuts when the brake is applied. This can be at position M2a, M2b, or between M2a and M2b. When the pads wear this position will move.
4. Make sure that the distance the rod moves when you apply the brake is 0.75 to 1.0 inches (19-25 mm). If the travel is more than this, the brake piston can hit the mechanical stop before the brake engages fully. This condition is shown in Figure 6 , E (dimension TT).

## 6. Operation of Brake Systems

Look at the electrical schematics of your machine to find how your brake is controlled. Some machines release the brake when you close the door. Some machines have a control relay to release or apply the brake.

### 6.1. How to Apply the Brake for Machines with a "Break Release" Output

1. Turn the "brake release" control output off to de-energize the air valve to remove air pressure to the air cylinder (Figure 1, item 1).
2. With no air pressure, a spring in the air cylinder will apply force to the hydraulic cylinder (Figure 1, item 8). This will apply pressure to the brake pads (Figure 2, item 4) against the rotor disk (Figure 1, item 5). (Figure 6, item C,D)

**Note 6:** If electrical power or compressed air is missing, hydraulic pressure will apply the brake.

### 6.2. How to Release the Brake for Machines with a "Brake Release" Output

1. Turn the control output called "brake release" on to energize the air cylinder valve.
2. Air pressure compresses the spring and releases the brake. (Figure 6, item B)

**6.3. How to Apply and then Release the Brake Quickly** —There are two air tubes at (Figure 1, item 1). One supplies compressed air from an air valve. The other sends this compressed air to a pressure switch. If you remove one of the two tubes when compressed air is there, you will apply the brake.


1. Disconnect the air tubing (Figure 1, item 1).



2. Turn the "brake release" output on. The air valve will supply compressed air to one of the tubes. (Figure 1, item 1).
3. Quickly move one of the compressed air tubes (Figure 1, item 1) on and off the air cylinder.
4. After you complete this procedure, connect the air tubing.

#### 6.4. How the Brake Operates on Divided Cylinder Machines

Figure 7: A Typical First and Second Brake on a Divided Cylinder Machine





- On divided cylinder machines, two pair of air tubes connect to different ends of the air cylinder.
- When the cylinder turns, air pressure at Figure 7, item 1 compresses the spring and releases the brake.
- When you operate the stop control, air pressure at 1 is removed. Then the spring in the air cylinder applies the brake.
- If you open the door, the 2nd brake is applied. Then the air pressure at Figure 7, item 2 and the spring apply the brake.

**6.5. The Second Brake** —If your machine has a second brake which uses air pressure and spring pressure, it will have a pressure regulator. Make sure that you adjust the air pressure of the second brake (Figure 7, item 2) to 10 – 12 PSI (0.7-0.84 kg/cm-cm).

— End of BIEUUM01 —


# Disc Brake

M9V4840\_, M7V4836\_, 68036F\_, 68036H5\_, 48040M7K, 68036M5K, 72046M5K




# Disc Brake

M9V4840\_, M7V4836\_, 68036F\_, 68036H5\_, 48040M7K, 68036M5K, 72046M5K



**Caliper Repair Kit:**  
A double caliper is shown.  
The repair kit is used for single calipers also.



\* - 2 per kit

# Disc Brake

M9V4840\_, M7V4836\_, 68036F\_, 68036H5\_, 48040M7K, 68036M5K, 72046M5K

## Parts List—Disc Brake

Find the correct assembly first, then find the needed components. The item letters (A, B, C, etc.) assigned to assemblies are referred to in the "Used In" column to identify which components belong to an assembly. The item numbers (1, 2, 3, etc.) assigned to components relate the parts list to the illustration.


Used In	Item	Part Number	Description	Comments
			-----ASSEMBLIES-----	
	A	GBR6836E	INST=DISC BRAKE 6836E	M9V4840, M7V4836 68036F_, 68036H5_
	B	GBR68002	6836M5K DISC BRAKE	6836M5K
	C	GBR72001	7246M5K DISC BRAKE	7246M5K
	D	GBR48003	4840M7K DISC BRAKE INSTALL	48040M7K
			-----COMPONENTS-----	
A,D	1	AAC4840F	AIRCYL=BRAKE ASSY, 4840F7	
B,C	1	AAC68001	AIRCYL=BRAKE ASSY, 6836F5A	
all	2	02 22417	48M7 BRAKE+PROX MNT BRKT	
all	3	W3 65238	*WLMT=MASTER BRAKE CYL BRKT	
all	4	54KMC1125U	MASTER CYLINDER	
all	5	52XY0ER004	STRADTUN3/16MJX1/8FP#2405-3-2	
all	6	54KC7961BG	BRAKE HOSE=1/8"X18"OAL #50612	
all	7	52AY0ER003	STR.1/4"MJICX1/8"MP#2404-4-2	
A,C	8	X2 04454	MACH=BRK CALPR MNT PLT,6836	
B	8	X2 04454A	6836M5K BRAKE CALIPER MOUNT PLATE	
ABC	9	X2 04458	BRAKE ROTOR HUB-6836E	
D	9	X2 21867	MACH=CALIPER DISK HUB,4840F	
ABC	10	X2 04459	BRAKE ROTOR-6836E	
D	10	X2 21866	MACH=CALIPER DISK, 4840F	
all	12	15K095	HXCPSCR 3/8-16UNC2AX1 GR5 ZINC	
all	13	15U255	LOCKWASHER MEDIUM 3/8 ZINCPL	
all	14	15G205	HXNUT 3/8-16UNC2B ZINC GR2	
all	15	15K151	HXCAPSCR 1/2-13UNC24X1.25 GR5	
all	16	15U300	LOKWASHER REGULAR 1/2 ZINC PLT	
all	17	15U490	FLTWASH 1+1/2X17/32X1/4 ZINC	
all	18	15G230	HXNUT 1/2-13UNC2B SAE ZINC GR2	
ABC	20	54KC7975	CALIPER HYD D/A 1/2"	
D	20	54KC7974	CALIPER HYD D/A 3/8 DISC RETRACT.	
all	22	15K214E	HXCAPSCR 5/8-11UNC2AX1.5 GR5 Z	
all	23	15U315	LOKWASHER MEDIUM 5/8 ZINCPL	
all	24	15K155A	SKCPSCR-1/2-13X1.5	
all	25	15K086G	HEXCAPSCR 3/8-24UNF X5" GRD. 8	
ABC	26	56Q1RE	1+7/8" BUSH VPUL QD TYPE E	
D	26	56Q1RSK	1+7/8" BUSH VPUL QD TYPE SK	
all	27	27A031C	UBOLT 1.25PIPE 5/16-18 ZINC	
all	28	02 10539	SPACER FOR PIPE ZINC PLATED	
all	29	02 175057	SPACER=BALLVALVE MTG	
all	30	15U210	LOKWASHER MEDIUM 5/16 ZINCPL	
all	31	15U200	FLATWASHER(USS STD) 5/16"ZNC P	
all	32	15G196	HXFLGNUT 5/16-18 ZINC	
all	33	54KC7961BSEAL	SEAL WASHER CONICAL,BRAKE HOSE	

# Air Cylinder Components and Installation

## 1. How To Get the Correct Piston Cup Shape


The figure that follows shows the correct shape and the incorrect shape of the piston cup. Tighten the locknut only until you can turn the piston cup and the washer on the stem with some resistance. If you tighten the locknut too much, this will cause the incorrect shape. This can stop air cylinder movement.

Figure 1: Compare Piston Cup Shapes



## 2. Air Cylinder Components

Figure 2: Air cylinder



Air Cylinder Components and Installation

**Table 1: Parts List—Air Cylinder Components**

Find the assembly for your machine and the letter shown in the "Item" column. The components for your machine will show this letter or the word "all" in the "Used In" column. The numbers shown in the "Item" column are those shown in the illustrations.				
Used In	Item	Part Number	Description/Nomenclature	Comments
Assemblies				
	A	AAC4840F	Assembly; Air cylinder; Two direction operation; Brake;	4840F_, 4840H_68036H_
	B	AAC68002	Spring; Air cylinder; Two direction operation; Brake	6836M5K, 7246M5K
Components				
all	1	02 18650B	Stem; Air cylinder; Two direction operation; Brake; 7.88L	
all	2	W2 18646	Air cylinder; Two direction operation; Brake	
all	3	53A031XB	Hydraulic fitting; Elbow 90 degrees; 1/4	
all	4	60C132	O-Ring; #329; 2"; 3/16"; Buna-N; 70	
all	5	27B250	Spacer; Rolled; 0.5; .521; 0.636 X 1.5	
all	6	27B34010SS	Spacer; Rolled; 0.5; 0.51; 0.625; 0.062	
all	7	02 02194	Piston cup; Air cylinder; 2+3/8"	
all	8	02 18651	Washer; Flat; 3/8; 1.63 X 0.14	
all	9	15G220	Nut; Nylon insert lock; 8; 24	
all	10	60C106	O-Ring; #011; 5/16"; 1/16"; Buna-N; 70	
all	11	02 02105B	Washer; Piston cup; Brass; 2.38"	
all	12	02 02085	Washer; Back-up; Piston cup; 2"OD	
all	13	06 20702E	Cylinder head; Stem side	
all	14	02 02101	Cylinder head; Spring side	
A	15	02 21865	Spring; Air cylinder; Two direction operation; Brake	
B	15	02 17024	Spring; Air cylinder; Two direction operation; Brake	
all	16	W6 20702F	Rod; Air cylinder; Two direction operation; Brake	
all	17	60C110	O-Ring; #011; 1/2"; 3/32"; Buna-N; 70	
all	18	02 02185	Washer; Flat; 3/8; 0.75 X 0.12	
all	19	5N0ECLSBE2	Pipe; 1/4; Close (threads only); Brass	
all	20	51V015	Pipe Fitting; Tee; 1/4	
all	21	53A008B	Hydraulic fitting; Hose end straight connector; 1/4	
all	22	5SCC0EBE	Pipe FittingCoupling; 1/4;	
all	23	15G185	Nut; Hex; 5/16; 18	
all	24	20L601F	Identification tag; "F"	
all	25	20L601X	Identification tag; "X"	
all	26	27A005A	Muffler; 1/4"	

— End of BIIFLM11 —

## Cylinder Installation

Figure 1: Shell and Cylinder






Figure 2: Detailed views







Figure 3: Shell



Cylinder Installation

**Table 1: Parts List—Cylinder Installation**

Find the assembly for your machine and the letter shown in the "Item" column. The components for your machine will show this letter or the word "all" in the "Used In" column. The numbers shown in the "Item" column are those shown in the illustrations.				
Used In	Item	Part Number	Description/Nomenclature	Comments
Assemblies				
	A	GSF4840F	Installation Group; Shell front; 48040F_, 48040H_	4840F_, 4840H_, 4840M7K
	B	GCA4840F	Installation Group; Cylinder; 48040F_, 48040H_	4840F_, 4840H_, 4840M7K
Components				
all	1	03 48053B	Gasket; 48040F_ ; 1/8	
all	2	15K240	Bolt; Hex head; 3/4-10UNC	
all	3	15U492	Washer; Flat	
all	4	15U340	Washer; Lock	
all	5	15G240	NutHex; 3/4-10UNC	
all	6	15K250	Bolt; Hex head; 3/4-10UNC	
all	7	15U494	Washer; Flat	
all	8	15K310	Bolt; Hex head; 1+1/4-12X4	Coarse thread. This part applies to machines made after 05, 2008.
all	8	15K309	Bolt; Hex head; 1.25-7UNC X 4.0	Fine thread. This part applies to machines made through 05, 2008.
all	9	15U600	Washer; Flat	
all	10	20C007G	Thread lock compound; Loctite 242	
all	11	X2 21916	Pull-up plate; Cylinder	
all	12	X2 21917	Cover; Cylinder hub	
all	13	02 21918	Gasket; Cover; Cylinder hub	
all	14	15K235AA	Bolt; Hex head; 3/4-10X2.75	
all	14	15K234CA	Bolt; Hex head; 3/4-10X2.25	
all	15	15U321H	Washer; Flat	
all	16	15U188	Washer; Flat	
all	17	15K040T	Bolt; Torx button head; 1/4-20X3/4	
all	18	60C155V	O-Ring; Viton; 4.75ID; 3/16CS	
all	19	60C157V	O-Ring; Viton; 4+7/8ID; 3/16CS	
all	20	15K235AA	Bolt; Hex head; 3/4-10X2.75	
all	21	ACA4840F7B	Cylinder	Standard Cylinder - 38" door
all	21	ACA4840F7P	Cylinder	Pickfree Cylinder

— End of BIIFLM07 —

## Bearing Housing Components and Installation

Figure 1: Bearing housing




Figure 2: Bearing housing




Figure 3: Bearing housing





Figure 4: Bearing housing



**Table 1: Parts List— Bearing Housing Installation**

Find the assembly for your machine and the letter shown in the "Item" column. The components for your machine will show this letter or the word "all" in the "Used In" column. The numbers shown in the "Item" column are those shown in the illustrations.				
Used In	Item	Part Number	Description/Nomenclature	Comments
Assemblies				
	A	ABM4840F	Assembly; Bearing housing; 48040F_, 48040H7_	4840F_, 4840H_, 4840M7K
	B	ABM4840FV	Assembly; Bearing housing; Fluoroelastic polymer (Viton) ; 48040F_, 48040H_	4840F_, 4840H_, 4840M7K
	C	ABN4840F	Tested part; Bearing housing; 48040F_, 48040H_	4840F_, 4840H_, 4840M7K
	D	ABN4840FV	Tested part; Bearing housing; Fluoroelastic polymer (Viton); 48040F_, 48048H_	4840F_, 4840H_, 4840M7K
	E	GBM4840F	Installation Group; Bearing housing; 48040F_, 48040H_	4840F_, 4840H_, 4840M7K
Components				
none	1	X2 21800	Machined part; Bearing housing	
all	2	X2 21801	Machined part; Shaft	
all	3	15K039	Bolt; Hex head; 1/4-20 UNC	
all	4	15U180	WasherLock	
all	5	X2 21816	Machined part; Pulley key	
all	6	15N091	Bolt; Phillip pan head; 8/32UNC	
all	7	02 21817	Water ring	
AC	8	60C160DB	O-Ring; Buna-N	
BD	8	60C160DV	O-Ring; Viton	
AC	9	60C275	O-Ring; Buna-N	
BD	9	60C275V	O-Ring; Viton	
AC	10	24S148	Seal; Shaft; Nitrile	
BD	10	24S148V	Seal; Shaft; Viton	
all	11	54A986	Bearing; Taper roller; SKF	
all	12	54A987	Bearing; Taper roller; SKF	
all	13	X2 21802	Seal sleeve	
all	14	X2 21803	Machined part; Seal holder; Front	
all	15	X2 21804	Plate; Seal; Front	
all	16	02 21805	Seal holder; Rear	
all	17	02 21806	Grease shield; Front	
all	18	02 21807	Grease shield;Front	
all	19	02 21810	Gasket; Seal holder;Front	
all	20	02 21811	Gasket; Seal holder; Rear	
all	21	02 21812	Gasket; Seal	
AC	22	24S146	Seal; Shaft; Nitrile	
BD	22	24S146V	Seal; Shaft; Viton	
AC	23	24S114	Seal; Shaft; Nitrile	
BD	23	24S114V	Seal; Shaft; Viton	
AC	24	60C190	O-Ring; Buna-N	
BD	24	60C190D	O-Ring; Viton	
all	25	56AHN24	Bearing locknut	

Bearing Housing Components and Installation

Find the assembly for your machine and the letter shown in the "Item" column. The components for your machine will show this letter or the word "all" in the "Used In" column. The numbers shown in the "Item" column are those shown in the illustrations.				
Used In	Item	Part Number	Description/Nomenclature	Comments
all	26	56AHW124	Bearing lockwasher	
all	27	56ATW24	Bearing tongue washer	
all	28	15K112	Bolt; Hex head; 3/8-16X1+1/2	
all	29	15U260	Washer; Lock	
all	30	20C003A	Adhesive; L# 380; Black; Bonding; High strength	
all	31	53A031B	Hydraulic fitting; Compression fitting; 90 elbow; 1/4	
all	32	5N0C01KG42	Pipe; 1/8; 1.5; Galvanized steel; Threads, two ends	
all	33	53A005B	Hydraulic fitting; Connector; 1/4; male; 1/8; Compression fitting	
all	34	53A500	Hydraulic fitting; Sleeve; Delrin; 1/4	
all	35	53A501	Hydraulic fitting; Insert; Brass; 1/4	
all	36	53A059A	Hydraulic fitting; Tube-fitting nut; Brass; 1/4	
all	37	5SP0CFESSV	Pipe Fitting; Plug; Square head with vent; 1/8	
all	38	5SLOCBEA	Pipe Fitting; Elbow; 90 degree; Brass; 1/8	
all	39	5N0CCLSB42	Pipe; Close (threads only); Brass; 1/8	
all	40	54M029	Relief fitting; Alemite	
all	41	15K310	Bolt; Hex head; 1+1/4-12X4	Coarse thread. This part applies to machines made after 05/30/2008.
all	41	15K309	Bolt; Hex head; 1.25-7UNC X 4.0	Fine thread. This part applies to machines made through 05/30/2008.
all	42	15U600	Washer; Flat	
all	43	20C007G	Thread lock compound; Loctite 242	
all	44	15K255ZN	Bolt; Hex head; 8UNCX1.5	
all	45	15U393	Washer; Flat	
all	46	02 21818	Drip shield	
all	47	AIR58003	Air injection; Bearing housing	
all	48	53A007B	Hydraulic fitting; Connector; 1/4; female; 1/4; Compression fitting	
all	49	5SB0E0CBEO	Pipe Fitting; Hex Bushing Reducer; Brass; 1/4X1/8	
all	50	54M015	Grease fitting	
all	51	01 10025Y	Dataplate; Grease	
all	52	60E004TC	Tubing; Nylon; 1/4"	

— End of BIIFLM08 —



BIIFLM09 (Published) Book specs- Dates: 2018044A Lang: ENG01 Applic: IFL

## Air Injection Components

Figure 1: Air Injection Components




Figure 2: Air Flow in the Bearing Housing




Table 1: Parts List—Air Injection Components

Find the assembly for your machine and the letter shown in the "Item" column. The components for your machine will show this letter or the word "all" in the "Used In" column. The numbers shown in the "Item" column are those shown in the illustrations.

Used In	Item	Part Number	Description/Nomenclature	Comments
Assemblies				
	A	AIR58003	Assembly; Air injection	
Components				
all	1	96J019G	Filter Regulator; 1/4"; 0-60PSI	
all	2	30N095	Pressure Gauge; 1/8"; 0-15PSI	
all	3	51V015	Pipe Fitting; Tee; 1/4 ; Brass	
all	4	5N0ECLSBE2	Pipe; 1/4; Close (threads only); Brass	
all	5	53A031B	Hydraulic fitting; Elbow 90 degrees; 1/4; 1/8	
all	6	53A059A	Hydraulic fitting; Tube fitting nut; 1/4	
all	7	53A500	Hydraulic fitting; Sleeve; 1/4; Brass	
all	8	53A501	Hydraulic fitting; Insert; 1/4; Brass	
all	9	60E004TE	Tubing; Round; 0.25; NYLON	
all	10	53A005B	Hydraulic fitting; Hose end straight connector; 1/4	
all	11	60E004TC	Tubing; Round; 0.25; NYLON	

— End of BIIFLM09 —


# Frame and Tilt

4

# Frame Pivots and Tilt Stops

48040M7K, 68036M5K, 72046M5K


Figure 1: Frame Pivots




# Frame Pivots and Tilt Stops

48040M7K, 68036M5K, 72046M5K


Figure 2: Tilt Stops



View C-C: Tilt stops 68036M5K (4 places)



Center back tilt stop




Tilt Stops 72046M5K (left & right)



# Frame Pivots and Tilt Stops

48040M7K, 68036M5K, 72046M5K

Figure 3: Tilt Stops



# Frame Pivots and Tilt Stops


48040M7K, 68036M5K, 72046M5K

Parts List—Frame Pivots and Tilt Stops				
Find the correct assembly first, then find the needed components. The item letters (A, B, C, etc.) assigned to assemblies are referred to in the "Used In" column to identify which components belong to an assembly. The item numbers (1, 2, 3, etc.) assigned to components relate the parts list to the illustration.				
Used In	Item	Part Number	Description	Comments
-----ASSEMBLIES-----				
	A	GHF68004	6836M5K FRAMES+PIVOT INSTALL	68036M5K
	B	GHF72001	7246M5K FRAMES+PIVOT INSTALL	72046M5K
	C	GHF48007	4840M7K HYD TILT 2-WAY	48040M7K
-----COMPONENTS-----				
all	1	X2 22655	6836M5K BALLBUSH HOUSING	
all	2	02 22659	6836M5K TILT FRAME PIVOT BRACKET	
all	3	54A707	SPHERICAL PLAIN BRG BALL BUSHING 3" RBC# B48-L	
all	4	56AHW114	TW114 BEARING LOCWASHER	
all	5	56ATW14	TONGUE WASH TIM K91514 FOR N14	
all	6	56AHN14	N14 BEARING LOCKNUT	
all	7	W2 22659A	6836M5K TILT FRAME SHAFT SUPPT WLMT	
all	8	02 22659B	6836M5K TILT FRAME SHAFT SUPPT 16GA SHIM	
all	9	54M025	HYDFIT 1/8"-90 ALEMITE 1613-B	
AB	10	02 22680	MD6836M5K TILT FRAME REAR STOP BRKT	
all	11	02 22680A	6836M5K TILT STOP DOUBLER	
all	12	02 22734	6836M5K TILT FRAME REAR STOP RESTPAD	
all	13	15K232B	HEXCAPSCR 3/4-10X1+1/2 GR8 ZINC	
all	14	15U321H	FLTWASH 3/4 HARD ASTM F436	
all	15	15U340	LOCKWASH MEDIUM 3/4 ZINCPL	
all	16	15G240A	HEXNUT 3/4-10UNC2B SAE GR8 ZIN	
all	17	15K232A	HEXCAPSCR 3/4-10X2 GR8 ZINC	
all	18	15K151	HXCAPSCR 1/2-13UNC24X1.25 GR5	
all	19	15U280	FL+WASHER(USS STD)1/2 ZNC PL+D	
all	20	15U300	LOKWASHER REGULAR 1/2 ZINC PLT	
all	21	15G230	HXNUT 1/2-13UNC2B SAE ZINC GR2	
all	22	15K121	HXTAPBOLT 3/8-16UNC2X2" GR5 ZI	
all	23	15U240	FLATWASHER(USS STD) 3/8" ZNC P	
all	24	15U255	LOCKWASHER MEDIUM 3/8 ZINCPL	
all	25	15G206	HEXNUT 3/8-16 UNC2 SS 18-8	
AB	26	02 25081	MD7246M5K TILT FRAME REAR STOP BRKT	
C	26	02 24049	4840M7K TILT STOP BRKT	
C	27	02 24027A	4840M7K TILT STOP SHORT	

# Suspension: Marshmellow Springs & Shocks

48040M7K, 68036M5K, 72046M5K

Figure 1: Marshmellow Springs






# Suspension: Marshmallow Springs & Shocks

48040M7K, 68036M5K, 72046M5K

Figure 2: Shock Absorbers



View B-B: Shock Absorbers (4 places)

### Parts List—Marshmallow Springs & Shocks

Find the correct assembly first, then find the needed components. The item letters (A, B, C, etc.) assigned to assemblies are referred to in the "Used In" column to identify which components belong to an assembly. The item numbers (1, 2, 3, etc.) assigned to components relate the parts list to the illustration.

Used In	Item	Part Number	Description	Comments
-----ASSEMBLIES-----				
	A	GSS68002	6836M5K SUSPENSION/SHOCK INSTALL	68036M5K, 72046M5K
	B	GSS48002	4840M7K SUSPENSION/SHOCK INSTALL	48040M7K
-----COMPONENTS-----				
AB	1	60B144	MM SPRG 8X3.5X12 #W22-358-0228	
C	1	60B140	MM SPRG 6.5X3X8 F#W223580186	
AB	2	02 22801	6836M5K MARSHMELLOW COVER MOUNT	
C	2	02 24065	4840M7K MARSHMELLOW COVER MOUNT	
AB	3	02 22802	6836M5K MARSHMELLOW COVER	
C	3	02 24066	4840M7K MARSHMELLOW COVER	
all	4	12P015B	TRW BLK NYL PUSH FAST	
AB	5	60BS6839	SHOCK ABSORBER #08570007Y	
C	5	60BS6832	SHOCK ABSORBR GABRIEL #65488440X	
AB	6	X2 04425	SPACER=SHOCK, 6836E (COLOR=WARM GRAY)	

# Suspension: Marshmallow Springs & Shocks

48040M7K, 68036M5K, 72046M5K

## Parts List—Suspension: Marshmallow Springs & Shocks

Find the correct assembly first, then find the needed components. The item letters (A, B, C, etc.) assigned to assemblies are referred to in the "Used In" column to identify which components belong to an assembly. The item numbers (1, 2, 3, etc.) assigned to components relate the parts list to the illustration.

Used In	Item	Part Number	Description	Comments
C	6	05 20190	MTG-SPACER=SHOCK ABSORBER72T	
all	7	15K235CA	HXCAPSCR 3/4-10X4 GR8 ZINC	
all	8	15U393	FLTWASH 1" HARD ASTM F436	
all	9	15G244B	HEXFLGSR L/N 3/4-10 C/H ZINC	
C	10	05 20187C	SPACER=SHOCK ABSORBER	




# Hydraulic Assemblies

5

# Hydraulic Tank

48040M7K, 68036M5K, 72046M5K

Figure 1: Hydraulic tank



# Hydraulic Tank

48040M7K, 68036M5K, 72046M5K





<b>Parts List—Hydraulic Tank</b>				
Find the correct assembly first, then find the needed components. The item letters (A, B, C, etc.) assigned to assemblies are referred to in the "Used In" column to identify which components belong to an assembly. The item numbers (1, 2, 3, etc.) assigned to components relate the parts list to the illustration.				
Used In	Item	Part Number	Description	Comments
-----ASSEMBLIES-----				
	A	AHT68005	6836M5K HYDRAULIC TANK ASSY	
-----COMPONENTS-----				
all	1	W2 22731	6836M5K HYDRAULIC TANK WLMT	
all	2	02 22730	6836M5K HYD TANK LID	
all	3	02 22737	6836M5K HYDRAULIC TANK GASKET	
all	4	27E5506H	6836M5K PUMP/MOTOR ASSY	
all	5	27E7112	INTANK RETURN FILTER 1+1/4"	
all	6	27E7111	SUCT.STRAINER=EZYFLO#S-15-100	
all	7	27E7201	FILLER-BREATH-FILT.LHA#ABB-40N	
all	8	27E7301	SIGHTGAUGE-FLUID:STAUFF#SNA-2T	
all	9	52ZJ0PS002	ELBOW MALE ORFS/NPT #12-16 CLO-S	
all	10	5N1ECLSF42	NPT NIP 1.25XCLS TBE BLKSTLS40	
all	11	5SL1EFFA0P	NPTLNB 90DEG 1.25X3/4BLKMAL150	
all	12	52ZC0PS001	TUBEFITSTR3/4"#12-FLO-S	
all	13	96D084	BALL VALVE BRZ 1"BONOMI 171N	
all	14	5SP1ACESC	NPT PLUG 1" SQ CORED BLK CI	
all	15	52AY0MR001	STR MALE ADPT ORB/NPT #10-1/2 F50F-S	
all	16	52XY0KP00Y	1/2"QUICK DISCONN.MALE #H4-63	
all	17	60EH50C34A	HYD.HOSE 3/4" X 34" +90FSW + STRFSW	
all	18	52ZJ00S011	TUBEFIT90EL3/4"FACESEAL ORING	
all	19	15K095	HXCPSCR 3/8-16UNC2AX1 GR5 ZINC	
all	20	15G198	HXFLGNUT 3/8-16 ZINC	
all	21	15K095C	HXCAPSCR 3/8-16X1.25 GR.8 ZN.	
all	22	15U240	FLATWASHER(USS STD) 3/8" ZNC P	
all	23	27A0625NLS	CLAMP NUT 3/8-16 W/SPRING	



# Hydraulic Tilt Valves & Fittings

48040M7K, 68036M5K, 72046M5K

Figure 1: Manifolds and valves



To/from right cylinder

To/from pump


To/from left cylinder

Tilt Block

# Hydraulic Tilt Valves & Fittings



48040M7K, 68036M5K, 72046M5K

Figure 2: Junction blocks and counterbalance valves



Door/Dryell Block

### Right and Left Tilt Cylinders:





# Hydraulic Tilt Valves & Fittings

48040M7K, 68036M5K, 72046M5K

<b>Parts List—Hydraulic Tilt Valves &amp; Fittings</b>				
Find the correct assembly first, then find the needed components. The item letters (A, B, C, etc.) assigned to assemblies are referred to in the "Used In" column to identify which components belong to an assembly. The item numbers (1, 2, 3, etc.) assigned to components relate the parts list to the illustration.				
Used In	Item	Part Number	Description	Comments
-----ASSEMBLIES-----				
	A	AHT68004	6836M5K HYDRAULIC HOSE & FITTING ASSY	68036M5K
	B	AHT72001	7246M5K HYDRAULIC HOSE & FITTING ASSY	72046M5K
	C	AHT48004	4840M7K HYDRAULIC HOSE & FITTING ASSY	48040M7K
-----COMPONENTS-----				
all	1	60EH50C12A	HYD.HOSE 3/4"+2 X FORSW=12"	
all	2	52ZC00S011	TUBESTRCON 1/2 X 5/8 #8-10 F5OLO-S	
all	3	96DH455C	MANIFOLD, DAMAN AD03P022S/S	
all	4	96DH455D	CART, RELIEF SUN# RDDA-LAN	
all	5	52PY0GR003	HEXPLUG 5/8" OR-SEAL #10-P50N-S	
all	6	52ZC00S012	TUBESTRCON 1/2 X 1/2 #8 F5OLO-S	
all	7	52JY0GR004	ELB90 3/80RXMJIC#6801LL-6-6NWO	
all	8	52AY0ER005	STR.1/4"FPX3/8"FJIC#6506-4-6	
all	9	27E731500	LIQFILL GAGE 0-1500PSI/BAR LF25 1-1500-4L	
all	10	52EY0KR003	COUP.STR5/8MORX1/2FPS	
all	11	60EH40C16A	HYD HOSE 1/2" + 2 X FORSW=16"	
all	12	96RH714E71	CONTROL VALVE HYTOS RPE3-063Y11-23050E5	
A	13	60EH40C50B	HYD HOSE 1/2" + 2 X FORSW=50"	
B	13	60EH40C58A	HYD HOSE 1/2" + 2 X FORSW=58"	
C	13	60EH40C38B	HYD.HOSE 1/2"+2 X FORSW=38	
A	14	60EH40C53K	HYD HOSE 1/2" + 2 X FORSW=53+1/2"	
B	14	60EH40C61K	HYD HOSE 1/2" + 2 X FORSW=61+1/2"	
C	14	60EH40C45A	HYD HOSE 1/2" + 2 X FORSW=45"	
A	15	60EH40C71A	HYD HOSE 1/2" + 2 X FORSW=71"	
B	15	60EH40C85B	HYD HOSE 1/2" + 2 X FORSW=85"	
C	15	60EH40C68A	HYD HOSE 1/2" + 2 X FORSW=68"	
all	16	52XY0KP00X	1/2"QUICK DISCONN.FEM#H4-62	
all	17	27E797A	JUNCTION BLOCK DAMAN #AJ2700208S	
all	18	52ZJ00S005	TUBFITSTRTHD45ELFC#12V50L0-S	
A	19	60EH40C66A	HYD HOSE 1/2" + 2 X FORSW=66"	
B	19	60EH40C68A	HYD HOSE 1/2" + 2 X FORSW=68"	
C	19	60EH40C49A	HYD HOSE 1/2" + 2 X FORSW=49"	
A	20	60EH40C28B	HYD.HOSE 1/2"+2 X FORSW=28	
B	20	60EH40C34A	HYD HOSE 1/2" + 2 X FORSW=34"	
C	20	60EH40C25B	HYD HOSE 1/2" + 2 X FORSW=25"	
all	21	96DH471	COUNTERBALANCE VALVE-SUN BODY	
all	22	96DH471A	CARTRIDGE-COUNTERBAL.SUN	
all	23	52ZCF50L0S	TUBEFITSTR3/4X1/2"#12-8F50LOS	
AB	24	60EH40C35P	HYD HOSE 1/2" + 2 X FORSW=35+3/4"	
C	24	60EH40C31K	HYD HOSE 1/2" + 2 X FORSW=31.5"	



# Hydraulic Tilt Valves & Fittings

48040M7K, 68036M5K, 72046M5K




### Parts List—Hydraulic Tilt Valves & Fittings

Find the correct assembly first, then find the needed components. The item letters (A, B, C, etc.) assigned to assemblies are referred to in the "Used In" column to identify which components belong to an assembly. The item numbers (1, 2, 3, etc.) assigned to components relate the parts list to the illustration.

Used In	Item	Part Number	Description	Comments
All	25	52ZJ00S016	TUBEFIT90ELBOW 1/2X3/4 #8-12 C5OLO-S	
all	26	52ZC0PS002	TUBEFITSTRSWIVEL 3/4"#12 F65OL-S	
all	27	27E5521	HOSECLAMP HALVES 1/2 PARK#H3205PP	
all	28	27E5522	CLAMP COVER PL 1/2 PARKER#CP-3	
all	29	15P062	1/4-14X4 HEX WASHER HEAD TEK SCREW ZINC	
all	30	52ZC00S005	TUBEFIT 3/4"X5/8"#12-10F50L0S	
all	31	52ZC00S013	TUBESTRCON 1/2 X 1/2 #8 FF5OLO-S	

# Hydraulic Cylinder

48040M7K, 68036M5K, 72046M5K



**Section A-A  
Cylinder Clevis**

### Parts List—Hydraulic Cylinder Mounting

Find the correct assembly first, then find the needed components. The item letters (A, B, C, etc.) assigned to assemblies are referred to in the "Used In" column to identify which components belong to an assembly. The item numbers (1, 2, 3, etc.) assigned to components relate the parts list to the illustration.

Used In	Item	Part Number	Description	Comments
-----ASSEMBLIES-----				
	A	GHC68004	6836M5K HYDRAULICS INSTALL	68036M5K
	B	GHC72001	7246M5K HYDRAULICS INSTALL	72046M5K
	C	GHC48004	4840M7K HYDRAULICS INSTALL	48040M7K
-----COMPONENTS-----				
AB	1	27E164035A	HYDRAULIC CYL 4" BORE X 35" STROKE BLACK	
C	1	27E163C31A	HYDRAULIC CYL 3.25" BORE X 31" STROKE	
AB	2	15G277	HEXJAMNUT 1+7/8-12UNF GR5 ZINC	
C	2	15G264A	HEXJAMNUT 1+1/4-12UNF 2B ZINC	
AB	3	X2 22698	6836M5K HYDRAULIC CYLINDER CLEVIS END	
C	3	X2 24043	4840M7K HYDRAULIC CYLINDER CLEVIS END	
AB	4	17B182	INTRETRING 2+3/16 ENDRIES#QGCG	
C	4	17B181	RETRING;INT;1.725;ENDRIES HO162	
AB	5	02 22699	6836M5K CLEVIS END SPACER	
C	5	02 24071	4840M7K CLEVIS END SPACER	

# Hydraulic Cylinder

48040M7K, 68036M5K, 72046M5K

## Parts List—Hydraulic Cylinder

Find the correct assembly first, then find the needed components. The item letters (A, B, C, etc.) assigned to assemblies are referred to in the "Used In" column to identify which components belong to an assembly. The item numbers (1, 2, 3, etc.) assigned to components relate the parts list to the illustration.

Used In	Item	Part Number	Description	Comments
AB	6	54A704	BALLBUSHING 1+3/8" NO SEALS-SKF#GEZ-106-ES	
C	6	54A702	SPHERICAL PLAIN BRG BALL BUSHING 1" RBC#B16-L	NO SEALS
AB	7	17A129	CLEVIS PIN 1+3/8" X 6" ZN PLATE	
C	7	17A130	CLEVIS PIN 1" X 6" ZN PLATE	
all	8	15H060	STDCOTTERPIN 3/16X2 ZINCPL	
AB	9	17A128	CLEVIS PIN 1+3/8" X 5" ZN PLATE	
C	9	17A102	CLEVIS PIN 1"X4"DRILLED ZINC	
all	10	54M021	GRSFIT 1/8PIPE X 1/4STR 1607-B	








# Door Assemblies

6

# Installation 38" Hydraulic Door



48040M7K








# Installation 38" Hydraulic Door

48040M7K



**VIEW C-C**



# Installation 38" Hydraulic Door

48040M7K

<b>Parts List—Installation 38" Hydraulic Door</b>				
Find the correct assembly first, then find the needed components. The item letters (A, B, C, etc.) assigned to assemblies are referred to in the "Used In" column to identify which components belong to an assembly. The item numbers (1, 2, 3, etc.) assigned to components relate the parts list to the illustration.				
Used In	Item	Part Number	Description	Comments
-----ASSEMBLIES-----				
	A	GSD4840FA	IN STL=SHELL 38" DOOR, 4840F	
	B	GHT48007	4840M7K HYD MTR/TORQARM	
-----COMPONENTS-----				
All	1	A25 00100A	4840F 38" X 4" SHELLDOOR	
all	2	W3 25159S	* WLMT,DOORSSTRIKER,SS =ALL52	
all	3	W3 25180	*COVER=SWITCH & DOOR STRIKER	
all	4	09R012STDG	* 09R012 +MOUNTING HDWRE+INST	
all	5	20A015GA	SHIM=FRICITION=CWU DOORSWITCH	
all	6	15K009	SKCPSCR 6-32 3A1 5/8 ALLOY	
all	7	15G072	HXCTRLOKNUT 6-32IF1100 ZINC GR	
all	8	03 25159W	SHIM=DOOR LATCH STRIKER=52WTB	
all	11	W3 25282B	38" DOOR TRAY WELDMENT	
all	12	02 21968A	EXTENDED COVER=CHAIN COUPLING, 4840F	
all	13	W3 25078B	4840M7K 2ND DRSW BRKT	
all	14	09RM01212S	CAPSW 12' 180DEG ROLLER SILVER	
all	15	03 25170A	SHIM=HINGE BKT BOLT-ON=52WTB	
all	16	02 21873A	38" DOOR OPEN STRICKER 4840F	
all	17	02 21874A	38" DOOR OPEN STOP 4840	
all	18	60C075	TRUCK BUMPER 2+1/2ODW3/8HO.613	
all	19	02 21967A	BRKT=38" AUTODOOR PROX 4840	
all	20	09RPS30CAS	PROXSW QK CONN 30M NO-AC SHLD	
all	21	09RPTAC092	CONN. 90 FEM 3-PIN AC 3A 2M	
all	22	SA 10 020	* DOORLATCH ASSY-SMALL	
all	23	W3 25300G	WLMT=TORQUE ARM,4840F OPPOSITE HAND	
all	24	54AA00PBB	SPHERICAL PLAIN BRG BALL BUSHING 3/4 RBC-B12L	
all	25	54M021	GRSFIT 1/8PIPE X 1/4STR 1607-B	
all	26	03 25604	ADAPTER FOR B12-L BUSHING	
all	27	W3 25301	* BRACKET WELD=DOOR ACTUATOR	
all	28	03 25278	BRKT=MOTOR MOUNT AUTO DOOR	
all	29	03 25285	PLATE=MOTOR MOUNT AUTO DOOR	
all	30	02 09109	DISC=3"DUMP VALVE RIGID SEAT	
all	310	27E320025	TDRQMOTOR- HYDRAULIC DANFOSS DH400 151 2129	
all	32	56Q1A1610	1.0" BUSH VPUL TPRLOCK1610TLXN	
all	33	1.50E+09	KEY#15 WOODRUF 1/4X1 NIC ALLOY	
all	34	54J220	DRCCOUPHALF C5018X1610 TBH	



# Installation 38" Hydraulic Door

48040M7K

## Parts List—Installation 38" Hydraulic Door

Find the correct assembly first, then find the needed components. The item letters (A, B, C, etc.) assigned to assemblies are referred to in the "Used In" column to identify which components belong to an assembly. The item numbers (1, 2, 3, etc.) assigned to components relate the parts list to the illustration.

Used In	Item	Part Number	Description	Comments
all	35	27E5511D	FLEX.COUP.=5018TBF COUPLING 1610	
all	36	02 175048	DRIPSHIELD=3"INLET VALVE	
all	37	27E5511C	FLEX.COUP.-CHAIN=5018CHN	
all	38	52AY0KR004	HEXPTPEBUSH 1/2MX1/4F#0102-8-4	
all	39	52JY0ER005	ELBOWPIPE 1/4 STR.#5502-4-4	
all	40	52ZC0ES001	TUBEFIT 1/4"STR.#4-4-FLO-S	
all	41	52XY0ER010	FEMPIPESWIV 1/4" #1405-4-4	
all	42	60EH21C08S	ASSY=HYD HOSE 1/4"X8" SHORT	
all	43	60EH21C10L	ASSY=HYD HOSE 1/4"X10" LONG	
all	44	60EH21C102	ASSY=HYD HOSE 1/4" + 2 X FORSW =102"	
all	45	96DH488A	BODY, SUN SANDWICH BODIES #GBA	
all	46	96DH487B	CARTRIDGE SUN #NCCB-LCN	
all	47	15K088	HEXCAPSCR 3/8-16NCX7/8 GR 5 ZI	
all	48	15U255	LOCKWASHER MEDIUM 3/8 ZINCPL	
all	49	15U240	FLATWASHER(USS STD) 3/8" ZNC P	
all	50	15G205	HXNUT 3/8-16UNC2B ZINC GR2	
all	51	15K105	HXCAPSCR 3/8-16UNC2A1.25 GR5 P	
all	52	15K110	HEXCAPSCR 3/8-16UNC2AX1.5 GR5-	
all	53	15U238	LOKWAS INTOOTH 3/8" (US STD) 4	
all	54	15K151	HXCAPSCR 1/2-13UNC24X1.25 GR5	
all	55	15U280	FL+WASHER(USS STD)1/2 ZNC PL+D	
all	56	15U300	LOKWASHER REGULAR 1/2 ZINC PLT	
all	57	15U490	FLTWASH 1+1/2X17/32X1/4 ZINC	
all	58	15P180	TRDCUT-F HXHD 1/4-20UNC2X5/8 S	
all	59	15K031	BUTSOKCAPSCR 1/4-20X1/2 SS18-8	
all	60	15U181	LOCKWASHER MEDIUM 1/4 SS18-8	
all	61	15K084	TRUSS HXSOK 3/8-16 X 23/32SS	
all	62	15K120	HXCAPSCR 3/8-16UNC2AX2 GR5 ZIN	
all	63	15G218	HXLKONUT NYL 3/8-16 STL/ZNC	

## Installation, Manual Door

Figure 1: Installation, Manual Door 48040F\_(shown), 48040M7K





Figure 2: Installation, Manual Door 48040F\_ (shown), 48040M7K



**Table 1: Parts List—The Standard Door Installation**


Find the assembly for your machine and the letter shown in the "Item" column. The components for your machine will show this letter or the word "all" in the "Used In" column. The numbers shown in the "Item" column are those shown in the illustrations.				
Used In	Item	Part Number	Description/Nomenclature	Comments
Assemblies				
	A	GSD4840F	Installation Group; Shell door; 48040F_	4840F_, 30" Door
	B	GSF4840FA	Installation Group; Shell door; 4840M7K	4840M7K, 38" Door
Components				
all	1	E25 00100	Assembly; Switch; Door interlock	
all	2	09RM01212S	Switch; Door open	
A	3	Y3 25084C	Machined part; Door ring;30" Door	
B	3	Y3 25084E	Machined part; Door ring; 38" Door	
A	4	03 25026D	Gasket; Door ring; 1/16"	
B	4	03 25026F	Gasket; Door ring; 1/16"	
A	5	03 25026E	Gasket; Door ring; 1/8"	
B	5	03 25026G	Gasket; Door ring; 1/8"	
all	6	W3 25180	Cover; Interlock switch, Striker	
A	7	W3 25159S	Weldment; Striker; Door latch	
B	7	02 21873A	Weldment; Striker; Door latch	
all	8	03 25170A	Shim; Bracket;	
all	9	03 25159W	Shim; Striker;Door latch	
A	10	W3 25078A	Weldment; Bracket; Switch; Door open; 48040F_	
B	10	W3 25078B	Weldment; Bracket; Switch; Door open; 4840M7K	
all	11	60C075	Rubber bumper; 2+1/2	
all	12	15K105	Bolt; Hex head; 3/8-16	
all	13	15G205	Nut; Hex; 3/8-16	
all	14	15U238	Washer; Lock, internal tooth; 3/8"	
all	15	15U240	Washer; Flat; 3/8"	
A	16	02 21874	Stop; Door open; 48040F_	
B	16	02 21874A	Stop; Door open; 4840M7K	
all	17	15K151	Bolt; Hex head; 1/2-13	
all	18	15U300	Washer; Lock; 1/2	
all	19	15U490	Washer; Flat; 1+1/2X17/32X1/4	
all	20	15K031	Bolt; Socket head button; 1/4-20X1/2	
all	21	15U181	Washer; Lock; 1/4	
all	22	15K100	Bolt; Hex head; 3/8-16X1+1/4	
all	23	15U260	Washer; Lock; 3/8	
all	24	15U246	Washer; Flat; 1"	
all	25	15K022	Bolt; Socket; 10-24	

— End of BIIFLM14 —

# Components, Manual Door - 38"

48040M7K

Figure 1: Components, Manual Door




### Legend

- A. Front View
- BB. Cross Section View, Refer to Figure 2
- F. 4 instances
- G. 12 instances

# Components, Manual Door - 38"

48040M7K

Figure 2: Components, Manual Door



**BB**

**C**

**E**

**D**

**Legend**

- C. Door glass and gasket
- D. Door channel bolts
- E. Retainer ring


# Components, Manual Door - 38"

48040M7K

<b>Parts List—Components, Manual Door 38"</b> Find the correct assembly first, then find the needed components. The item letters (A, B, C, etc.) assigned to assemblies are referred to in the "Used In" column to identify which components belong to an assembly. The item numbers (1, 2, 3, etc.) assigned to components relate the parts list to the illustration.				
Used In	Item	Part Number	Description	Comments
			-----ASSEMBLIES-----	
	A	A25 00100A	4840F 38" X 4" SHELLDOOR	
			-----COMPONENTS-----	
all	1	Y3 25060B	DOOR=DRILLED=38" TAPERED	
all	2	03 25058B	RING= 38" DOOR GLASS RETAINER	
all	3	W3 25085K	WLMT= 38" DOOR GASKET RETAINER	
all	4	03 25085H	GASKET=40 DURO 3/8 THICK FOR 38" DOOR	
all	5	20C047	ADHES.3M #1099 INDUST QUARTS	
all	6	03 25083B	GASKET FOR GLASS, 38" DOOR	
all	7	03 25013C	DOORGLASS-SIZE 33.94"	
all	8	15K106B	BUTSOKCAPSCR 3/8-16NCX1+3/8 SS	
all	9	24G030N	ROLLED WASH.379ID NYLTITE 37W	
all	10	27B2400K0L	SPACER ROLL.43ID.562L.03T SS	
all	11	15G200	HXCPNUT 3/8-16 UNC2A 5/8X1/2	
all	12	15U260	LOCKWASHER MEDIUM 3/8 SS18-8	
all	13	03 25061A	CHANNEL INNER=38" DOOR	
all	14	03 25089A	CHANNEL=OUTER=38" DOOR	
all	15	A25 04500A	38" DOOR - BEARING&HINGE PIN ASSY, 4840F	
all	16	SA 15 028	* DOOR LATCH ASSY-DIVCYLS	
all	17	02 15633B	ADJPLATE=DOORLATCH 16GA	
all	18	02 15633A	DOOR LATCH HANDLE 42Q	
all	19	60B090	AIRMT S-131 1CONV.F#W013587731	
all	20	5SB0E0CBEO	NPTHEXBUSH 1/4X1/8 BRASS 125#	
all	21	53A031B	BODY-EL90MALE.25X1/8 #269C-42B	
all	22	53A059A	NUT 1/4"BR.HOLYOKE AND #61A-4	
all	23	53A500	SLEEVE DELRIN 1/4"OD#60PT-4	
all	24	53A501	TUBE INSERT .163"OD #63PT-4-40	
all	25	60E004TE	1/4"OD X.170"ID NYL(BLK)TUBING	
all	26	15K202T	HEXCAPSCR 1/2-13 X 4.75 SS	
all	27	27B2750L0T	SPC RROLL.562ID.937L.048T ZNK	
all	28	02 18187S	SPRING=DOOR STAINLESS STEEL	
all	29	15U280	FL+WASHER(USS STD)1/2 ZNC PL+D	
all	30	15G234	LOKNUT 1/2-13NC CAD FLXLOC#21F	
all	31	15N200	FILMACSCR 1/4-20UNCX2 SS18-8 S	
all	32	15G170	HEXNUT 1/4-20UNC2 SS18-8	
all	33	54M015	GREASEFIT 60X36/60X44 1610BL	

# Door Hinge Components and Installation

48040M5K



### Parts List—Door Hinge Components and Installation

Find the correct assembly first, then find the needed components. The item letters (A, B, C, etc.) assigned to assemblies are referred to in the "Used In" column to identify which components belong to an assembly. The item numbers (1, 2, 3, etc.) assigned to components relate the parts list to the illustration.

Used In	Item	Part Number	Description	Comments
-----ASSEMBLIES-----				
	A	A25 04500A	38" DOOR - BEARING&HINGE PIN ASSY, 4840F	
-----COMPONENTS-----				
all	1	03 25170	HINGE BKT.BOLT-ON=52T BND@PT	
all	2	W3 25071	* HINGE WELDMENT-30"DOOR	
all	3	54A976977	TIMKN #L44610/L44643=1.00"BORE	
all	4	03 25302	PIN DOOR HINGE	
all	5	15U500	FLATWASH 2"OD X 1+1/16 X .060	
all	6	15G248	HXJAMNUT 1-14UNF2B ZINC GR2	
all	7	15G249	HXCAPNUT L-CROWN 1-14UNF2B ZIN	
all	8	54JH13562B	HINGE COL SPLIT 3.56 FL TOP	
all	9	15K022	SOKCPSCR 10-24UNC2 X1+1/4 SS18	



## Door Latch

Figure 1: Door Latch




Table 1: Parts List—Door Latch

Find the assembly for your machine and the letter shown in the "Item" column. The components for your machine will show this letter or the word "all" in the "Used In" column. The numbers shown in the "Item" column are those shown in the illustrations.

Used In	Item	Part Number	Description/Nomenclature	Comments
Assemblies				
	A	SA 15 028	Assembly, Door latch	
Components				
all	1	02 15105	Retainer ring	
all	2	02 15297	Striker	
all	3	02 15298	Cylinder	
all	4	02 15836	Spring	
all	5	15H090	Pin	
all	6	60C122	O-ring, 1"X1/8	
all	7	60C128	O-ring, 1+3/8X1/8	

— End of BIIFGM19 —

## Door Latch

Figure 1: Door Latch




Table 1: Parts List—

Find the assembly for your machine and the letter shown in the "Item" column. The components for your machine will show this letter or the word "all" in the "Used In" column. The numbers shown in the "Item" column are those shown in the illustrations.				
Used In	Item	Part Number	Description/Nomenclature	Comments
Assemblies				
	A	SA 10 020	Installation Group, Door latch	
Components				
all	1	02 10188	Cylinder	
all	2	02 10222	Spring	
all	3	02 10221	Retainer	
all	4	Y2 10314	Latch	
all	5	60C112	O-Ring, 5/8X3/32	
all	6	60C115	O-Ring, 3/4X1/8	
all	7	17B014	Retaining ring	

— End of BIHDBM04 —

# Water and Steam

7

# Water

48040M7K


Figure 1: Water valves installed



# Water

48040M7K

Figure 2: Hot and cold water valve assembly






# Water

48040M7K

Figure 3: Hot water for supply, third water, reuse water



**Water****48040M7K****Parts List—Water**

Find the correct assembly first, then find the needed components. The item letters (A, B, C, etc.) assigned to assemblies are referred to in the "Used In" column to identify which components belong to an assembly. The item numbers (1, 2, 3, etc.) assigned to components relate the parts list to the illustration.

Used In	Item	Part Number	Description	Comments
-----ASSEMBLIES-----				
	A	GVW48026	4840M7K STD H20 HOT/COLD/COOLDOWN	
	B	AVW48026	4840M7K STD H20 HOT/COLD/COOLDOWN ASSY	
-----COMPONENTS-----				
all	1	27A062640A	UNISTRUT 13/16HT X 40"LG (COLOR=AZURE BLUE)	
all	2	27A0150	CLP-RGDSTL PS#1100-1+1/2	
all	3	15K085	HEXCAPSCR 3/8-16UNC2AX3/4 GR5	
all	4	15U240	FLATWASHER(USS STD) 3/8" ZNC P	
all	5	15G198	HXFLGNUT 3/8-16 ZINC	
all	6	5P1KG4003K	1.5" X 3.5" SCH40 GALV" TOE/GOE	
all	7	5SL1KNFA	NPT ELBOW 90DEG 1.5" GALMAL 15	
all	8	5N1K04AG42	NPT NIP 1.5X4 TBE GALSTL SK40	
all	9	5N1KCLSG42	NPT NIP 1.5XCLS TBE GALSTLSK40	
all	10	5N1K37KG42	NPT NIP 1.5X37.5 TBE GALSTL SK40	
all	11	5SL1KNFK	NPT ELB 45DEG 1.5 GALMAL 150#	
all	12	5.10E+99	KINGCOMNIP 1.5" IDXNPT #STC20	
all	13	5SCC1KNF	NPT COUP 1.5 GALMAL 150#	
all	14	5N1K06AG42	NPT NIP 1.5X6 TBE GALSTL SK40	
all	15	5S1KMGA0P	TEE 1.5X1.5X3/4 150# GALV	
all	16	5N1K08AG42	NPT NIP 1.5"X8 TBE GALSTL SK40	
all	17	96D087FBA	1.5"BALVAL+ACT BRS N/C BONOMI (SPRING RET)	
all	18	5S1KNFA	NPT TEE 1.5" GALMAL 150#	
all	19	51P058	PLUGPIPE 1+1/2"NPT POLY #57	
all	20	27E971D	VICT COUP 1.5"GALV #75	
all	21	5SB0P0KNFO	NPTHEXBUSH 3/4X1/2 GALMAL 150#	
all	22	5N0KCLSG42	NPT NIP 1/2XCLS TBE GALSTLSK40	
all	23	96TDC2AA71	1/2"N/C2WY240V50/60C VLV(DRYVC)	
all	24	5N0P03AG42	NPT NIP 3/4X3 TBE GALSTL SK40	
all	25	5SB0P0CNFA	NPTHEXBUSH 3/4X1/8GALV150#CORD	
all	26	30N100	PRESSGAUGE 1/8"BACKCN.0-30PSI	
all	27	5S0KNFA	NPT TEE 1/2" GALMAL 150#	
all	28	5SL0KNFA	NPT ELB 90DEG 1/2 GALMAL 150#	
all	29	51X017	UNIONSTRADT 1/2"#1404-8-8	
all	30	5SP0PHFSS	NPT PLUG 3/4 SQ SOLID STL/ZINC	
all	31	96D050A	3/4"BALLVALVE BRZ BONOMI 171N	
all	32	96D0009E	3/4"NPTBRZ N/C STEAMVAL ANGBOD	



**Water**

48040M7K




**Parts List—Water**

Find the correct assembly first, then find the needed components. The item letters (A, B, C, etc.) assigned to assemblies are referred to in the "Used In" column to identify which components belong to an assembly. The item numbers (1, 2, 3, etc.) assigned to components relate the parts list to the illustration.

Used In	Item	Part Number	Description	Comments
all	33	51X019	UNIONSTRADT 3/4"#0107-12-12	
all	34	5SL0PNFA	NPTELB 90DEG 3/4 GALMAL 150#	
all	35	5N0PCLSG42	NPT NIP 3/4XCLS TBE GALSTL S40	
all	36	96J031D	3/4"PRESSREG SET 28# FEMXUN=WATTS#LF25AUB-ZB	
all	37	5SX0PNF	NPT CROSS 3/4" GALMAL 150#	
all	38	60E086C023	ASSY=3/4"X23"LG+ENDS	
all	39	5SL0EBEC	NPTELB 90DEG STRT 1/4 BRASS125	
all	40	6.00E+302	HOSE 2.5"WATER CORRUGATED(V50)	
all	41	27A082	HOSECLAMP 2.5625-3.5CADSC#HS48	
all	42	SA 03 009	1.5"SIPHONBRKR+SCUPPER ASSY	

# Steam

48040M7K



**Sparger**

# Steam

48040M7K

<b>Parts List—Steam</b>				
Find the correct assembly first, then find the needed components. The item letters (A, B, C, etc.) assigned to assemblies are referred to in the "Used In" column to identify which components belong to an assembly. The item numbers (1, 2, 3, etc.) assigned to components relate the parts list to the illustration.				
Used In	Item	Part Number	Description	Comments
-----ASSEMBLIES-----				
	A	GVS48004	4840M7K STEAM,BRASS VALVE INSTALL	
	B	AVS48400	ASSY=STEAM PIPE+NOZZLE,4840	
-----COMPONENTS-----				
all	1	51T060	Y-STRAINER 1+1/4" CAST IRON	
all	2	5SP0PHFSS	NPT PLUG 3/4 SQ SOLID STL/ZINC	
all	3	5N1E12AF42	NPT NIP 1.25X12 TBE BLKSTL SK4	
all	4	96D0011E	1.25"NPTBRZ N/C STEAMVALANGBD	
all	5	02 22540A	1+1/4" STEAM TUBING 6836M5K HYD	
all	6	60E518C35A	STMHOSE SSFLEX 1"=35+2SSENDS	
all	7	W2 11365	*STEAM PIPE+FLANGE WLMT	
all	8	02 11369D	GASKET STEAM FLANGE MTG DYE	
all	9	X6 20247A	3/4" NPT .5" SPARGER MACH.	

## Installation, Drain Valve Body With One Valve

Figure 1: Installation, Drain Valve Body With One Valve



Installation, Drain Valve Body With One Valve


**Table 1: Parts List—Installation Drain Valve Body with One Valve**

Find the assembly for your machine and the letter shown in the "Item" column. The components for your machine will show this letter or the word "all" in the "Used In" column. The numbers shown in the "Item" column are those shown in the illustrations.				
Used In	Item	Part Number	Description/Nomenclature	Comments
Assemblies				
	A	GVD48400	Installation Group, Drain valve body with one valve, 4840F_, 4840H_	
Components				
all	1	A14 06400	Assembly*, Bonnet and air cylinder, 4"	
all	2	A14 06500B	Assembly, Drain valve 4"	
all	3	02 15026	Gasket, Drain valve	
all	4	20C040B	Silicone	
all	5	15K096	Bolt 3/8-16UNC2X1SS18-8	
all	6	15U201	Washer, Flat, 3/8"	
all	7	24G030N	Washer, Rolled, Nylon, 3/8"	
all	8	15U260	Washer,Lock, 3/8"	
all	9	15G206	Nut, Hex, 3/8"	

— End of BIIFLM21 —

## Drain Valve Body with Two Valves

Figure 1: Drain Valve Body with Two Valves



Drain Valve Body with Two Valves

Figure 2: Pressure gage




Figure 3: Compressed air tank




Table 1: Parts List—Drain Valve Body with Two Valves

Find the assembly for your machine and the letter shown in the "Item" column. The components for your machine will show this letter or the word "all" in the "Used In" column. The numbers shown in the "Item" column are those shown in the illustrations.				
Used In	Item	Part Number	Description/Nomenclature	Comments
Assemblies				
	A	GVD48402	Installation Group	
Components				
all	1	AVD48402	Assembly, Drain Valve Body with Two Valves	
all	2	A14 06400	Bonnet Assembly	
all	3	02 15026	Gasket	
all	4	20C040B	Silicone	
all	5	15K096	Bolt, 3/8-16X1	
all	6	15U201	Washer, Flat, 7/8X3/8X.062	
all	7	24G030N	Washer, Nylon, 3/8	
all	8	15U260	Washer, Lock, 3/8	
all	9	15G206	Nut, 3/8-16	
all	10	02 14443	Gasket, 4"	
all	11	W2 11304C	Valve body	
all	12	5SP0KGFSS	Plug, 1/2"	
all	13	51P055	Plug, 1.5"	
all	14	W3 25307D	Compressed air tank	
all	15	30N102	Pressure gage, 1/4", .0-150 PSI	
all	16	96H018	Needle valve, 1/4"X 1/8"	

— End of BIIIH4M03 —





Chemical

8




# Soap Chute

48040M7K, 68036M5K, 72046M5K




# Soap Chute

48040M7K, 68036M5K, 72046M5K



Hot water for flushing



View A-A




### Parts List—Soap Chute

Find the correct assembly first, then find the needed components. The item letters (A, B, C, etc.) assigned to assemblies are referred to in the "Used In" column to identify which components belong to an assembly. The item numbers (1, 2, 3, etc.) assigned to components relate the parts list to the illustration.

Used In	Item	Part Number	Description	Comments
-----ASSEMBLIES-----				
	A	AWS68006	6836M5K SOAP CHUTE ASSY	68036M5K, 72046M5K
	B	AWS48021	4840M7K SOAP CHUTE ASSY	48040M7K
-----COMPONENTS-----				
A	1	W3 65400C	WLMT=6836M5K SOAP CHUTE BODY	
B	1	W3 65400D	WLMT=4840M7K SOAP CHUTE BODY	
all	2	W3 65410A	WLMT=LID SOAP CHUTE 6836M5K	
all	3	03 65411	GASKT=SOAP CHUTE LID	
all	4	27A009C	LATCH-ADJUSTABLE 304 S/S	
all	5	15P100	#8 X 3/8 PHILPANHD TYPE B SMS	
all	6	27A002	NOZZLE BRASS 3/8" SPRAYSYSTEMS	
all	7	02 22806	6836M5K SUPPLY NOZZLE NIPPLE	
all	8	5SL0KBEA	NPTLBR 90DEG 1/2 BRASS 125#	
all	9	51X017	UNIONSTRADT 1/2"#1404-8-8	
all	10	60E086K226	3/4X226 WATER HOSE + 1/2 ENDS	
all	11	27A060	HOSECLAMP1+5/16-2.25CADSC#HS28	
all	12	02 03870D	FLEXTUBE=2"ID X 14"LG W/CUFFS	
all	13	54E016M	FLGBRG 3/8X5/8X3/8BRZ#FB610-3	
all	14	15K039	HXCAPSCR 1/4-20UNC2AX3/4 GR5 Z	
all	15	15U185	FLATWASHER(USS STD) 1/4" ZNC P	
all	16	15U180	LOCKWASHER MEDIUM 1/4 ZINCPL	
all	17	15K096	HEXCAPSCR 3/8-16UNC2X1SS18-8	

# Eight Port Peristaltic Supply Manifold


48040M7K, 68036M5K, 72046M5K





# Eight Port Peristaltic Supply Manifold

48040M7K, 68036M5K, 72046M5K



Hot water for flushing

### Parts List—Eight Port Peristaltic Supply Manifold

Find the correct assembly first, then find the needed components. The item letters (A, B, C, etc.) assigned to assemblies are referred to in the "Used In" column to identify which components belong to an assembly. The item numbers (1, 2, 3, etc.) assigned to components relate the parts list to the illustration.

Used In	Item	Part Number	Description	Comments
-----ASSEMBLIES-----				
	A	GWL68001	6836M5K PERISTALTIC INSTALL	68036M5K
	B	GWL72001	72M5K PERISTALTIC INSTALL	72046M5K
-----COMPONENTS-----				
all	1	02 22789A	8 PORT POLYPROP MANIFOLD 3/8" CHEM/1" WATER	
all	2	5SP0KXFHS	HEXHD PIPE PLUG 1/2"POLYPRO	
all	3	02 22727	68M5K PERISTALTIC SUPPT BRKT	
all	4	27A053	1-1/2" 316 SS CONDUIT HANGER	
all	5	60E086K83A	HOSE ASSY=3/4X83 + 1/2 ENDS	
all	6	51X017	UNIONSTRADT 1/2"#1404-8-8	
all	7	5SL1KNFACK	NPTLNB 90DEG 1X1/2 GALMAL 150#	
all	8	51ET1AE01	HOSEADAPT PVC 1"MT X 1" INSERT	
all	9	51E099SS	DIXON 1"KINGCOMBNIP S.S.#RST10	
A	10	60E010B174A	HOSE ASSY: POLYWIRECLR TUBING 1"ID X 174" NO ENDS	
B	10	60E010B228A	HOSE ASSY: POLYWIRECLR TUBING 1"ID X 228" NO ENDS	
all	11	27A090S	HOSECLAMP 13/16-1.5"SS#64016B	




# Control and Sensing Assemblies

9

# Switch Panel Pivot Arm

48040M7K, 68036M5K, 72046M5K

Figure 1: Detailed Views







# Switch Panel Pivot Arm

48040M7K, 68036M5K, 72046M5K

<b>Parts List—Switch Panel Pivot Arm</b>				
Find the correct assembly first, then find the needed components. The item letters (A, B, C, etc.) assigned to assemblies are referred to in the "Used In" column to identify which components belong to an assembly. The item numbers (1, 2, 3, etc.) assigned to components relate the parts list to the illustration.				
Used In	Item	Part Number	Description	Comments
			-----ASSEMBLIES-----	
	A	ASP68001	6836M5K SWITCHPANEL BOX/ARM ASSY	
			-----COMPONENTS-----	
	all	1	W2 22780	6836M5K SWITCHPANEL ARM WLMT
	all	2	W2 22790	WLMT=6836MK5 SWITCH PANEL ARM MOUNT
	all	3	02 22781	6836M5K SWTICHPANEL ADJUST BUSHING
	all	4	02 22744A	6836M5K SWTCHPNL PIVOT SLEEVE OUTER
	all	5	02 22743	6836M5K SWITCHPANEL PIVOT TRACK
	all	6	02 22744	6836M5K SWTCHPNL PIVOT SLEEVE INNER
	all	7	02 22743A	6836M5K SWITCHPANEL PIVOT TRACK UPPER
	all	8	W2 22701	WLMT=6836M5K SWITCH PANEL BOX
	all	9	02 22702	6836M5K SWITCH PNL/MILTOUCH OUTER
	all	10	ESP67MTX	SWPNL: MILTOUCH 8.4" SCREEN
	all	11	ESP67XNX	SWPNL:MILTOUCH+TILT CNTL-ISO
	all	12	15Q077	SOKSETSCR 1/4-20X1/4 ZINC ALLE
	all	13	15K065	HEXCAPSCR 5/16-18UNC2AX1 GR5 Z
	all	14	15U210	LOKWASHER MEDIUM 5/16 ZINCPL
	all	15	15G185	HXNUT 5/16-18UNC2B SAE ZINC GR

# Tilt Limit Switches

48040M7K, 68036M5K, 72046M5K





### Parts List—Tilt Limit Switches

Find the correct assembly first, then find the needed components. The item letters (A, B, C, etc.) assigned to assemblies are referred to in the "Used In" column to identify which components belong to an assembly. The item numbers (1, 2, 3, etc.) assigned to components relate the parts list to the illustration.

Used In	Item	Part Number	Description	Comments
-----ASSEMBLIES-----				
	A	GPS68001	6836M5K PROX SWITCH INSTALL	48040M7K, 68036M5K 72046M5K
	B	GPS72001	7246M5K PROX SWITCH INSTALL	
-----COMPONENTS-----				
A	1	W2 22751	6836M5K PROXIMITY SWITCH MOUNT SHAFT WLMT	
B	1	W2 25083	7246M5K PROX SWITCH ADJST SHFT WLMT	
all	2	W3 60220B	PROX SW MTG WLMT 30MM, 6440	
all	3	02 22750	6836M5K PROX SWITCH TARGET	
all	4	09RPS30CAS	PROXSW QK CONN 30M NO-AC SHLD	
all	5	09RPTAC095	CONN. 90 FEM 3-PIN AC 3A 5M	
all	6	09RPS30DAS	PRXSW QK CONN 30M NC-AC SHLD	
all	7	09RPS30ADS	PROX SW QK CONN 30M NO-DC SHLD	
all	8	09RPSDC095	CON.90DEG FEMALE DC 3A300V 5M	

# Excursion Switch

48040M7K, 68036M5K, 72046M5K



### Parts List—Excursion Switch

Find the correct assembly first, then find the needed components. The item letters (A, B, C, etc.) assigned to assemblies are referred to in the "Used In" column to identify which components belong to an assembly. The item numbers (1, 2, 3, etc.) assigned to components relate the parts list to the illustration.

Used In	Item	Part Number	Description	Comments
-----ASSEMBLIES-----				
	A	GES68001	6836M5K EXCURSION SWITCH INSTALL	
-----COMPONENTS-----				
all	1	09R008A	MICSW SPDT BZE6-2RN183	
all	2	02 22736	6836M5K EXCURSION SWITCH MOUNT BRKT	
all	3	02 22735	6836M5K EXCURSION SWITCH TARGET	
all	4	15K030	HEXCAPSCR 1/4-20UNC2X1/2 GR5 Z	
all	5	15U185	FLATWASHER(USS STD) 1/4" ZNC P	
all	6	15G177	HXNUT 1/4-28UNF2B SAE ZINC GR2	
all	7	15U180	LOCKWASHER MEDIUM 1/4 ZINCPL	
all	8	15K085	HEXCAPSCR 3/8-16UNC2AX3/4 GR5	
all	9	15G205	HXNUT 3/8-16UNC2B ZINC GR2	
all	10	15U240	FLATWASHER(USS STD) 3/8" ZNC P	
all	11	15U255	LOCKWASHER MEDIUM 3/8 ZINCPL	

## VIBRATION SAFETY SWITCH ADJUSTMENTS

### B What the Vibration Safety Switch Does

The *vibration safety switch* pictured below is an important safety feature. If properly adjusted, the switch will momentarily actuate as a result of repeated machine movement caused by an out-of-balance condition. Table A below illustrates the effect of the *vibration safety switch* actuation.

**Table A—Effect of Tripping Vibration Safety Switch**

Machine Model	Function of Vibration Safety Switch
30015, 30020, and 30022	Disables high speed extract
All microprocessor-controlled washer-extractors not listed above, and all dye machines	De-energizes three-wire relay, effectively terminating machine operation

## Adjustments


When the machine leaves Milnor<sup>®</sup>, the actuator arm is tie-wrapped to prevent damage (except on 30015, 30020, and 30022 models). **This tie wrap must be removed after the machine is set into position but before the machine is operated.**

Adjustment of this switch from the factory setting is not recommended; however, it should be checked for proper functioning and adjusted if its proper setting is lost.

As shown at right in FIGURE 1, the unit consists of a *sensitive micro-switch* with an extended actuating arm supporting an eccentric weight. The weight may be adjusted by moving it up and down on the arm and by rotating it on the arm. In addition, the *micro-switch* itself may be tilted from side to side.

**The sensitivity of the switch increases as the eccentricweight is raised on the actuating arm and decreases as the weight is lowered.**

The unit should be adjusted so that the actuating arm will always reset by itself, this being accomplished by rotating either the switch or the weight to give just enough bias to cause the switch to reset. Check the adjustment by moving the arm to the left then slowly releasing it. Make sure the micro-switch clicks when the arm is **slowly** released, thus indicating



**FIGURE 1** (MSSMA408BE)  
**Vibration Switch**

that it has reset. In the released position the arm should rest **lightly** but definitely against the stop on the *micro-switch* case that prevents any further arm movement to the left.

For machines with rigid mounted shells, where the machine is bolted to a very substantial foundation, very little machine movement will occur for a given degree of out-of-balance. Under such conditions it may be better to adjust the switch to be very sensitive. With less substantial foundations (e.g., ones where the sub-soil is mushy or springy or otherwise not as desirable), considerably greater machine movement will occur for a given degree of out-of-balance, in which case a less sensitive *vibration switch* setting may be indicated.

# Vibration Safety Switch

BMP910038/2012383B  
(Sheet 1 of 1)




Pellerin Milnor Corporation  
P. O. Box 400, Kenner, LA 70063-0400

Litho in U.S.A.

## Parts List—Vibration Safety Switch

Find the correct assembly first, then find the needed components. The item letters (A, B, C, etc.) assigned to assemblies are referred to in the "Used In" column to identify which components belong to an assembly. The item numbers (1, 2, 3, etc.) assigned to components relate the parts list to the illustration.




Used In	Item	Part Number	Description	Comments
			-----ASSEMBLIES-----	
A		SAE03 151	* ASSY-VIBRATION SWT=LG CONTR	(ALL MODELS EXCEPT BWP,CPE) 3015/22 V/T/G/F 3022F,362F, 4232F 3621,3626,4226,4230V 3022X,3626X,4226X,4232X 4244, 6044,7244WP/SP CONTAINS 001,002, 005A-009
B		SAE03 151A	*ASSY-VIBRATION SWT=BALCOM	(MODELS 3621BWP,CPE ONLY) CONTAINS 001,002, 005B-009
			-----COMPONENTS-----	
all	1	02 02038	PLATE INSULATING SMALL9NOV51	
all	2	15P008	TRDCUT PANHD 6-32X1 NIKSTL +WA	
A	5	02 15119	BRACKET=VIBSW CAD	
B	5	02 10264	BRACKET=SAFESW CAD	
all	6	09R020	SWITCH NC VIBR#WZ-2RW84429-P52	
all	7	03 01059	VIBSWITCH CLAMP CADSTL	
all	8	03 01058	VIBSWITCH WEIGHT-CADSTL	
all	9	15P101	TRDCUT-F PANHD 8-32X3/8 NIKSTL	





# Air Chamber Level Switch with Overflow Pressure Switch

72044WR2,WR3,SR3 72046M5K, 48040M7K







# Air Chamber Level Switch with Overflow Pressure Switch

72044WR2,WR3,SR3 72046M5K, 48040M7K

<b>Parts List</b>				
Find the correct assembly first, then find the needed components. The item letters (A, B, C, etc.) assigned to assemblies are referred to in the "Used In" column to identify which components belong to an assembly. The item numbers (1, 2, 3, etc.) assigned to components relate the parts list to the illustration.				
Used In	Item	Part Number	Description	Comments
-----ASSEMBLIES-----				
	A	ALS68002	72WP/SP PRESURE LEVEL SWITCH ASSY OVERFLOW	REFERENCE
	B	ALS48001	4840M7K LEVEL SWITCH ASSY	
-----COMPONENTS-----				
all	1	5N0KCLSG42	NPT NIP 1/2XCLS TBE GALSTLSK40	
all	2	5S0KNFA1A	NPT TEE 1/2X1/2X1" GALMAL 150#	
all	3	5SLOPNFC0K	NPT 90D STREET 3/4X1/2 GAL150#	
all	4	96DB0PNA	HOSEBIBB 3/4" MALEINLT 45DEG. ACETAL	
all	5	5N1A07AG42	NPT NIP 1X7 TBE GALSTL SK40	
all	6	5SR1A0ENF	NPT RED 1X1/4 GALMAL 150#	
all	7	5SB0E0CBEO	NPTHEXBUSH 1/4X1/8 BRASS 125#	
all	8	53A047H	MALCON 5/16X1/8POLY PH#68P-5-2	
all	9	60E005	TUBING BLK.POLY.5/160DX3/16ID	
all	10	53A019B	BODYMALECON5/16X1/8COM#B68A-5A	
all	11	53A032	ELB90MAL5/16X1/8POLY #169P-5-2	
all	12	51V010A	TEE 1/8"BRSEXTR BLOCTYP#2203P2	
all	13	5N0CCLSB42	NPT NIP 1/8XCLS TBE BRASS STD	
all	14	5SP0CBEHS	NPT PLUG 1/8 HXCTRSNK BRASS	
all	15	51E502A	HOSESTEM BRASS 1/8MPT X3/16	
all	16	27A043	HOSECLAMP 5/16"DIA.SPRING#A-5S	
all	17	60E004NA	TUBING CLEAR PVC 3/16"IDX5/16"OD	
all	18	09N069	PRESS SW 4"WC INVENSYS 738-719	
all	19	27A047A	HOSE CLAMP 5/16" NOMINIAL MIN .256"	
all	20	08BNLTT	LEVEL TRANSDUCER BD->TEST	
all	21	5N0E11ABE2	NPT NIP 1/4X11 TBE BRASS STD	

# Temperature Probe

48040M7K, 68036M5K, 72046M5K



### Parts List—Temperature Probes

Find the correct assembly first, then find the needed components. The item letters (A, B, C, etc.) assigned to assemblies are referred to in the "Used In" column to identify which components belong to an assembly. The item numbers (1, 2, 3, etc.) assigned to components relate the parts list to the illustration.


Used In	Item	Part Number	Description	Comments
-----ASSEMBLIES-----				
	A	30R0043PB	TEMPERATURE PROBE ASSY=BRASS	
-----COMPONENTS-----				
all	1	09B067	BUTTSPLICE(INS) 16-22GA.	
all	2	30R0043P	TEMP PROBE:THERMISTOR 30K OHMS	
all	3	51A026E	FLUID CONNECTOR 1/4TUBEX1/2MPT	
all	4	30R0043PF	FERRULE=TEMP PROB.25COMPFIT	




Dimensional

10







LOAD/UNLOAD PLAN




FOUNDATION PLAN




DETAIL: SAFETY SCREEN




INSTALLATION DETAIL




REAR VIEW



PLAN VIEW




RIGHT UNLOAD VIEW




LEFT VIEW

BASELINE "Z" (REFERENCE FOR VERTICAL DIMENSIONS) CORRESPONDS TO TOP OF GROUT. SEE NOTE 3 AND 4.



FRONT VIEW

CENTERLINE "X" (REFERENCE FOR LEFT/RIGHT DIMENSIONS). SEE NOTE 3.



RIGHT LOAD VIEW

ITEM	LEGEND
X1	SHIPPING TIE DOWN BRACKET
W4	REUSE WATER INLET, 1-1/2" NPT, OPTIONAL, SEE NOTE 9.
W3	THIRD WATER INLET, 1-1/2" NPT, OPTIONAL, SEE NOTE 9.
W2	COLD WATER INLET, 1-1/2" NPT
W1	HOT WATER INLET, 1-1/2" NPT
S1	STEAM INLET 1-1/4" NPT
L2	DRY SUPPLY
L1	PERISTALTIC INLETS, 8 PORTS, STANDARD
F4	1-1/16" DIAMETER ANCHOR BOLT HOLES, USE 3/4" X 6" BOLTS MINIMUM. IF F3 HOLES ARE NOT USED, YOU MUST ANCHOR THE (2) F4 HOLES NEAREST TO F3, BOTH SIDES. ALTERNATE F4 HOLES ARE AVAILABLE TO ACCOMMODATE DRAIN TROUGHS.
F3	1-1/16" DIAMETER ANCHOR BOLT HOLES, USE 3/4" X 6" BOLTS. YOU MUST ANCHOR THESE (2) F3 HOLES OR (4) F4 HOLES.
F2	1-1/16" DIAMETER ANCHOR BOLT HOLES, USE 3/4" X 6" BOLTS MINIMUM. ANCHOR ONE OF THE 3 HOLES IN EACH BOXED AREA.
F1	BASEPADS, SEE NOTE 7.
E8	SAFETY LIGHT SCREEN, DASHED
E7	SAFETY LIGHT SCREEN MIRROR
E6	SAFETY LIGHT SCREEN RECEIVER
E5	SAFETY LIGHT SCREEN EMITTER
E4	LOW VOLTAGE BOX
E3	HIGH VOLTAGE & INVERTER BOX
E2	MiTouch-EX™ TOUCH SCREEN CONTROLLER
E1	MAIN ELECTRICAL CONNECTION
D3	HYDRAULIC TANK, MANUAL DRAIN, 1" NPT
D1	DRAIN VALVE, 4-1/2" DIAMETER
B1	DOOR
A1	MAIN AIR INLET, 1/4" NPT

- NOTES**
- SAFETY LIGHT SCREEN MUST BE INSTALLED BEFORE OPERATING MACHINE.
  - SOFTWARE CAN ONLY USE 3 WATERS, YOU MAY HAVE OPTIONAL THIRD OR OPTIONAL REUSE INLETS AS SHOWN.
  - SHIM TO LEVEL THE MACHINE AND ALLOW FOR 1" [25] MINIMUM GROUT. ANCHOR WITH ONE ANCHOR BOLT PER BASEPAD (F1). MINIMUM USE 3/4" X 6" BOLTS. MINIMUM SEE INSTALLATION MAINTENANCE MANUAL FOR FURTHER INSTRUCTIONS.
  - SHADED AREAS ARE BASE PLATES WHICH MUST BE CONTINUOUSLY SUPPORTED ON 1" [25] THICK GROUT.
  - AS OF THIS WRITING, THE MINIMUM CLEARANCE REQUIRED BY U.S. NATIONAL ELECTRIC CODES, FROM ELECTRIC BOX TO ANY OBJECT IS:  
 36 [914] IF OBJECT IS AN UNGROUNDED (INSULATED) WALL  
 42 [1067] IF OBJECT IS A GROUNDED WALL (ie. BARE CONCRETE, BRICK, ETC.)  
 48 [1219] IF OBJECT IS ANY LIVE PART.  
 CHECK LOCAL ELECTRIC CODES FOR FURTHER RESTRICTIONS.
  - CUSTOMER TO SUPPLY CIRCUIT BREAKER OR FUSED BRANCH CIRCUIT DISCONNECT (SAFETY) SWITCHES WITH LAG TYPE FUSES FROM POWER SOURCE TO MACHINE. A SEPARATE GROUND WIRE MUST BE CONNECTED FROM DISCONNECT TO EQUIPMENT.
  - BASELINE "Z" IS THE SAME FOR ALL MILNOR MACHINES AND IS SHOWN ON ALL DIMENSIONAL DRAWINGS. THE DISTANCE BETWEEN BASELINE "Z" AND THE FINISHED FLOOR MAY VARY (WITH CHANGES IN FLOOR HEIGHT) AS REQUIRED TO INSURE THAT BASELINE "Z" IS HORIZONTAL AND ALL COMPONENTS REQUIRING GROUT ARE SET ON A MINIMUM 1" [25] THICK GROUT BED.
  - USE REFERENCE LINES "X", "Y", AND "Z" TO LOCATE ALL SERVICE CONNECTIONS.
  - NUMBERS IN BRACKETS [ ] DENOTE DIMENSIONS IN MILLIMETERS.
  - ALL DIMENSIONS SHOWN ARE APPROXIMATE, SUBJECT TO NORMAL MANUFACTURING TOLERANCES, AND TO OCCASIONAL CHANGES WITHOUT NOTICE THROUGH REDESIGN AND/OR RELOCATION OF COMPONENTS, ETC. DO NOT USE FOR CONSTRUCTION UNLESS CERTIFIED, AND IN NO EVENT PRE-PIPE CLOSER THAN FIVE FEET FROM MACHINE. FACTORY MUST BE CONSULTED FOR DIMENSIONS IF MACHINE IS TO BE MOVED THROUGH NARROW OR LOW CORRIDORS OR OPENINGS.



**ATTENTION**  
 MOST REGULATORY AUTHORITIES (INCLUDING OSHA IN THE USA) HOLD THE OWNER/USER ULTIMATELY RESPONSIBLE TO MAINTAIN A SAFE WORKING ENVIRONMENT. ACCORDINGLY, THE OWNER/USER MUST RECOGNIZE ALL FORESEEABLE SAFETY HAZARDS, FURNISH SAFETY INSTRUCTIONS AND GUIDANCE TO ALL PERSONNEL WHO MAY COME IN CONTACT WITH THE INSTALLATION, AND PROVIDE ALL NECESSARY ADDITIONAL SAFETY GUARDS, FENCES, RESTRAINTS, DEVICES, ETC., NOT FURNISHED BY THE EQUIPMENT MANUFACTURER OR VENDOR.

**ATTENTION**  
 THE FLOOR AND/OR OTHER SUPPORT COMPONENTS MUST HAVE SUFFICIENT STRENGTH (AND RIGIDITY WITH DUE CONSIDERATION FOR NATURAL OR RESONANT FREQUENCY THEREOF) TO WITHSTAND THE FULLY LOADED WEIGHT OF THE MACHINE INCLUDING THE GOODS, THE WATER, AND ANY REPEATED SINUSOIDAL (ROTATING) FORCES GENERATED DURING ITS OPERATION. WRITE THE FACTORY FOR ADDITIONAL MACHINE DATA FOR USE BY A COMPETENT SOIL AND/OR STRUCTURAL ENGINEER.

4840M7K




**MILNOR** PELLERIN MILNOR CORPORATION  
 P.O. Box 400 Kenner, LA 70063, USA, Phone 504/467-9591, FAX 504/469-1849, Email: milnorinfo@milnor.com



BASELINE "Z" (REFERENCE FOR VERTICAL DIMENSIONS) CORRESPONDS TO TOP OF GROUT. SEE NOTE 3 AND 4.

REFERENCE LINE "Y" (REFERENCE FOR FRONT/REAR DIMENSIONS). SEE NOTE 3.

LEFT VIEW



CENTERLINE "X" (REFERENCE FOR LEFT/RIGHT DIMENSIONS). SEE NOTE 3.

FRONT VIEW


D2	DUAL DRAIN VALVES, TWO 4-1/2" DIAMETER CONNECTIONS
ITEM	LEGEND

- NOTES**
- AS OF THIS WRITING, THE MINIMUM CLEARANCE REQUIRED BY U.S. NATIONAL ELECTRIC CODES, FROM ELECTRIC BOX TO ANY OBJECT IS:  
 36 [914] IF OBJECT IS AN UNGROUNDED (INSULATED) WALL.  
 42 [1067] IF OBJECT IS A GROUNDED WALL (i.e. BARE CONCRETE, BRICK, ETC.).  
 48 [1219] IF OBJECT IS ANY LIVE PART.  
 CHECK LOCAL ELECTRIC CODES FOR FURTHER RESTRICTIONS.
  - CUSTOMER TO SUPPLY CIRCUIT BREAKER OR FUSED BRANCH CIRCUIT DISCONNECT (SAFETY) SWITCHES WITH LAG TYPE FUSES FROM POWER SOURCE TO MACHINE. A SEPARATE GROUND WIRE MUST BE CONNECTED FROM DISCONNECT TO EQUIPMENT.
  - BASELINE "Z" IS THE SAME FOR ALL MILNOR MACHINES AND IS SHOWN ON ALL DIMENSIONAL DRAWINGS. THE DISTANCE BETWEEN BASELINE "Z" AND THE FINISHED FLOOR MAY VARY (WITH CHANGES IN FLOOR HEIGHT) AS REQUIRED TO INSURE THAT BASELINE "Z" IS HORIZONTAL AND ALL COMPONENTS REQUIRING GROUT ARE SET ON A MINIMUM 1" [25] THICK GROUT BED.
  - USE REFERENCE LINES "X", "Y", AND "Z" TO LOCATE ALL SERVICE CONNECTIONS.
  - NUMBERS IN BRACKETS [ ] DENOTE DIMENSIONS IN MILLIMETERS.
  - ALL DIMENSIONS SHOWN ARE APPROXIMATE, SUBJECT TO NORMAL MANUFACTURING TOLERANCES, AND TO OCCASIONAL CHANGES WITHOUT NOTICE THROUGH REDESIGN AND/OR RELOCATION OF COMPONENTS, ETC. DO NOT USE FOR CONSTRUCTION UNLESS CERTIFIED, AND IN NO EVENT PRE-PIPE CLOSER THAN FIVE FEET FROM MACHINE. FACTORY MUST BE CONSULTED FOR DIMENSIONS IF MACHINE IS TO BE MOVED THROUGH NARROW OR LOW CORRIDORS OR OPENINGS.

**ATTENTION**  
 MOST REGULATORY AUTHORITIES (INCLUDING OSHA IN THE USA) HOLD THE OWNER/USER ULTIMATELY RESPONSIBLE TO MAINTAIN A SAFE WORKING ENVIRONMENT. ACCORDINGLY, THE OWNER/USER MUST RECOGNIZE ALL FORESEEABLE SAFETY HAZARDS, FURNISH SAFETY INSTRUCTIONS AND GUIDANCE TO ALL PERSONNEL WHO MAY COME IN CONTACT WITH THE INSTALLATION, AND PROVIDE ALL NECESSARY ADDITIONAL SAFETY GUARDS, FENCES, RESTRAINTS, DEVICES, ETC., NOT FURNISHED BY THE EQUIPMENT MANUFACTURER OR VENDOR.

**ATTENTION**  
 THE FLOOR AND/OR OTHER SUPPORT COMPONENTS MUST HAVE SUFFICIENT STRENGTH (AND RIGIDITY WITH DUE CONSIDERATION FOR NATURAL OR RESONANT FREQUENCY THEREOF) TO WITHSTAND THE FULLY LOADED WEIGHT OF THE MACHINE INCLUDING THE GOODS, THE WATER, AND ANY REPEATED SINUSOIDAL (ROTATING) FORCES GENERATED DURING ITS OPERATION. WRITE THE FACTORY FOR ADDITIONAL MACHINE DATA FOR USE BY A COMPETENT SOIL AND/OR STRUCTURAL ENGINEER.

4840M7K OPTIONS




DWG# BD4840M7KAB  
 2016253D







THIS DRAWING IS FOR THE DRYELL LOADING OPTION. USE THIS DRAWING WITH BD4840M7KAE




LEFT VIEW: SHIPPING




FOUNDATION PLAN




RIGHT VIEW LOAD POSITION ELBOW UP




REAR VIEW WASH




PLAN VIEW LOAD




RIGHT VIEW UNLOAD & TRAVEL CLEARANCE




LEFT VIEW WASH



FRONT VIEW WASH



RIGHT VIEW LOAD



INSTALLATION DETAIL

ITEM	LEGEND
X1	SHIPPING TIE DOWN BRACKET
F4	1-1/16" DIAMETER ANCHOR BOLT HOLES, USE 3/4" X 6" BOLTS MINIMUM. IF F3 HOLES ARE NOT USED, YOU MUST ANCHOR THE (2) F4 HOLES NEAREST TO F3, BOTH SIDES. ALTERNATE F4 HOLES ARE AVAILABLE TO ACCOMMODATE DRAIN TROUGHS.
F3	1-1/16" DIAMETER ANCHOR BOLT HOLES, USE 3/4" X 6" BOLTS. YOU MUST ANCHOR THESE (2) F3 HOLES OR (4) F4 HOLES.
F2	1-1/16" DIAMETER ANCHOR BOLT HOLES, USE 3/4" X 6" BOLTS MINIMUM. ANCHOR ONE OF THE 3 HOLES IN EACH BOXED AREA.
F1	BASEPADS, SEE NOTE 7.
E8	SAFETY LIGHT SCREEN, DASHED
E7	SAFETY LIGHT SCREEN REFLECTOR (STANDARD)
E6	SAFETY LIGHT SCREEN RECEIVER (STANDARD)
E5	SAFETY LIGHT SCREEN EMITTER (STANDARD)
E2	MiTouch-EX™ TOUCH SCREEN CONTROLLER
B1	DRYELL LOADING, OPTIONAL

- NOTES**
- SHIM TO LEVEL THE MACHINE AND ALLOW FOR 1" [25] MINIMUM GROUT. ANCHOR WITH ONE ANCHOR BOLT PER BASEPAD (F1). MINIMUM USE 3/4" X 6" BOLTS. MINIMUM SEE INSTALLATION MAINTENANCE MANUAL FOR FURTHER INSTRUCTIONS.
  - SHADED AREAS ARE BASE PLATES WHICH MUST BE CONTINUOUSLY SUPPORTED ON 1" [25] THICK GROUT.
  - AS OF THIS WRITING, THE MINIMUM CLEARANCE REQUIRED BY U.S. NATIONAL ELECTRIC CODES, FROM ELECTRIC BOX TO ANY OBJECT IS:
    - 36 [914] IF OBJECT IS AN UNGROUNDED (INSULATED) WALL.
    - 42 [1067] IF OBJECT IS A GROUNDED WALL (ie. BARE CONCRETE, BRICK, ETC.)
    - 48 [1219] IF OBJECT IS ANY LIVE PART.
 CHECK LOCAL ELECTRIC CODES FOR FURTHER RESTRICTIONS.
  - CUSTOMER TO SUPPLY CIRCUIT BREAKER OR FUSED BRANCH CIRCUIT DISCONNECT (SAFETY) SWITCHES WITH LAG TYPE FUSES FROM POWER SOURCE TO MACHINE. A SEPARATE GROUND WIRE MUST BE CONNECTED FROM DISCONNECT TO EQUIPMENT.
  - BASELINE "Z" IS THE SAME FOR ALL MILNOR MACHINES AND IS SHOWN ON ALL DIMENSIONAL DRAWINGS. THE DISTANCE BETWEEN BASELINE "Z" AND THE FINISHED FLOOR MAY VARY (WITH CHANGES IN FLOOR HEIGHT) AS REQUIRED TO INSURE THAT BASELINE "Z" IS HORIZONTAL AND ALL COMPONENTS REQUIRING GROUT ARE SET ON A MINIMUM 1" [25] THICK GROUT BED.
  - USE REFERENCE LINES "X", "Y", AND "Z" TO LOCATE ALL SERVICE CONNECTIONS.
  - NUMBERS IN BRACKETS [ ] DENOTE DIMENSIONS IN MILLIMETERS.
  - ALL DIMENSIONS SHOWN ARE APPROXIMATE, SUBJECT TO NORMAL MANUFACTURING TOLERANCES, AND TO OCCASIONAL CHANGES WITHOUT NOTICE THROUGH REDESIGN AND/OR RELOCATION OF COMPONENTS, ETC. DO NOT USE FOR CONSTRUCTION UNLESS CERTIFIED, AND IN NO EVENT PRE-PIPE CLOSER THAN FIVE FEET FROM MACHINE. FACTORY MUST BE CONSULTED FOR DIMENSIONS IF MACHINE IS TO BE MOVED THROUGH NARROW OR LOW CORRIDORS OR OPENINGS.
- ATTENTION**  
 MOST REGULATORY AUTHORITIES (INCLUDING OSHA IN THE USA) HOLD THE OWNER/USER ULTIMATELY RESPONSIBLE TO MAINTAIN A SAFE WORKING ENVIRONMENT. ACCORDINGLY, THE OWNER/USER MUST RECOGNIZE ALL FORESEEABLE SAFETY HAZARDS, FURNISH SAFETY INSTRUCTIONS AND GUIDANCE TO ALL PERSONNEL WHO MAY COME IN CONTACT WITH THE INSTALLATION, AND PROVIDE ALL NECESSARY ADDITIONAL SAFETY GUARDS, FENCES, RESTRAINTS, DEVICES, ETC., NOT FURNISHED BY THE EQUIPMENT MANUFACTURER OR VENDOR.
- ATTENTION**  
 THE FLOOR AND/OR OTHER SUPPORT COMPONENTS MUST HAVE SUFFICIENT STRENGTH (AND RIGIDITY WITH DUE CONSIDERATION FOR NATURAL OR RESONANT FREQUENCY THEREOF) TO WITHSTAND THE FULLY LOADED WEIGHT OF THE MACHINE INCLUDING THE GOODS, THE WATER, AND ANY REPEATED SINUSOIDAL (ROTATING) FORCES GENERATED DURING ITS OPERATION. WRITE THE FACTORY FOR ADDITIONAL MACHINE DATA FOR USE BY A COMPETENT SOIL AND/OR STRUCTURAL ENGINEER.

4840M7K with DRYELL

DM 0 0.5M 1M DWG# BD4840M7KAC 2019126D

INCHES 0 12 24 36

MILNOR PELLERIN MILNOR CORPORATION

P.O. Box 400 Kenner, LA 70063, USA, Phone 504/467-9591, FAX 504/469-1849, Email: milnorinfo@milnor.com