



Published Manual Number/ECN: MPP42WEDBE/2019066A


- Publishing System: TPAS2
- Access date: 02/08/2019
- Document ECNs: Latest

Service

**42044CP2, CP3, NP2, NP3, WP2,
WP3 SM**

42044WR2, WR3

Washer-Extractors



**Read the
separate
safety
manual
before
installing,
operating,
or servicing**



Table of Contents

MPP42WEDBE/19066A

Page	Description	Document
1	Limited Standard Warranty	BMP720097/2019036
2	How to Get the Necessary Repair Components	BIUUUD19/20081231
3	Trademarks	BNUUUU02/2017285A
4	Safety—Divided Cylinder and Staph-Guard™ Washer-Extractors	BIUUUS27ND/20051111
9	About the Forces Transmitted by Milnor® Washer-extractors	BIWUUU02/20001108
11	Understanding Tag Guidelines	BIUUUU02HD/20160713
15	Installation Tag Guidelines - 42044, 60044, 72044 SR2/SR3 & WR2/WR3	BNWG4I01/2018213A
18	Safety Placard Use and Placement, 4244WP2 & NP2 SM	BMP040080/2007215V
20	Safety Placard Use and Placement ISO, 4244WP2 & NP2 SM	BMP040081/2007215V
22	Prevent Damage from Chemical Supplies and Chemical Systems	BIWUUU03/2017353A
27	1. Service and Maintenance	
28	General Assembly	BMP030028/2006144B
36	Lubrication and Preventive Maintenance for Hydrocushion Machines	MSSM0201CE/2004046V
46	Lubricants for Milnor Machines	MSSM0132AE/199903AV
47	Motor Maintenance	BIUUUM03/2011433A
51	Torque Requirements for Fasteners	BIUUUM04/20180109
59	2. Drive Assemblies	
60	Drive Chart	BMP050075/2013353B
62	Drive Base Installation	BMP050074/2006286B
66	Jackshaft	BMP050076/2005525B
68	Brake Assembly	BMP050077/2015422A
71	Autospot Installation	BMP050078/2006135B
73	Autospot Installation	BMP050079/2006135B
75	V-Belt Tension Adjustments	MSSM0301AE/199126BV
77	3. Bearing Assemblies	
78	Main Bearing and Seal Replacement for Divided Cylinder Machines	MSSM0303AE/198451BV
88	Main Bearing Assembly	BMP840040/2006344B
91	4. Frame, Pivots, and Suspension	
92	Suspension Adjustments for Divided Cylinder Machines	MSSM0302AE/198414BV
98	Suspension Cylinder Locations	BMP701235/2017155A
99	Suspension Cylinder Assemblies	BMP701408/2006275B
101	5. Shell and Door Assemblies	

Table of Contents, continued

MPP42WEDBE/19066A

Page	Description	Document
102	Door Seal Replacement on Rapid Load Models	MSSMA413AE/198530BV
106	Cylinder Assembly 4244WP2, NP2, CP2, SP2	BMP701232/2006352B
107	Cylinder Assembly 4244WP3, SP3	BMP080003/2008112B
108	Shell Doors	BMP990047/2008095B
110	Cylinder Doors	BMP990048/2006336B
112	Door Latch	BMP700630/2011265B
113	6. Control and Sensing Assemblies	
114	Excursion Switch	BMP060038/2006333B
115	Vibration Safety Switch Adjustments	MSSMA408BE/199273BV
117	Vibration Safety Switch	BMP140032/2014155A
118	Air Chamber Level Switch	BMP060046/2018484A
119	Temperature Probe	BMP180075/2018484A
121	7. Chemical Supply Devices	
122	Rules for the Field Installation of Pumped-Type Liquid Supply Systems	MSSM0213AE/1989457V
124	Supply Injector Assembly	BMP970075/2006402B
127	8. Water and Steam Piping and Assemblies	
128	Water & Steam Schematics	BMP940112/2003262V
130	Water Inlets	BMP030031/2006402B
132	Steam Inlet	BMP030032/2003262V
135	Flushing Water Supply	BMP030033/2006402B
137	Servicing Air Cylinders	MSSM0130AE/199313AV
139	Universal Actuators & Mounting Hardware for Watts Ball Valves - New Pivot	BMP920005/1996067V
142	Watts Ball Valves and Repair Kits	BMP920007/1996067V
144	Air Cylinders for 1", 1.25", 1.5", & 2" Watts Ball Valves	BMP920006/2017465B
146	Pressure Regulators	BMP900031/2011276B
148	8" & 10" Stainless Dump Valve	BMP780095/2006363B
149	3 & 4 Inch Dump Valve Assembly	BMP800228/2002226V
151	9. Pneumatic Piping and Assemblies	
152	Pneumatic Schematics - 42044WP2/CP2/NP2	BMP940113/1994497V
154	3 Way Pilot Valves	BMP900032/1991182V
155	Asco 3-way Solenoid Valves	BMP701359/1997086V
157	2-Way Electric Water Valve	BMP920029/1998443V
159	Air Valves & Mounting Hardware	BMP780087/1983457B
160	Parts List - Air Valves & Mounting Hardware	BMP780087R/2018462A
162	Quick Exhaust Valves	BMP701406/2002382V
164	Brake Air Cylinder	BMP070011/2014184A

PELLERIN MILNOR CORPORATION LIMITED STANDARD WARRANTY

We warrant to the original purchaser that MILNOR machines including electronic hardware/software (**hereafter referred to as "equipment"**), **will be free from defects in material and workmanship for a** period of one year from the date of shipment (unless the time period is specifically extended for certain parts pursuant to a specific MILNOR published extended warranty) from our factory with no operating hour limitation. This warranty is contingent upon the equipment being installed, operated and serviced as specified in the operating manual supplied with the equipment, and operated under normal conditions by competent operators.

Providing we receive written notification of a warranted defect within 30 days of its discovery, we will—at our option—repair or replace the defective part or parts, EX Factory (labor and freight specifically NOT included). We retain the right to require inspection of the parts claimed defective in our factory prior to repairing or replacing same. We will not be responsible, or in any way liable, for unauthorized repairs or service to our equipment, and this warranty shall be void if the equipment is tampered with, modified, or abused, used for purposes not intended in the design and construction of the machine, or is repaired or altered in any way without MILNOR's written consent.

Parts damaged by exposure to weather, to aggressive water, or to chemical attack are not covered by this warranty. For parts which require routine replacement due to normal wear—such as gaskets, contact points, brake and clutch linings, belts, hoses, and similar parts—the warranty time period is 90 days.

We reserve the right to make changes in the design and/or construction of our equipment (including purchased components) without obligation to change any equipment previously supplied.

ANY SALE OR FURNISHING OF ANY EQUIPMENT BY MILNOR IS MADE ONLY UPON THE EXPRESS UNDERSTANDING THAT MILNOR MAKES NO EXPRESSED OR IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR ANY PARTICULAR USE OR PURPOSE OR ANY OTHER WARRANTY IMPLIED BY LAW INCLUDING BUT NOT LIMITED TO REDHIBITION. MILNOR WILL NOT BE RESPONSIBLE FOR ANY COSTS OR DAMAGES ACTUALLY INCURRED OR REQUIRED AS A RESULT OF: THE FAILURE OF ANY OTHER PERSON OR ENTITY TO PERFORM ITS RESPONSIBILITIES, FIRE OR OTHER HAZARD, ACCIDENT, IMPROPER STORAGE, MIS-USE, NEGLIGENCE, POWER OR ENVIRONMENTAL CONTROL MALFUNCTIONS, DAMAGE FROM LIQUIDS, OR ANY OTHER CAUSE BEYOND THE NORMAL RANGE OF USE. REGARDLESS OF HOW CAUSED, IN NO EVENT SHALL MILNOR BE LIABLE FOR SPECIAL, INDIRECT, PUNITIVE, LIQUIDATED, OR CONSEQUENTIAL COSTS OR DAMAGES, OR ANY COSTS OR DAMAGES WHATSOEVER WHICH EXCEED THE PRICE PAID TO MILNOR FOR THE EQUIPMENT IT SELLS OR FURNISHES.

THE PROVISIONS ON THIS PAGE REPRESENT THE ONLY WARRANTY FROM MILNOR AND NO OTHER WARRANTY OR CONDITIONS, STATUTORY OR OTHERWISE, SHALL BE IMPLIED.

WE NEITHER ASSUME, NOR AUTHORIZE ANY EMPLOYEE OR OTHER PERSON TO ASSUME FOR US, ANY OTHER RESPONSIBILITY AND/OR LIABILITY IN CONNECTION WITH THE SALE OR FURNISHING OF OUR EQUIPMENT TO ANY BUYER.

BMP720097/19036

How to Get the Necessary Repair Components



This document uses Simplified Technical English.
Learn more at <http://www.asd-ste100.org>.

You can get components to repair your machine from the approved supplier where you got this machine. Your supplier will usually have the necessary components in stock. You can also get components from the Milnor® factory.

Tell the supplier the machine model and serial number and this data for each necessary component:

- The component number from this manual
- The component name if known
- The necessary quantity
- The necessary transportation requirements
- If the component is an electrical component, give the schematic number if known.
- If the component is a motor or an electrical control, give the nameplate data from the used component.

To write to the Milnor factory:

Pellerin Milnor Corporation
Post Office Box 400
Kenner, LA 70063-0400
UNITED STATES

Telephone: 504-467-2787
Fax: 504-469-9777
Email: parts@milnor.com

— End of BIUUUD19 —

Trademarks

BNUUUU02.R01 0000158093 A.2 7/13/17 1:11 PM Released

These words are trademarks of Pellerin Milnor Corporation and other entities:

Table 1 Trademarks

AutoSpot™	GreenTurn™	Milnor®	PulseFlow®
CBW®	GreenFlex™	MilMetrix®	PurePulse®
Drynet™	Hydro-cushion™	MilTouch™	Ram Command™
E-P Express®	Linear Costa Master™	MilTouch-EX™	RecircONE®
E-P OneTouch®	Linear Costo™	Miltrac™	RinSave®
E-P Plus®	Mentor®	MultiTrac™	SmoothCoil™
Gear Guardian®	Mildata®	PBW™	Staph Guard®

End of document: BNUUUU02

Safety—Divided Cylinder and Staph-Guard™ Washer-Extractors

1. General Safety Requirements—Vital Information for Management Personnel [Document BIUUUS04]

Incorrect installation, neglected preventive maintenance, abuse, and/or improper repairs, or changes to the machine can cause unsafe operation and personal injuries, such as multiple fractures, amputations, or death. The owner or his selected representative (owner/user) is responsible for understanding and ensuring the proper operation and maintenance of the machine. The owner/user must familiarize himself with the contents of all machine instruction manuals. The owner/user should direct any questions about these instructions to a Milnor® dealer or the Milnor® Service department.

Most regulatory authorities (including OSHA in the USA and CE in Europe) hold the owner/user ultimately responsible for maintaining a safe working environment. Therefore, the owner/user must do or ensure the following:

- recognize all foreseeable safety hazards within his facility and take actions to protect his personnel, equipment, and facility;
- work equipment is suitable, properly adapted, can be used without risks to health or safety, and is adequately maintained;
- where specific hazards are likely to be involved, access to the equipment is restricted to those employees given the task of using it;
- only specifically designated workers carry out repairs, modifications, maintenance, or servicing;
- information, instruction, and training is provided;
- workers and/or their representatives are consulted.

Work equipment must comply with the requirements listed below. The owner/user must verify that installation and maintenance of equipment is performed in such a way as to support these requirements:

- control devices must be visible, identifiable, and marked; be located outside dangerous zones; and not give rise to a hazard due to unintentional operation;
- control systems must be safe and breakdown/damage must not result in danger;
- work equipment is to be stabilized;
- protection against rupture or disintegration of work equipment;
- guarding, to prevent access to danger zones or to stop movements of dangerous parts before the danger zones are reached. Guards to be robust; not give rise to any additional hazards; not be easily removed or rendered inoperative; situated at a sufficient distance from the danger zone; not restrict view of operating cycle; allow fitting, replacing, or maintenance by restricting access to relevant area and without removal of guard/protection device;
- suitable lighting for working and maintenance areas;
- maintenance to be possible when work equipment is shut down. If not possible, then protection measures to be carried out outside danger zones;
- work equipment must be appropriate for preventing the risk of fire or overheating; discharges of gas, dust, liquid, vapor, other substances; explosion of the equipment or substances in it.

- 1.1. **Laundry Facility**—Provide a supporting floor that is strong and rigid enough to support—with a reasonable safety factor and without undue or objectionable deflection—the weight of the fully loaded machine and the forces transmitted by it during operation. Provide sufficient clearance for machine movement. Provide any safety guards, fences, restraints, devices, and verbal and/or posted restrictions necessary to prevent personnel, machines, or other moving machinery from accessing the machine or its path. Provide adequate ventilation to carry away heat and vapors. Ensure service connections to installed machines meet local and national safety standards, especially regarding the electrical disconnect (see the National Electric Code). Prominently post safety information, including signs showing the source of electrical disconnect.
- 1.2. **Personnel**—Inform personnel about hazard avoidance and the importance of care and common sense. Provide personnel with the safety and operating instructions that apply to them. Verify that personnel use proper safety and operating procedures. Verify that personnel understand and abide by the warnings on the machine and precautions in the instruction manuals.
- 1.3. **Safety Devices**—Ensure that no one eliminates or disables any safety device on the machine or in the facility. Do not allow machine to be used with any missing guard, cover, panel or door. Service any failing or malfunctioning device before operating the machine.
- 1.4. **Hazard Information**—Important information on hazards is provided on the machine safety placards, in the Safety Guide, and throughout the other machine manuals. **Placards must be kept clean so that the information is not obscured. They must be replaced immediately if lost or damaged. The Safety Guide and other machine manuals must be available at all times to the appropriate personnel.** See the machine service manual for safety placard part numbers. Contact the Milnor Parts department for replacement placards or manuals.
- 1.5. **Maintenance**—Ensure the machine is inspected and serviced in accordance with the norms of good practice and with the preventive maintenance schedule. Replace belts, pulleys, brake shoes/disks, clutch plates/tires, rollers, seals, alignment guides, etc. before they are severely worn. Immediately investigate any evidence of impending failure and make needed repairs (e.g., cylinder, shell, or frame cracks; drive components such as motors, gear boxes, bearings, etc., whining, grinding, smoking, or becoming abnormally hot; bending or cracking of cylinder, shell, frame, etc.; leaking seals, hoses, valves, etc.) Do not permit service or maintenance by unqualified personnel.

2. **Safety Alert Messages—Internal Electrical and Mechanical Hazards** [Document BIUUUS11]

The following are instructions about hazards inside the machine and in electrical enclosures.



WARNING 1: Electrocution and Electrical Burn Hazards—Contact with electric power can kill or seriously injure you. Electric power is present inside the cabinetry unless the main machine power disconnect is off.

- Do not unlock or open electric box doors.
- Do not remove guards, covers, or panels.
- Do not reach into the machine housing or frame.
- Keep yourself and others off of machine.
- Know the location of the main machine disconnect and use it in an emergency to remove all electric power from the machine.



WARNING 2: Entangle and Crush Hazards—Contact with moving components normally isolated by guards, covers, and panels, can entangle and crush your limbs. These components move automatically.

- Do not remove guards, covers, or panels.
- Do not reach into the machine housing or frame.
- Keep yourself and others off of machine.
- Know the location of all emergency stop switches, pull cords, and/or kick plates and use them in an emergency to stop machine motion.

3. Safety Alert Messages—External Mechanical Hazards [Document BIUUUS12]

The following are instructions about hazards around the front, sides, rear or top of the machine.



WARNING 3: Crush Hazards—Suspended machines only—Spaces between the shell and housing can close and crush or pinch your limbs. The shell moves within the housing during operation.

- Do not reach into the machine housing or frame.
- Keep yourself and others clear of movement areas and paths.

4. Safety Alert Messages—Cylinder and Processing Hazards

[Document BIUUUS13]

The following are instructions about hazards related to the cylinder and laundering process.



WARNING 4: Crush Hazards—Contact with the turning cylinder can crush your limbs. The cylinder will repel any object you try to stop it with, possibly causing the object to strike or stab you. The turning cylinder is normally isolated by the locked cylinder door.

- Do not attempt to open the door or reach into the cylinder until the cylinder is stopped.
- Do not place any object in the turning cylinder.
- Do not operate the machine with a malfunctioning door interlock.
- Divided cylinder machines only—Keep yourself and others clear of cylinder and goods during inching or Autospot operation.
- Do not operate the machine with malfunctioning two-hand manual controls.



WARNING 5: Confined Space Hazards—Confinement in the cylinder can kill or injure you. Hazards include but are not limited to panic, burns, poisoning, suffocation, heat prostration, biological contamination, electrocution, and crushing.

- Do not attempt unauthorized servicing, repairs, or modification.



WARNING 6: Explosion and Fire Hazards—Flammable substances can explode or ignite in the cylinder, drain trough, or sewer. The machine is designed for washing with water, not any other solvent. Processing can cause solvent-containing goods to give off flammable vapors.

- Do not use flammable solvents in processing.
- Do not process goods containing flammable substances. Consult with your local fire department/public safety office and all insurance providers.

5. Safety Alert Messages—Unsafe Conditions [Document BIUUUS14]

5.1. Damage and Malfunction Hazards

5.1.1. Hazards Resulting from Inoperative Safety Devices



DANGER 7: Entangle and Sever Hazards—Cylinder door interlock—Operating the machine with a malfunctioning door interlock can permit opening the door when the cylinder is turning and/or starting the cycle with the door open, exposing the turning cylinder.

- Do not operate the machine with any evidence of damage or malfunction.



WARNING 8: Multiple Hazards—Operating the machine with an inoperative safety device can kill or injure personnel, damage or destroy the machine, damage property, and/or void the warranty.

- Do not tamper with or disable any safety device or operate the machine with a malfunctioning safety device. Request authorized service.



WARNING 9: Electrocution and Electrical Burn Hazards—Electric box doors—Operating the machine with any electric box door unlocked can expose high voltage conductors inside the box.

- Do not unlock or open electric box doors.



WARNING 10: Entangle and Crush Hazards—Guards, covers, and panels—Operating the machine with any guard, cover, or panel removed exposes moving components.

- Do not remove guards, covers, or panels.

5.1.2. Hazards Resulting from Damaged Mechanical Devices



WARNING 11: Multiple Hazards—Operating a damaged machine can kill or injure personnel, further damage or destroy the machine, damage property, and/or void the warranty.

- Do not operate a damaged or malfunctioning machine. Request authorized service.



WARNING 12: Explosion Hazards—Cylinder—A damaged cylinder can rip apart during extraction, puncturing the shell and discharging metal fragments at high speed.

- Do not operate the machine with any evidence of damage or malfunction.



WARNING 13: Explosion Hazards—Inner door latches (divided cylinder machines)—A damaged or improperly seated latch can cause the inner door to open during operation, damaging the cylinder and shell. A damaged cylinder can rip apart during extraction, puncturing the shell and discharging metal fragments at high speed.

- Ensure that the inner door is securely latched when loading and unloading.
- Do not operate the machine with any evidence of damage or malfunction.



WARNING 14: Explosion Hazards—Clutch and speed switch (multiple motor machines)—A damaged clutch or speed switch can permit the low speed motor to engage during extract. This will over-speed the motor and pulleys and can cause them to rip apart, discharging metal fragments at high speed.

- Stop the machine immediately if any of these conditions occur: • abnormal whining sound during extract • skidding sound as extract ends • clutches remain engaged or re-engage during extract

5.2. Careless Use Hazards

5.2.1. Careless Operation Hazards—Vital Information for Operator Personnel (see also operator hazards throughout manual)



WARNING 15: Multiple Hazards—Careless operator actions can kill or injure personnel, damage or destroy the machine, damage property, and/or void the warranty.

- Do not tamper with or disable any safety device or operate the machine with a malfunctioning safety device. Request authorized service.
- Do not operate a damaged or malfunctioning machine. Request authorized service.
- Do not attempt unauthorized servicing, repairs, or modification.
- Do not use the machine in any manner contrary to the factory instructions.
- Use the machine only for its customary and intended purpose.
- Understand the consequences of operating manually.

5.2.2. Careless Servicing Hazards—Vital Information for Service Personnel (see also service hazards throughout manuals)



WARNING 16: Electrocutation and Electrical Burn Hazards—Contact with electric power can kill or seriously injure you. Electric power is present inside the cabinetry unless the main machine power disconnect is off.

- Do not service the machine unless qualified and authorized. You must clearly understand the hazards and how to avoid them.
- Abide by the current OSHA lockout/tagout standard when lockout/tagout is called for in the service instructions. Outside the USA, abide by the OSHA standard in the absence of any other overriding standard.



WARNING 17: Entangle and Crush Hazards—Contact with moving components normally isolated by guards, covers, and panels, can entangle and crush your limbs. These components move automatically.

- Do not service the machine unless qualified and authorized. You must clearly understand the hazards and how to avoid them.
- Abide by the current OSHA lockout/tagout standard when lockout/tagout is called for in the service instructions. Outside the USA, abide by the OSHA standard in the absence of any other overriding standard.



WARNING 18: Confined Space Hazards—Confinement in the cylinder can kill or injure you. Hazards include but are not limited to panic, burns, poisoning, suffocation, heat prostration, biological contamination, electrocution, and crushing.

- Do not enter the cylinder until it has been thoroughly purged, flushed, drained, cooled, and immobilized.

— End of BIUUUS27 —

About the Forces Transmitted by Milnor® Washer-extractors

During washing and extracting, all washer-extractors transmit both static and dynamic (cyclic) forces to the floor, foundation, or any other supporting structure. During washing, the impact of the goods as they drop imparts forces which are quite difficult to quantify. Size for size, both rigid and flexibly-mounted machines transmit approximately the same forces during washing. During extracting, rigid machines transmit forces up to 30 times greater than equivalent flexibly-mounted models. The actual magnitude of these forces vary according to several factors:

- machine size,
- final extraction speed,
- amount, condition, and type of goods being processed,
- the liquor level and chemical conditions in the bath preceding extraction, and
- other miscellaneous factors.

Estimates of the maximum force normally encountered are available for each Milnor® model and size upon request. Floor or foundation sizes shown on any Milnor® document are only for on-grade situations based only on previous experience without implying any warranty, obligation, or responsibility on our part.

1. Rigid Machines

Size for size, rigid washer-extractors naturally require a stronger, more rigid floor, foundation, or other supporting structure than flexibly-mounted models. If the supporting soil under the slab is itself strong and rigid enough and has not subsided to leave the floor slab suspended without support, on grade installations can often be made directly to an existing floor slab if it has enough strength and rigidity to safely withstand our published forces without transmitting undue vibration. If the subsoil has subsided, or if the floor slab itself has insufficient strength and rigidity, a deeper foundation, poured as to become monolithic with the floor slab, may be required. Support pilings may even be required if the subsoil itself is “springy” (i.e., if its resonant frequency is near the operating speed of the machine). Above-grade installations of rigid machines also require a sufficiently strong and rigid floor or other supporting structure as described below.

2. Flexibly-mounted Machines

Size for size, flexibly-mounted machines generally do not require as strong a floor, foundation, or other supporting structure as do rigid machines. However, a floor or other supporting structure having sufficient strength and rigidity, as described in [Section 3](#), is nonetheless vitally important for these models as well.

3. How Strong and Rigid?

Many building codes in the U.S.A. specify that laundry floors must have a minimum live load capacity of 150 pounds per square foot (732 kilograms per square meter). However, even compliance with this or any other standard does not necessarily guarantee sufficient rigidity. In any event, it is the sole responsibility of the owner/user to assure that the floor and/or any other supporting structure exceeds not only all applicable building codes, but also that the floor and/or any other supporting structure for each washer-extractor or group of washer-extractors actually has sufficient strength and rigidity, plus a reasonable factor of safety for both, to support the weight of all the fully loaded machine(s) including the weight of the water and goods, and including the published 360° rotating sinusoidal RMS forces that are transmitted by the machine(s). Moreover, the floor, foundation, or other supporting structure must have sufficient

rigidity (i.e., a natural or resonant frequency many times greater than the machine speed with a reasonable factor of safety); otherwise, the mentioned 360° rotating sinusoidal RMS forces can be multiplied and magnified many times. It is especially important to consider all potential vibration problems that might occur due to all possible combinations of forcing frequencies (rotating speeds) of the machine(s) compared to the natural frequencies of the floor and/or any other supporting structure(s). A qualified soil and/or structural engineer must be engaged for this purpose.

Figure 1: How Rotating Forces Act on the Foundation




Figure 1 above is intended to depict both on-grade and above-grade installations and is equally applicable to flexibly-mounted washer-extractors, as well as to rigid models installed either directly on a floor slab or on a foundation poured integrally with the slab. Current machine data is available from Milnor® upon request. All data is subject to change without notice and may have changed since last printed. It is the sole responsibility of every potential owner to obtain written confirmation that any data furnished by Milnor® applies for the model(s) and serial number(s) of the specific machines.

— End of BIWUI02 —

BIUUUI02HD (Published) Book specs- Dates: 20160713 / 20160713 / 20160713 Lang: ENG01 Applic: HDU

Tag Guidelines for the Models Listed Below

42044CP2 42044NP2 42044SP2 42044SP3 42044WP2 42044WP3 60044SP2
 60044SP3 60044WP2 60044WP3 72044SP2 72044SP3 72044WP2 72044WP3


Notice 1: This information may apply to models in addition to those listed above. It applies to paper tags. It does not apply to the vinyl or metal safety placards, which must remain permanently affixed to the machine and replaced if no longer readable.

Paper tags on the machine provide installation guidelines and precautions. The tags can be tie-on or adhesive. You can remove tie-on tags and white, adhesive tags after installation. Yellow adhesive tags must remain on the machine.

Tag Guidelines for the Models Listed Below

The following entries explain the installation tags. Each entry includes: 1) the tag illustration, 2) the tag part number displayed at the bottom of the tag, and 3) the meaning of the tag.

Display or Action



Explanation


Read the manuals before proceeding. This symbol appears on most tags. The machine ships with safety, operator, and routine maintenance guides for customer use. Milnor dealer manuals for installing, servicing, and commissioning this machine are also available from the Milnor Parts department.



B2TAG88005: This carefully built product was tested and inspected to meet Milnor® performance and quality standards by (identification mark of tester).




B2TAG94078: Do not forklift here; do not jack here; do not step here—whichever applies.




B2TAG94079: Rig for crane lifting (either 3-point or 4-point, depending on the number of lifting eyes provided) using a steep angle on the chains (closer to vertical than horizontal).




B2TAG94081: Motor must rotate in this direction. On single motor washer-extractors and centrifugal extractors, the drive motor must turn in this direction during draining and extraction. This tag is usually wrapped around a motor housing. If the motor turns in the opposite direction when the machine is first tested, the electrical hookup is incorrect and must be reversed as explained in the schematic manual.



B2TAG94084: Do not lift from one corner of the machine, as this can cause the frame to rack, damaging it.




B2TAG94097: The cylinder must rotate **counterclockwise** during draining and extraction (spin) when viewed from here (rear of machine). Otherwise, reverse the electric power connections, as explained in the schematic manual.




B2TAG94117: The brake assembly under the machine is fragile. Fork lift only under main structural supports.

Display or Action


Explanation



B2TAG94118: Do not strike shipping container during forklifting. Fragile components inside.




B2TAG96007: Add grease here. Refer to the preventive maintenance schedule in the service manual.



B2T2001013: Hot water connection.



B2T2001014: Cold water connection.



B2T2001028: Look for tags inside the machine. These tags may identify shipping restraints to be removed or components to be installed. Do not start the machine until these actions are completed.



B2T2002013: Do not start the machine until shipping restraints are removed. This tag will appear on the outside of the machine to alert you to the presence of internal shipping restraints. A tag will also appear on the restraint to help identify it. Most, but not all shipping restraints display the color red. Some shipping restraints are also safety stands. Do not discard these.

Tag Guidelines for the Models Listed Below

Display or Action



Explanation


B2T2004027: Steam connection (optional)

— End of BIUUUI02 —

Installation Tag Guidelines

BNWG4I01.R01 0000187278 A.2 5/22/18 4:30 PM Released

42044SR2	42044SR3	42044WR2	42044WR3
60044SR2	60044SR3	60044WR2	60044WR3
72044SR2	72044SR3	72044WR2	72044WR3


 **NOTICE:** This information may apply to models in addition to those listed above. It applies to paper tags. It does not apply to the vinyl or metal safety placards, which must remain permanently affixed to the machine and replaced if no longer readable.

Paper tags on the machine provide installation guidelines and precautions. The tags can be tie-on or adhesive. You can remove tie-on tags and white, adhesive tags after installation. Yellow adhesive tags must remain on the machine.

The following entries explain the installation tags. Each entry includes: 1) the tag illustration, 2) the tag part number at the bottom of the tag, and 3) the meaning of the tag.

Display or Action

Explanation




Read the manuals before proceeding. This symbol appears on most tags. The machine ships with safety, operator, and routine maintenance guides for customer use. Milnor dealer manuals for installing, commissioning, and servicing the machine are also available from the Milnor Parts department.



B2TAG88005: This carefully built product was tested and inspected to meet Milnor performance and quality standards by (identification mark of tester).




B2TAG94078: Do not forklift here; do not jack here; do not step here—whichever applies.



B2TAG94079: Rig for crane lifting (either 3-point or 4-point, depending on the number of lifting eyes provided) using a steep angle on the chains (closer to vertical than horizontal).


B2TAG94081: Motor must rotate in this direction. On single motor washer-extractors and centrifugal extractors, the drive motor must turn in this direction during draining and extraction. This tag is usually wrapped around a motor housing. If the motor turns in the opposite direction when the machine is first tested, the electrical hookup is incorrect and must be reversed as explained in the schematic manual.




B2TAG94084: Do not lift from one corner of the machine, as this can cause the frame to rack, damaging it.




B2TAG94097: The cylinder must rotate **counterclockwise** during draining and extraction (spin) when viewed from here (rear of machine). Otherwise, reverse the electric power connections, as explained in the schematic manual.




B2TAG94117: The brake assembly under the machine is fragile. Fork lift only under main structural supports.




B2TAG94118: Do not strike shipping container during fork-lifting. Fragile components inside.



B2TAG96007: Add grease here. Refer to the preventive maintenance schedule in the service manual.




B2T2001013: Hot water connection.




B2T2001014: Cold water connection.



B2T2001015: Reuse (third) water connection. (Optional)



B2T2001016: Flushing water connection. This is the water that goes into the supply compartment or pumped chemical manifold to flush chemicals into the machine.



B2T2001028: Look for tags inside the machine. These tags may identify shipping restraints to be removed or components to be installed. Do not start the machine until these actions are completed.



B2T2002013: Do not start the machine until shipping restraints are removed. This tag will appear on the outside of the machine to alert you to the presence of internal shipping restraints. A tag will also appear on the restraint to help identify it. Most, but not all shipping restraints display the color red. Some shipping restraints are also safety stands. Do not discard these.



B2T2004027: Steam connection.

End of document: BNWG4I01

Safety Placard Use and Placement 42044WP2 & NP2 SINGLE MOTOR DRIVE

BMP040080/2007215B
(Sheet 1 of 2)




Pellerin Milnor Corporation
P. O. Box 400, Kenner, LA 70063-0400


Litho in U.S.A.

Notes:


1. Replace placard immediately, if removed or unreadable.
2. Approximate locations of placards are shown. Mounting holes are provided on machine. Use #8 self-tapping screws.




REAR VIEW



FRONT VIEW



LEFT VIEW



RIGHT VIEW



Pellerin Milnor Corporation
P. O. Box 400, Kenner, LA 70063-0400

Litho in U.S.A.

Parts List—Safety Placard Placement

Find the correct assembly first, then find the needed components. The item letters (A, B, C, etc.) assigned to assemblies are referred to in the "Used In" column to identify which components belong to an assembly. The item numbers (1, 2, 3, etc.) assigned to components relate the parts list to the illustration.

Used In	Item	Part Number	Description	Comments
			-----ASSEMBLIES----- none	
			-----COMPONENTS-----	
all	10	01 10627A	NPLT:DIV-CYL/STAPH WARN-TCATA	
all	20	01 10377A	NPLT:ELEC HAZARD LG-TCATA	
all	30	01 10689A	NPLT:BELT HAZARD SM TCATA	
all	40	01 10648A	NPLT:GEAR HAZARD -TCATA	
all	50	01 10685A	NPLT:BURN HAZARD-TCATA	
all	60	01 10699B	NPLT:SERV HZRD-ALUM-TCATA	

Safety Placard Use and Placement ISO 42044WP2 & NP2 SINGLE MOTOR DRIVE

BMP040081/2007215B
(Sheet 1 of 2)




Pellerin Milnor Corporation
P. O. Box 400, Kenner, LA 70063-0400

Litho in U.S.A.


ISO Placards shown on this page

Notes:


1. Replace placard immediately, if removed or unreadable.
2. Approximate locations of placards are shown. Mounting holes are provided on machine. Use #8 self-tapping screws.




REAR VIEW



LEFT VIEW



FRONT VIEW



RIGHT VIEW



Pellerin Milnor Corporation
P. O. Box 400, Kenner, LA 70063-0400

Litho in U.S.A.

Parts List—Safety Placard Placement

Find the correct assembly first, then find the needed components. The item letters (A, B, C, etc.) assigned to assemblies are referred to in the "Used In" column to identify which components belong to an assembly. The item numbers (1, 2, 3, etc.) assigned to components relate the parts list to the illustration.

Used In	Item	Part Number	Description	Comments
-----ASSEMBLIES-----				
none				
-----COMPONENTS-----				
all	10	01 10627X	NPLT:DIVCYL SG WARNG FRT ISO	
all	20	01 10377	NPLTE:"WARNING" 4X4	
all	30	01 10628X	NPLT:NONTILT W/E WARNING SIDE	
all	40	01 10648X	NPLT:ACTUATED VALVE WARN-ISO	
all	50	01 10649X	NPLT:HOT BEHIND CVR WARN-ISO	

Prevent Damage from Chemical Supplies and Chemical Systems

BNUUUR02.C01 0000160549 A.2 8/29/17 3:22 PM Released

All Milnor® washer-extractors and CBW® tunnel washers use stainless steel with the AISI 304 specification. This material gives good performance when chemical supplies are correctly applied. If chemical supplies are incorrectly applied, this material can be damaged. The damage can be very bad and it can occur quickly.

Chemical supply companies usually:

- supply chemical pump systems that put the supplies in the machine,
- connect the chemical pump system to the machine,
- write wash formulas that control the chemical concentrations.

The company that does these procedures must make sure that these procedures do not cause damage. **Pellerin Milnor Corporation accepts no responsibility for chemical damage to the machines it makes or to the goods in a machine.**

1. How Chemical Supplies Can Cause Damage

BNUUUR02.R01 0000160548 A.2 A.4 8/30/17 3:15 PM Released

Dangerous Chemical Supplies and Wash Formulas

Some examples that can cause damage are:

- a very high concentration of chlorine bleach,
- a mixture of acid sour and hypo chlorite,
- chemical supplies (examples: chlorine bleach, hydrofluosilicic acid) that stay on the stainless steel because they are not quickly flushed with water.

The book “Textile Laundering Technology” by Charles L. Riggs gives data about correct chemical supplies and formulas.

Incorrect Configuration or Connection of Equipment

Many chemical systems:

- do not prevent a vacuum in the chemical tube (for example, with a vacuum breaker) when the pump is off,
- do not prevent flow (for example, with a valve) where the chemical tube goes in the machine.

Damage will occur if a chemical supply can go in the machine when the chemical system is off. Some configurations of components can let the chemical supplies go in the machine by a siphon ([Figure 1. Incorrect Configurations That Let the Chemical Supply Go In the Machine by a Siphon](#)). Some can let chemical supplies go in the machine by gravity ([Figure 2. Incorrect Configurations That Let the Chemical Supply Go In the Machine by Gravity](#)).

Figure 1. Incorrect Configurations That Let the Chemical Supply Go In the Machine by a Siphon





Figure 2. Incorrect Configurations That Let the Chemical Supply Go In the Machine by Gravity




2. Equipment and Procedures That Can Prevent Damage

BNUUUR02.R02 0000160545 A.2 A.8 8/30/17 3:28 PM Released

Use the chemical manifold supplied.

There is a manifold on the machine to attach chemical tubes from a chemical pump system. The manifold has a source of water to flush the chemical supplies with water.

Figure 3. Examples of Manifolds for Chemical Tubes. Your equipment can look different.



Close the line.

If the pump does not always close the line when it is off, use a shutoff valve to do this.

Do not let a vacuum occur.

Supply a vacuum breaker in the chemical line that is higher than the full level of the tank.


Flush the chemical tube with water.

If the liquid that stays in the tube between the pump and the machine can flow in the machine, flush the tube with water after the pump stops.

Put the chemical tube fully below the inlet.

It is also necessary that there is no pressure in the chemical tube or tank when the system is off.

Figure 4. A Configuration that Prevents Flow in the Machine When the Pump is Off (if the chemical tube and tank have no pressure)



Prevent leaks.

When you do maintenance on the chemical pump system:

- Use the correct components.
- Make sure that all connections are the correct fit.
- Make sure that all connections are tight.

End of document: BNUUUR02

Service and Maintenance

1



General Assembly
4231 & 4244WP2/WP3

BMP030028/2006144B
 (Sheet 1 of 8)



Pellerin Milnor Corporation
 P. O. Box 400, Kenner, LA 70063-0400

Litho in U.S.A.




General Assembly
4231 & 4244WP2/WP3

BMP030028/2006144B
 (Sheet 2 of 8)



Pellerin Milnor Corporation
 P. O. Box 400, Kenner, LA 70063-0400

Litho in U.S.A.



DRIVE CHART
 SEE
 BMP710025

WATER LEVEL
 FLOAT
 CHAMBER
 SEE
 BMP810111


STEAM INLET
 SEE
 BMP030032

WATER INLETS
 SEE
 BMP030031

STEAM INLET
 SEE
 BMP030032

29

5 COMPARTMENT
 SUPPLY




11




Pellerin Milnor Corporation
P. O. Box 400, Kenner, LA 70063-0400

Litho in U.S.A.

**SECONDARY
DOOR SWITCH**



**DOOR ASSEMBLY
SEE BMP990047**




General Assembly
4231 & 4244WP2/WP3

BMP030028/2006144B
(Sheet 4 of 8)



Pellerin Milnor Corporation
P. O. Box 400, Kenner, LA 70063-0400

Litho in U.S.A.



DRAIN VALVE
SEE
BMP780095

PUSH DOWN
9,36

General Assembly
4231 & 4244WP2/WP3


BMP030028/2006144B
(Sheet 5 of 8)



Pellerin Milnor Corporation
P. O. Box 400, Kenner, LA 70063-0400

Litho in U.S.A.

6




General Assembly
4231 & 4244WP2/WP3

BMP030028/2006144B
(Sheet 6 of 8)



Pellerin Milnor Corporation
P. O. Box 400, Kenner, LA 70063-0400

Litho in U.S.A.



EXCURSION
SWITCH
24

MULTI-MOTOR DRIVE BASE SHOWN
SEE BMP710024

FOR SINGLE MOTOR DRIVE BASE
(NOT SHOWN HERE) SEE BMP050074

General Assembly
4231 & 4244WP2/WP3

BMP030028/2006144B
(Sheet 7 of 8)




Pellerin Milnor Corporation
P. O. Box 400, Kenner, LA 70063-0400

Litho in U.S.A.




REAR
BELT
GUARD
25

30



QUICK RELEASE
FOR PUSH DOWN
37



VALVE SET
COVER 26

27



Pellerin Milnor Corporation
P. O. Box 400, Kenner, LA 70063-0400

Litho in U.S.A.

Used In	Item	Part Number	Description	Comments
			ASSEMBLIES-----	
			none	
			COMPONENTS-----	
all	1	02 15627W	DRIVEBASE ENCL FRT 4244WEMIC	
all	2	X2 16137	ENCL DR. BSE-SD 64.38"LG	
all	3	X2 15628	ENCL DR. BSE-RR 69"LG	
all	4	X2 16137	ENCL DR. BSE-SD 64.38"LG	
all	5	AD 15 101	SIGHT GLASS ASSY-SS=WEHU	
all	6	02 15014D	GASKET SHELL RING DYA	
all	7	02 15936B	COVER=4244WP2 WNO SUPPLY RT	
all	8	02 15936A	+COVER=4244WP2&3 SUPPLY SIDE	
all	9	60B100	AIRMT S116B 1CONV F3582017564	
all	10	60E306A24A	HOSE *3.5"ID GATES PE X24"	
all	11	03 01448A	COV=CONT BOX NAVY	
all	12	02 15450	RESTPAD(RUBBER) 4/42WEHU	
all	13	60E306A12A	HOSE *3.5"ID GATES PE X12"	
all	14	AD 15 090A	AIRCHAMBER PRESWITCH INSTALL	
all	15	02 18107	GASKET=8"FLANGED DUMP VALVE	
all	16	W2 15585E	*WLMT=COV 2ND DR SW 4244/31	
all	17	02 15585D	BRKT=2ND DRSW 4244/4231WP/SG	
all	18	02 15139	PIN-DOOR HINGE	
all	19	AD 15 042A	DOOR INTERLOCK SWITCH INSTAL	
all	20	AD 15 042	*DOOR INTERLOCK SWITCH ASSY	
all	21	AD 15 091	SOAP CHUTE LID INSTALLATION	
all	22	X2 15683	SUPPORT-SHAFT=2/42WEHU	
all	23	02 15695	GASKET=SHAFT SUP 2/42WEHU	
all	24	E03 33100	* EXCURSION SWITCH ASSY	
all	25	X2 16137	ENCL DR. BSE-SD 64.38"LG	
all	26	03 CL721K	COVER:W/E DYE MICRO VAL SET	
all	27	AVA6243W37	*MIC6 AIRVALASSY 4231-4244WPU	

Used In	Item	Part Number	Description	Comments
all	28	30R0043PB	TEMPERATURE PROBE ASSY=BRASS	
all	29	60E011	TUBING 1"ID X 1+3/16"OD POLYUR	
all	30	02 15937A	+COV=4244WP2&3 ELEC BOX SIDE	
all	31	09R008ASTD	* 09R008A+MOUNTING HDWRE+INST	
all	32	02 20016	COVER=SIDE SUPPLY 4244SGH	
all	33	02 15619	BRKT=42 SUPINJ BEND @PRINT	
all	34	09RM02212S	CAPSW 12' 180DEG ROLLER SILVER	
all	35	60E301A18A	HOSE= *2.5"ID PE X18"	
all	36	02 20016	COVER=SIDE SUPPLY 4244SGH	

LUBRICATION AND PREVENTIVE MAINTENANCE FOR HYDRO-CUSHION[®] MACHINES

General Requirements

Maintenance procedures require:

- A hand operated grease gun.
- The correct lubricants (see “LUBRICANTS FOR MILNOR MACHINES,” in the Table of Contents).

Lubricant Requirements

To achieve the optimum performance and service life from the Milnor[®] machine and as a warranty requirement, the machine must be lubricated in strict accordance with the instructions in this section.

⚠ DANGER ⚠



ENTANGLE AND CRUSH HAZARD—Belts and pulleys can entangle and crush body parts.

- ☞ Lock OFF and tag out power at the wall disconnect before servicing, except where specifically instructed otherwise in this section.
- ☞ Insure belt and pulley guards are in place during service procedures.
- ☞ Permit only qualified maintenance personnel to perform these procedures.

⚠ DANGER ⚠



CRUSH/SEVER HAZARD—Tilting mechanism can crush or sever parts of your body caught in them.

- ☞ Install the safety stands before performing maintenance under a tilted machine.
- ☞ NEVER test or operate (manually or automatically) any machine function with any portion of a person’s body under the tilted machine—even if the safety stands are installed.

▲ DANGER ▲



CRUSH/SEVER HAZARD—Tilting machines with tilt wheels/cradles may lunge forward or rearward and even fall over if the tilt wheels at the non-tilted end are raised out of their cradles—killing/injuring personnel and/or damaging property.

- ☞ **NEVER** manually tilt (lift) both ends of the machine at the same time. One end must always be seated in its cradle.
- ☞ **ALWAYS** visually inspect the tilt wheels to be sure they are all fully seated in their cradles before each manual tilt up.
- ☞ Hydraulic valve manual operation must be done by trained competent maintenance personnel who thoroughly understand the system and all the consequences of manual operations.
- ☞ **ALWAYS** understand beforehand all the consequences of manually operating hydraulic valves.
- ☞ Never permit operation with malfunctioning tilt limit switches.

Correct Grease Gun Procedures

1. **Do not use a pneumatic grease gun.** Pump grease slowly, taking 10-15 seconds to complete each stroke. A grease gun can build up extremely high pressure which will force seals out of position and cause them to leak, even though both the seal and the bearing housing are equipped with spring loaded relief plugs.
2. **Apply quantity of grease called for in the checklist.** Over-lubrication can be as damaging as under-lubrication. Where quantities are stated in strokes, one stroke of the grease gun is assumed to provide .0624 fluid ounces (1.77 grams) (by volume) of grease. Therefore, one fluid ounce (28.3 grams) of grease would be provided by 16 strokes of the grease gun. Determine the flow rate of your grease gun by pumping one ounce into a calibrated container. If fewer than 16 strokes are required, all quantities in strokes in the chart should be reduced accordingly, and if more than 16 strokes are required, the number of strokes should be increased. Before starting lubrication, **make sure your grease gun is working and that you get a full charge of grease with every stroke.**
3. **Do not pump grease in until it oozes out of the spring loaded relief plugs.** Plugs bleed out excess grease and help prevent abnormal pressures from building up in the housing during operation (especially when the machine is first commissioned and after each lubrication). **Plugs will not protect against over-lubrication.**
4. **Do not over-lubricate motors.** Over-lubrication of a motor can seriously damage it by forcing grease into motor windings. Over-lubrication of the extract motor can force grease into the centrifugal switch causing it to malfunction.
5. **Do not allow grease to drip on the brake disk or clutch tire/drum during lubrication.** This will reduce the braking action considerably, and may permit the cylinder to creep while loading and unloading.




FIGURE 1 (MSSM0201CE)
Hydraulic Fluid Reservoir Fill and Level Check Point
 (located at rear of 48", 52", and 72" tilt machines only)




FIGURE 2 (MSSM0201CE)
Typical Hydro-Cushion Maintenance Points




FIGURE 3 (MSSM0201CE)
Typical Upper Hydro-Cushion Grease Fitting

Daily and Weekly Maintenance Items

Frequency	Component	Action
Daily	Hydraulic Tilt System (48", 52", and 72" Tilt machines) • Reservoir FIGURE 1 and NOTE 1	Check fluid with machine not tilted
	Hydro-Cushions [®] (all machines) FIGURES 2 and 3	Check for leaks
Weekly	Final stage and other v-belts (throughout all machines) FIGURES 1 and 12 NOTES 2 and 3	Check for wear and tension

NOTE 1: Tank should be approximately three-quarters full when the machine is not tilted. Do not over-fill.

NOTE 2: V-belt instructions for the first week of operation

- After 24 hours operation (three eight hour days), tighten final stage v-belts.
- After 80 hours operation (ten eight hour days), tighten final stage v-belts again.
- After 160 hours of operation (twenty eight hour days), tighten final stage v-belts, and check all other v-belts and tighten if necessary.

NOTE 3: All v-belts are not alike. "Super" or "High Capacity" v-belts frequently have considerably higher capacities than "Standard" belts. Sometimes, one brand of v-belt is more suitable than another brand of v-belt, although both v-belts are "interchangeable". It is always best to purchase replacement belts from the original manufacturer of the equipment. Purchasing exact replacements of the original belts is the best way to assure belt life equal to the original set. Occasionally, Milnor[®] will change a belt specification to improve belt life. Belts purchased from Milnor[®] are as currently specified.




FIGURE 4 (MSSM0201CE)
42" Divided Cylinder Front Bearing and Seal Grease Fittings




FIGURE 5 (MSSM0201CE)
42" Staph-Guard® Front and Rear Bearing and Seal Grease




FIGURE 6 (MSSM0201CE)
42" Divided Cylinder Rear Bearing and Seal Grease Fittings




FIGURE 7 (MSSM0201CE)
60" and 72" Divided Cylinder Front Seal and Bearing Grease Fittings

Monthly Maintenance Items

Frequency	Component	Action
Monthly (see NOTE 4)	All Divided cylinder and Staph-Guard® main bearing and seals FIGURES 4 through 10, NOTES 5 and 6	
	<ul style="list-style-type: none"> Each bearing grease fitting 	0.37 ounces (10.6 grams), six strokes at two locations
	<ul style="list-style-type: none"> Each seal grease fitting 	0.12 ounces (3.54 grams), two strokes at two locations

NOTE 4: Once a month or once every 200 operating hours, whichever occurs first.

NOTE 5: Main bearings and jackshaft bearings (if so equipped) are prepacked with lubricant at the factory. Do not add grease for thirty days. During the first month's operation, some grease will ooze out of the automatic grease fittings at the bottom of the housing(s). This is normal. These grease fittings allow excess grease to escape, thus avoiding over-heating. This escaping lubricant need not be replaced. Every time these bearings are lubricated, the surplus grease will come out of the spring loaded relief fittings after a few hours running time.

NOTE 6: Bearings can run hot enough to make it extremely uncomfortable for a person to hold his hand on the bearing housing for more than a few seconds. This is normal.




FIGURE 8 (MSSM0201CE)
60" and 72" Divided Cylinder Rear Seal and Bearing




FIGURE 9 (MSSM0201CE)
60044 and 72044 Staph-Guard®
Front Bearing and Seal Grease Fit-




FIGURE 10 (MSSM0201CE)
60044 and 72044 Staph-Guard®
Rear Bearing and Seal Grease Fittings (lo-




FIGURE 11 (MSSM0201CE)
All Open-Pocket Machine Seal and
Bearing
Grease Fitting Plate

Frequency	Component	Action
Monthly (see NOTE 4)	42" Open pocket main bearings and seals FIGURE 11, NOTES 5 and 6	
	• Front and rear bearing grease fitting	0.12 ounces (3.54 grams), two strokes at two locations
	• Seal grease fitting	0.06 ounces (1.77 grams), one stroke at one location
	48" Open pocket main bearings, seals and Hydro-Cushions® FIGURES 11 and 13, NOTES 4, 5, 6 and 7	
	• Front and rear bearing grease fitting	0.31 ounces (8.85 grams), five strokes at two locations
	• Seal grease fitting	See "Semi-Annual Maintenance Items" in this section
	• Hydro-Cushion® bypass (48" open-pocket only)	Drain small quantity of oil. If milky, see note 7 below
	52" and 72" Open pocket main bearings and seals FIGURE 11, NOTES 4, 5, and 6	
	• Front bearing grease fitting	0.62 ounces (17.7 grams), ten strokes at one location
	• Rear bearing grease fitting	0.31 ounces (8.8 grams), five strokes at one location
	Drive train components FIGURE 12	
	• Pulleys and clutches	Check for wear
	• All components	Remove soil build-up

NOTE 7: "Milky" oil is contaminated by water. Drain cylinder and unscrew cap on bottom of bypass (See BMP890047). Remove piston rod and inspect the upper piston cups and lower piston for wear or damage. Worn piston cups allow water from the air supply to enter hydrocushion. Repair worn parts and change oil.




FIGURE 12 (MSSM0201CE)
Typical Drive Train Components (48" machine shown)




FIGURE 13 (MSSM0201CE)
Hydrocushion Bypass Valve
(48" machines only")



FIGURE 14 (MSSM0201CE)
Handwheel Screw
 (42" Divided Cylinder and Staph-Guard® only)




FIGURE 15 (MSSM0201CE)
Typical Door Hinge




FIGURE 16 (MSSM0201CE)
Handwheel Stop
 (42" Divided Cylinder and Staph-Guard® only)




FIGURE 17 (MSSM0201CE)
42" Staph-Guard®
Idler Shaft
Grease Fitting




FIGURE 18 (MSSM0201CE)
60" and 72" Staph-Guard® Idler Shaft
and Disc Brake Grease Fittings
(60" shown)




FIGURE 19 (MSSM0201CE)
Typical Jackshaft
Grease Fittings
(52" machine shown)

Monthly Maintenance Items

Frequency	Component	Action
Monthly (see NOTE 4)	Handwheel screw (42" Divided Cylinder and Staph-Guard®) • Screw thread FIGURE 14	Three drops of light machine oil
	Door hinges • Grease fittings FIGURE 15	0.12 ounces (3.54 grams), two strokes at each location
	Handwheel stop (42" Divided Cylinder and Staph-Guard®) • Grease fitting FIGURE 16	0.06 ounces (1.77 grams), one stroke at one location
	Idler shaft (Staph-Guard® only) • Grease fittings FIGURES 17 and 18	0.31 ounces (8.85 grams), five strokes at two locations
	Disc brake (60" and 72" Staph-Guard® only) • Grease fittings FIGURE 18	0.12 ounces (3.54 grams), two strokes at one location
	Jackshaft (if equipped) • Grease fittings FIGURE 19 NOTES 5 and 6	0.12 ounces (3.54 grams) two strokes at two locations
	Tilt wheels (42", 48", and 72" Tilt Models) • Grease fittings FIGURE 20	0.12 ounces (3.54 grams), two strokes at each location




FIGURE 20 (MSSM0201CE)
Tilt Wheels
 (42" and 48" tilt machines only)




FIGURE 21 (MSSM0201CE)
Disk Brake Reservoir
 (Staph-Guard® only)



FIGURE 22 (MSSM0201CE)
Brake Band Grease Fittings
 (60044 and 72044WP2/WP3)




FIGURE 23 (MSSM0201CE)
Brake Shoes (all machines)



FIGURE 24 (MSSM0201CE)
Disk Brake
 (Staph-Guard® only)



FIGURE 25 (MSSM0201CE)
Hydraulic Tilt Pressure Gauge
 (On rear of 42", 48", and 72" tilt models)



FIGURE 26 (MSSM0201CE)
Door Seal Pressure Regulator

Quarterly Maintenance Items

Frequency	Component	Action
Quarterly	Brake Components	
	• Disk brake reservoir (60" and 72" Staph-Guard [®] only) FIGURE 21	Check level, refill as required (Always use fresh fluid from a sealed container)
	• Brake band grease fittings (60044 and 72044 WP2/WP3 only) FIGURE 22	0.06 ounces (1.77 grams), one stroke at two locations. Do not allow grease to drip on brake surfaces.
	• Brake shoes FIGURE 23	Check for wear, adjust or replace as required.
	• Disc brake pads (60" and 72" Staph-Guard [®] only) FIGURE 24	Check for wear, replace as required
	Hydro-Cushions[®] FIGURES 2 and 3	Check oil level, add as necessary Inspect washer, replace as necessary
	Motors FIGURE 12 NOTES 8 and 9	See "BALDOR MOTOR MAINTENANCE..." MSSM0274AE in this manual.
	Hydraulic tilt pressure gauge FIGURE 25	Check pressure while machine is returning from a tilted position
	• 42" Open pocket	800 PSI (55 Bar)
	• 48" Open pocket	900 PSI (62 Bar)
	• 72" Open pocket	1000 PSI (69 Bar)
	Door seal pressure regulator FIGURE 26	Check settings with machine in bare manual and clockwise wash rotation. See instructions for operating individual outputs in the reference manual.
	• 42" and 48" Open pocket	48 - 50 PSI (3.37 - 3.51 Kg/cm ²)
	• 60" and 72" Rapid load	25 - 28 PSI (1.76 - 1.97 Kg/cm ²)
	• 60" and 72" Staph-Guard [®]	18 - 20 PSI (1.27 - 1.41 Kg/cm ²)

NOTE 8: If motor manufacturer's instructions conflict with manual section, follow nameplate instructions. motors are warranted by their manufacturers, not by Milnor[®].

NOTE 9: Pump grease slowly with relief ports open. Do not over-lubricate.




FIGURE 27 (MSSM0201CE)
Typical Gear Reducer Fill and Drain




FIGURE 28 (MSSM0201CE)
**Push Back and Forward Hydraulic System
 Gauges and Regulators
 (42", 48", and 72" Tilt Models)**




FIGURE 29 (MSSM0201CE)
**Push-Down Control Valve
 (72" Rapid load and Staph-Guard® only)**




FIGURE 30 (MSSM0201CE)
**Shell Door Recirculation Hose
 (48" dye machine only - cover removed for clarity)**

Semi-Annual Maintenance Items

Frequency	Component	Action
Semi-Annual	Main bearings and seals • 48" Seal grease fittings FIGURE 11	0.12 ounces (3.54 grams), two strokes at one location
	Gear reducer FIGURE 27	Check oil level, refill as required
	Push Back and Forward System FIGURE 28 and NOTE 10	
	• Down position pressure gauge and regulator	Check pressure in a "wash step" 3 - 5 PSI (.21- 0.35 Kg/cm ²)
	• Tilt position pressure regulator and gauge	Check pressure in a "wash step" 30 PSI (2.11Kg/cm ²)
	Push-down control valves (72" Rapid load and Staph-Guard®) FIGURE 29 and NOTE 11	Observe operation and adjust if required
	Recirculation (48" dye models only) FIGURE 30	Replace hose

Annual or Less Frequent Maintenance Items

Frequency	Component	Action
Annual	Gear reducer FIGURE 27	Change oil and clean magnetic plug (if so equipped)
	Hydro-Cushions® FIGURE 2	Change oil
Every 2 years	Hydraulic system FIGURE 28	Change oil

NOTE 10: 52" and 72" machines are not equipped with a tilt pressure regulator or gauge.

NOTE 11: Adjust push-down control valves so that machine moves down evenly, and all push-down sockets meet simultaneously. If the back of the machine comes down first, close the valve slowly. If the front comes down first, open the valve.

LUBRICANTS FOR MILNOR® MACHINES

The following are lubricants used in Milnor® machines. Always refer to the preventive maintenance instructions for specific lubricating instructions. Consult lubricant manufacturer to verify equivalence before using a substitute. Mixing different base greases can cause bearing and seal damage.

Washer-Extractors											
	Bearing housings	Gear reducers	Isolators	Hydro-Cushions®	Motors	Commutator cam	Balancing mechanism	Disc brake (if so equipped)	Hydraulic tilt mechanism	Door latches	Other grease points
Open Pocket Machines											
30015, 20, 22, C, S, and M	30										
3022F8J	220		220								
36021Q4x, 36026Q4x											
36021BWP						Wells	1540				
36021Q6x, 36026Q6x, 42024Q4x, 42026Q6x	EPLF 2	220			EPLF 2			DOT 3	1030	Door	EPLF 2
36030Fxx			1030								
42032Fxx											
42026QHP 48032BHP/BTL/BTN 48036QHP/QTL/QTN		220		220							
52038WP1/WTL/WTN											
64046ExN 72046ExN 72058JxN			1030	1030				DOT 3	68		
Divided Cylinder Machines											
42031 - 44 WP2/3 42031 - 44 SP2/3 60044 SP2/3 72044 SP2/3	EPLF 2	220		1030	EPLF 2			DOT 3		Door	EPLF 2

CBW®, Extractor, Press, Shuttles, Conveyors, and Dryvacs															
	Bearing housings	Gear reducer	Drive motors	Hydro-Cushions®	Hydraulic mechanisms	Disc brake	Mist oiler	Guide rollers	Drive/Support rollers	Blower shaft bearings	Press pressure pump	Blower motors	Inflatable rib couplings	Shuttle chain	All other grease points
CBW®		220					T32	EPLF 2	EPLF 2						EPLF 2
42032M7E	EPLF 2			220	68	DOT 3					630		SRI		
42032M9E			EPLF 2	32											
Single Stage Press		1030													
Press							23								
Dryer									EPLF 2	EP2		R			
Shuttle & Conveyor		634												FL	
Dryvac															

Oils

DOT 3	= NAPA Super Heavy Duty Brake Fluid DOT 3
23	= Shell Tellus® 23
30	= High quality SAE 30, 40, or 50 weight motor oil (non-detergent, if available)
32	= Shell Tellus® 32
T32	= Shell Turbo® T32
68	= Shell Tellus® 68
220	= Shell Morlina® 220
630	= Valvoline Special Moly® EP 630
634	= Mobile SHC® 634 Oil
1030	= Shell Rotella T® 10W30
1540	= Shell Rotella T® HD 15W40

Greases

Door	= Doorease® Stick lubricant
EPLF 2	= Shell Alvania® EP-LF Type 2
EP2	= Shell Darina® EP-2
FL	= Recol Food Lubricant
R	= Shell Dolium® R
Wells	= Wells CL200 Cam Lubricant
SRI	= Chevron SRI oil

Motor Maintenance



This document uses Simplified Technical English.
Learn more at <http://www.asd-ste100.org>.

This document is for motors used on Milnor® machines that have grease fittings. If the motor manufacturer supplies maintenance instructions, use them. If not, use this document.

NOTICE P1: "Remove power from the machine" means use the necessary safety procedure for your location. In the USA, this is the OSHA lockout/tagout (LOTO) procedure. More local requirements can also apply.



WARNING 2: Risk of Severe Injury—A machine in operation without safety guards can pull in and mutilate your body.

- You must be an approved maintenance technician.
- Replace guards and covers that you remove for maintenance.



WARNING 3: Risk of Severe Injury—The machine has electrical power when the Master switch (M) on the control panel is off or on.

- Remove power from the machine (see Notice P1).

1. Necessary Maintenance

- 1.1. **Keep the motors clean.**—Examine and clean motors each 500 hours of operation or a minimum of each three months. Keep the motors free of dirt, oil, grease, and water. Contamination that prevents good airflow will cause too much heat and cause motor damage.
- 1.2. **Examine a motor that shows unusual symptoms.** —Examine a motor that becomes too hot, makes noise, makes smoke, smells unusual, or opens the circuit breaker frequently. Examine a motor if the inverter gives errors. Make sure that all electrical connections are tight. Make sure that the wire insulation is good. Use a low resistance ohmmeter. Disassemble the motor to clean it fully If necessary.
- 1.3. **Lubricate the motors.**—This document gives the lubricant frequency, quantity, type, and procedure. These are all important. See the related section in document BIIFUM02 which gives the calibration procedures for grease guns.

2. How to Find the Interval and Quantity of Grease to Add

frame code—codes for the standard motor dimensions used by motor manufacturers.

standard interval—the number of hours that a motor can operate in typical conditions before you must add grease.


operation conditions—the conditions that can decrease the life of the motor and make it necessary to lubricate more frequently.

rating—One of three levels of operation conditions: typical, bad, very bad.

multiplication number—a decimal number given to the rating. Typical = 1.0, bad = 0.5, and very bad = 0.2.

This section gives the steps you use to find the interval and quantity of grease to add. The examples use the motor data plate shown in [Figure 1](#).

Figure 1: Typical Data Plate on a Motor



1. Find the frame code and RPM on the motor data plate. Example:

Frame code = 215T, RPM = 1725

2. Find the standard interval in [Table 1](#). Example:

Standard interval = 12,000 hours

3. Find the rating and multiplication number in [Table 2](#) for your worst operation condition. Example: ambient temperature = 102°F (39°C). Moderate contamination.

Rating = bad, Multiplication number = 0.5

4. Calculate the correct interval (the number of hours of operation before it is necessary to add grease). Example:

$$12,000 \times 0.5 = 6,000 \text{ hours}$$

Where:

12,000 is the standard interval

0.5 is the multiplication number for a rating = bad.

5. Find the quantity of grease for the frame code for your motor in [Table 3](#). You can use the bearing data in the table to do maintenance. Do not use this data to adjust the quantity of grease. Example:

grease volume = 0.16 ounces (4.7 grams)

grease gun cycles = 2.5

Table 1: Standard Interval

NEMA (IEC)** Range of Frame Codes	Interval in Hours for the Given RPM			
	3600 RPM*	1800 RPM*	1200 RPM*	900 RPM*
Up to 215 (132)	5500	12000	18000	22000
254 to 286 (160 - 180)	3600	9500	15000	18000
324 to 365 (200 - 225)	2200	7400	12000	15000
404 to 5000 (280 - 315) 6313 or 6314 bearings	2200	3500	7400	10500
	Roller bearings	1100	1750	3700

* Use this column if this is near or the same RPM as your motor.
 ** Frame codes given by the IEC are shown in parentheses.

Table 2: Operation Condition and Multiplication Number

Operation Conditions*			Rating	Multiplication Number
Maximum Ambient Temperature	Or Atmospheric Contamination	Or Bearing Type		
104°F (40°C)	Clean, not much corrosion	Ball bearing with a groove of large depth	Typical	1.0
122°F (50°C)	Moderate dirt, corrosion	Ball thrust, roller	Bad	0.5
>122°F (>50°C)	Much dirt, abrasive dust, corrosion	n.a.	Very bad	0.1

* The worst condition sets the rating.

Table 3: Grease Quantity (total quantity for all bearings in the motor)

NEMA (IEC) Range of Frame Codes	Largest Bearing Dimension in Range			Quantity of Grease *		Cycles of the Grease Gun
	Category of Bearing	Outer Diameter (mm)	Width (mm)	(Ounces)	(Grams)	
0 thru 215 (132)	6307	80	21	0.16	4.7	2.5
254 to 286 (160 - 180)	6311	120	29	0.32	9.1	5
324 to 365 (200 - 225)	6313	140	33	0.43	12.2	7
404 to 5000 (280 - 315)	NU322	240	50	1.11	31.5	18

* This is the quantity for the two bearings.

3. Grease Types and Procedures

Table 4: Type of Grease

Rating from Table 2	Type of Grease
Typical	Shell Dolium R, Chevron SRI, or equivalent
Bad	
Very Bad	Darmex 707 or equivalent



CAUTION [4]: Damage and Malfunction Risks—Too much grease gun pressure can put grease in the motor and cause electrical components to burn out. If grease touches a brake or a clutch surface, this can cause a malfunction.

- Apply grease carefully.

Apply grease as follows:

1. **Remove power from the machine (see Notice P1).**
2. Clean grease fittings.
3. If the motor has a grease outlet plug, remove it.
4. Add the recommended quantity of grease (See [Item 5](#)). Stop immediately if you see new grease around the motor shaft, wires or the grease outlet plug.
5. If the motor has a grease outlet plug, replace it.

— End of BIUUM03 —

Torque Requirements for Fasteners



This document uses Simplified Technical English. Learn more at <http://www.asd-ste100.org>.

The document about the assembly gives the torque requirements for other fasteners. **If fastener torque specifications or threadlocker requirements in an assembly document are different from this document, use the assembly document.**

Figure 1: The Bolts in Milnor® Equipment

The Marks on Bolt Heads	Legend
	<p>A. SAE Grades 1 and 2, ASTM A307, and stainless steel</p> <p>B. Grade BC, ASTM A354</p> <p>C. SAE Grade 5, ASTM A449</p> <p>D. SAE Grade 8 and ASTM A354 BD</p>

1. Torque Values

These tables give the standard dimension, grade, threadlocker, and torque requirements for fasteners frequently used on Milnor® equipment.

Note 1: Data from the Pellerin Milnor® Corporation “Bolt Torque Specification” (bolt_torque_milnor.xls/2002096).

1.1. Fasteners Made of Carbon Steel

1.1.1. Without a Threadlocker

Table 1: Torque Values for Standard Fasteners with Maximum 5/16-inch Diameters and No Lubricant

Dimension	The Grade of the Bolt							
	Grade 2		Grade 5		Grade 8		Grade BC	
	Pound-Inches	N-m	Pound-Inches	N-m	Pound-Inches	N-m	Pound-Inches	N-m
1/4 x 20	66	7	101	11	143	16	126	14
1/4 x 28	76	9	116	13	163	18	--	--
5/16 x 18	136	15	209	24	295	33	258	29
5/16 x 24	150	17	232	26	325	37	--	--

Torque Requirements for Fasteners

Table 2: Torque Values for Standard Fasteners Larger Than 5/16-inch Diameters and No Lubricant

Dimension	The Grade of the Bolt							
	Grade 2		Grade 5		Grade 8		Grade BC	
	Pound-feet	N-m	Pound-feet	N-m	Pound-feet	N-m	Pound-feet	N-m
3/8 x 16	20	27	31	42	44	59	38	52
3/8 x 24	23	31	35	47	50	68	--	--
7/16 x 14	32	43	49	66	70	95	61	83
7/16 x 20	36	49	55	75	78	105	--	--
1/2 x 13	49	66	75	102	107	145	93	126
1/2 x 20	55	75	85	115	120	163	--	--
9/16 x 12	70	95	109	148	154	209	134	182
9/16 x 18	78	106	121	164	171	232	--	--
5/8 x 11	97	131	150	203	212	287	186	252
5/8 x 18	110	149	170	231	240	325	--	--
3/4 x 10	172	233	266	361	376	510	329	446
3/4 x 16	192	261	297	403	420	569	--	--
7/8 x 9	167	226	429	582	606	821	531	719
7/8 x 14	184	249	473	641	668	906	--	--
1 x 8	250	339	644	873	909	1232	796	1079
1 x 12	274	371	704	954	994	1348	--	--
1 x 14	281	381	723	980	1020	1383	--	--
1 1/8 x 7	354	480	794	1077	1287	1745	1126	1527
1 1/8 x 12	397	538	891	1208	1444	1958	--	--
1 1/4 x 7	500	678	1120	1519	1817	2464	1590	2155
1 1/4 x 12	553	750	1241	1682	2012	2728	--	--
1 3/8 x 6	655	888	1469	1992	2382	3230	2085	2827
1 3/8 x 12	746	1011	1672	2267	2712	3677	--	--
1 1/2 x 6	869	1178	1949	2642	3161	4286	2767	3751
1 1/2 x 12	979	1327	2194	2974	3557	4822	--	--

Table 3: Torque Values for Plated Fasteners with Maximum 5/16-inch Diameters and No Lubricant

Dimension	The Grade of the Bolt							
	Grade 2		Grade 5		Grade 8		Grade BC	
	Pound-Inches	N-m	Pound-Inches	N-m	Pound-Inches	N-m	Pound-Inches	N-m
1/4 x 20	49	6	76	9	107	12	95	11
1/4 x 28	56	6	88	10	122	14	--	--
5/16 x 18	102	12	156	18	222	25	193	22
5/16 x 24	113	13	174	20	245	28	--	--

Table 4: Torque Values for Plated Fasteners Larger Than 5/16-inch Diameters and No Lubricant

Dimension	The Grade of the Bolt							
	Grade 2		Grade 5		Grade 8		Grade BC	
	Pound-feet	N-m	Pound-feet	N-m	Pound-feet	N-m	Pound-feet	N-m
3/8 x 16	15	20	23	31	33	44	29	38
3/8 x 24	17	23	26	35	37	49	--	--
7/16 x 14	24	32	37	50	52	71	46	61
7/16 x 20	27	36	41	55	58	78	--	--
1/2 x 13	37	49	56	76	80	106	70	93
1/2 x 20	41	55	64	85	90	120	--	--
9/16 x 12	53	70	81	110	115	153	101	134
9/16 x 18	59	79	91	122	128	174	--	--
5/8 x 11	73	97	113	150	159	212	139	186
5/8 x 18	83	110	127	172	180	240	--	--
3/4 x 10	129	173	200	266	282	376	246	329
3/4 x 16	144	192	223	297	315	420	--	--
7/8 x 9	125	166	322	430	455	606	398	531
7/8 x 14	138	184	355	474	501	668	--	--
1 x 8	188	250	483	644	682	909	597	796
1 x 12	205	274	528	716	746	995	--	--
1 x 14	210	280	542	735	765	1037	--	--
1 1/8 x 7	266	354	595	807	966	1288	845	1126
1 1/8 x 12	298	404	668	890	1083	1444	--	--
1 1/4 x 7	375	500	840	1120	1363	1817	1192	1590
1 1/4 x 12	415	553	930	1261	1509	2013	--	--
1 3/8 x 6	491	655	1102	1470	1787	2382	1564	2085
1 3/8 x 12	559	758	1254	1672	2034	2712	--	--
1 1/2 x 6	652	870	1462	1982	2371	3161	2075	2767
1 1/2 x 12	733	994	1645	2194	2668	3557	--	--

1.1.2. With a Threadlocker

Table 5: Threadlocker by the Diameter of the Bolt (see Note 2)

LocTite Product	Dimension			
	1/4-inch	1/4- to 5/8-inch	5/8- to 7/8-inch	1-inch +
LocTite 222	OK			
LocTite 242		OK		
LocTite 262			OK	
LocTite 272			High temperature	
LocTite 277				OK

Note 2: The acceptable bolt size ranges for various LocTite® threadlocking products is the LocTite manufacturer's **general** recommendation. Specific applications sometime require that a LocTite product is applied to a bolt size outside the ranges shown here. For example, Milnor specifies LocTite 242 for use on certain 1" bolt applications and has confirmed this usage with the LocTite manufacturer. You may see variances such as this in the documentation for specific machine assemblies.

Torque Requirements for Fasteners

Table 6: Torque Values if You Apply LocTite 222

Dimension	The Grade of the Bolt							
	Grade 2		Grade 5		Grade 8		Grade BC	
	Pound-inches	N-m	Pound-inches	N-m	Pound-inches	N-m	Pound-inches	N-m
1/4 x 20	60	7	96	11	132	15	108	12
1/4 x 28	72	8	108	12	144	16	--	--

Table 7: Torque Values if You Apply LocTite 242

Dimension	The Grade of the Bolt							
	Grade 2		Grade 5		Grade 8		Grade BC	
	Pound-feet	N-m	Pound-feet	N-m	Pound-feet	N-m	Pound-feet	N-m
5/16 x 18	11	15	17	23	25	34	22	30
5/16 x 24	13	18	19	26	27	37	27	37
3/8 x 16	20	27	31	42	44	60	38	52
3/8 x 24	23	31	35	47	50	68	--	--
7/16 x 14	32	43	49	66	70	95	61	83
7/16 x 20	36	49	55	75	78	106	--	--
1/2 x 13	49	66	75	102	107	145	93	126
1/2 x 20	55	75	85	115	120	163	--	--
9/16 x 12	70	95	109	148	154	209	134	182
9/16 x 18	78	106	121	164	171	232	--	--
5/8 x 11	97	132	150	203	212	287	186	252
5/8 x 18	110	149	170	230	240	325	--	--

Table 8: Torque Values if You Apply LocTite 262

Dimension	The Grade of the Bolt							
	Grade 2		Grade 5		Grade 8		Grade BC	
	Pound-feet	N-m	Pound-feet	N-m	Pound-feet	N-m	Pound-feet	N-m
3/4 x 10	155	210	240	325	338	458	296	401
3/4 x 16	173	235	267	362	378	512	--	--
7/8 x 9	150	203	386	523	546	740	477	647
7/8 x 14	165	224	426	578	601	815	--	--

Table 9: Torque Values if You Apply LocTite 272 (High-Temperature)

Dimension	The Grade of the Bolt							
	Grade 2		Grade 5		Grade 8		Grade BC	
	Pound-feet	N-m	Pound-feet	N-m	Pound-feet	N-m	Pound-feet	N-m
1 x 8	350	475	901	1222	1272	1725	1114	1510
1 x 12	383	519	986	1337	1392	1887	--	--
1 x 14	393	533	1012	1372	1428	1936	--	--
1-1/8 x 7	496	672	1111	1506	1802	2443	1577	2138
1-1/8 x 12	556	754	1247	1691	2022	2741	--	--
1-1/4 x 7	700	949	1568	2126	2544	3449	2226	3018
1-1/4 x 12	774	1049	1737	2355	2816	3818	--	--
1-3/8 x 6	917	1243	2056	2788	3335	4522	2919	3958
1-3/8 x 12	1044	1415	2341	3174	3797	5148	--	--
1-1/2 x 6	1217	1650	2729	3700	4426	6001	3873	5251
1-1/2 x 12	1369	1856	3071	4164	4980	6752	--	--

Table 10: Torque Values if You Apply LocTite 277

Dimension	The Grade of the Bolt							
	Grade 2		Grade 5		Grade 8		Grade BC	
	Pound-feet	N-m	Pound-feet	N-m	Pound-feet	N-m	Pound-feet	N-m
1 x 8	325	441	837	1135	1181	1601	1034	1402
1 x 12	356	483	916	1242	1293	1753	--	--
1 x 14	365	495	939	1273	1326	1798	--	--
1-1/8 x 7	461	625	1032	1399	1674	2270	1464	1985
1-1/8 x 12	516	700	1158	1570	1877	2545	--	--
1-1/4 x 7	650	881	1456	1974	2362	3202	2067	2802
1-1/4 x 12	719	975	1613	2187	2615	3545	--	--
1-3/8 x 6	851	1154	1909	2588	3097	4199	2710	3674
1-3/8 x 12	970	1315	2174	2948	3526	4781	--	--
1-1/2 x 6	1130	1532	2534	3436	4110	5572	3597	4877
1-1/2 x 12	1271	1723	2852	3867	4624	6269	--	--

1.2. Stainless Steel Fasteners

Table 11: Torque Values for Stainless Steel Fasteners 5/16-inch and Smaller

Dimension	316 Stainless		18-8 Stainless		18-8 Stainless with Loctite 767	
	Pound-Inches	N-m	Pound-Inches	N-m	Pound-Inches	N-m
1/4 x 20	79	9	76	9	45	5
1/4 x 28	100	11	94	11	56	6
5/16 x 18	138	16	132	15	79	9
5/16 x 24	148	17	142	16	85	10

Table 12: Torque Values for Stainless Steel Fasteners Larger Than 5/16-inch

Dimension	316 Stainless		18-8 Stainless		18-8 Stainless with Loctite 767	
	Pound-feet	N-m	Pound-feet	N-m	Pound-feet	N-m
3/8 x 16	21	28	20	27	12	16
3/8 x 24	23	31	22	29	13	18
7/16 x 14	33	44	31	42	19	25
7/16 x 20	35	47	33	45	20	27
1/2 x 13	45	61	43	58	26	35
1/2 x 20	47	64	45	61	27	37
9/16 x 12	59	81	57	77	34	46
9/16 x 18	66	89	63	85	38	51
5/8 x 11	97	131	93	125	56	75
5/8 x 18	108	150	104	141	62	84
3/4 x 10	132	179	128	173	77	104
3/4 x 16	130	176	124	168	75	101
7/8 x 9	203	275	194	263	116	158
7/8 x 14	202	273	193	262	116	157
1 x 8	300	406	287	389	172	233
1 x 14	271	367	259	351	156	211
1-1/8 x 7	432	586	413	560	248	336
1-1/8 x 12	408	553	390	529	234	317
1-1/4 x 7	546	740	523	709	314	425
1-1/4 x 12	504	683	480	651	288	390
1-1/2 x 6	930	1261	888	1204	533	722
1-1/2 x 12	732	992	703	953	422	572

2. Preparation



WARNING 2: Fire Hazard—Some solvents and primers are flammable.

- Use threadlocker and primers with sufficient airflow.
 - Do not use flammable material near ignition sources.
1. Clean all threads with a wire brush or a different tool.
 2. Remove the grease from the fasteners and the mating threads with solvent. Make the parts dry.

Note 3: Loctite 7649 Primer™ or standard solvents will remove grease from parts.

3. Apply a spray of Loctite 7649 Primer™ or equal on the fasteners and the mating threads. Let the primer dry for one minute minimum.

3. How to Apply a Threadlocker




CAUTION 3: Malfunction Hazard—Heat, vibration, or mechanical shocks can let the fasteners loosen if you do not apply the threadlocker correctly. Loose fasteners can cause malfunctions of the equipment.

- Read the threadlocker manufacturer's instructions and warnings. Obey these instructions.

Apply the threadlocker only to the areas where the fastener threads and the mating threads engage.

Figure 2: Blind Hole




3.1. Blind Holes

1. Apply the threadlocker down the threads to the bottom of the hole.
2. Apply the threadlocker to the bolt.
3. Tighten the bolt to the value shown in the correct table ([Table 5](#) to [Table 11](#)).

3.2. Through Holes

1. Put the bolt through the assembly.
2. Apply the threadlocker only to the bolt thread area that will engage the nut.
3. Tighten the bolt to the value shown in the correct table ([Table 5](#) to [Table 11](#)).


Figure 3: Through Hole



3.3. Disassembly—For high-strength threadlocker, apply heat for five minutes. Disassemble with hand tools while the parts are hot.

For low-strength and moderate-strength threadlocker, disassemble with hand tools.

Figure 4: Disassembly



— End of BIUUM04 —



Drive Assemblies

2



Pellerin Milnor Corporation
P. O. Box 400, Kenner, LA 70063-0400

Litho in U.S.A.





Pellerin Milnor Corporation
P. O. Box 400, Kenner, LA 70063-0400

Litho in U.S.A.

Parts List—Drive Chart

Find the correct assembly first, then find the needed components. The item letters (A, B, C, etc.) assigned to assemblies are referred to in the "Used In" column to identify which components belong to an assembly. The item numbers (1, 2, 3, etc.) assigned to components relate the parts list to the illustration.

Used In	Item	Part Number	Description	Comments
			-----ASSEMBLIES-----	
	A	D16 00561	DRIVE CHART=4244WE SINGLE MOTO	
			-----COMPONENTS-----	
all	1	02 16124	VPUL 5B20 (Q2) BRN PE-5008	
all	2	56Q2DQ2S	2+3/16" SPLIT BUSHING BROWN Q2	
all	3	56VB120X	VBELT BX120 RAWEDGE COG	
all	4	56080B5SF	VPUL 5B8.0/A7.6 (SF) TYPE QD	
all	5	56Q2HSF	2+7/16" BUSH VPUL QD TYPE SF	
all	6	02 175121	KEY=5/8SQ	
all	7	5607B110	PULLEY 7B11.0 TYPE E	
all	8	56Q2AE	2.0" BUSHING VPUL QD TYPE "E"	
all	9	02 15794	KEY-1/2X2+1/2 4231-4244SGH	
all	10	56VB070XB3	VBAND 3RBX70 EACH=1	
all	11	56070B6SF	VPUL 6B7.0/A6.6 (SF) TYPE QD	
all	12	56Q1RSF	1+7/8" BUSH VPUL QD TYPE SF	




Drive Base Installation
4244WP2 SM (Single Motor)

BMP050074/2006286B
 (Sheet 1 of 4)



Pellerin Milnor Corporation
 P. O. Box 400, Kenner, LA 70063-0400

Litho in U.S.A.






Drive Base Installation
4244WP2 SM (Single Motor)

BMP050074/2006286B
 (Sheet 2 of 4)



Pellerin Milnor Corporation
 P. O. Box 400, Kenner, LA 70063-0400

Litho in U.S.A.









Drive Base Installation 4244WP2 SM (Single Motor)

BMP050074/2006286B
(Sheet 3 of 4)



Pellerin Milnor Corporation
P. O. Box 400, Kenner, LA 70063-0400

Litho in U.S.A.






Pellerin Milnor Corporation
P. O. Box 400, Kenner, LA 70063-0400

Litho in U.S.A.



Used In	Item	Part Number	Description	Comments
			-----ASSEMBLIES-----	
A		SA 16 021S	DRIVE BASE 4244WE SGL MOTOR	4244WP2 SM
B		GBJ25003	JACKSHAFT INSTALL 60SG 1 MOTOR	
			-----COMPONENTS-----	
all	1	W2 16141A	DRIVEBASE 4244WE 50/60 SGLMOTO	
all	2	02 15605E	ACTUATOR=EXCURSION SW 42SG-SIG	
all	3	02 16088	SWAY BRACE=MOTOR MOUNT 4244	
all	4	X2 15604	CLAMP=MACH MTR MTG HINGEPIN	
all	5	02 15652	FORK=MOTOR MOUNT ADJ SCREW	
all	6	02 21859A	BRAKE TORQUE ARM 42 1 MOTOR	
all	7	05 20131E	MTRPLATE 6044SG 1 MOTOR	
all	8	54AF22210	PILLBLK BRG P2B-S2-200RE 2"	
all	9	15D119	HXTAPSCR 1/2-13X4 GR5 ZNC FTL	
all	10	15U300	LOKWASHER REGULAR 1/2 ZINC PLT	
all	11	15G230	HXNUT 1/2-13UNC2B SAE ZINC GR2	
all	12	15U490	FLTWASH 1+1/2X17/32X1/4 ZINC	
all	13	15K180	HXCAPSCR 1/2-13UNCAX2 GR5 ZINC	
all	14	15K151	HXCAPSCR 1/2-13UNC24X1.25 GR5	
all	15	15K173A	HXCAPSCR 1/2-13UNC2AX1.75 GR5	
all	16	02 19283	NUT=1/2-13UNCX1+1/2SQ SPEC	
all	17	15K162	HXCAPSCR 1/2-13UNC2AX1.5 GR5 P	
all	18	02 11603C	WASHER DBLR=1.5W/CUTOFF SIDE	
all	19	15P200	TRDCUT-F HXWASHD 3/8-16X3/4NIK	
All	20	02 19023	DRIVE BASE ADJ. SCREW 13.5LG	
all	21	15G250	HXNUT 1-8UNC2B SAE ZNC GR2	
all	22	17W060	SPHERICALWASHER SET 1" M/F	
all	23	15U393	FLTWASH 1" HARD ASTM F436	
all	24	15K108	SKCPSC 3/8-16 UNC 3X1 BLK	
all	25	15U255	LOKWASHER MEDIUM 3/8 ZINCPL	
all	26	15G216	SQNUT 3/8-16UNC2B SAE ZINC GR2	
all	27	15K225	HEXCAPSCR 5/8-11X2+1/2	

Parts List, cont.—Drive Base Installation				
Used In	Item	Part Number	Description	Comments
all	28	15U315	LOKWASHER MEDIUM 5/8 ZINCPL	
all	29	02 11603A	WASHER DBLR=2" W/CUTOFF SIDE	
all	30	02 19577	ADJ ANGLE MOTOR	
all	31	02 11603A	WASHER DBLR=2" W/CUTOFF SIDE	
all	32	15G238	HXNUT 5/8-11UNC2B SAE ZINC GR2	
all	33	02 19383	BEARHOUSE MT PLATE FRONT	
all	34	15U314	FLATWASHER(USS STD) 5/8" ZNC P	
all	35	15U355A	28GA ADJWASH=BRGHOUS ZINC PL	
all	36	54M025	HYDFIT 1/8"-90 ALEMITE 1613-B	
all	37	5SCC0CBE	NPT COUP 1/8 BRASS 125# 103A-A	
all	38	5N0C03AG42	NPT NIP 1/8X3 TBE GALSTL SK40	



SECTION B-B

INSERT ALL 1/2" FASTENERS
HAND TIGHT. THEN TORQUE
IN THE FOLLOWING SEQUENCE,
SHOWN BELOW, TO BOTH
FRONT AND BACK



SECTION A-A



Pellerin Milnor Corporation
P. O. Box 400, Kenner, LA 70063-0400

Litho in U.S.A.


Parts List—Jackshaft
Find the correct assembly first, then find the needed components. The item letters (A, B, C, etc.) assigned to assemblies are referred to in the "Used In" column to identify which components belong to an assembly. The item numbers (1, 2, 3, etc.) assigned to components relate the parts list to the illustration.

Used In	Item	Part Number	Description	Comments
			-----ASSEMBLIES-----	
	A	ABJ25006	JKSHFT 6044SG 1 MOTOR SPHRCL	
			-----COMPONENTS-----	
all	1	X2 18711H	JACKSHAFT=6440SG SPHERICAL	
all	2	54A988	SKF BRNG #22217CCK/C3/W33	
all	3	54A989	SNW 17 X 2-15/16" ADAPTER	
all	4	X2 19381D	BRNG HOLDER=SPHRCL BRNG-REAR	
all	5	X2 19381C	BRNG HOLDER=SPHRCL BRNG-FRT	
all	6	X2 15702A	RETAINER-SPHRCL BRNG	
all	7	02 19384	COVER=BRG HOUSE FT+REAR	
all	8	X2 19378	BRGHSG SUP=TIMKENS MACHINED	
all	9	15K193	SOKCAPSCR 1/2-13X2.75GR8 HK	
all	10	15U180	LOCKWASHER MEDIUM 1/4 ZINCPL	
all	11	15K030	HEXCAPSCR 1/4-20UNC2X1/2 GR5 Z	
all	12	15K041	HXCAPSCR 1/4-20UNC2AX1 GR 5 ZI	
all	13	02 19195	RING=GREASE SLNGR JKSHFT WHT	
all	14	02 19196	RING=GREASE SLNGR JKSHFT BLK	
all	15	51A001	ADAPTER 1/8 PT BRASS	
all	16	5SLOCBEC	NPTELB 90DEG STRT 1/8 BRASS125	

Brake Assembly

4244WP2/WR2, 4244SP2/SR2


Figure 1: Brake Assembly



Brake Assembly

4244WP2/WR2, 4244SP2/SR2

Figure 2: Exploded view of the caliper and repair kit components



* - 2 per kit

Parts List—Brake Assembly

Find the correct assembly first, then find the needed components. The item letters (A, B, C, etc.) assigned to assemblies are referred to in the "Used In" column to identify which components belong to an assembly. The item numbers (1, 2, 3, etc.) assigned to components relate the parts list to the illustration.

Used In	Item	Part Number	Description	Comments
	A	GBR42002	DISC BRAKE 4244SP2 SM	4244WP2/WR2, 4244SP2 /SR2 INSTALLATION PARTS- REFERENCE NUMBER
	B	ABR42002	DISC BRAKE ASSY 4244SP2 SM	ASSEMBLY
-----COMPONENTS-----				
A	1	X2 21858	MACH=BRK CALPR MNT PLT,4840	
A	2	X2 21866	MACH=CALIPER DISK, 4840F	
A	3	X2 21867	MACH=CALIPER DISK HUB,4840F	
A	4	54KC7976	CALIPER HYD D/A 3/8IN RETRACT.H200DLRG	CALIPER REPAIR KIT
	4A	54KC7964RK	54KC7964 REPAIR KIT	PART OF KIT - 4A
	4B	54KC7964R2	BLEEDER SCREW-W. C. BRANHAM #4000-1049	PART OF KIT - 4A
	4C	54KC7964R1	ORING EPR #220 W. C. BRANHAM #4000-1059	PART OF KIT - 4A
	4D	54KC7963R1	PUCK/FRICTION PAD=W. C. BRANHAM #4000-1052	PART OF KIT - 4A
	4E	54KC7963R2	PANHD SCREW - W. C. BRANHAM #4000-1118	PART OF KIT - 4A
	4F	54KC7964R4	ORING EPR #010 W. C. BRANHAM #4000-1002	PART OF KIT - 4A
B	5	AAC65002	AIRCYL BRAKE SINGLE MOTOR	PART OF B, SEE BMP070011

Brake Assembly

4244WP2/WR2, 4244SP2/SR2

Parts List—Brake Assembly

Find the correct assembly first, then find the needed components. The item letters (A, B, C, etc.) assigned to assemblies are referred to in the "Used In" column to identify which components belong to an assembly. The item numbers (1, 2, 3, etc.) assigned to components relate the parts list to the illustration.

Used In	Item	Part Number	Description	Comments
	A	GBR42002	DISC BRAKE 4244SP2 SM	4244WP2/WR2, 4244SP2 /Sr2 INSTALLATION PARTS- REFERENCE NUMBER ASSEMBLY
	B	ABR42002	DISC BRAKE ASSY 4244SP2 SM	
-----COMPONENTS-----				
A	1	X2 21858	MACH=BRK CALPR MNT PLT,4840	
A	2	X2 21866	MACH=CALIPER DISK, 4840F	
A	3	X2 21867	MACH=CALIPER DISK HUB,4840F	
A	4	54KC7976	CALIPER HYD D/A 3/8IN RETRACT.H200DLRG	CALIPER REPAIR KIT PART OF KIT - 4A PART OF KIT - 4A PART OF KIT - 4A PART OF KIT - 4A PART OF KIT - 4A
	4A	54KC7964RK	54KC7964 REPAIR KIT	
	4B	54KC7964R2	BLEEDER SCREW-W. C. BRANHAM #4000-1049	
	4C	54KC7964R1	54KC7964R1	
	4D	54KC7963R1	PUCK/FRICTION PAD=W. C. BRANHAM #4000-1052	
	4E	54KC7963R2	PANHD SCREW - W. C. BRANHAM #4000-1118	
	4F	54KC7964R4	ORING EPR #010 W. C. BRANHAM #4000-1002	
B	5	AAC65002	AIRCYL BRAKE SINGLE MOTOR	PART OF B, SEE BMP070011
B	6	02 21650	MASTER CYL SUPP BRKT	PART OF B
B	7	W3 65238	*WLMT=MASTER BRAKE CYL BRKT	PART OF B
B	8	54KMC1125U	MASTER CYL = WILWOOD # 260-3380	PART OF B
B	9	52XY0ER004	STRADTUN3/16MJX1/8FP#2405-3-2	PART OF B
B	10	54KC7961BG	BRAKE HOSE=1/8"X18"OAL #50612	PART OF B
B	10B	54KC7961BSEAL	SEAL WASHER CONICAL,BRAKE HOSE	PART OF B
B	11	52AY0ER003	STR.1/4"MJICX1/8"MP#2404-4-2	PART OF B
B	12	15K095	HXCPSCR 3/8-16UNC2AX1 GR5 ZINC	PART OF B
B	13	15U255	LOCKWASHER MEDIUM 3/8 ZINCPL	PART OF B
B	14	15G205	HXNUT 3/8-16UNC2B ZINC Gr2	PART OF B
all	15	15K162	HXCAPSCR 1/2-13UNC2AX1.5 GR5 P	
all	16	15U300	LOKWASHER REGULAR 1/2 ZINC PLT	
all	17	15K041E	SKCPSCR 1/4-20X1+1/4"BLK	
all	18	15G166A	HXLOKNUT NYL1/4-20 UNC2A STL/Z	
all	19	15P200	TRDCUT-F HXWASHD 3/8-16X3/4NIK	
all	20	56Q1RSK	1+7/8" BUSH VPUL QD TYPE SK	
all	21	15K065	HEXCAPSCR 5/16-18UNC2AX1 GR5 Z	
all	22	15U210	LOKWASHER MEDIUM 5/16 ZINCPL	
All	23	15G185	HXNUT 5/16-18UNC2B SAE ZINC GR	




Autopot Installation
4244WP2 SM

BMP050078/2006135B
 (Sheet 1 of 2)



Pellerin Milnor Corporation
 P. O. Box 400, Kenner, LA 70063-0400

Litho in U.S.A.



**THIS ASSEMBLY USED ON MODELS
 PRODUCED FROM 3/15/05 TO 2/14/06
 (FOR LATER DESIGN, SEE BMP050079.)**



Pellerin Milnor Corporation
P. O. Box 400, Kenner, LA 70063-0400

Litho in U.S.A.

Parts List—Autospot Installation


Find the correct assembly first, then find the needed components. The item letters (A, B, C, etc.) assigned to assemblies are referred to in the "Used In" column to identify which components belong to an assembly. The item numbers (1, 2, 3, etc.) assigned to components relate the parts list to the illustration.

Used In	Item	Part Number	Description	Comments
			-----ASSEMBLIES-----	
	A	G28 15700C	INST=42" HYDRO AUTOSPT SM	
			-----COMPONENTS-----	
all	1	W2 19178	WLMT=AUTOSPOT SW/MNT 42"SG	
all	2	W2 15958	WLMT=TARGET 42" HYDRO SGL MTR	
all	3	02 15958A	BRKT=SW MNT 42 HYDRO SGL MTR	
all	4	02 15958B	COVER=42 HYDRO AUTOSPOT	
all	5	02 15961	BELTGUARD=AIROP AUTOSPOT	
all	6	54X020	PULTIMBLT E#40L050D-S26050	
all	7	56Q0MHS	.627" BUSH VPUL TYPE H,D,OR QT	
all	8	03 01329	SHAFT=AIROPAUTOSPOT OUR MATL	
all	9	02 10507	BEARING HOUSING- CUP- PLATED	
all	10	02 10508	BEARING HOUSING- PLATED- ZINC	
all	11	54C025	GEARBLT SYNC-COG DAYCO#345L050	
All	12	09RPS07RDS	7MM SENSING RECTANGULAR SHLD	



Pellerin Milnor Corporation
P. O. Box 400, Kenner, LA 70063-0400


Litho in U.S.A.



**THIS ASSEMBLY USED ON MODELS
PRODUCED FROM 2/14/06
(FOR EARLIER DESIGN, SEE BMP050078.)**

ADJUSTMENTS:

- A. Insure the switch face is parallel to target by rotating the mounting plate on the bar and tightening the split collar.
- B. Gap between target and switch sensor should be 3/16" [9mm]. Adjust the gap by sliding the mounting ring on slotted holes on mounting brackets.





Pellerin Milnor Corporation
P. O. Box 400, Kenner, LA 70063-0400

Litho in U.S.A.

Parts List—Autospot Installation

Find the correct assembly first, then find the needed components. The item letters (A, B, C, etc.) assigned to assemblies are referred to in the "Used In" column to identify which components belong to an assembly. The item numbers (1, 2, 3, etc.) assigned to components relate the parts list to the illustration.

Used In	Item	Part Number	Description	Comments
			-----ASSEMBLIES-----	
	A	G28 16202	INST=42WE S/M AUTOSPOT	
			-----COMPONENTS-----	
all	1	W2 16181	WLMT=PROX GUIDE MNT 42WE	
all	2	W3 60220C	WLMT=PROX MNT 60" AUTOSPOT	
all	3	02 16142	4244WE PROX TARGET	
all	4	09RPS07RDS	7MM SENSING RECTANGULAR SHLD	

V-BELT TENSION ADJUSTMENTS

This instruction is to be used for adjusting the belt tension on the following machine models:

42031WE2	42031SG2	42031WE3	42031SG3
42044WE2	42044SG2	42044WE3	42044SG3

A belt tension testing device (Milnor[®] part number 30T001) and a straight edge are required when using these instructions.

Tension Settings

Set the o-rings on the tension testing device (FIGURE 1) as follows:

1. Move the upper o-ring to the topmost position, resting against the bottom edge of the cap.
2. Find the proper Belt Deflection setting (by machine model and belt function) in the appropriate table in this section.
3. Move the lower o-ring on the tension tester to this deflection setting on the inches scale.

NOTE 1: The tension testing device is marked on one side in inches and pounds and on the other side in centimeters and kilograms. All values in the tables are in inches (in) and pounds (lbs).

NOTE 2: The instruction sheet provided with the tension testing device should not be used. Use only the instructions provided herein.

NOTE 3: The reference (ref) codes shown in the tables are for factory use only.




FIGURE 1 (MSSM0301AE)
Tension Tester Scales

Belt Tension Measurements

1. Place a straight edge along the top edge of the belt to be tested so that it spans both pulleys. Place the tension tester in the center of the belt and press down on the cap until the lower o-ring is in line with the straight edge, as shown.
2. Read the setting of the upper o-ring on the lbs scale of the tension tester.
3. Compare this value with the acceptable range in the appropriate table. If the belt is brand new (has never been run), use the range in the Initial Tension column. If the belt is not brand new, locate the acceptable range in the Final Tension column.
4. If the reading on the tension tester is *less* than the range shown in the table, the belt is *too loose* and must be tightened. If the reading is *greater* than the range shown in the table, the belt is *too tight* and must be loosened. Adjust the belt until the reading falls within the acceptable range in the table.




FIGURE 2 (MSSM0301AE)
Taking Measurements with
the Tension Tester

42031WE2/WE3 and 42044WE2/WE3 Belt Tension Measurements

	Belt Deflection (inches)	Initial Tension		Final Tension	
		(LBS)	(REF)	(LBS)	(REF)
Wash/2-Speed Wash	11/64	9.6-13.0	MP3	7.4-10.0	MN
Drain	3/8	8.0-11.0	LP3	6.2-8.5	LN
Main	50Hz	10.5-14.3	NP3	8.1-11.0	NN
	60Hz				

42031SG2/SG3 and 42044SG2/SG3 Belt Tension Measurements

	Belt Deflection (inches)	Initial Tension		Final Tension	
		(LBS)	(REF)	(LBS)	(REF)
Wash/2-Speed Wash	11/64	9.6-13.0	MP3	7.4-10.0	MN
Drain	3/8	8.0-11.0	LP3	6.2-8.5	LN
E1 (optional)	11/32	9.6-13.0	MP3	7.4-10.0	MN
Upper Jackshaft to Lower Jackshaft	50Hz	10.5-14.3	NP3	8.1-11.0	NN
	60Hz				

Bearing Assemblies

3

MAIN BEARING AND SEAL REPLACEMENT FOR DIVIDED CYLINDER MACHINES

This section applies to the front and rear cylinder shaft bearings of all divided cylinder machines (Rapid Load, Staph-guard[®], dye machines, etc.). It does not apply to jackshaft bearings, idler shaft bearings or bearings on open pocket machines.

The bearings covered by this section are double row, spherical roller, self aligning bearings; Koya, SKF, FMC, Torrington or equal. Referring to FIGURE 1, the rear (clean side on Staph-guard[®] models) bearing is firmly held in the bearing housing (bearing and seal carrier) by the shaft seal holder, preventing axial movement. The front (soil side on Staph-guard[®] models) bearing is free to move axially in the bearing housing to accommodate thermal expansion of the shaft during operation and is thus the "floating" bearing. Both bearings are held in place on the tapered portion of the shaft by a bearing lockwasher and locknut.

The front and rear bearings are each protected from contamination from wash water by three spring loaded, lip type seals and a shaft seal leak-off cavity (that carries off any water that leaks past the main water seals) as shown in FIGURE 1.




Figure 1 (MSSM0303AE)
Cross Section View of Front and Rear Bearing Assemblies
(Bearing Assembly for 60" and 72" WED Shown. Others similar.)

Access to the bearings and seals for lubrication is provided by the various grease passages. Excess lubricant is excreted through the bearing and seal cavity leak-offs as shown on FIGURE 1. The bearings and seals must be lubricated regularly and the leak-off cavities flushed out periodically through the plugged cleanout connections, in strict accordance with the preventive maintenance procedures elsewhere.

If bearing replacement becomes necessary due to wear, it is essential that the bearings *and seals* are replaced. Seal replacement requires removal of the bearing housing and seal sleeve. (In rare instances where the seals are known to be in good condition, it is not necessary to remove the bearing housing, seals or seal sleeve when a bearing is replaced.) **A pulling fixture is required to remove the bearing housing. A set of guide rods, a seal sleeve setting fixture and a bearing setting fixture are required for reinstallation of the housing.** These tools are available for rental or purchase from the Milnor[®] factory and are pictured elsewhere in this section. Contact the factory two weeks in advance of repairs, when ordering these tools.

This maintenance is performed in the following order:

1. Remove old bearing(s). When removing both bearings, remove the front (soil side) bearing first.
2. Remove bearing housings, seal sleeves, and seals.
3. If both bearings were removed, install the bearing housing, seal sleeve, seals, and new bearing on the rear (clean side).
4. Install the bearing housing, seal sleeve, seals, and new bearing on the front (soil side).
5. Tighten bearing(s).

See the Main Bearing Assembly drawing for your machine for bearing component part numbers.

Removing the Bearing (Front or Rear)

1. Loosen, then remove the main drive belts and cylinder shaft pulley (if applicable) by lowering the drive base with the jacking bolts. Do not attempt to pry belts off with a pry bar or by rolling the sheave. Remove the bearing cover (or shaft seal holder) to expose the bearing.
2. Bend back the locking tang on the bearing lock-washer then remove the locknut and lockwasher.
3. The center tapped hole in the shaft end is an oil passage through which oil may be forced between the tapered shaft and the bearing inner race. Install a pipe fitting into this tapped hole as shown in figure to the right. Using a "Porto-Power" or similar hand operated hydraulic pump, force fluid into the passage. Pump hard to build up fluid pressure. This pressure will cause the inner race to expand slightly; just enough to free the tapered surfaces and allow the bearing to slip off easily. If the bearing is not readily removed, remove the front water level




FIGURE 2 (MSSM0303AE)
Connection From Hydraulic Pump to Assist in Bearing Removal

inspection plate and use a timber to pry up the cylinder to remove cylinder weight from the bearings. Once the bearing is removed, the cylinder drops only approximately 1/32" before the shaft comes to rest on the shaft support.

4. Slide the bearing off of the shaft and if it is to be reused, place it on a clean surface and cover with a clean, lint free cloth.

Removing the Bearing Housing (Bearing and Seal Carrier), Seal Sleeve, and Seals (Front or Rear)

These procedures require the use of a pulling fixture and guide rods available from the Milnor[®] factory. With the bearing cover (or shaft seal holder) and the bearing removed, proceed as follows:

1. Remove the three bearing housing cap bolts and the grease lines from the bearing housing front plate. Install guide rods in two of the bolt holes, as shown in FIGURE 3.
2. Install the pulling fixture as shown in FIGURE 4, by placing each of the four threaded rods through a hole in the steel plate with hexnuts to the outside of the plate then screwing each rod into the appropriate tapped hole in the bearing housing (same holes as used to mount the bearing cover or shaft seal holder).




FIGURE 3 (MSSM0303AE)
**Two Bearing Housing Guide
Rods in Position**




FIGURE 4 (MSSM0303AE)
**Bearing Housing Pulling
Fixture in Position**

NOTE: Step 2a or 2b below will cause the bearing housing to slide away from the shell. Shims were placed under one or more of the three bearing housing pads during factory assembly to align the housing and insure its being exactly parallel with the shaft. **When removing the bearing housing, be sure to keep these shims separate and identified so that they may be returned to their proper location, otherwise the bearing and seal will be out of line and may be damaged after a short operating period.** As a precaution in case the shims are lost during disassembly, you will find stamped next to the bearing housing the proper thickness of shims required (if any) under each adjacent bearing housing pad. The stamped number indicates the shim thickness in thousandths of an inch. For example, the number “38” indicates that 38/1000 (.038") shims would be required under this pad.

- 2a. Tighten all four hexnuts on the threaded rods such that the pulling fixture plate is pressed against the shaft end. With an impact wrench, tighten down on the center bolt until the housing slides out, or
- 2b. If no impact wrench is available, simply continue to tighten down on each of the four hexnuts behind the pulling fixture plate, alternately and progressively, until the housing slides out. It may be necessary to place a spacer (approx. two inches long) between the plate and the shaft to provide enough clearance between the plate and the bearing housing.
3. Once the bearing housing is free of the shell, carefully slide it off of the guide rods and place on a clean work surface.
4. The seal sleeve will almost always remain on the shaft when the housing is removed. Remove the seal sleeve *taking care not to damage or scar it* and place it on a clean work surface.

Precautions for Bearing Replacement

The most important ingredient in successful bearing and seal installation is *cleanliness*. The bearing housing must be free of all foreign matter. The grease and leak-off passages must be blown clear and all *foreign* matter removed. You must have a clean work area. Keep your hands and tools free from grit and grime. Wash your hands before starting and as required during these procedures. Foreign matter is, without doubt, the most frequent cause of bearing failure, and one over which the manufacturer has no control.

Where cleaning is required, bearings, bearing housings and seal sleeves may be cleaned with the following solvents or cleaning agents (in strict accordance with the manufacturer’s recommendations as such substances are generally toxic and/or explosive under certain conditions):

Benzene	Gasoline	Naptha
Chlorethane	Kerosene	Trichlorethylene
Freons	Mineral Spirts	

Do not, however, expose any components to the above substances for more than 24 hours and only use at room temperature. Never use the following solvents or cleaning agents: alcohols, cresols, phenols, flouro propanols, or other similar chemicals or mixtures.

NOTE: Hammer blows, overheating, or improper use of force can damage precision parts.

Replacing the Bearing Housing, Seal Sleeve, and Seals (Front or Rear)

1. With the seal sleeve removed, press all old seals out of the bearing housing. Remove the large o-ring from the outside of the housing. Thoroughly clean the bearing housing and flush out all grease passages to make certain they are unblocked. Remove the o-rings from the inside of the seal sleeve and clean the seal sleeve.
2. While the bearing housing is disassembled, charge all grease passages with grease. This will assure that there are no blockages.
3. Replace the o-rings in the seal sleeve and the large o-ring on the outside of the bearing housing. Replace with new o-rings if the old ones are worn.
4. Press new seals into the bearing housing. You may gently work the seals in with a mallet and metal drift as shown in FIGURE 5.

▲ CAUTION ▲

Each seal must be of the proper material and face the proper direction. The type of material and direction the seal faces may differ from one seal to another within the same bearing housing and also from one type of machine to another. It is essential to consult the Main Bearing Assembly drawing for your machine for the proper part number and direction to face each seal.

5. Slip the seal sleeve into the bearing housing as shown in FIGURE 6 below right, using care not to damage or fold under any of the seal lips. Be sure to insert the sleeve in the proper direction (see Bearing Assembly drawing).



FIGURE 5 (MSSM0303AE)
**Installing Seals in
Bearing Housing**



FIGURE 6 (MSSM0303AE)
**Installing Seal Sleeve in
Bearing Housing**

NOTE: If both housings are being installed, install the rear housing first.

6. With two of the three temporary guide rods in position on the shell, place the bearing housing onto the guide rods and install the seal sleeve setting fixture on to the bearing housing as shown in FIGURE 7. The seal sleeve setting fixture prevents the seal sleeve from being pushed out of the housing as the housing is inserted into the shell. Note that the seal sleeve setting fixture and the bearing setting fixture are very similar, but the seal sleeve setting fixture has a longer hub.
7. With a clean, lint free cloth, apply a coating of light machine oil to the outside of the housing, to assist in installation. Push the housing into the shell as shown in FIGURE 8. Once the housing is far enough into the shell to support itself, place any shims back into position between the housing and the shell. Remove, then replace guide rods if required to place shims under bearing housing pads.



FIGURE 7 (MSSM0303AE)
Installing the Bearing Housing Setting Fixture onto Housing (42" machine shown)




FIGURE 8 (MSSM0303AE)
Pushing the Bearing Housing into the Shell (60" Rapid-load machine shown)

8. Install the third guide rod, spacers if required, and hex-nuts, using these to seat the housing fully, as shown in FIGURE 9. Remove the seal sleeve setting fixture.
9. Remove the guide rods and install the bearing housing cap bolts. See "BOLT TORQUE REQUIREMENTS" elsewhere, for proper torques.
10. With the grease gun, pump grease into the inner portion of the bearing cavity, such that when the bearing is installed, the space between the bearing and the seals will be approximately 1/3 full of grease.
11. Proceed to "Measuring Unmounted Clearance . . ." below, even if both the front and rear bearings are being replaced. Once the rear bearing is installed, the bearing housing replacement procedures may then be repeated for the front (soil side) bearing housing.



FIGURE 9 (MSSM0303AE)
Tightening the Bearing Housing into the Shell (42" machine shown)

Measuring Unmounted Clearance and Setting Bearing (Front or Rear)

The bearings used on Milnor[®] washer and dye extractors are the very best anti-friction devices available for these applications. However, the anti-frictional characteristics of the bearings will be reduced if they are not properly installed. It is of critical importance when installing these tapered roller bearings, to accomplish the following (A step by step procedure follows this synopsis):

1. Accurately measure the unmounted internal clearance of the bearing (gap between the rollers and outer race before the bearing is installed). This is an essential quality control measure.
2. Calculate the final internal clearance by subtracting the specified clearance reduction (amount that the internal clearance must be reduced when the bearing is tightened onto the tapered shaft) from the unmounted clearance.
3. Tighten the bearing onto the shaft until the final internal clearance as calculated is achieved and verified by measurement.

These measurements are taken in thousandths of an inch. Although this requires precise work, attention to detail and a good set of feeler gauges, it is the only way to insure that the bearing will be tightened onto the shaft to precisely the right tension. If you have any questions on performing the measurements or adjustments described below, your local bearing supplier or the Milnor[®] factory can assist you. Although these procedures require precision over and above that normally required for laundry room maintenance, they are standard in bearing installation and absolutely essential:

NOTE: Step 1 which follows, requires a good set of feeler gauges including .001" through .010" in thousandths of an inch increments. Contact your local bearing supplier.

1. When you are ready to proceed (and not before) remove the new bearing from its box or protective wrapping. Do not attempt to clean the bearing or wash out the preservative coating. On a clean work surface, stand the bearing on edge and insert a .003 feeler gauge into the bearing as shown in FIGURE 10, at right. The gauge should be inserted just inside the outer race between two rollers and worked through to the opposite row of rollers. Rotate the inner race of the opposite row so that the end of the feeler gauge is caught between a roller and the outer race.
2. Try to pull the gauge straight out. If it comes out, increase the size of the gauge by .001". If it does not come out, decrease the gauge by .001". The thickest feeler gauge that will come out is the unmounted internal clearance of the bearing.
3. Compare the measured clearance with the "Unmounted Clearance" in the table below. If the measured clearance is not within the range shown, do not use the bearing. Contact your bearing supplier for an exchange.



FIGURE 10 (MSSM0303AE)
**Measuring Bearing
Unmounted Clearance
(bridge for 42" machine shown)**

NOTE 1: The clearances listed in the chart are industry standards and therefore apply to all brands of bearings supplied by Milnor[®]. If other sources of bearings are used, refer to the manufacturer's instructions for proper clearances.

NOTE 2: To locate your bearing on the chart, match the first five characters of the manufacturer's part number (*not the Milnor[®] part number*) with those in the chart. For example, for a manufacturer's part number 22217LBK, find under "Manufacturer Part Number" the line "22217 . . ."

Table of Bearing Clearances

Manufacturer Part Number	Unmounted Clearance		Clearance Reduction	
	Minimum	Maximum	Minimum	Maximum
223300071	.0091	.002	.003
222130030	.0039	.001	.002
222160028	.0037	.001	.002
222170044	.0057	.0015	.0025
223120030	.0039	.001	.002
223160037	.0049	.001	.002
223200044	.0057	.0015	.0025
223280063	.0081	.002	.003
232200044	.0057	.0015	.0025

4. Calculate and record the final internal clearance by deducting the "Clearance Reduction" for your bearing (see above chart) from the measured clearance. For example, if you measured .004 and the clearance reduction is .001 to .002, then the final internal clearance should be between .002 and .003.
5. Hand pack the bearing with grease by rotating the inner race and rollers, forcing grease between all rollers.

NOTE: The bearing will be set into position in Step 6. If both front and rear bearings are being installed, the rear (clean side on Staph-guard[®] models) bearing should be set in position first because it is the fixed bearing.

6. Set the bearing into the housing (with the taper facing the proper direction) and seat the bearing using the bearing setting fixture. This fixture is installed in similar fashion to the seal sleeve setting fixture. If you have just set the rear bearing and the front bearing housing is yet to be installed, leave the bearing setting fixture in place for now.
7. If you have just set the rear bearing and the front bearing housing is yet to be installed, repeat all steps in bearing housing installation, measuring unmounted clearance and setting bearing, for the front bearing and housing. The bearing setting fixture should not be removed from the rear housing until it is needed to seat the front bearing. This will prevent rear bearing components from being pushed out of position by the shaft as the front housing components are seated. Remove the bearing setting fixture from the front housing once the bearing is seated.

Tightening Bearing(s) (Front and/or Rear)

1. Once both bearings are seated, or if only one bearing was replaced, install the bearing lockwasher(s) and locknut(s). Use a hammer and a metal drift as shown in FIGURE 11, to tighten the locknut. **It is imperative to only tap lightly and to assure that metal chips from the drift or locknut do not fall off and contaminate the bearing.** If both bearings are being tightened, work between the front and rear bearings and turn the basket by hand periodically, while tightening the locknut(s).
2. After tightening the bearing(s) onto the tapered shaft, check the internal clearance as pictured in FIGURE 12, by working a feeler gauge between the outer race and a roller of the outer row then between the outer race and a roller of the inner row.

NOTE: Sometimes, when setting the bearings, all the load is taken by only one row of rollers (although the load would quickly equalize on both rows after the machine has run for only a few minutes). If all the load is taken by one row, you will get an erroneous clearance reading. It is therefore, necessary to use the feeler gauge to measure the *clearance of both rows of rollers*. With the bearing in place on the machine it is admittedly rather difficult to get a feeler gauge back past the first row of rollers to measure the second *but it must be done*.

3. If one row of rollers is tight but the other has measurable clearance, tap lightly on the end of the shaft nearest the tight row of rollers to cause the shaft to shift axially and equalize the roller loading. Adjust the bearing tightness to achieve the internal clearance previously calculated.
4. When the proper internal clearance has been attained, lock the nut by bending over the matching tang on the lockwasher, making sure that all unused tangs are bent as near the nut as possible so that they will not rub against the bearing roller cage.

Check each unused tab individually to insure this.




FIGURE 11 (MSSM0303AE)
**Tightening the Bearing
Locknut (42" machine shown)**



FIGURE 12 (MSSM0303AE)
**Measuring the Mounted Internal
Clearance of the Bearing
(42" machine shown)**

-
5. With the grease gun, fill the space between the bearing and the front of the housing 1/3 full of grease.
 6. Install the bearing cover plate or shaft seal holder, as appropriate. When installing the shaft seal holder, take care not to damage the seal as it is gently pushed over the shaft. Cover the keyway on the end of the shaft with tape to prevent the sharp corners of the keyway from cutting the seal lip. Also, make sure that the seal lip does not turn over as it passes over rough areas.


Main Bearing Assembly

42031, 42044 CP2/CP3, NP2/NP3, WP2/WP3, SP2/SP3, DA2/DA3, DP2/DP3

BMP840040/2006344B
(Sheet 1 of 2)

MILNOR
Pellerin Milnor Corporation
P. O. Box 400, Kenner, LA 70063-0400

Litho in U.S.A.



**STAPH-GUARD
MACHINES
ONLY**



Pellerin Milnor Corporation
P. O. Box 400, Kenner, LA 70063-0400

Litho in U.S.A.

Used In	Item	Part Number	Description	Comments
			-----ASSEMBLIES-----	
A		GBM15001	*FRONT-REAR MAIN BRG ASSY 42W	4244WP2,CP2,CP3
B		GBM15001V	*42WE+CM+NS BEARASY=VITONSEAL	4244WP2,WP3 VITON SEALS
C		AD 16 018	*BEARASY:MAIN(LOD+CLN)4244SGU	4244CP2,CP3 VITON SEALS
			-----COMPONENTS-----	
all	1	5N0ECLSBE2	NPT NIP 1/4XCLS TBE BRASS 125#	
all	2	51P008B	PLUG SQSLD 1/4"BLK LVENT STEEL	
all	3	5SCC0EBE	NPT COUP 1/4 BRASS 125# W/HEX	
all	4	5N0C01KG42	NPT NIP 1/8X1.5 TBE GALSTL S40	
all	5	5SCC0CBE	NPT COUP 1/8 BRASS 125# 103A-A	
all	6	54M029	RELIEFFIT 1/8STR ALEMITE 47200	
all	7	54M015	GREASEFIT 60X36/60X44 1610BL	
all	9	X2 15538	CARRIER=FRONT BRG+SEAL	
All	10	02 15706	GASKET = BEARCAP	
all	11	02 15578	BEARCAP-CADSTL (1/42C)	
all	12	56S22312T	SPHEROLBRG FAG#22312EASK.M.C3	
all	13	56AHN12	N12 BEARING LOCKNUT	
all	14	56AHW12	W12 BEARING LOCKWASHER	
AB	15	15K083	HXCAPSCR 3/8-16 UNC2AX1/2 GR5	
all	16	15U255	LOCKWASHER MEDIUM 3/8 ZINCPL	
all	17	15K228B	HEXCAPSCR 3/4-10 X 1+1/2 GR 5/	
all	18	02 15292	LOCK WASH=BEARHSN 6/42C CAD	
all	19	02 15528	GREASE RESTRICTOR=42"SEALS	
all	20	02 15695	GASKET=SHAFT SUP 2/42WEHU	
all	21	15B245	HXCAPSCR 3/4-10UNC2AX1.75 GR5	
all	22	15U340	LOCKWASH MEDIUM 3/4 ZINCPL	
all	23	60C164	ORING 6+1/21DX1/8 -260	
all	24	60C137A	ORING 2+3/4ID1/8CS BUNA70 #232	
all	25	X2 15263D	SEALSLEEVE=2.75SHAFT(17-4PH)	
all	26	24S120	SEAL 3.25X4.25X.5 JM#9547 LUP	

Parts List, cont.—Main Bearing				
Used In	Item	Part Number	Description	Comments
AC	27	24S120	SEAL 3.25X4.25X.5 JM#9547 LUP	
B	27	24S120V	SEAL 3.25X4.25X.50 JM#9547LUP	
all	28	5SPOCBEHS	NPT PLUG 1/8 HXC TRSNK BRASS	
all	29	15U355F	24GA ADJWASH=BRGHOUS ZINC PL	
all	30	15U355F	24GA ADJWASH=BRGHOUS ZINC PL	
all	31	5N0C03AG42	NPT NIP 1/8X3 TBE GALSTL SK40	
all	32	X2 15539	CARRIER=REAR BRG+SEAL	
all	33	X2 15702	RETAINER=REAR BRG+SEAL	
all	34	60C152C	ORING 4+7/8IDX1/8CS BUNA70#249	
all	35	24S005	SEAL 2.25 X 3.0 X .375 SS BUNA	
all	36	15K095	HXCPCSR 3/8-16UNC2AX1 GR5 ZINC	
all	37	X2 15683	SUPPORT-SHAFT=2/42WEHU	
C	38	51P013	PLUG HXCNTRSUNK 1/4"BRASS	
C	39	X2 15746	RETAINER=BRG=SOILSD:C2-15702	

Frame, Pivots, and Suspension

4

SUSPENSION ADJUSTMENTS FOR DIVIDED CYLINDER MACHINES

The suspension system on Milnor[®] Hydro-cushion[®] machines is adjusted and thoroughly tested at the factory. It should not require subsequent adjustment unless the machine is distorted during shipment or installation or unless some component of the system, such as a Hydro-cushion[®] cylinder is replaced.

There are two primary objectives when adjusting the suspension system on any Hydro-cushion[®] machine model:

1. To position the shell in the proper location within the frame (hanging dimensions) to maximize freedom of movement of the shell and to insure proper draining, and
2. To adjust the length of up and down travel at each of the push-down locations (push down travel) so that the shell will not be distorted (racked) when pushed down.




FIGURE 1 (MSSM0302AE)

**Hydro-cushion[®] Suspension System Components
(does not depict a specific machine)**

All Milnor[®] Hydro-cushion[®] machines contain the following suspension system components (as shown on the typical system on the previous page):

1. Hydro-cushion[®] cylinder—which suspend the shell and cylinder within the frame and provide vibration damping during extraction.
2. Pneumatic push down devices (air bags)—which when inflated, force the shell downward where it is held against rigid pads during loading, unloading, washing, and draining.
3. Metal or rubber pads—some rigidly fixed to the shell and some rigidly fixed to the frame, which come in contact when the shell is pushed down.

The actual configuration of these components varies from model to model.

How Shell Adjustments are Made

Regardless of machine model, repositioning of the shell is always accomplished by adjusting the nuts at the top of the upper Hydro-cushion[®] shafts. To move the shell up or down at the location of any Hydro-cushion[®], see FIGURE 2 and proceed as follows:

▲ CAUTION ▲

These procedures should be accomplished with power to the machine locked off.

1. Straighten the tongues on the keyed lock washer using pliers, screw driver, etc.
2. Loosen the lock nut (upper hex nut) and move it all the way up to the top of the shaft, but do not remove it.
3. Use the adjusting nut (lower hex nut) to “crank” the shaft up or down as required.
4. Once final adjustment is made, while holding the adjusting nut to prevent it from turning, retighten the lock nut against the adjusting nut (with the lock washer between).
5. Rebend the tongues on the lockwasher as before, to prevent movement of the nuts.




FIGURE 2 (MSSM0302AE)
**Hydro-cushion[®] Upper
Shaft and Adjusting Nuts**

Shell Hanging Dimensions and Adjustment Procedures

To adjust the shell of a divided cylinder machine, proceed as follows:

1. Locate the shell hanging dimension for your machine in the table below and adjust your machine accordingly. Take measurements on the left and right sides of the shell, to assure that the shell is horizontal, left to right.
2. The shell and cylinder should be level front to back. Check this with a bubble level, as shown in FIGURE 3.
3. If further adjustment is required in order to level the cylinder, make small adjustments at all four corners. For example, if the cylinder slopes down to the front, try raising the two front corners by 1/16" (2mm) and lowering the two rear corners by 1/16" (2mm). Always split the difference.

NOTE: Only slight deviations from the dimensions shown should be used to level the shell. If large deviations are required, this may indicate that the frame is out of level. If so, this condition must be corrected before attempting to level the shell.




FIGURE 3 (MSSM0302AE)
Shell Hanging Dimensions for Divided Cylinder Machines
 (Left side view of 60044WE shown)

Push-Down Travel Dimensions and Adjustment Procedures

▲ CAUTION ▲

Some of the following procedures require power to the machine. Take the necessary precautions to assure that no one operates the machine controls while personnel are adjusting the push-down components.

42" Divided Cylinder Machines

The push-down stops on these machines consist of brackets attached to the shell and rubber rest pads, mounted atop the base pads (see figures below) which make contact when the shell pushes down. The rubber rest pads sit in metal pans and are raised or lowered by adding metal shims to or removing the shims from inside the pans. Extra shims and adhesive for securing the shims were supplied with your machine.

There is no specific push-down travel dimension for these machines; however, length of travel must be adjusted as follows:

1. With the *Master switch* set to *off*, and the shell hanging free, measure the gap between each bracket and base pad.
2. Add or remove shims from the appropriate pads as required to make all four gaps equal and to insure that no rest pad protrudes completely from its metal pan.

Test for equal length of travel at all four locations as follows:

3. With four sheet metal shims of *equal* thickness, set one shim *on top of* each rubber rest pad, such that at least a one inch length of the shim overhangs the outside edge of the pad.
4. Set the *Master switch* to *manual*, causing the shell to push-down.




FIGURE 4 (MSSM0302AE)
Push-down Travel Adjustment: 42" Div-cyls (42" Staph-guard® shown)

5. With the shell pushed down, attempt to pull each test shim out from between the bracket and rubber pad. The test shims should all be tight. If any shim(s) are not pinched tightly between the bracket and pad, take note of which one(s) are not.

Make final adjustments as follows:

6. Set the *Master switch* to *off*, remove the test shims and make the necessary changes to the shims below the rubber pads as indicated by the above test.
7. Repeat Steps 3 through 6 as required, until this test is successful.
8. Once the adjustments are completed, secure all shims and rubber rest pads with the adhesive provided.

60" Divided Cylinder Machines

These machines have push-down stops on the four corners of the frame which appear as shown in FIGURES 5 and 6. When pushed down, the ring weldments (which move with the shell) must seat firmly onto the plugs which are mounted atop the base pads. The push-down travel dimension must assure that 1) the ring weldments and plugs are far enough apart when the shell is not pushed down, so as not to interfere with the free movement of the shell, and 2) that all four stops are in solid contact when the shell is pushed down. To accomplish this, proceed as follows:

1. With the *Master switch* set to *off* and the shell hanging free, remove the bolts securing the ring weldments to the mounting brackets. Set each ring weldment on top of its respective plug, removing any shims which may have been used and placing them next to the ring weldment.
2. Measure the gap between the top of the ring weldment and the bottom of the mounting bracket, at each location.




FIGURE 5 (MSSM0302AE)
Shimming Ring Weldments




FIGURE 6 (MSSM0302AE)
Reconnecting Ring Weldments

-
3. Stack shims on top of the ring weldment as required to make each gap *exactly 2 inches* as shown in FIGURE 5. If the gap at any location is less than 2 inches without shims, the shell must then be raised in the frame, using the procedures previously described.
 4. Once the proper arrangement of shims is made, remount the ring weldment and shims to the mounting bracket (see FIGURE 6). Any extra shims may be stacked on the top side of the mounting bracket plate to which the ring weldment is attached.

Suspension Cylinder Locations

Use with BMP701408


BMP701235/2017155A
(Sheet 1 of 1)



Pellerin Milnor Corporation
P. O. Box 400, Kenner, LA 70063-0400

Litho in U.S.A.

Note: A letter is stamped on the end of the upper bolt to designate the cylinder assembly.



SEE BMP701408
FOR REPAIR PARTS:
HYDROCUSHION CYLINDER ASSEMBLY "B"
THROUGH HYDROCUSHION CYLINDER ASSEMBLY "K"

	MACHINE MODELS:								
	42031 CP2.NP2 WP2,WP3	42031 SP2,SP3	42044 CP2.NP2 WP2,WP3 D7P	42044 SP2/3; SR2/3	42044 WP2 SM, WP3 SM WR2,WR3	52038 WTL,WTN WP1	60044 WP2/3 SM SP2/3 SM WR2/3 SR2/3	72044 WP2,WP3 DA1	72044 SP2,SP3 SR2/SR3
POSITION:									
CYLINDER #1	B	B	C	C	C	D	K	H	G
CYLINDER #2	B	C	B	C	C	D	K	H	G
CYLINDER #3	B	C	B	C	C	D	K	F	G
CYLINDER #4	B	C	C	C	C	D	K	F	G


Suspension Cylinder Assemblies
42031,42044,52038,60044,72044

BMP701408/2006275B
 (Sheet 1 of 2)

Pellerin Milnor Corporation
 P. O. Box 400, Kenner, LA 70063-0400



Litho in U.S.A.



Used In		Item	Part Number	Description	Comments
<p>Parts List—Suspension Cylinder Assemblies Find the correct assembly first, then find the needed components. The item letters (A, B, C, etc.) assigned to assemblies are referred to in the "Used In" column to identify which components belong to an assembly. The item numbers (1, 2, 3, etc.) assigned to components relate the parts list to the illustration.</p>					
ASSEMBLIES					
B		SA 16 039	*HYDROCUSHION CYL ASSY-"B"		CYLINDER ASSY B
C		SA 16 038	*HYDROCUSHION CYL ASSY-"C"		CYLINDER ASSY C
D		SA 28 091	*HYDROCUSHION CYL ASSY-"D"		CYLINDER ASSY D
F		SA 36 021	*HYDROCUSHION CYL ASSY-"F"		CYLINDER ASSY F
G		SA 36 023	*HYDROCUSHION CYL ASSY-"G"		CYLINDER ASSY G
H		SA 36 047	*HYDROCUSHION CYL ASSY-"H"		CYLINDER ASSY H
K		SA 29 031K	*HYDROCUSHION CYL ASSY-"K"		CYLINDER ASSY K
<p>(Note: To identify which cylinder is supplied with your machine, see BMP701235 which should be located in the manual next to this document. Once you know which cylinder assembly you have, "B-K" listed above, identify your parts by referencing the "Used In" coding.)</p>					
COMPONENTS					
1	ABCDK	02 18244	BOLT=HYDCYL 27+7/8LG+KEYWAY		
1	K	02 18244A	BOLY=HYDCYL 28+7/8LG+KEYWAY		
1	FGH	03 06201	BOLT=HYDCYL 41+7/8LG+KEYWAY		
2	all	02 18840A	UPCAP=HYDROCYL 42+52+60		
4	all	5SP0KGFSS	NPT PLUG 1/2 SOSOLID GALSTL		
5	BC	X2 15356	PISTON=HYDROCYL 6"- 6 NOTCH		
5	DFGHK	X2 18228	PISTON=HYDROCYL 6"- 3 NOTCH		
6	all	5SP0GHFHKM	NPT PLUG 3/8"-HEXCSMAGNETIC ZN		
7A	FG	03 06139	SPRING=INNER HYDRO CYL 331LB/IN		FULL SPRING (PURPLE)
7B	G	03 06139A	SPRING=INNER HYDRO CYL		PLUS 1/2 SPRING "G" ONLY (PURPLE)
7C	H	03 06338	SPRING INNER-GOLD 14"LONG		GOLD
8	B	02 16068	MAIN SPRING 212LB/IN RED		RED
8	C	02 16125	MAIN SPRING 300LB/IN BLACK		BLACK
8	D	02 19039	MAIN SPRING 480LB/IN GREEN		GREEN
8	FG	03 06138	SPRING=OUT HYDROCYL 667LB/IN		ORANGE
8	G	03 06138A	SPRING=OUT HYDRO CYL		ORANGE
8	H	03 06337	SPRING-OUTER-GOLD 14.5"LONG		GOLD
8	K	03 09016	MAIN SPRING 1035LB/IN BLUE		BLUE
9	ABCDFGK	02 18619	BUSHING RETAINER + CAD		
9	H	03 06358	BUSHING RETAINER.CAD		
10	all	15B237	HXCAPSCR 1-8UNC2AX5.5 SAEGR5 Z		

Used In	Item	Part Number	Description	Comments
all	11	15G255A	SQNUT 1-8UNC2B SAE ZINC GR2	
all	12	15U400	LOCKWASHER MEDIUM 1" ZINCPL	
all	13	60C159A	ORING 5.475ID 1/4CS BN70 #433	
all	14	24S040	SEAL URETHNE 1-7/16 2.25 13/32	
GH	15	M2 18690	LOWER CAP=HYDROCYL	
all	16	02 18839A	MACHBUSH HYDRCYL CAP #433-OR	
BC	17	SA 15 084	*HYDCUSH CYL WLDMT (18"X/12")	
DI	17	SA 28 090	*HYDCUSH CYL WLDMT (18"/23")	
FGH	17	W3 06203	*HYDCUSH CYL WLDMT (35"/12")	
K	17	W2 18233	*HYDCUSH CYL WLDMT (20"X22")	
all	18	02 175034	SHIELD-BALBUSH-4/HYDRO MACH	
BDFGH	19	02 02230	6 WATER BARRIER (NEOPRENE)	
all	30	15G268	HXFJNAMNUT 1+1/2-12UNF2B ZINC	
all	31	02 18571A	PISTON ROD WASHER-.25"TK	
all	32	X3 06252	RETAINER-BALBUSH=4/72WEDU	
all	33	54M025	HYDFIT 1/8"-90 ALEMITE 1613-B	
all	34	27B240	SPCROLL.5ID.813L.062T STLZNC	
all	35	02 18534	HOLDPLATE= BALLBUSH ZNC/CAD	
all	36	15G230	HXNUT 1/2-13UNC2B SAE ZINC GR2	
F	37	Y3 06200	SPACER=HYDRO-CUSH CYL-MACH	
all	38	15K203	HXCAPSCR TFL 1/2-13X5 GR5 ZINC	
all	39	54A705	BALBUSH 1.5 SKF#GEZ108ESAVE467	
all	40	15N037	HXCAPSCR 1/2-13UNC2AX6.5 GR5 Z	
all	41	02 18256	LOKWASH-TONGUE 8WEH ZINC	
all	42	15K202	HXCAPSCR 1/2-13UNC2AX5 GR5 ZIN	
all	43	15U300	LOKWASHER REGULAR 1/2 ZINC PLT	
all	44	15G231	HXFJNAMNUT 1/2-13UNC2B ZINC G	
all	45	02 18534	HOLDPLATE= BALLBUSH ZNC/CAD	
all	46A	02 18795A	WASH-TIMING=HYDRO CYL 45DEG	USE ONE
all	46B	02 18795B	WASH-TIMING=HYDRO CYL 75DEG	USE ONE
all	47	15K191	HXCAPSCR 1/2-13UNC2AX2.5 GR5 Z	
FGH	48	AVH52001	ASSY=OILFIL SPOUT 72HYD CYL	

Shell and Door Assemblies

5

DOOR SEAL REPLACEMENT ON RAPID LOAD MODELS

Door Seal Replacement

The seal components referred to herein are contained in kits K28 0005R (for 60" machines) or K36 0003R (for 72" machines).

1. Remove old seal from the door cavity and carefully pull air tubing out of inner door so as not to cut tubing.
2. Remove as much as possible of the old adhesive from the rubber filler strip inside door cavity.
3. Carefully remove old seal from the air tubing fittings and attach new seal.
4. Carefully stretch new seal around door and into cavity. Because the new seal is fabric reinforced it is slightly narrower than the old style rubber seal; the wall is thinner and it does not stretch as easily. It will therefore feel much tighter than the all rubber seal when stretching it over the edge of the door.
5. After new seal is fitted and aligned into the door cavity, close both doors and inflate. Check to see that seals contact each other along the seam between the doors and that the seal contacts the shell front all around. To check this, attempt to slide a piece of paper between these surfaces.
6. If the seal does not contact the shell at locations A or D (see FIGURE 1), open the doors and stretch the seal toward these points.
7. If seals do not contact each other or the shell front in other areas, install rubber shims (part number 02 175267) between seal and filler strip as required to bring the seal further out from the door. Use adhesive (part number 20C015A) to attach shims to filler strip.
8. If seals do not contact each other at locations A and B, (see FIGURE 1), then at these points, glue tapered patches (part number 02 175134), as required, to the outside of seal (using adhesive 20C080C) to add thickness.
9. After seal has been completely fitted, roll seal up on one side, and with a small brush, paint adhesive (part number 20C015A) on filler strip to hold seal in place.




FIGURE 1 (MSSMA413AE)
Door Seal Checks

Door Seal—Preventive Maintenance

Check Door Alignment About the Shell Opening—Each door must be centered in its respective shell front opening. If the doors are not centered, the inflatable door seals will drag on the sealing edge of the shell front as the doors are opened and closed. The doors can be moved in any direction for centering by loosening the 1/2" hex cap nuts which hold the door assembly to the hinge cross brace as shown below.




FIGURE 2 (MSSMA413AE)
Door Alignments

Check Condition of Door Seal Channel—Be certain the sides of the channel in which the door seal fits are straight and that mainly the inner edge is not bent. See FIGURE 3 below. Because outer edge is double thickness it is not likely to be bent out of shape. But it is possible for the inner edge to become bent as shown.




FIGURE 3 (MSSMA413AE)
Door Alignment

Replace Worn Striker Plates—Each of the outer doors are securely held in the closed position by air latches. These air latches snap into striker plates bolted to the shell front. If the hole in these striker plates becomes worn, the shell doors will be allowed to move while the machine is in operation. It will look as though the doors are “breathing.” This will cause rapid wear and premature seal failure. Striker plate components are shown below.




FIGURE 4 (MSSMA413AE)
Worn Striker Plate

Check Door Alignment In and Out—Misalignment of the doors in and out of the shell front opening can be most often attributed to worn striker plates as described above. The doors should be adjusted so that, with one door open and one door closed, the closed door's inflatable seal channel will be centered on the shell front sealing surface when viewed edgewise (see FIGURE 5). If the door latch mechanism is loose, worn, or mismatched the door can travel too far into the machine, with the result that the inflatable seal can protrude past the door channel and the shell front sealing surface and be scissored when the door is reopened.




FIGURE 5 (MSSMA413AE)
Door Seals

Check Seal Air Pressure—Air pressure on these inflatable door seals should be set and maintained at 25 to 28 PSI. Too high air pressure will cause blowouts and too low air pressure will cause not enough contact between seal and shell front, thus movement and rapid wear. Kit K28 0011, which contains a fixed at 25 to 28 PSI regulator, plus a pressure gauge is available from the Milnor[®] factory. If yours is inoperative, it should be replaced.

Check Door Bumper—Be sure large rubber bumper (part number 60C075) on right hand door is in place and not worn.

Seal Vacuum Pump Feature

Since approximately June of 1980, all production machines have a vacuum pump which delays the opening of the door by 7.5 seconds and during that time literally sucks the air from the inflatable door seal. This is the single greatest extender of the life of the inflatable door seal. This feature is retrofitable to all 60" and 72" WE2 machines manufactured prior to June 1980. Order retrofit kit, part number K28 0013.


Cylinder Assembly 42044WP2, NP2, CP2, SP2

BMP701232/2006352B
(Sheet 1 of 1)



Pellerin Milnor Corporation
P. O. Box 400, Kenner, LA 70063-0400

Litho in U.S.A.



SEE
BMP990048

Parts List—Cylinder Assembly
Find the correct assembly first, then find the needed components. The item letters (A, B, C, etc.) assigned to assemblies are referred to in the "Used In" column to identify which components belong to an assembly. The item numbers (1, 2, 3, etc.) assigned to components relate the parts list to the illustration.

Used In	Item	Part Number	Description	Comments
			-----ASSEMBLIES-----	
			-----COMPONENTS-----	
	1	ACA16WE2B	CYL ASSY=4244WE2 304L TUNNL	42044WP2,CP2,NP2
	1	ACA16SG2B	CYL ASSY=4244SG2 304L TUNNL	42044SP2
	2	SA 15 103	CYLDOOR ASSY, STAMPED =42U	


Cylinder Assembly
42044WP3, 42044WP3 SM, 42044SP3

BMP080003/2008112B
 (Sheet 1 of 1)



Pellerin Milnor Corporation
 P. O. Box 400, Kenner, LA 70063-0400

Litho in U.S.A.



Parts List—Cylinder Assembly
 Find the correct assembly first, then find the needed components. The item letters (A, B, C, etc.) assigned to assemblies are referred to in the "Used In" column to identify which components belong to an assembly. The item numbers (1, 2, 3, etc.) assigned to components relate the parts list to the illustration.

Used In	Item	Part Number	Description	Comments
			-----COMPONENTS-----	
A	1	ACA16WE3B	* CYL ASSY=4244WE3 304L TUNNL	4244WP3
B	1	ACA16SG3B	* CYL ASSY=4244SG3 304L TUNNL	4244SP3
	all	SA 15 103	* CYLDOOR ASSY,STAMPED =42U	

Shell Doors


42031/42044CP2,NP2,WP2,WP3,SP2,SP3, 4244SP2 SM

BMP990047/2008095B
(Sheet 1 of 2)



Pellerin Milnor Corporation
P. O. Box 400, Kenner, LA 70063-0400

Litho in U.S.A.





Pellerin Milnor Corporation
P. O. Box 400, Kenner, LA 70063-0400

Litho in U.S.A.

Parts List—Shell Doors
Find the correct assembly first, then find the needed components. The item letters (A, B, C, etc.) assigned to assemblies are referred to in the "Used In" column to identify which components belong to an assembly. The item numbers (1, 2, 3, etc.) assigned to components relate the parts list to the illustration.

Used In	Item	Part Number	Description	Comments
			-----ASSEMBLIES-----	
A		SA 15 076A	SHELL DOOR ASY 42WE&SG CLEAN	
B		SA 15 097A	*SHELL DOOR ASY 42SG SOIL	
C		ASD42001	DOOR&LINER ASSY 42WE&SG	
			-----COMPONENTS-----	
C	1	15N196	PHILDRMACSCR 1/4-20UNC2X1+1/4S	
C	2	15G140	HXCAPNT 1/4-20 #C250=20 NKLPLT	
AB	3	15K151	HXCAPSCR 1/2-13UNC24X1.25 GR5	
AB	4	12K095	1" X 3/4" WASHER REDUCER	
AB	5	15U255	LOCKWASHER MEDIUM 3/8 ZINCPL	
A	6	15K110	HEXCAPSCR 3/8-16UNC2AX1.5 GR5-	
AB	7	15E007	KEY #7 WOODRUFF 3/4X1/8 SAE103	
AB	8	15U340	LOCKWASH MEDIUM 3/4 ZINCPL	
AB	9	15G244	HEXCAPNUT 3/4-10 #3292 BRASS-N	
AB	10	15Q140	SOKSETSCR CUP 3/8-16X1/2 BLK	
AB	11	53A059A	NUT 1/4"BR.HOLYOKE AND #61A-4	
C	12	15U181	LOCKWASHER MEDIUM 1/4 SS18-8	
AB	13	15U300	LOKWASHER REGULAR 1/2 ZINC PLT	
C	14	15K105	HXCAPSCR 3/8-16UNC2A1.25 GR5 P	
AB	15	15K041E	SKCPSCR 1/4-20X1+1/4"BLK	
C	16	02 15058	GASKET SHELDOR#APG726=BUNA N	
AB	17	12P1AGSB	SNAPBUSH 3/8"MH X 1/4" T=1/8	
C	18	53A501	TUBE INSERT .163"OD #63PT-4-40	
C	19	53A500	SLEEVE DELRIN 1/4"OD#60PT-4	
AB	20	54M020	GREASEFIT 30DEG 1611-B ALEMITE	
AB	21	5SB0E0CBEO	NPTHEXBUSH 1/4X1/8 BRASS 125#	
C	22	53A007B	BODYFEMCON.25X.25COMP#B66A-4B	
AB	23	60E004TE	1/4"OD X.170"ID NYL(BLK)TUBING	
AB	25	15U349	FLTWASH 101NYLON 1.93ODX1.25ID	
AB	26	53A031B	BODY-EL90MALE.25X1/8 #269C-42B	
AB	27	02 15053	HANDWHEEL-10" DDS+KW+POLISH	
B	28	X2 15035	RETAINER=DOOR HANDLE SCREW	

Used In	Item	Part Number	Description	Comments
C	29	02 15036	DOOR HANDLE SCREW 100-175WE	
C	30	02 15059	LINER=SHELLDOOR,GASKET	
C	31	02 15059A	SPACER=HR, SHELLDOOR 42WE	
C	32	Y2 15078	SHELL DOOR 42	
AB	33	X2 15016	DOOR HINGE MACHINED 6.218 LG	
A	34	W2 15034	*BAR DOOR LOCKING WELD	
B	34	W2 15763	*BAR DOOR INTLK WLMT-SG ONLY	
AB	35	02 15633S	ADJPLATE=DOORLATCH SS	
AB	36	SA 15 028	* DOOR LATCH ASSY-DIVCYLS	
C	37	03 64039D	COVER PLATE HANDWHEEL SCREW	
AB	38	54JH13125B	HINGE COL SPLIT 3.12 FL TOP	
AB	39	02 10391A	COVER STRIP=MICRO SW #10	

Cylinder Doors


42031/42044 CP2,CP3,NP2,NP3,WP2,WP3,SP2,SP3,DA3; 4244WP2 SM,WP3 SM,SP2 SM

BMP990048/2006336B
(Sheet 1 of 2)



Pellerin Milnor Corporation
P. O. Box 400, Kenner, LA 70063-0400

Litho in U.S.A.





Pellerin Milnor Corporation
P. O. Box 400, Kenner, LA 70063-0400

Litho in U.S.A.

Parts List—Cylinder Doors

Find the correct assembly first, then find the needed components. The item letters (A, B, C, etc.) assigned to assemblies are referred to in the "Used In" column to identify which components belong to an assembly. The item numbers (1, 2, 3, etc.) assigned to components relate the parts list to the illustration.

Used In	Item	Part Number	Description	Comments
-----ASSEMBLIES-----				
	A	SA 15 103	* CYLDOOR ASSY,STAMPED =42U	
-----COMPONENTS-----				
all	1	02 15826	DOOR-CYLINDER-SS-DRAWN	
all	2	02 15830	PLATE-CYLDOOR REINFORCING	
all	3	02 15825	ADAPTER PLATE=DOOR LATCH	
all	4	02 15832	SHIM=CYL DOOR LATCH	
all	5	02 15077	PLATE = SMALL DOORLATCH	
all	6	02 15041	BODY=CYLDOOR LATCH	
all	7	02 15040	PLUNGER=CYLDOOR LATCH(CAST)	
all	8	02 15093	SPRING=DOOR LATCH 9.4#/INCH	
all	9	02 15255	LOCKWASHER CYLDOOR LATCH	
all	10	02 15823	HALFHINGE-2/42"WEHU-302 SS	
all	11	02 15829	PIN=HINGE 1/4"	
all	12	15G168	SQNUT 1/4-20UNC2 SS18-8	
all	13	15U181	LOCKWASHER MEDIUM 1/4 SS18-8	
all	14	15K031	BUTSOKCAPSCR 1/4-20X1/2 SS18-8	
all	15	15G170	HEXNUT 1/4-20UNC2 SS18-8	
all	16	15N174	HXCAPSCR 1/4-20UNC2X5/8SS18-8	
all	17	15J008H	BUTTON HD RIVET 3/16 X 1/2" SS	

Door Latch

BMP700630/2011265B
(1 / 1)




Pellerin Milnor Corporation
P. O. Box 400, Kenner, LA 70063-0400

Litho in U.S.A.

Parts List—Door Latch
Find the correct assembly first, then find the needed components. The item letters (A, B, C, etc.) assigned to assemblies are referred to in the "Used In" column to identify which components belong to an assembly. The item numbers (1, 2, 3, etc.) assigned to components relate the parts list to the illustration.

Used In	Item	Part Number	Description	Comments
	A	SA 15 028	70239D* DOOR LATCH ASSY-DIVCYLS	
			ASSEMBLIES	
			COMPONENTS	
all	1	02 15105	RETAINER LATCHSPRING	
all	2	02 15297	91103B PLUNGER=DOORLOCK(DIVCYL)	
all	3	02 15298	CYLINDER-DOORLATCH INTERLOCK	
all	4	02 15836	68201A DOOR LATCH SPRING (302SS)	
all	5	15H090	01Z SPRNG PIN 1/4X1+7/8 LONG PLAIN	
all	6	60C122	ORING 1" ID 1/8CS BN 70 DURO #214	
all	7	60C128	ORING 1+3/8 ID 1/8CS BN 70DURO #220	



Control and Sensing Assemblies

6


Excursion Switch 4244SP2 SM

BMP060038/2006333B
(Sheet 1 of 1)



Pellerin Milnor Corporation
P. O. Box 400, Kenner, LA 70063-0400

Litho in U.S.A.



Parts List—Excursion Switch
Find the correct assembly first, then find the needed components. The item letters (A, B, C, etc.) assigned to assemblies are referred to in the "Used In" column to identify which components belong to an assembly. The item numbers (1, 2, 3, etc.) assigned to components relate the parts list to the illustration.

Used In	Item	Part Number	Description	Comments
	A	E03 33100A	EXCURSION SWITCH ASSY 42SGH	
			-----ASSEMBLIES-----	
			-----COMPONENTS-----	
all	1	09R008ASTD	* 09R008A+MOUNTING HDWRE+INST	
all	2	02 15783A	*PLATE=EXCURSION SW MTG	
all	3	02 10391	COVER STRIP=MICRO SW #6-8	
all	4	02 15789A	BKT=EXCURSION SWITCH=SGU	
all	5	02 15605E	ACTUATOR=EXCURSION SW 42SG-SIG	

VIBRATION SAFETY SWITCH ADJUSTMENTS

B What the Vibration Safety Switch Does

The *vibration safety switch* pictured below is an important safety feature. If properly adjusted, the switch will momentarily actuate as a result of repeated machine movement caused by an out-of-balance condition. Table A below illustrates the effect of the *vibration safety switch* actuation.

Table A—Effect of Tripping Vibration Safety Switch

Machine Model	Function of Vibration Safety Switch
30015, 30020, and 30022	Disables high speed extract
All microprocessor-controlled washer-extractors not listed above, and all dye machines	De-energizes three-wire relay, effectively terminating machine operation

Adjustments

When the machine leaves Milnor[®], the actuator arm is tie-wrapped to prevent damage (except on 30015, 30020, and 30022 models). **This tie wrap must be removed after the machine is set into position but before the machine is operated.**

Adjustment of this switch from the factory setting is not recommended; however, it should be checked for proper functioning and adjusted if its proper setting is lost.

As shown at right in FIGURE 1, the unit consists of a *sensitive micro-switch* with an extended actuating arm supporting an eccentric weight. The weight may be adjusted by moving it up and down on the arm and by rotating it on the arm. In addition, the *micro-switch* itself may be tilted from side to side.

The sensitivity of the switch increases as the eccentricweight is raised on the actuating arm and decreases as the weight is lowered.

The unit should be adjusted so that the actuating arm will always reset by itself, this being accomplished by rotating either the switch or the weight to give just enough bias to cause the switch to reset. Check the adjustment by moving the arm to the left then slowly releasing it. Make sure the micro-switch clicks when the arm is **slowly** released, thus indicating





FIGURE 1 (MSSMA408BE)
Vibration Switch

that it has reset. In the released position the arm should rest **lightly** but definitely against the stop on the *micro-switch* case that prevents any further arm movement to the left.

For machines with rigid mounted shells, where the machine is bolted to a very substantial foundation, very little machine movement will occur for a given degree of out-of-balance. Under such conditions it may be better to adjust the switch to be very sensitive. With less substantial foundations (e.g., ones where the sub-soil is mushy or springy or otherwise not as desirable), considerably greater machine movement will occur for a given degree of out-of-balance, in which case a less sensitive *vibration switch* setting may be indicated.

Vibration Safety Switch





Parts List—Vibration Safety Switch

Find the correct assembly first, then find the needed components. The item letters (A, B, C, etc.) assigned to assemblies are referred to in the "Used In" column to identify which components belong to an assembly. The item numbers (1, 2, 3, etc.) assigned to components relate the parts list to the illustration.

Used In	Item	Part Number	Description	Comments
-----ASSEMBLIES-----				
	A	SAE03 151	* ASSY-VIBRATION SWT=LG CONTR	
-----COMPONENTS-----				
all	1	02 02038	PLATE INSULATING SMALL9NOV51	
all	2	15P008	TRDCUT PANHD 6-32X1 NIKSTL +WA	
All	3	02 15119	BRACKET=VIBSW CAD	
all	4	09R020	SWITCH NC VIBR#WZ-2RW84429-P52	
all	5	03 01059	VIBSWITCH CLAMP CADSTL	
all	6	03 01058	VIBSWITCH WEIGHT-CADSTL	
all	7	15P101	TRDCUT-F PANHD 8-32X3/8 NIKSTL	

Air Chamber Level Switch

42044WR2,WR3,SR2,SR3 6044WR2,WR3,SR2




Parts List

Find the correct assembly first, then find the needed components. The item letters (A, B, C, etc.) assigned to assemblies are referred to in the "Used In" column to identify which components belong to an assembly. The item numbers (1, 2, 3, etc.) assigned to components relate the parts list to the illustration.

Used In	Item	Part Number	Description	Comments
-----ASSEMBLIES-----				
	A	AD 15 090A	AIRCHAMBER PRESWITCH INSTALL	
-----COMPONENTS-----				
all	1	5SB0E0CBEO	NPTHEXBUSH 1/4X1/8 BRASS 125#	
all	2	53A047H	MALCON 5/16X1/8POLY PH#68P-5-2	
all	3	5SR1A0ENF	NPT RED 1X1/4 GALMAL 150#	
all	4	5N1A07AG42	NPT NIP 1X7 TBE GALSTL SK40	
all	5	5S0KNFA1A	NPT TEE 1/2X1/2X1" GALMAL 150#	
all	6	5N0KCLSG42	NPT NIP 1/2XCLS TBE GALSTLSK40	
all	7	5SL0PNFC0K	NPT 90D STREET 3/4X1/2 GAL150#	
all	8	96DB0PNA	HOSEBIBB 3/4" MALEINLT 45DEG. ACETAL	
all	9	6.00E+06	TUBING BLK.POLY.5/160DX3/16ID	
all	10	51V010A	TEE 1/8"BRSEXTR BLOCTYP#2203P2	
all	11	51E502A	HOSESTEM BRASS 1/8MPT X3/16	
all	12	5SP0CBEHS	NPT PLUG 1/8 HXCTRSNK BRASS	
all	13	60E004NA	TUBING CLEAR PVC 3/16"IDX5/16"OD	
all	14	08BNLTT	LEVEL TRANSDUCER BD->TEST	

Temperature Probe

42044SR2, 42044WR2



Parts List

Find the correct assembly first, then find the needed components. The item letters (A, B, C, etc.) assigned to assemblies are referred to in the "Used In" column to identify which components belong to an assembly. The item numbers (1, 2, 3, etc.) assigned to components relate the parts list to the illustration.

Used In	Item	Part Number	Description	Comments
-----COMPONENTS-----				
all	1	30R0043P	TEMP PROBE:THERMISTOR 30K OHMS	

Chemical Supply Devices

7

RULES FOR THE FIELD INSTALLATION OF PUMPED-TYPE LIQUID SUPPLY SYSTEMS


APPLICABILITY: All Washer-Extractor Models

GENERAL

Pellerin Milnor Corporation does not guarantee machines against damage from corrosion caused by improper installation and/or operation of pumped-type liquid supply systems. The following precautions must be observed when pumps are used:


1. Always install the pumping unit lower than the discharge end of the chemical delivery tube as shown at right. This will prevent any excess chemical concentrate from dribbling out of the tube and onto unprotected machine surfaces when the machine is idle.

Merely putting a "drip loop" in the delivery tube won't help much. (It might reduce the dribble a little, but not enough to prevent damage.) **The real solution is to install the pumps below the discharge end of the delivery tubes so excess chemical won't dribble out of the tube long after the pumps stop.**



2. If the machine is also equipped with a flushing supply injector:

- a. Always wire the new system so the appropriate flushing valve also operates whenever chemical is being injected. This will dilute the concentrated chemical with obvious advantages. If possible, the water flushing valve should remain on for a minimum of 30 seconds after the longest injection time for that chemical.
- b. Always inject the chemical into a plastic cup (and direct the flushing water into the same cup). This way, any chemical that dribbles out



of the tube after the pump stops will be diluted by the water remaining in the cup.

3. Never inject any concentrated chemical directly onto any metal, rubber, or plastic surface of the machine other than the plastic cups provided.

It is not enough to merely inject the chemical onto a surface that will be subsequently flushed or wetted sometime during the wash process. This is because the "culprit" is the chemical which dribbles out later. The damage occurs when the residue of a chemical (even a diluted chemical) dries on a surface—as when a chemical dribbles out of the delivery tube after the last wash cycle is finished. As the chemical dries, the water content evaporates—leaving a deposit of a very concentrated chemical which is then free to attack the host surface throughout the night (or over the weekend) or until the machine is returned to service.

The only realistic solution is to make sure that the discharge end of each chemical delivery tube is above the pump so excess chemical left in the tube after the pump stops cannot dribble out later.


Supply Injector Assembly
4244WP2/WP3, 4244SP2 SM, 4244SP2/SP3, 4244SP2 SM

BMP970075/2006402B
 (Sheet 1 of 2)



Pellerin Milnor Corporation
 P. O. Box 400, Kenner, LA 70063-0400

Litho in U.S.A.





Pellerin Milnor Corporation
P. O. Box 400, Kenner, LA 70063-0400

Litho in U.S.A.

Parts List—Supply Injector Assembly
Find the correct assembly first, then find the needed components. The item letters (A, B, C, etc.) assigned to assemblies are referred to in the "Used In" column to identify which components belong to an assembly. The item numbers (1, 2, 3, etc.) assigned to components relate the parts list to the illustration.

Used In	Item	Part Number	Description	Comments
			-----ASSEMBLIES-----	
	A	SA-16-035A	ASSY, 5 FLUSH SUPINJ=4244WP + SP	4244WP2/WP3,4244SP2/SP3
	B	SA 16 034A	VALVASSY 5FLUSH=4244 WP+SP	
			-----COMPONENTS-----	
all	1	W2-15805	92612C* SUP-CHUTE 5-FLUSH=4231SGU	
All	2	24G018N	ROLLED WASH. 194ID NYLTITE 10W	
all	3	15G121	HXCAPNUT 10-24UNC2 #3266BR NKLPLTG2	
all	4	15N117	RDMACSCR 10-24UNC2X3/8 SS18-8	
All	5	15G130	HEXMACHSCRNUT 10-24UNC2 SS18-8	
all	6	15P100	07Z THDCUT-F PANHD 8-32 X 3/8 SS410	
all	7	SA-16-034A	86081# VALVASSY 5FLUSH=4244 WP+SP	
all	8	SA-09-047	70297B COVER=SUPPLY INJECTOR	
all	9	02-09100	92303B FRT VALVE ENCLOSURE	
all	10	02-09112	92303B REAR VALVE ENCLOSURE	
all	11	02-09103	93363C ENCLOSURE-VAL, TP+SIDES.	
all	12	27A017	PIPESTRP 1/2" 1-HOLE R. COND.	
all	13	5SL0KBEA	NPTELB 90DEG 1/2 BRASS 125#	
all	14	51X017	UNIONSTRADT 1/2" PH#0107-8-8	
all	15	15N140	RDMACSCR 10-24UNC2AX3/4 ZINC GR2	
all	16	15G125	HXMACHSCRNUT 10-24 UNC2B ZINC GR2	
all	17	02-09102	91116B+ENCLOSURE=VALVE LOW SIDEWRAP	
all	18	96TDC2AA37	1/2" N/C 2WAY 120V50/60C VALVE	
All	19	96TCC2AA37	3/8" N/C 2WAY 120V50/60C VALVE	
All	20	60E301A18A	HOSE= *2.5"ID PE X18"	

Water and Steam Piping and Assemblies

8

Water & Steam Schematics


42044WP2/CP2/NP2

BMP940112/2003262V
(Sheet 1 of 2)



Pellerin Milnor Corporation
P. O. Box 400, Kenner, LA 70063-0400

Litho in U.S.A.



* - STRAINER MUST BE CLEANED. SEE "PREVENTIVE MAINTENANCE" IN THE TABLE OF CONTENTS.

** - STANDARD COOLDOWN USES THE STANDARD WATER INLET VALVE AND IS SOFTWARE CONTROLLED. THE INDEPENDANT COOLDOWN VALVE ASSEMBLY IS OPTIONAL.



Pellerin Milnor Corporation
P. O. Box 400, Kenner, LA 70063-0400

Litho in U.S.A.

Parts List—Water & Steam Schematics

Find the correct assembly first, then find the needed components. The item letters (A, B, C, etc.) assigned to assemblies are referred to in the "Used In" column to identify which components belong to an assembly. The item numbers (1, 2, 3, etc.) assigned to components relate the parts list to the illustration.

Used In	Item	Part Number	Description	Comments
			-----ASSEMBLIES-----	
			none	
			-----COMPONENTS-----	
all	1	51T060	Y-STRAINER 1+1/4" CAST IRON	
all	2	96D0011E	1.25"NPTBRZ N/C STEAMVALANGBD	
all	3	96H018	ANGLE NEEDLE VLV 1/4" T X 1/8MP	
all	4	60E096C54A	STEAMH*OSE=1.25"X54"+2ENDS=(NO	
all	5	ASS25001	*52&60 STEAM SPARGER3/4ORFICE	
all	6	96D087BCSR	1.50WAT BVAL+ACT/BR/NC/ST/RH	
all	7	30F515	FLOW SENSOR SIGNET P51530-P0	
all	8	30F518	SIGNET S/S PIPE TEE 1.5"	
all	9	96M033	2.5"VAC BREAKER WATTS288A M2	
all	10	51T030	Y-STRAINER 3/4" CAST IRON	
all	11	96D050A	3/4"BALLVALVE BRZ WATTS#B6100	
all	12	96P053A37	3/4"VAL 110V HAYS#6-2110IS-120	
all	13	96M022	3/4" VAC BREAKER #288A	
all	14	96J030D	1/2"PRESSREG SET28# FEMXUN	
all	15	30N100	PRESSGAUGE 1/8"BACKCN.0-30PSI	
all	16	96M001	1/2X3/8" RELIEF VALVE SET31#	
all	17	96TDC2AA37	1/2" N/C 2WAY 120V50/60C VALVE	
all	18	96TCC2AA37	3/8" N/C 2WAY 120V50/60C VALVE	
all	19	96D087BCSR	1.50WAT BVAL+ACT/BR/NC/ST/RH	
all	20	96D095	VAL SAFETY 1"X1.25 SET 125#	
all	21	96M021SA	1/2" VACUUM BREAKER (STEAM)	
all	22	51T030	Y-STRAINER 3/4" CAST IRON	
all	23	51T60A00QA	3/4"STMTRP SARCO#212/10BTM.IN	

Water Inlets




4244WP2/WP3, 4244WP2 SM, 4244SP2/SP3, 4244SP2 SM

BMP030031/2006402B
(Sheet 1 of 2)



Pellerin Milnor Corporation
P. O. Box 400, Kenner, LA 70063-0400

Litho in U.S.A.



(4244SP2/SP3 MODELS SHOWN)

Water Inlets


4244WP2/WP3, 4244WP2 SM, 4244SP2/SP3, 4244SP2 SM

BMP030031/2006402B
(Sheet 2 of 2)



Pellerin Milnor Corporation
P. O. Box 400, Kenner, LA 70063-0400

Litho in U.S.A.



Parts List—Water Inlets

Find the correct assembly first, then find the needed components. The item letters (A, B, C, etc.) assigned to assemblies are referred to in the "Used In" column to identify which components belong to an assembly. The item numbers (1, 2, 3, etc.) assigned to components relate the parts list to the illustration.

Used In	Item	Part Number	Description	Comments
			-----ASSEMBLIES-----	
	A	G15 15900B	WATER INSTALLED H+C	
	B	AVW15003W	*VALVEASSY=1.5 AIROP COLD WTS	
	C	AVW15004W	*VALVEASSY=1.5 AIROP H+3RD WT	
	D	AVW15005	* INLET PIPING SUBASSY 42 WEH	
	E	AVW15007	* INLET PIPING SUBASSY 42SGH	
			-----COMPONENTS-----	
all	1	96D087BCSR	1.50WAT BVAL+ACT/BR/NC/ST/RH	
all	2	5N1K13AG42	NPT NIP 1.5X13 TBE GALSTL SK40	
all	3	5S1KNFA	NPT TEE 1.5" GALMAL 150#	
all	4	51P055	NPTPLUG 1.5 SQCORED GALCI 125#	
all	5	5N1K03AG42	NPT NIP 1.5X3 TBE GALSTL SK40	
all	6	02 16306	CLAMP=1+1/2" PIPE	
all	7	27A032	UBOLT 1.5"PIPE 3/8-16X3-3/4LEG	
all	8	15G205	HXNUT 3/8-16UNC2B ZINC GR2	
all	9	15U255	LOCKWASHER MEDIUM 3/8 ZINCPL	
all	10	5SL1KNFA	NPT ELBOW 90DEG 1.5" GALMAL 15	
all	11	W2 15847A	*RED1.5NPT-MALEX2.5S/S TUBE	
all	12	27A075	T-BOLT HOSECLAMP 2.78-3.09"	
all	13	60E301A43A	*HOSE=2.5"ID PE X 43"	




**Steam Inlet
4244WP2/WP3**

BMP030032/2003262V
(Sheet 1 of 3)




Pellerin Milnor Corporation
P. O. Box 400, Kenner, LA 70063-0400

Litho in U.S.A.



VIEW A-A



VIEW B-B




**Steam Inlet
4244WP2/WP3**

BMP030032/2003262V
(Sheet 2 of 3)



Pellerin Milnor Corporation
P. O. Box 400, Kenner, LA 70063-0400

Litho in U.S.A.





Pellerin Milnor Corporation
P. O. Box 400, Kenner, LA 70063-0400

Litho in U.S.A.

Used In	Item	Part Number	Description	Comments
			-----ASSEMBLIES-----	
	A	GVS15002	INSTALL=1.25STEAM 42WE2+3	
	B	AVS15001	\$1.25 BURKERT STEAM=42WE2+3	
	C	AVS03001	*1+1/4BURKERT +STRAINER	
	D	ASS25001	*52&60 STEAM SPARGER3/4ORFICE	
			-----COMPONENTS-----	
all	1	51T060	Y-STRAINER 1+1/4" CAST IRON	
all	2	5SP0PHFSS	NPT PLUG 3/4 SQ SOLID STL/ZINC	
all	3	5N1E05AG42	NPT NIP 1.25X5 TBE GALSTL SK40	
all	4	96D0011E	1.25"NPTBRZ N/C STEAMVALANGBD	
all	5	96H018	ANGLE NEEDLE VLV 1/4" X 1/8MP	
all	6	5SB0E0CBEO	NPTHEXBUSH 1/4X1/8 BRASS 125#	
all	7	5N1E16AG42	NPT NIP 1.25X16 TBE GALSTL SK4	
all	8	5SL1ENFA	NPT ELB 90DEG 1.25 GALMAL 150#	
all	9	5N1ECLSG42	NPT NIP 1.25XCLS TBE GALSTLS40	
all	10	5SU1ENF	NPT UNION 1.25" GALMAL 150#	
all	11	51E096C	MALESTEM 1.25"CADPL CAMP#IMS5	
all	12	AVS03001	*1+1/4BURKERT +STRAINER	
all	13	60E096C54A	STEAMH*OSE=1.25"X54" +2ENDS=(NO	
all	14	27A032	UBOLT 1.5"PIPE 3/8-16X3-3/4LEG	
all	15	15G205	HXNUT 3/8-16UNC2B ZINC GR2	
all	16	15U255	LOCKWASHER MEDIUM 3/8 ZINCPL	
all	17	15G200	HXCPNUT 3/8-16 UNC2A 5/8X1/2	
all	18	02 16306A	BRKT=1+1/4"PIPE SUPPORT	
all	19	15U240	FLATWASHER(USS STD) 3/8" ZNC P	
all	20	27A032M	UBOLT 2"PIPE 3/8-16 ZNC3.5" LG	
all	21	27A035	UBOLT3/8-16 3.625BETWN LEGS	
all	22	ASS25001	*52&60 STEAM SPARGER3/4ORFICE	
all	23	5SL1ESFA	NPT ELB 90DEG 1.25 304SS 150#	
all	24	W3 64566B	*WLM=STM SPARGER .75 ORF-12"L	
all	25	02 14647E	GASKET=DRNTRGH TO RECIRC BOX	
all	26	W2 15897E	*STEAM+WATER INLET WLDMT 42WE	

Used In	Item	Part Number	Description	Comments
all	27	27A084	HOSECLAMP 3+9/16-4.5CADSC#HS64	
all	28	60E306A07A	HOSE= *3.5ID PE X 7"	
all	29	87Z070010A	TUBE=3.5"ODX10"LG-SQ ENDS	
all	30	60E306A18A	HOSE= *3.5"ID PE X18"	




Flushing Water Supply
4244WP2/WP3, 4244WP2 SM, 4244SP2/SP3, 4244SP2 SM

BMP030033/2006402B
 (Sheet 1 of 2)



Pellerin Milnor Corporation
 P. O. Box 400, Kenner, LA 70063-0400

Litho in U.S.A.





Pellerin Milnor Corporation
P. O. Box 400, Kenner, LA 70063-0400

Litho in U.S.A.

Parts List—Flushing Water Supply

Find the correct assembly first, then find the needed components. The item letters (A, B, C, etc.) assigned to assemblies are referred to in the "Used In" column to identify which components belong to an assembly. The item numbers (1, 2, 3, etc.) assigned to components relate the parts list to the illustration.

Used In	Item	Part Number	Description	Comments
-----ASSEMBLIES-----				
	A	SA 15 080H	\$INLET=FLUSHSUP 42HYDRO	4244WP2/WP3
	B	SA 15 080I	\$INLET=FLUSHSUP 42SG	4244SP2/SP3
-----COMPONENTS-----				
all	1	96J030D	1/2"PRESSREG SET28# FEMXUN	
all	2	96M001	1/2X3/8" RELIEF VALVE SET31#	
all	3	5SB0G0EDEO	NPTHEXBUSH 3/8X1/4 GALCI 125#	
all	4	53A008B	BODYMALECON.25X.25COMP#B68A-4B	
all	5	5N0K10AG42	NPT NIP 1/2X10 TBE GALSTL SK40	
all	6	5N0KCLSG42	NPT NIP 1/2XCLS TBE GALSTLSK40	
all	7	5S0KNFB	NPT SIDEOUT TEE 1/2" GALMAL	
all	8	5SCC0KNF	NPT COUP 1/2 GALMAL 150#	
A	9	60E086K14A	3/4X14 WATER HOSE W/1/2ENDS	
B	9	60E086K28A	3/4X28 WATER HOSE W/1/2ENDS	
all	10	30N100	PRESSGAUGE 1/8"BACKCN.0-30PSI	
all	11	5SB0K0CDEO	NPTHEXBUSH 1/2X1/8 GALCI 125#	


SERVICING AIR CYLINDERS

This is the general procedure for rebuilding an air cylinder using a Milnor[®] furnished repair kit, once the air cylinder has been removed from the machine. See the specific air cylinder and major assembly parts drawing(s) for component identification and removal/replacement information.

Maintenance procedures require:

- Two threaded rods and nuts, twice the length of the tie bolts.
- The appropriate repair kit.

▲ CAUTION ▲



EXPLOSION HAZARD—Spring tension can cause air cylinder to burst apart with great force during disassembly. You can be struck by air cylinder parts.

☞ **Follow maintenance instructions carefully.**

☞ **Wear eye protection.**

NOTE: Use a new locknut when re-assembling air cylinder (see the appropriate parts drawing).

1. Replace two diagonally opposite tie bolts with threaded rods and nuts as shown in FIGURE 1.
2. Tighten nuts on the threaded rods until they contact the air cylinder.
3. Remove the other two tie bolts and the nuts, washers, clips, and actuators from the external end of piston stem.




FIGURE 1 (MSSM0130AE)
Using Threaded Rods

- Loosen nuts on threaded rods evenly, permitting cylinder heads to separate. Use only a few turns on one nut before moving to the other one. Continue until springs have no tension.




FIGURE 2 (MSSM0130AE)
Correct Piston Cup Shape




FIGURE 3 (MSSM0130AE)
Distorted Piston Cup Shape

- Note position and orientation of piston cup(s), washers, and springs. Replace worn parts, then reassemble in reverse order. Tighten locknut until it is just barely possible to turn the piston cup and washer assembly on the stem. Correct piston cup shape is shown in FIGURE 2. **DO NOT** overtighten, as this causes the piston cup to deform to the shape shown in FIGURE 3 and may cause piston to bind in cylinder.

Universal Actuators & Mounting Hardware for Watts Ball Valves - New Pivot


BMP920005/96067V
(Sheet 1 of 3)



Pellerin Milnor Corporation
P. O. Box 400, Kenner, LA 70063-0400

BMP920005/96067V (1 of 3)

Litho in U.S.A.





Pellerin Milnor Corporation
P. O. Box 400, Kenner, LA 70063-0400

BMP920005/96067V (2 of 3)

Litho in U.S.A.

Parts List—Actuators & Mounting Hardware for Watts Ball Valves
Find the correct assembly first, then find the needed components. The item letters (A, B, C, etc.) assigned to assemblies are referred to in the "Used In" column to identify which components belong to an assembly. The item numbers (1, 2, 3, etc.) assigned to components relate the parts list to the illustration.

Used In		Item	Part Number	Description	Comments
-----ASSEMBLIES-----					
AA	96D085BCSL	92000Z	1.00WAT	BVAL+ACT/BR/NC/ST/LH	
AB	96D085BCSR	93513S	1.00WAT	BVAL+ACT/BR/NC/ST/RH	
AC	96D085BOSL	93513S	1.00WAT	BVAL+ACT/BR/NO/ST/LH	
AD	96D085BOSR	93513S	1.00WAT	BVAL+ACT/BR/NO/ST/RH	
AE	96D085SOSR	92000Z	1.00WAT	BVAL+ACT/SS/NO/ST/RH	
AF	96D085SCSR	92000Z	1.00WAT	BVAL+ACT/SS/NC/ST/RH	
BA	96D086BCSL	93513S	1.25WAT	BVAL+ACT/BR/NC/ST/LH	
BB	96D086BCSR	93513S	1.25WAT	BVAL+ACT/BR/NC/ST/RH	
BC	96D086BOSL	93513S	1.25WAT	BVAL+ACT/BR/NO/ST/LH	
BD	96D086BOSR	93513S	1.25WAT	BVAL+ACT/BR/NO/ST/RH	
BE	96D086SCNR	92000Z	1.25WAT	BVAL+ACT/SS/NC/90/RH	
BF	96D086CSL	92000Z	1.25WAT	BVAL+ACT/SS/NC/ST/LH	
BG	96D086CSR	92000Z	1.25WAT	BVAL+ACT/SS/NC/ST/RH	
BH	96D086SOSL	92000Z	1.25WAT	BVAL+ACT/SS/NO/ST/LH	
BJ	96D086SOSR	92000Z	1.25WAT	BVAL+ACT/SS/NO/ST/RH	
CA	96D087BCSL	93513S	1.50WAT	BVAL+ACT/BR/NC/ST/LH	
CB	96D087BCSR	93513S	1.50WAT	BVAL+ACT/BR/NC/ST/RH	
CC	96D087BOSR	92000Z	1.50WAT	BVAL+ACT/BR/NO/ST/RH	
CD	96D087SCNR	92000Z	1.50WAT	BVAL+ACT/SS/NC/90/RH	
CE	96D087SCSR	92000Z	1.50WAT	BVAL+ACT/SS/NC/ST/RH	
CF	96D087SOSR	92000Z	1.50WAT	BVAL+ACT/SS/NO/ST/RH	
DA	96D088BCSR	92177S	2.00WAT	BVAL+ACT/BR/NC/ST/RH	
DB	96D088BCNR	92177S	2.00WAT	BVAL+ACT/BR/NC/90/RH	
DC	96D088BCSL	92177S	2.00WAT	BVAL+ACT/BR/NC/ST/LH	
DD	96D088BOSR	92177S	2.00WAT	BVAL+ACT/BR/NO/ST/RH	
DE	96D088SCNR	92177S	2.00WAT	BVAL+ACT/SS/NC/90/RH	
DF	96D088CSR	92177S	2.00WAT	BVAL+ACT/SS/NC/ST/RH	
DG	96D088SOSR	92177S	2.00WAT	BVAL+ACT/SS/NO/ST/RH	
DH	96D088BCNL	92177S	2.00WAT	BVAL+ACT/BR/NC/90/LH	
DJ	96D088BOSL	92177S	2.00WAT	BVAL+ACT/BR/NO/ST/LH	
DK	96D088CSL	92177S	2.00WAT	BVAL+ACT/SS/NC/ST/LH	
DL	96D088SOSL	92177S	2.00WAT	BVAL+ACT/SS/NO/ST/LH	
-----COMPONENTS-----					
AA-AD, BA-BD, CA-CC	1	SA 10 056F	92000Z	AIRCYL=2.38ODX2.70STX20.5#CD	
AE-AF, BE-BJ, CD-CF	1	SA 10 056G	92000Z	*AIRCYL=2.38ODX2.70STX20.5#SS	
DA-DD, DH-DJ	1	SA 10 057C	95222D	AIRCYL=3.00DX3.89ST171/176CD	
DE-DG, DH-DJ, DK-DL	1	SA 10 057D	95222#	AIRCYL=3.00DX3.89ST171/176SS	
AA-AE AF	2	96D085WEXS	07Z	BALVAL 1" BRZ WATTS#B6400SSZ107	
BA-BD	2	96D085WSS	07Z	BALVAL 1" SS WATTS S8000-Z107	
BE-BJ	2	96D086WEXS	08Z	BAVAL 1+1/4BRZ WATS#B6400SSZ107	
CA-CC	2	96D086WSS	08Z	BAVAL 1+1/4"SS WATTS S8000-Z107	
	2	96D087WEXS	09Z	BAVAL 1+1/2BRZ WATS#B6400SSZ107	

Used In	Item	Part Number	Description	Comments
CD-CF	2	96D087WSS	08Z	BAVAL 1+1/2"SS WATTS S8000-Z107
DA-DD, DH-DJ	2	96D088WEXS	09Z	BALVAL 2" BRZ WATTS#B6400SSZ107
DE-DG, DK-DL	2	96D088WSS	09Z	BALVAL 2" SS WATTS S8000-Z107
AA,AC AB,AD,AE, AF	3	03 01634A 03 01634	94053# 94053C	ACTUATOR CHANNL SUPPORT-LEFT ACTUATOR CHANNL SUPPORT 1.0"
BA,BC,BF, BH,CA	3	07 20700L	88512#	ACTUATOR ZEE SUPPORT-LEFT
BB,BD,BE, BG,BJ,CB, CC,CE,CF	3	07 20700	88512D	ACTUATOR ZEE SUPPORT
CD	3	03 01633 03 01628	92651C 92126D	ACTUATOR SUPPORT BRKT 1.0" ACTUATOR ZEE SUP 3"AIRCYL
DA,DB, DD-DG	3	03 01628L	92126#	ACT ZEE SUP 3" AIRCYL-LEFT
AA,AC AB,AD-AF, CD	4	03 01632A 03 01632	90507# 90507C	ACTUATOR BEARING SUPPRT-LEFT ACTUATOR BEARING SUPPORT-1"
BA,BC,BF, BH,CA	4	07 20702L	88512#	ACTUATOR BEARING SUPPORT-LFT
BB,BD,BE, BG,BJ,CB, CC,CE,CF	4	07 20702A	88512C	ACTUATOR BEARING SUPPORT
DA,DB, DD-DG	4	03 01629	92023C	ACTUATOR BEARING SUPPORT 3
DC,DH-DL	4	03 01629L	92023#	ACT BEARING SUPPORT 3"-LEFT
AA-AF,CD BA-BJ, CA-CC,CF, DA-DL	5	54E001PABA 54E002PABA	89281B 89281B	ASSY=1/4"PRESSBEARING ASSY=5/16"PRESSBEARING
AA,AB,AF, CD	6	03 01631	91507B+VALVE	CRANK N.C.WATTS 1.0"
AC-AE BA,BB,BE, BF,BG,CA, CB,CE	6	03 01631A 07 20703A	88381B 91507B	VALVE CRANK N.O.WATTS-1.0" VALVE CRANK N.C.WATTS 1.5"
BC,BD,BH, BJ	6	07 20703B	88153B	VALVE CRANK N.O.WATTS 1.5"
DA,DC,DF, DK	6	03 01624B	92061B	CRANK=NC 2"BALVAL .626 STEM
DB,DD,DE, DG,DH,DJ, DL	6	03 01624C	92061B	CRANK=NO 2"BALVAL .626 STEM
all except CC,CD	7	15K031	BUTSOKCAPSCR	1/4-20X1/2 SS18-8
CC,CD	7	15N117	RDMACSCR	10-24UNC2X3/8SS18-8
all	8	15U181	LOCKWASHER	MEDIUM 1/4 SS18-8
all	9	15N130	RDMACHSCR	10-24UNC2A X 1/2 SS18-8
all	10	15U135	FLATWASH#10	.4370DX.203IDX.04TSS188



Pellerin Milnor Corporation
P. O. Box 400, Kenner, LA 70063-0400

Litho in U.S.A.

Parts List, cont.—Universal Actuators & Mounting Hardware for Watts Ball Valves

Used In	Item	Part Number	Description	Comments
all	11	15G126	01Z HXLOCKNUT NYLON 10-24 UNC SS NM	
all	12	15N159	HEXCAPSCR 1/4-20UNC2AX7/16 18-8SS	
all	13	15G170	HEXNUT 1/4-20UNC2 SS18-8	
AA-AF, BE, CD, DA-DL	14	07 20703D	89354B WASHER=2.00"WATTS CRANK	
BA-BD, BF-BJ, CA-CC, CE, CF	14	07 20703C	89354B WASHER=1.25-1.50 WATTS CRANK	
all	15	02 15893	92683B SPACER=BALL VALVE CRANK STEM	
all	16	15U188	01Z FLTWASH 1/4 STD COMM SS18-8	
all	17	15N186	HXCAPSCR 1/4-20UNC2X3/4SS18-8	
all	18	15G164	01Z HX THIN LOCKNUT NYL1/4-20 SS	
BA, BB, BE, BJ, CE	19	03 01661A	92271B BRKT=RHT AIR CYL SUPT-S/S	
DA, DB, DD-DG	19	03 01625A	92271B 3" AIR-CYL SPT BRK R-SIDE RT	
DC, DH-DL	19	03 01625B	92271# 3" AIR-CYL SPT BRK R-SIDE LT	
BE, BG, BJ, CE-CF	20	03 01662A	92271B BRKT=LFT AIR CYL SUPT-S/S	
DA, DB, DD-DG	20	03 01625C	92271B 3" AIR-CYL SPT BRK L-SIDE RT	
DC, DH, DJ-DL	20	03 01625D	92271# RIGHT=3"AIR CYL SUPT BRKT	
all	21	15K190S	HXCAPSCR 1/2-13UNC2AX2.5 FLTHRD SS	
all	22	27B24S0K1P	SPACER ROLL.5ID1.75L.062T 304 SS	
all	23	15U318S	FLATWASH 1.12ODX.656IDX.09T 304 SS	
AB, DA-DL	24	15G234NS	HXLOCKNUT NYL 1/2-13UNC2 SS18-8	
all	25	15K180S	HXCAPSCR 1/2-13UNCAX2 18-8SS	
all	26	27B24SSK1F	SPACER ROLL.5ID1.25L.062T S/S	
all	27	15U310	LOKWASHER REGULAR 1/2 SS18-8	
all	28	15G231S	HXFINJAMNUT 1/2-13UNC2B SS18-8	
AA-AF	29	03 01633	92651C ACTUATOR SUPPORT BRKT 1.0"	
BA-BJ	29	07 20771	88407C ACTUATOR SUPPORT BRKT 1.25"	
CA-CF	29	07 20770	88243B ACTUATOR SUPPORT BKT 1+1/2"	
DA-DL	29	03 01626	89473B ACTUATOR SUPPORT BRKT 2"VAL	

Watts Ball Valves and Repair Kits




Pellerin Milnor Corporation
P. O. Box 400, Kenner, LA 70063-0400

BMP920007/96067V (1 of 2)


Litho in U.S.A.

BMP920007/96067V
(Sheet 1 of 2)


BALL VALVES WITHOUT ACTUATOR PADS FOR MANUAL OPERATION



1/2" BRONZE OR 1/2", 3/4" STAINLESS
NO REPAIR KITS




3/4", 1"
BRONZE
NO REPAIR KITS



DETAIL
OLD STYLE STEM

AIR OPERATED BALL VALVES



1", 1-1/4", 1-1/2", 2"
BRONZE & STAINLESS

(For Bracketry and Mounting Hardware, See BMP920005. For Air Cylinders that Operate Watts Ball Valves, See BMP920006.)

HOW TO USE THIS DRAWING:

The ball valves are separated by size, material, and type of operation. Find the cross section which shows your ball valve (example 1-1/2" bronze air operated). See the parts list for the item number which represents your ball valve (1-1/2" bronze air operated would be item 10 on the parts list). For valves that offer repair kits the internal parts are labeled and marked as to which kit they are found in:

- (BK) part of Ball Kit
- (SK) part of Stem Kit
- (SSK) part of Seat/Seal Kit

For the part number of the Seat/Seal Kit for item 10 (1-1/2" bronze air operated valve) see the parts list and look for item 10SSK, likewise the Stem Kit will be 10SK.
NOTE:

AIR OPERATED VALVES: (SSK) kits for air operated ball valves include all parts required to repair either our old style or new style stems. A packing nut seal is provided to repair our old style stems which had a seal in the packing nut (see Detail). Our new style stem uses a double o-ring design.



Pellerin Milnor Corporation
P. O. Box 400, Kenner, LA 70063-0400

BMP920007/96067V (2 of 2)

Litho in U.S.A.

Parts List—Watts Ball Valves and Repair Kits
Find the correct assembly first, then find the needed components. The item letters (A, B, C, etc.) assigned to assemblies are referred to in the "Used In" column to identify which components belong to an assembly. The item numbers (1, 2, 3, etc.) assigned to components relate the parts list to the illustration.

Used In	Item	Part Number	Description	Comments
			ASSEMBLIES	
			none	
			COMPONENTS	
all	1	96D034	04Z BALLVALVE 1/2" WATTS #6400-SS	1/2"BRONZE-MANUAL, NO KITS
all	2	96D040WSS	01Z 1/2" BALLVALVE S/S WATTS#S-8000	1/2"STAINLESS-MANUAL
all	002BK	96V040BK	BALL KIT WATTS #BV4SSA6	
all	002SSK	96V040SSK	01Z REPKIT 1/2"VAL WATTS#3SSK-02-RK	
all	3	96D050A	01Z 3/4"BALLVALVE BRZ WATTS#B6100	3/4"BRONZE-MANUAL, NO KITS
all	4	96D055WSS	01Z 3/4"BALLVALVE S/S WATTS#S-8000	3/4"STAINLESS-MANUAL
all	004BK	96V055BK	BALL & STEM KIT WATTS #4BSK-SSRK	
all	004SSK	96V055SSK	01Z REPKIT 3/4"VAL WATTS#4SSK-02-RK	
all	5	96D084	01Z BALL VALVE 1" WATTS#B6100 BRZ	1" BRONZE-MANUAL , NO KITS
all	6	96D085WEXS	07Z BALVAL 1" BRZ WATTS#B6400SSZ107	1" BRONZE-AIR OPERATED
all	006BK	96V085BK	BALL KIT WATTS #1-BALL-RK-Z107	
all	006SK	96V085SK	02Z STEM KIT 1" WATTS#1-ST-RK-Z107	
all	006SSK	96V085SSK	02Z REPKIT 1"BALVAL#1SSK-02-KK-Z107	
all	7	96D085WSS	07Z BALVAL 1" SS WATTS S8000-Z107	1" STAINLESS-AIR OPERATED
all	007BK	96V085BK	BALL KIT WATTS #1-BALL-RK-Z107	
all	007SK	96V085SK	02Z STEM KIT 1" WATTS#1-ST-RK-Z107	
all	007SSK	96V085SSK	02Z REPKIT 1"BALVAL#1SSK-02-KK-Z107	
all	8	96D086WEXS	08Z BAVAL 1+1/4BRZ WATTS#B6400SSZ107	1-1/4"BRONZE-AIR OPERATED
all	008BK	96V086BK	BALL KIT WATTS #1.25-BALL-RK-Z107	
all	008SK	96V086A7SK	02Z STEMKIT 1.25-1.5-ST-RK-Z107	



Parts List, cont.—Watts Ball Valves and Repair Kits				
Used In	Item	Part Number	Description	Comments
all	008SSK	96V086SSK	02Z REPKIT 1.25BALVALSSK-02-RK-Z107	
all	9	96D086WSS	08Z BAVAL 1+1/4"SS WATTS S8000-Z107	1-1/4"STAINLESS-AIR OPER.
all	009BK	96V086BK	BALL KIT WATTS #1.25-BALL-RK-Z107	
all	009SK	96V086A7SK	02Z STEMKIT 1.25-1.5-ST-RK-Z107	
all	009SSK	96V086SSK	02Z REPKIT 1.25BALVALSSK-02-RK-Z107	
all	10	96D087WEXS	09Z BAVAL 1+1/2BRZ WATTS#B6400SSZ107	1-1/2"BRONZE-AIR OPERATED
all	010BK	96V087BK	BALL KIT WATTS #1.5-BALL-RK-Z107	
all	010SK	96V086A7SK	02Z STEMKIT 1.25-1.5-ST-RK-Z107	
all	010SSK	96V087SSK	02Z REPAIR KIT 1.5" BALL VALVE	
all	11	96D087WSS	08Z BAVAL 1+1/2"SS WATTS S8000-Z107	1-1/2"STAINLESS-AIR OPER.
all	011BK	96V087BK	BALL KIT WATTS #1.5-BALL-RK-Z107	
all	011SK	96V086A7SK	02Z STEMKIT 1.25-1.5-ST-RK-Z107	
all	011SSK	96V087SSK	02Z REPAIR KIT 1.5" BALL VALVE	
all	12	96D088WEXS	09Z BALVAL 2" BRZ WATTS#B6400SSZ107	2"BRONZE-AIR OPERATED
all	012BK	96V088BK	BALL KIT WATTS #2-BALL-RK-Z28	
all	012SK	96V088SK	03Z STEM KIT 2" WATTS#2-ST-RK-Z107	
all	012SSK	96V088SSK	02Z REPKIT 2"VAL WATZSSK-02-RK-Z107	
all	13	96D088WSS	09Z BALVAL 2" SS WATTS S8000-Z107	2"STAINLESS-AIR OPERATED
all	013BK	96V088BK	BALL KIT WATTS #2-BALL-RK-Z28	
all	013SK	96V088SK	03Z STEM KIT 2" WATTS#2-ST-RK-Z107	
all	013SSK	96V088SSK	02Z REPKIT 2"VAL WATZSSK-02-RK-Z107	

Air Cylinders for 1", 1.25", 1.5" & 2" Watts Ball Valves

BMP920006/2017465B
(Sheet 1 of 2)

MILNOR
Pellerin Milnor Corporation
P. O. Box 400, Kenner, LA 70063-0400

Litho in U.S.A.



NOTES:

1. LUBRICATE SPRINGS WITH A LAYER OF GREASE BUT NOT SO MUCH AS TO CAUSE EXCESS TO LEAK OUT.
2. DO NOT GREASE THE CUP, ITEM 17! DOING SO WOULD BLOCK THE AIR LINES.



Pellerin Milnor Corporation
P. O. Box 400, Kenner, LA 70063-0400

Litho in U.S.A.

Parts List—Air Cylinders for 2" Watts Ball Valves
Find the correct assembly first, then find the needed components. The item letters (A, B, C, etc.) assigned to assemblies are referred to in the "Used In" column to identify which components belong to an assembly. The item numbers (1, 2, 3, etc.) assigned to components relate the parts list to the illustration.

Used In	Item	Part Number	Description	Comments
			-----ASSEMBLIES-----	
A		SA 10 057C	95222D AIRCYL=3.00DX3.89ST171/176CD	FOR 2" BALLVALVES
B		SA 10 057D	95222# AIRCYL=3.00DX3.89ST171/176SS	FOR 2" STAINLESS BALLVALVES
C		SA 10 056F	BRAKEAIRCYL=2.38ODX2.70STX20.5#CD	FOR 1,1.25,1.5 BALLVALVES
D		SA 10 056G	*AIRCYL=2.38ODX2.70STX20.5#SS	FOR 1,1.25,1.5 STAINLESS BALLVALVES
			-----COMPONENTS-----	
A,B	1	03 01615	94191B PISTON STEM 3"AIRCYL	
C,D	1	02 18650	96461B STEM=2 WAY AIRCYLINDER	
all	2	15G234NS	HXLOCKNUT NYL 1/2-13UNC2 SS18-8	
all	3	15U243S	FLAWASHER 7/8ODX33/64IDX16GA 18-8SS	
all	4	03 01209A	92536B STEMCLIP H=1.313 BALVAL S/S	
all	5	54E220	NYLINER 8L2FF BUSHING 1/2X9/16X.140	
A	6	15G191	HXFINJAMNUT 5/16-24UNC2 ZINC GR2	
B,C,D	6	15G190	HEXFINJAMNUT 5/16-18NC2 SS18-8	
A	7	15U210	LOKWASHER MEDIUM 5/16 ZINCPL	
B,C	7	15U205	LOCKWASHER MEDIUM 5/16" 18-8SS	
D	7	15U200S	FLATWASHER US STD 5/16 SS18-8	
A	8	02 10585H	91142# TIE BOLT=5/16-18X10LNG PLTD	
B	8	02 10585G	91142# TIE BOLT=5/16-18X10LG (SS)	
C	8	02 10585E	91142# TIE BOLT=5/16-18X8.25LG PLTD	
D	8	02 10585A	91142# TIE ROD=5/16-18X8+1/4 (SS)	
A	9	03 01623	90351C CYLINDER HEAD 3"AIRCYLINDER	
Bl	9	03 01623A	90351# CYLHEAD 3"AIRCYLINDER-S/S	
C	9	02 02546	87341C CYLHEAD=SLIDESTEM	
D	9	02 02546S	87341# CYLINDER HEAD=SLIDE STEM SS	
all	10	27B32024SS	SPACER ROLL .51IDX.6250DX1.5L STN S	USES 2
A,B	11	03 01621	94266BTUBE 2+7/8 AIR CYLINDER 9"	
C,D	11	02 02068	94266A AIRCYL-STAINLESS=DUMPVALVE	
A,B	12	03 01617C	92133B SPRING=FL11.5SR23.5#MD2.368	
C	12	02 15881	96471# SPRING=BRAKE2.10D11FL15.5#"	
D	12	02 15881A	85504Z SPRING,02 -15881+HEAVY PAINT	
A,B	13	03 01616C	92133B SPRING=FL11.355SR20.5MD1.811	
C	13	02 15880	96471B SPRING=BRAKE1.50D10.3FL17#"	
D	13	02 15880A	85504Z SPRING,02-15880 +HEAVY PAINT	
all	14	60C106	ORING 5/16ID 1/16CS BN 70 DURO #011	
A,B	15	03 01620A	92133B 3"AIR CYL=SPRING RETAINER	

Parts List, cont.—Air Cylinders for 2" Watts Ball Valves				
Used In	Item	Part Number	Description	Comments
C,D	15	02 18651	73171A WASHER=2 WAY BRAKE CYL	
A,B	16	X3 01619A	92066# MACH=3"ACYL BRASS PISCUP WSH	
C,D	16	02 02105B	92253B 2.38"ACYL BRASS PISCUP WASHR	
A,B	17	02 19302	93356B PISTON CUP 2+7/8ID CYLINDER	
C,D	17	02 02194	93217B PISTONCUP=DUMPVALVE 2+3/8"	
A,B	18	03 01618	91522B PISTON CUP WASHER 3"AIRCYL	
C,D	18	02 02085	94092B UP WASHER=2"OD=PISTON CUP	
all	19	15G220	02Z LTHX THIN LOKNUT 3/8-24 SSNITE	
A,B,D	20	03 01313S	85506B+STOP=AIRCYL W/2+11/16STR.SS	
C	20	03 01313	70219A STOP=AIR CYL W/2+11/16STROKE	
A,B	21	03 01630	87506B 3"AIRCYL PSTN CUP COMPLMTWSH	
C,D	21	02 02185	79237A WASHER=PISTON CUP COMP LIMIT	
A	22	03 01622	88531# CYL HEAD TAPHOLE 3"AIRCYL SS	
B	22	03 01622A	88531# CYLHEAD TAPHOLE-3"ARCYL S/S	
C	22	02 02101	71334A CYLHEAD W/TAPPED HOLE	
D	22	02 02101S	88531B CYLINDER HEAD TAP HOLE (SS)	
A,Bl	23	60C134	ORING 2.5 ID 3/16CS BN 70 DURO #333	
C,D	23	60C132	ORING 2"IDX3/16CS BUNA70 #32	
all	24	5N0ECLSBE2	NPT NIPPLE 1/4XCLS TBE BRASS 125#	
all	25	5SCCOEBE	NPT COUP 1/4 BRASS 125# #103	
all	26	5SB0E0CBEO	HEXPIPBUSH 1/4 X 1/8 BRASS 125#	
all	27	96H018	NEEDLE VALVE	
A,B	28	03 01627B	92023# LEFT=3"AIR CYL MNTG BRKT	
C	28	03 01660C93231B	BRKT=AIR CYL MONUT LEFT	
D	28	03 01660A	92271B BRKT=AIR CYL MNT LFT-S/S	
A,B	29	03 01627A	92023B RIGHT=3"AIR CYL MNTG BRKT	
C	29	03 01660D	BRKT=AIR CYL MOUNT RIGHT	
D	29	03 01660B	92271# BRKT=AIR CYL MNT RHT-S/S	
all	30	15U200	FLATWASHER(USS STD) 5/16"ZNC PLT	
all	31	15G231S	HXFINJAMNUT 1/2-13UNC2B SS18-8	USES 2
A	32	20L601K	ID TAG NATL#1614 ALUM EMB "K"	USES 2
B	32	20L601E	ID TAG NATL#1614 ALUM EMB "E"	USES 2
CD	32	20L601G	ID TAG NATL#1614 ALUM EMB "G"	USES 2
C	33	20L601F	ID TAG NATL#1614 ALUM EMB "F"	USES 1
D	33	20L601V	ID TAG NATL#1614 ALUM EMB "V"	USES 1
all	34	03 01620E	92136B.WASHER=2.86ODX2.06IDX.105THK	
A,B	35	27B2400K0N	SPCROLL.5ID.687L.062T SS	USES 1


Pressure Regulators

BMP900031/2011276B
(1 / 2)




Pellerin Milnor Corporation
P. O. Box 400, Kenner, LA 70063-0400

Litho in U.S.A.



To clean:

1. Remove spring cage and all parts above diaphragm.
2. Loosen and remove diaphragm lock nut, lock washer, pressure plate, and diaphragm from valve stem.
3. Unscrew seat cylinder from body and remove entire assembly.
4. Open gate valve to flush out collected sediment.



To clean :

1. Remove bottom plug and gasket.
2. Loosen disc holder with screwdriver or socket wrench.
3. Inspect disc and clean.
4. Seat can be removed, if necessary, with an allen wrench or socket wrench.
5. Unscrew and remove adjusting screw, check nut, and spring cage screws. Lift off spring cage, spring washer and adjusting spring.
6. Loosen and remove lock nut, lock washer, plate, and diaphragm.
7. Lift stem assembly upwards to remove from body.
8. To reassemble valve follow above instructions in reverse. Tighten or loosen adjusting screw for the required pressure of 28 P.S.I.



Pellerin Milnor Corporation
P. O. Box 400, Kenner, LA 70063-0400

Litho in U.S.A.

Parts List—Pressure Regulators

Find the correct assembly first, then find the needed components. The item letters (A, B, C, etc.) assigned to assemblies are referred to in the "Used In" column to identify which components belong to an assembly. The item numbers (1, 2, 3, etc.) assigned to components relate the parts list to the illustration.

Used In	Item	Part Number	Description	Comments
-----COMPONENTS-----				
	1	96J030FF	01Z 1/2"PRESS REG SET 28# FEM X FEM	1/2" REGULATOR 3621V ONLY
	2	96J030D	01Z 1/2" PRESREGULTR SET 28# FEM-UN	1/2" REGULATORS ALL OTHER MODELS
	3	96J031D	01Z 3/4" PRESREGULTR SET 28# FEM-UN	3/4" REGULATORS


8" & 10" Stainless Dump Valve
42044WP2/CP2/SP2/SP3/NP2 52038WP1 60044WP2/WP3/SP2/SP3
72044WP1/D5N 72058SP2

BMP780095/2006363B
 (Sheet 1 of 1)



Pellerin Milnor Corporation
 P. O. Box 400, Kenner, LA 70063-0400

Litho in U.S.A.



Parts List—8" & 10" Stainless Dump Valve

Find the correct assembly first, then find the needed components. The item letters (A, B, C, etc.) assigned to assemblies are referred to in the "Used In" column to identify which components belong to an assembly. The item numbers (1, 2, 3, etc.) assigned to components relate the parts list to the illustration.

Used In	Item	Part Number	Description	Comments
A		SA 28 124	*8" SGL DUMPVALVE 4244+52+60	42044WP2/CP2/SP2/SP3/NP2 52038WP1
B		SA 36 015	10" SGL DUMP VALVE 72WE+SG+WT	60044WP2/WP3/SP2/SP3
C		SA 28 158	* BONNET+AIRCYL=8"SS DUMPVALV	72044WP1/SP2, 72058D5N
D		SA 36 044	* BONNET+AIRCYL=10"SS DUMPVAL	8" DUMP VALVE 10" DUMP VALVE
-----COMPONENTS-----				
CD	1	02 02101	CYLHEAD W/TAPPED HOLE	
CD	2	15U210	LOKWASHER MEDIUM 5/16 ZINCPL	
CD	3	60C132	ORING 2"IDX3/16CS BUNA70 #329	
CD	4	02 02068	AIRCYL-STAINLESS=DUMPVALVE	
CD	5	02 10585D	TIE BOLT=5/16-18X7.875 PLTD	
CD	6	03 01313	STOP=AIR CYL W/2+11/16STROKE	
CD	7	15G220	LTHX THIN LOKNUT 3/8-24 SSNTE	
CD	8	02 02194	PISTONCUP=DUMPVALVE 2+3/8"	
CD	9	02 02085	UP WASHER=2"OD=PISTON CUP	
CD	10	60C106	ORING 5/16ID 1/16CS BUNA70#011	
CD	11	02 02185	WASHER=PISTON CUP COMP LIMIT	
all	12	02 02105B	XXXXX	
CD	13	03 06429	SPRING=2.11ODX6.5FL 64#"	
CD	14	60C132	ORING 2"IDX3/16CS BUNA70 #329	
CD	15	24G020N	ROLLED WASH.252ID NYLTITE 25W	
CD	16	X2 02743	BONNET=2"DUMP VALVE	
CD	17	02 18931F	GASKET=DUMPVALVE-1/60+72WEHU	
CD	18	02 16021I	DUMPVALV STEM-4"+8"316SS	
CD	19	15G168	SQ Nut 1/4-20UNC2 SS18-8	
all	20	15K086	HXCAPSCR 3/8-16NCX3/4 SS18-8	
CD	21	15K041S	HEXCAPSCR 1/4-20UNC2AX1 SS18-8	
CD	23	02 16021E	WASHER 3/8IDX1.250D DUMPVAL	
A	24	02 18068	9 SEAT-RESILIENT=8"DUMPVALVE	
B	24	03 06084	SEAT-RESILIENT=10"DUMPVALVE	
A	25	5SP0KGFSS	NPT PLUG 1/2 SOSOLID GALSTL	
CD	26	60C106	ORING 5/16ID 1/16CS BUNA70#011	
AC	27	02 18796	DISC-8" DUMP VALVE S/S	
BD	27	03 06083	DISC-10"DUMP VALVE S/S	
all	28	15U245	FLTWASH 3/8 STD COMM 18-8 SS	
A	29	02 18104	GASKET=8"DUMP VALVE BONNET	
B	29	03 06086G	GASKET=10" DUMP VALVE BONNET	
A	30	02 18931E	BONNET=8"DUMP VALVE	8" DUMP VALVE
B	30	03 06086F	BONNET=10"DUMP VALVE	10" DUMP VALVE
CD	32	02 16021C	BUMPER=DUMP VALVE BONNET	
CD	33	02 16021D	DUMP VALVE BUMPER RETAINER	
A	34	W2 18931	*BODY=8"DUMPVALV=4244.60.52	
B	34	W3 06086	*BODY=10"DUMP VALVE 72WE,SG,T	
A	35	02-18107	GASKET=8"FLANGED DUMP VALVE	
B	35	03 06085D	GASKET=10"FLANGEDUMP72D 8050	

3 & 4 Inch Dump Valve Assembly

BMP800228/2002226V
(Sheet 1 of 2)




Pellerin Milnor Corporation
P. O. Box 400, Kenner, LA 70063-0400

Litho in U.S.A.

▲ WARNING ▲



EXPLOSION HAZARD--Air cylinder can burst apart with great force. Circled items are under high spring tension. Follow maintenance instructions MSSM0130AE carefully.



Parts List—3 & 4 Inch Dump Valve Assembly
Find the correct assembly first, then find the needed components. The item letters (A, B, C, etc.) assigned to assemblies are referred to in the "Used In" column to identify which components belong to an assembly. The item numbers (1, 2, 3, etc.) assigned to components relate the parts list to the illustration.

Used In	Item	Part Number	Description	Comments
	N	W2 15997	ASSEMBLIES--	
	P	AVD14003	BODY=4" DUMPVALVE=4231WE+SG	CBW REUSE TANK 3621/26Q4G/J/P,
	Q	AVD14001A	91000Z ASSY DMPVALVE 36QU	Q6G/J/P
	R	AVD14001	89000Z ASSY=DUMP VALVE 42S6P	4226Q4G/J/P,Q6G/J/P
	S	A14 06500B	89000Z ASSY=DUMP VALVE 3621F8P	3621F8P
	T	A15 15100	82341T*DUMP VALVE ASSY=4S/S 4226QHE	4840F7J,F7W,F7N,F7B 48/42QTL/NHP, 48BTL/NHP
	U	A14 06500	84242C 4"SGL.DUMPVALVE 4231WE+SG	4231WP2,WP3WW CBW@.4232F7J,P,W 3630F8J,W,P
	V	A14 06500A	84242@*DUMP VALVE ASSY=4"NPT SS	3621NSP
	W	A14 06500F	84242J* 4"SS DUMPVALVE=3621+4226DYA	4226DA1
	X	SA 09 013A	84266@ DUMPVALVE=10GA 4" S/S	4226DP1,DYP
	Y	A14 06400	84242C*DUMP VALVE ASSY-3"NPT SS	3016NSE
	Z	A14 06400A	89457U* BONNET+CYL=4"SS DIVCYL DUMP	00N-00T(CONTAINS 1-23)
			89457%* BONNET+AIRCYL=4"DYA DUMPVAL	00U-00X(CONTAINS 1-23)
			COMPONENTS	
all	1	02 02101	71334A CYLHEAD W/TAPPED HOLE	
Y	2	15U210	LOKWASHER MEDIUM 5/16 ZINCP	
Z	2	15U205	LOCKWASHER MEDIUM 5/16" 18-8SS	
Y	3	60C132	ORING 2"ID 3/16CS BUNA 70 DURO #329	
Z	3	60C132V	ORING 2 ID 3/16CS VITON 75 # 329	
all	4	02 02068	94266A AIRCYL-STAINLESS=DUMPVALVE	
Y	5	02 10585D	91142# TIE BOLT=5/16-18X7.875 PLTD	
Z	5	02 10585	91142B TIE BOLT=5/16-18X7.875LG SS	
all	6	03 01313	70219A STOP=AIR CYL W/2+11/16STROKE	
all	7	15G220	02Z LTHX THIN LOKNUT 3/8-24 SSNTE	
all	8	02 02085	75161A UP WASHER=2"OD=PISTONCUP	
all	9	02 02194	93217B PISTONCUP=DUMPVALVE 2+3/8"	
all	10	02 02105B	92253B 2.38"ACYL BRASS PISCUP WASHR	
Y	11	60C106	ORING 5/16ID 1/16CS BN 70 DURO #011	
Z	11	60C106V	O-RING 5/16"IDX1/16"CS VITON 11-011	
all	12	02 18651	73171A WASHER=2WAY BRAKECYL	
all	13	02 02185	79237A WASHER=PISTON CUP COMP LIMIT	
all	14	02 17023	83392B SPRING-SS=DUMP 1.50D8FL21#"	



Pellerin Milnor Corporation
P. O. Box 400, Kenner, LA 70063-0400

Litho in U.S.A.

Parts List, cont.—3 & 4 Inch Dump Valve Assembly

Used In	Item	Part Number	Description	Comments
All	15	02 16021I	94191# DUMPVAL STEM-4"+8" DYE 316L	
Y	16	X2 02743	87382B BONNET=2"DUMP VALVE	
Z	16	X2 02743S	73141B BONNET=2"DUMP VALVE-SS	
all	17A	15G168	SQNUT 1/4-20UNC2 SS18-8	
all	17B	24G020N	ROLLED WASHER .252"ID NYLTITE #25W	
all	17C	15K041S	HEXCAPSCR 1/4-20UNC2AX1 SS18-8	
all	17D	15U181	LOCKWASHER MEDIUM 1/4 SS18-8	
all	18	02 14447	92037B BONNET=4"S/S DUMP VALVE	
Y	19	02 18931F	93362B GASKET=DUMPVALVE-1/60+72WEHU	
Z	19	02 18932B	93362# GASKET=DUMPVAL 1/8"RED SILIC	
Y	20	02 16021E	94323B WASHER 3/8IDX1.250D DUMPVAL	
Z	20	02 18651A	83526B WASHER=DUMP VALVE DISC	
Y	21	02 16021C	92051B BUMPER=DUMP VALVE BONNET	
Y	21	02 16021D	92632B DUMP VALVE BUMPER RETAINER	
Z	21	02 16021S	84206B BUMPER=DUMP VAL BONT S/S	
all	22	02 14446	87503B DISC-4"S/S DUMP VALVE	
all	23	15U245	01Z FLTWASH 3/8 STD COMM 18-8 SS	
(P-V,X)	24	02 14443	93362B GASKET-4"S/S DUMP VAL BONNET	
W	24	02 14443E	91067B GASKET=DUMP/VENT VAL N-8090	
all	25A	15K086	HXCAPSCR 3/8-16NCX3/4 SS18-8	
all	25B	24G030N	ROLLED WASHER .379"ID NYLTITE #37W	
P-T	25C	15U200	FLATWASHER(USS STD) 5/16"ZNC PLT	
R	26	W2 14740	94261D*WLMT=DUMP VALVE 3621F8P	
S	26	W2 11304	89417T*DUMP VALVE BODY WELDMT 4226	
N,T	26	W2 15997	91383@* BODY=4"DUMPVALVE=4231WE+SG	
U	26	W2 14445S	80433@*DUMPVALVE WLMT=SCREWED 4"NPT	
V	26	W2 14445	91383Y* BODY=4"DUMPVALVE=36BWE+QTS	
W	26	W2 14445F	91383@*DUMP VALVE WLDMT 4226DYP	
X	26	W2 14445J	80433T*DUMPVALVE WLMT=SCREWED 3"NPT	
Q	26	W2 14740A	91446Y*WLDMT=DUMP VALVE 42S6P	
P	26	W2 11943	93071D*WLMT=DUMPVAL DRN TO REAR 36Q	
(Q-T)	27	5SP0KGFSS	NPT PLUG 1/2 SOSOLID GALSTL	
(U-X)	27	5SP0KSFHC	NPT PLUG 1/2 HEX 304SS 150#	
all	28	02 14166	77131A SEAT 4" DUMP VALVE BUNA-N	
all	29	96DB0PNA	01Z HOSE BIBB 3/4" MALE INLT CELCON	ONLY ON SOME MODELS

Pneumatic Piping and Assemblies


9



DRAWING
 (See other page for parts list,
 if applicable.)

PNEUMATIC SCHEMATICS 42044WP2/CP2/NP2

BMP940113/94497V (Page 1)





PARTS LIST

(See other page for drawing.)

PNEUMATIC SCHEMATICS 42044WP2/CP2/NP2

BMP940113/94497V (Page 2)

ITEM	PART NUMBER	DESCRIPTION	HOW PART IS USED IN ASSEMBLY (Only if pertinent)
001	96R301A37	04Z 1/8" PILOT 3W-NC 110/50 120/60	
002	96R302A37	05Z 1/8" AIR PILOT 3WANO 120V50/60C	
003	96M051	USE KZK5B00100	
004	09N082A	12Z PRESSW NASON CLOSE @ 62 LB.	
005	96D047AAK	05Z CHECK VALVE 1/4" DELT#CMMQ20B	
006	30N102	06Z PRESSGUAGE 1/4" BOTCONN 0-160PSI	
007	96H018	NEEDLE VALVE	
008	W3 25307D	88186C*TANK=AIR PRESSURE RESERVE	
009	96J019E	1/4" PRESREG2-50PSI NOR#R06-221-RNEA	
010	30N101	08Z PRESSGAUGE 1/8" BACKCONN 0-60PSI	
011	60B100	67314A ARMT S116B 1CONV F3582017564	
012	69C050A	POLYETHYLENE BAG 9X6X13X.005 ***** END OF PARTS LIST *****	CP2/NP2 ONLY CP2/NP2 ONLY CP2/NP2 ONLY CP2/NP2 ONLY

How to Read Parts List

Reference Item Numbers—Items 00A, 00B, 00C, etc., or 00X, 00Y, 00Z, etc., appearing at the top of some parts lists, are for reference and provide:

1. The part number for the entire assembly depicted in the drawing or a major sub-assembly thereof, and/or
 2. The range of machine models this drawing applies to.
- If more than one reference item appears, this usually means this drawing applies to more than one assembly (and thus to more than one range of machines).

Component Item Numbers—For any item on the drawing (e.g., item ①), there may be several corresponding items on the parts list (e.g., 001A, 001B, 001C, etc.) which are similar components on different assemblies. "How Part Is Used In Assembly" identifies which components apply to your machine, by listing either the machine model, or the reference item number from the top of the parts list (e.g., 00A, 00B, 00C, etc.), or a particular characteristic (e.g., bronze or stainless steel), or special ordering information, such as a repair kit number.

3-Way Pilot Valves

BMP900032/91182V
(Sheet 1 of 1)



Pellerin Milnor Corporation
P. O. Box 400, Kenner, LA 70063-0400

BMP900032/91182V (1 of 1)


Litho in U.S.A.

(VALVES SHOWN DE-ENERGIZED)

Parts List—3-Way Pilot Valves

Find the correct assembly first, then find the needed components. The item letters (A, B, C, etc.) assigned to assemblies are referred to in the "Used In" column to identify which components belong to an assembly. The item numbers (1, 2, 3, etc.) assigned to components relate the parts list to the illustration.

Used In	Item	Part Number	Description	Comments
			ASSEMBLIES	
			none	
			COMPONENTS	
all	1	96R301A37	05Z 1/8" AIRPILOT 3W NC 120V50/60	
all	1	96R301A24	06Z 1/8" AIRPILOT 3W NC 24V50/60	
all	3	96R302A37	06Z 1/8" AIRPILOT 3W NO 120V50/60	
all	3	96R302A24	07Z 1/8" AIRPILOT 3W NO 24V50/60	



NORMALLY
CLOSED

NORMALLY
OPEN

FOR REPAIR OR REPLACEMENT PARTS FOR PILOT VALVES
USED ON WASHER EXTRACTORS GENERALLY PRIOR TO
JUNE 1, 1985, SEE BMP701359.

Asco 3-way Solenoid Valves

Applicable Models




Pellerin Milnor Corporation
P. O. Box 400, Kenner, LA 70063-0400

BMP701359/97086V (1 of 2)

Litho in U.S.A.

BMP701359/97086V
(Sheet 1 of 2)



FLOW DIAGRAMS:

ENERGIZED	DE-ENERGIZED	VALVE
		NORMALLY CLOSED
		NORMALLY OPEN

OPERATION

NORMALLY CLOSED VALVE – OPEN WHEN ENERGIZED
CLOSED WHEN DE-ENERGIZED

NORMALLY OPEN VALVE – CLOSED WHEN ENERGIZED
OPEN WHEN DE-ENERGIZED

COMPONENTS LABELED (*) ARE CONTAINED IN KIT "00Q", SEE PARTS LIST FOR OTHER AVAILABLE KITS.

Identification and Description

Check nameplate for correct catalog number, pressure, voltage, and service.

Safety Instructions



⚠ DANGER ⚠

SHOCK HAZARD - will cause death or severe injury.

☞ Lock OFF - and tag out power at wall disconnect before servicing. Power switches on machine and control box disable only control circuit power in electrical boxes.



⚠ WARNING ⚠

EXPLOSION HAZARD- may cause serious injury.

☞ Release pressure to valve before disassembly.



⚠ CAUTION ⚠

BURN HAZARD - Solenoid enclosures become too hot to touch when energized for a long period. This will not damage the solenoid, but may cause a painful burn.

☞ Allow solenoids to cool before servicing the valves.

Cleaning - Clean all solenoid valves periodically. If the voltage to coil is correct, sluggish valve operation usually indicates that cleaning is required.

Maintenance

READ ALL SAFETY STATEMENTS ABOVE BEFORE PROCEEDING ANY FURTHER!

Coil Replacement

1. Remove retaining clip. NOTE: When metal retaining clip disengages, it springs upward.
2. Slip yoke containing coil and sleeves off solenoid base sub-assembly.
3. Replace coil.
4. Reassemble in reverse order.

Valve Disassembly and Reassembly

1. Remove retaining clip.
2. Slip entire solenoid enclosure off the solenoid base sub-assembly.
3. Remove solenoid base sub-assembly, core assembly and core spring.
4. Remove diaphragm spring, diaphragm assembly and gasket.
5. Replace all worn or damaged parts
- 6.

Troubleshooting

Control Circuit: Listen for a metallic click when energizing the solenoid. Absence of the click indicates loss of power to the solenoid. Check for loose connections, blown fuses, open or grounded coil circuit, and broken lead wires.

Faulty Coil: Check for open circuit in coil. Replace coil if necessary.

Low Voltage: Voltage across coil leads must be at least 85% of nameplate rating for proper operation.


Incorrect pressure: Pressure to valve must be within range specified on nameplate.

Excessive leakage: Disassemble valve and clean all parts. Replace all worn parts for best results.



Pellerin Milnor Corporation
P. O. Box 400, Kenner, LA 70063-0400

Litho in U.S.A.



Identification and Description

Check nameplate for correct catalog number, pressure, voltage, and service.

Safety Instructions



⚠ DANGER ⚠

SHOCK HAZARD will cause death or severe injury.
Lock OFF and tag out power at wall disconnect before servicing. Power switches on machine and control box disable only control circuit power in electrical boxes.



⚠ WARNING ⚠

EXPLOSION HAZARD may cause serious injury.
Release pressure to valve before disassembly.



⚠ CAUTION ⚠

BURN HAZARD Solenoid enclosures become too hot to touch when energized for a long period. This will not damage the solenoid, but may cause a painful burn.
Allow solenoids to cool before servicing the valves.

Maintenance

READ ALL SAFETY STATEMENTS ABOVE BEFORE PROCEEDING ANY FURTHER!

Coil Replacement

1. Remove retaining clip. NOTE: When metal retaining clip disengages, it springs upwards.
2. Slip yoke containing coil and sleeves off solenoid base sub-assembly.
3. Replace coil.
4. Reassemble in reverse order.

Valve Disassembly and Reassembly

1. Remove retaining clip.
2. Slip entire solenoid enclosure off the solenoid base sub-assembly.
3. Remove solenoid base sub-assembly, core assembly and core spring.
4. Remove diaphragm spring, diaphragm assembly and gasket.
5. Replace all worn or damaged parts.
6. Reassemble in reverse order.

Troubleshooting

Control Circuit: Listen for a metallic click when energizing the solenoid. Absence of the click indicates loss of power to the solenoid. Check for loose connections, blown fuses, open or grounded coil circuit, and broken lead wires.

Faulty coil: Check for open circuit in coil. Replace coil if necessary.
Low voltage: Voltage across coil leads must be at least 85% of nameplate rating for proper operation.

Incorrect pressure: Pressure to valve must be within range specified on nameplate.
Excess leakage: Disassemble valve and clean all parts. Replace all worn parts for best results.



Pellerin Milnor Corporation
P. O. Box 400, Kenner, LA 70063-0400

Litho in U.S.A.

Parts List—2-Way Electric Water Valve

Used In	Item	Part Number	Description	Comments
	00A	96TDC2AA24	03Z 1/2" N/C 2WAY 24V50/60C VALVE	VALVE ASSEMBLY
	00B	96TDC2AA37	03Z 1/2" N/C 2WAY 120V50/60C VALVE	VALVE ASSEMBLY
	00C	96TDC2AA71	03Z 1/2" N/C 2WAY 240V50/60C VALVE	VALVE ASSEMBLY
	001A	96T1001A24	SOLENOID 24V50/60C ASCO#260283-001	USED WITH 00A
	001B	96T1001A37	SOLENOID 120V50/60C ASCO#260283-002	USED WITH 00B
	001C	96T1001A71	SOLENOID 240V50/60C ASCO#260283-003	USED WITH 00C
	002	96V1001CLP	METAL CLIP M6	USED IN 00A, 00B, 00C
	003	96V1001PLT	NAMPLATE, BLANK REDHAT II COIL M6	USED IN 00A, 00B, 00C
	004	96V1001WSH	STAR WASHER REDHAT II COIL M6	USED IN 00A, 00B, 00C
	005	96V235B	PARTKIT ASCO #K258-120 FOR 8210D2	REPAIRS 00A, 00B, 00C




AIR VALVES & MOUNTING HARDWARE

BMP780087
83457B


DETAIL A

00AA
00AB




DETAIL B

00BA
00BB
00BC




DETAIL C

00CA
00CB
00CC




DETAIL D

00DA



DETAIL E

00EA
00EB
00EC
00ED
00EE
00EF



Air Valves & Mounting Hardware

BMP780087R/18462A
(Sheet 1 of 2)



Pellerin Milnor Corporation
P. O. Box 400, Kenner, LA 70063-0400

Litho in U.S.A.

Parts List—Air Valves & Mounting Hardware

Find the correct assembly first, then find the needed components. The item letters (A, B, C, etc.) assigned to assemblies are referred to in the "Used In" column to identify which components belong to an assembly. The item numbers (1, 2, 3, etc.) assigned to components relate the parts list to the illustration.

Used In	Item	Part Number	Description	Comments
-----ASSEMBLIES-----				
	AA	AVA030537	78173S ONE 1/8 AIRVALVE REG.AIR120V	
	AB	AVA030571	84386S ONE 1/8 AIRVALVE REG.AIR240V	
	BA	AVA030324	79066S1/4"NC24V ASCO AIRVAL+MTG HWD	
	BB	AVA030337	79066S1/4"NC120VASCO AIRVAL+MTG HWD	
	BC	AVA030371	79066S1/4"NC240VASCO AIRVAL+MTG HWD	
	CA	AVA030224	78173S1/8"NC24V ASCO AIRVAL+MTG HWD	
	CB	AVA030237	84386S1/8"NC120VASCO AIRVAL+MTG HWD	
	CC	AVA030271	84386S1/8"NC240VASCO AIRVAL+MTG HWD	
	DA	AVA0304	78136# TWO PLUGS+MTG HWD	
	EA	AVA030124	78173S TWO 1/8"AIRVALVE+MTG HWD 24V	
	EB	AVA030124A	78182S TWO 1/8AIRVAL+MTG HWD 1-NO	
	EC	AVA030137	82183S TWO 1/8 AIRVALVE+MTG HWD120V	
	ED	AVA030137A	78182S TWO 1/8AIRVAL+MTG HWD 1-NO	
	EE	AVA030171	78173S TWO 1/8"AIRVALVE+MTG HWD240V	
	EF	AVA030171A	78182S TWO 1/8AIRVAL+MTG HWD 1-NO	
-----COMPONENTS-----				
all	1	03 01524	79177B CHANNEL=PLUG HOLDER	
all	2	03 01509	77362A PLUG=MANIFOLD PORTS	
all	3	60C105	ORING 1/4 ID 1/16CS BN 70 DURO #010 05Z	
all	4	15P105	TRDCUT-F PANHD 8-32X5/8 NIKSTL	
AA,CB,EC, ED	5	96T1001A37	SOLENOID 120V50/60C ASCO#260283-002	
AB,CC,EE, EF	5	96R300B02	COIL 220/50SFT-240/60SFT#162-919-26	
EA,EB,CA	5	96T1001A24	SOLENOID 24V50/60C ASCO#260283-001	
all	6	03 01182B	78036B ANGLE=SUPPORT AIR VALVE	
all	7	03 01538	86053B CHANNEL=OIL SHIELD-1/8AIRVAL	
all	8	15P101B	TRDCUT-F PANHD 8-32X3/8	
all	9	15U120	LOCKWASHER MEDIUM #8 ZINCPL	
all	10	53A031B	BODY-MAL90ELL1/4X1/8COMPPH#269C-42B	
AB only	11	53A032	MAL90ELL 5/16X1/8POLYFLO #169P-5-2	
all	12	96R300AAM	78183L*NC VALVEBODY+HARDWARE	
BA only	13	96T1002A24	SOLENOID 24V50/60C ASCO#260283-005	
BB only	13	96T1002A37	SOLENOID 120V50/60C ASCO#260283-006	
BC only	13	96T1002A71	SOLENOID 240V50/60C ASCO#260283-007	
all	14	53A031XB	BODY=MAL90EL 1/4X1/4COMP #269C-4-4B	



Pellerin Milnor Corporation
P. O. Box 400, Kenner, LA 70063-0400

Litho in U.S.A.

Parts List, cont.—Air Valves & Mounting Hardware

Used In	Item	Part Number	Description	Comments
all	15	96V350	1/4" VALVEBODY ASCO #UFTX8320A89	
all	16	03 01523	85096C BRKT=LOCK AIR VALVE	
all	17	53A005B	BODY=MALECONN 1/4X1/8COMP #B68A-4A	
all	18	53A059	SLEEVE 1/4" COMP IMP #60F BRASS	
all	19	53A059A	NUT 1/4"COMP.HOLYOKE ANDERSON#61A-4	
EB,EC,EF	20	96R300ABM	78183@*NO VALVEBODY+HARDWARE	
all	21	03 01508	77362A FITTING-SCREW 7/16 HEX	






Quick Exhaust Valves

BMP701406/2002382V
(Sheet 1 of 2)



Pellerin Milnor Corporation
P. O. Box 400, Kenner, LA 70063-0400

Litho in U.S.A.





Pellerin Milnor Corporation
P. O. Box 400, Kenner, LA 70063-0400

Litho in U.S.A.

Parts List—Quick Exhaust Valves

Find the correct assembly first, then find the needed components. The item letters (A, B, C, etc.) assigned to assemblies are referred to in the "Used In" column to identify which components belong to an assembly. The item numbers (1, 2, 3, etc.) assigned to components relate the parts list to the illustration.


Used In	Item	Part Number	Description	Comments
-----ASSEMBLIES-----				
	A	MESSAGE B2	REPAIR KITS ONLY <>	DELTROL
	B	96M051	USE KZK5B00100	WABCO
	C	96M054	QWIKEXHAUSTVLV 3/4"URETHANE	PARKER
	D	MESSAGE B1	PARTS NO LONGER SOLD	ASCO
	E	MESSAGE B2	REPAIR KITS ONLY <>	GOYEN
	F	96M055	QUICK EXHAUST VALVE 1/4"	DELTROL
-----COMPONENTS-----				
all	1	96M053A	KIT,QWIKRELVLV EV20A#10091-18	DELTROL VALVE ONLY
all	3	96M051B	DIAPHRAM,QWIKREL WAB#PS112-12	WABCO VALVE ONLY
all	4	96M051A	GASKET,WABCO QUICK EXHAUST VLV	WABCO VALVE ONLY
all	5A	96M052A	REPKIT,QES#M1319 (FOR 96M052)	GOYEN VALVE ONLY
all	5B	96M055A	REPAIR KIT FOR 96M055# 10128-99	DELTROL VALVE ONLY
all	6	96M054K	REPKIT 3/4"QWIKEXHAUSTVLV	PARKER VALVE ONLY

Brake Air Cylinder

⚠ WARNING ⚠



EXPLOSION HAZARD - Air cylinder can burst apart with great force. Circled items are under high spring tension. Follow maintenance instructions MSSM0130AE carefully.



Brake Air Cylinder

Parts List—Brake Air Cylinder				
Find the correct assembly first, then find the needed components. The item letters (A, B, C, etc.) assigned to assemblies are referred to in the "Used In" column to identify which components belong to an assembly. The item numbers (1, 2, 3, etc.) assigned to components relate the parts list to the illustration.				
Used In	Item	Part Number	Description	Comments
-----ASSEMBLIES-----				
	A	AAC65002	AIRCYL BRAKE SINGLE MOTOR	
-----COMPONENTS-----				
all	1	02 18650B	STEM=2WAY AIRCYL BRAKE 7.88L	
all	2	W2 18646	*CYLINDER-AIR=DOUBLEACT BRAKE	
all	3	53A031XB	BODY-EL90MALE.25X25 #269C-4-4B	
all	4	60C132	ORING 2"IDX3/16CS BUNA70 #329	
all	5	27B250	SPCRROLL.5ID1.5L.062T STLZNC	
all	6	27B34010SS	SPACERROLL .51ID.625L.062T SS	
all	7	02 02194	PISTON CUP=DUMPVALVE 2+3/8"	
all	8	02 18651	WASHER=2 WAY BRAKE CYL	
all	9	15G220	NUTLOK THINHX 3/8-24 SS/NYL	
all	10	60C106	ORING 5/16ID 1/16CSBUNA70#011	
all	11	02 02105B	2.38"ACYL BRASS PISTONCUP WSHR	
all	12	02 02085	UP WASHER=2"OD=PISTON CUP	
all	13	06 20702E	FLOW NOT ACTUATOR CYL HEAD	
all	14	02 02101	CYLHEAD W/TAPPED HOLE	
all	15	02 17024	SPRING-SS=DUMP 1.5OD4FL40#/"	
all	16	W6 20702F	*FLOW NOT VLV=AIR-CYL ROD WLD	
all	17	60C110	ORING 1/2IDX3/32CS BUNA70 #112	
all	18	02 02185	WASHER=PISTON CUP COMP LIMIT	
all	19	5N0ECLSBE2	NPT NIP 1/4XCLS TBE BRASS 125#	
all	20	51V015	TEE 1/4 FGDBRASS 101T7-444	
all	21	53A008B	BODYMALECON.25X.25COMP#B68A-4B	
all	22	5SCC0EBE	NPT COUP 1/4 BRASS 125# W/HEX	
all	23	15G185	HXNUT 5/16-18UNC2B SAE ZINC GR	
all	24	96M055	DELTROL QUICK EXHAUST VLV.1/4"	
all	25	27A005	MUFFLER 3/8" BANTAM B38	