



	·
D1	DRAIN TO REAR, 3" PIPE SOCKET JOINT.
E1	MAIN ELECTRICAL CONNECTION.
E2	HIGH VOLTAGE CONTROL BOX.
E3	LOW VOLTAGE CONTROL BOX.
E4	E-P PLUS CONTROLS ® (V6J), MILTOUCH CONTROLS ™ (V6Z)
F1	FOUNDATION BASE PADS, 2 PLACES.
	5/8" X 6" BOLTS MINIMUM.
F2	(18) 13/16" DIAMETER ANCHOR BOLTS HOLES, USE
L1	STANDARD SOAP CHUTE.
L2	LIQUID SUPPLY INLETS.
N1	SEE NOTE 9.
W1	ELECTRIC HOT WATER INLET,1-1/4" NPT, V6J
W2	ELECTRIC COLD WATER INLET ,1-1/4" NPT, V6J

## NOTES

- SHIM TO LEVEL THE MACHINE AND ALLOW FOR 1" [25] MINIMUM GROUT. ANCHOR ALL (18) ANCHOR BOLT HOLES (SEE NOTE 9.) OR THE WARRANTY WILL BE DECLARED INVAILD. USE 5/8" X 6" BOLTS, MINIMUM. SEE INSTALLATION MAINTENANCE MANUAL FOR FURTHER INSTRUCTIONS.
- MAINTENANCE MANUAL FOR FORTHER INSTRUCTIONS.

  WATER INLET PIPING AND BRACKETRY CAN BE EASILY REMOVED TO TEMPORARILY REDUCE OVERALL MACHINE WIDTH FOR PASSAGE THROUGH DOOR WAYS.

  IF ABSOLUTELY NECESSARY, THE MACHINE WAY SPAN A DRAIN TROUGH UP TO 15 (381) WIDE (THUS ELIMINATING UP TO 2 ANCHOR BOLTS PER SIDE, BUT ONLY THOSE IDENTIFIED (N1).
- INUSE IDENTIFIED (NT).

  BE INTIRE BASE OF MACHINE MUST BE CONTINUOUSLY SUPPORTED. IF MACHINE IS TO BE INSTALLED OVER A DRAIN TROUGH, THE MACHINE MUST BE MOUNTED TO A PEDESTAL BASE, NOT SUPPLIED BY P.M.

  V NEVER REDUCE DRAIN PIPING BELOW NPT SIZE OF CONNECTIONS.

- 7 NEVER REDUCE DRAIN PIPING BELOW NPT SIZE OF CONNECTIONS.

  6 AS OF THIS WRITING, THE MINIMUM CLEARANCE REQUIRED BY U.S. NATIONAL ELECTRIC CODES, FROM ELECTRIC BOX TO ANY OBJECT IS:

  36 [914] IF OBJECT IS AN UNGROUNDED (INSULATED) WALL.

  42 [1067] IF OBJECT IS A GROUNDED WALL (B. BARE CONCRETE, BRICK, ETC.)

  48 [1219] IF OBJECT IS ANY LIVE PART.

  CHECK LOCAL ELECTRIC CODES FOR FURTHER RESTRICTIONS.

  5 CUSTOMER TO SUPPLY CIRCUIT BREAKER OR FUSED BRANCH CIRCUIT DISCONNECT (SAFETY) SWITCHES WITH LOG TYPE FUSES FROM POWER SOURCE TO MACHINE. A SEPARATE GROUND WIRE MUST BE CONNECTED FROM DISCONNECT TO EQUIPMENT.

  4 BASELINE "Z" IS THE SAME FOR ALL MILNOR MACHINES AND IS SHOWN ON ALL DIMENSIONAL DRAWINS. THE DISTANCE BETWEEN BASELINE" Z" MOTHER THAT BASELINE "Z" IS HORIZONTAL AND ALL COMPONENTS REQUIRING GROUT ARE SET ON A MINIMUM 1" [25] THICK GROUT BED.
- S USE REFERENCE LINES X, Y, AND Z' 10 LOCATE ALL SERVICE CONNECTIONS.

  NUMBERS IN BRACKETS [] DENOTE DIMENSIONS IN MILIMETERS.

  ALL DIMENSIONS SHOWN ARE APPROXIMATE, SUBJECT TO NORMAL MANUFACTURING TOLERANCES, AND TO OCCASIONAL CHANGES WITHOUT NOTICE THROUGH REDESIGN AND/OR RELOCATION OF COMPONENTS, ETC. DO NOT USE FOR CONSTRUCTION UNLESS CERTIFIED, AND IN NO EVENT PRE-PIPE CLOSER THAN FIVE FEET FROM MACHINE, FACTORY MUST BE CONSULTED FOR DIMENSIONS IF MACHINE IS TO BE MOVED THROUGH NARROW OR LOW CORRIDORS OR OPENINGS.

ATTENTION

MOST REGULATORY AUTHORITIES (INCLUDING OSHA IN THE USA) HOLD THE

OWNER/USER ULTIMATELY RESPONSIBLE TO MAINTAIN A SAFE WORKING ENVIRONMENT.

ACCORDINGLY, THE OWNER/USER MUST RECOGNIZE ALL FORESEEABLE SAFETY HAZAROS,

FURNISH SAFETY INSTRUCTIONS AND GUIDANCE TO ALL PERSONNEL WHO MAY COME

N CONTACT WITH THE INSTALLATION, AND PROVIDE ALL NECESSARY ADDITIONAL SAFETY

GUARDS, FENCES, RESTRAINTS, DEVICES, ETC., NOT FURNISHED BY THE EQUIPMENT

MANIJEACIJIERO RO FYNDOR MANUFACTURER OR VENDOR.

THE FLOOR AND/OR OTHER SUPPORT COMPONENTS MUST HAVE SUFFICIENT STRENGTH AND RIGIDITY WITH DUE CONSIDERATION FOR NATURAL OR RESONANT FREQUENCY THEREOF) TO WITHSTAND THE FULLY LOADED WEIGHT OF THE MACHINE INCLUDING THE GOODS, THE WATER, AND ANY REPEATED SINUSOIDAL (ROTATING) FORCE GENERATED DURING ITS OPERATION. WRITE THE FACTORY FOR ADDITIONAL MACHINE DATA FOR USE BY A COMPETENT SOIL AND/OR STRUCTURAL ENGINEER.

