

30015/3022T5E/J/X (LOW VOLTAGE) 3 Phase and Single Phase V1000 INVERTER			
CONSTANT	VALUE	CONSTANT	VALUE
A1-01	2 Note 3	D1-01	10.5
A1-02	0	D1-02	143.3 Note 4
A1-03	Note 2	D1-05	19
B1-01	0	D1-06	19
B1-02	1	H1-03	7
B1-03	1	H1-04	4
C1-01	30	H1-05	3
C1-03	120	H1-06	5
C2-01	1.0	H2-01	E
C4-01	1.3	L1-01	0
C6-01	1	L2-01	2
C6-02	2	L3-01	0
E1-01	230.2	L3-04	0
E1-03	F	L3-05	0
E1-04	143.3 Note 4	L8-05	0
E1-05	230.2	L8-07	0
E1-06	60	H1-01	40
E1-07	3	H1-02	41
E1-08	12		
E1-09	1.5		
E1-10	12		
E2-01	Note 1		

- Note 1: Enter Ampere rating of inverter
Note 2: 2220 is initialize - otherwise 0
Note 3: Set to 0 after programming
Note 4: If Gear Guardian machine, change value to 136.5

Release Date: July 20, 2011

Revision C