

W4 THIRD (OR REUSE) WATER INLET, ELECTRICALLY OPERATED, I-1/4" NPT CONNECTION T2 REUSE TANK OVERFLOW TO SEWER, 3"ID HOSE TO SEWER PROVIDED OPTIONAL REUSE TANK OPTIONAL AIR-OPERATED STEAM INLET, Y-STRAINER REMOVE REMOVED FOR SHIPPING MUST BE ADDED AT INSTALLATION, 1"NPT CONNECTION L4 5 COMPARTMENT SUPPLY DUAL DRAINS FOR RECIRCULATION, DRAIN TO REUSE, 3" PI SOCKET JOINT DUAL DRAINS FOR RECIRCULATION, DRAIN TO SEWER, 3" P SOCKET JOINT OPTIONAL SINGLE DRAIN DOWN, 3" PIPE SOCKET JOINT CONNECTION OPTIONAL DUAL DRAIN, 3" PIPE SOCKET JOINT CONNECTIONS LEGEND

- NOTES

 6 AS OF THIS WRITING, THE MINIMUM CLEARANCE REQUIRED BY U.S. NATIONAL ELECTRIC CODES, FROM ELECTRIC BOX TO ANY OBJECT IS:

 36 [914] IF OBJECT IS AN UNGROUNDED (INSULATED) WALL.

 42 [1057] IF OBJECT IS A GROUNDED WALL (E.BARE CONGRETE, BRICK, ETC.)

 48 [1219] IF OBJECT IS ANY LIVE PART.

 CHECK LOCAL ELECTRIC CODES FOR FURTHER RESTRICTIONS.

 5 CUSTOMER TO SUPPLY CIRCUIT BREAKER OR FUSED BRANCH CIRCUIT DISCONNECT (SAFETY) SWITCHES WITH LAG TYPE FUSES FROM POWER SOURCE TO MACHINE. A SEPARATE GROUND WIRE MUST BE CONNECTED FROM DISCONNECT TO EQUIPMENT.

 BASELINE "Z" IS THE REFERENCE FOR ALL VERTICAL DIMENSIONS. ON MACHINES WITH WITH FIXED BASE PADS, BASELINE "Z" CORRESPONDS TO THE BOTTOM OF THE FEET WHEN ADJUSTABLE FEET, BASELINE "Z" CORRESPONDS TO THE BOTTOM OF THE FEET WHEN ADJUSTED FEET, BASELINE "Z" CORRESPONDS TO THE BOTTOM OF THE BOTTOM AND TRAVERSING SHUTTLES, BASELINE "Z" "CORRESPONDS TO THE BOTTOM OF THE BOTTOM AIL. THE DISTANCE BETWEEN BASELINE "Z" SAND THE FINISHED FLOOR WILL VARY AS REQUIRED TO ENSURE BASELINE "Z" SHORRIZONTAL AND ANY INTERFACING MACHINES REQUIRING GROUT ARE SET ON A MINIMUM 1"[25] THICK GROUT BED.

 3 USE REFERENCE LINES "X", "Y", AND "Z" TO LOCATE ALL SERVICE CONNECTIONS.
- THICK GROUT BED.

 3 USE REFERENCE LINES "X", "Y", AND "Z" TO LOCATE ALL SERVICE CONNECTIONS.

 2 NUMBERS IN BRACKETS [] DENOTE DIMENSIONS IN MILLIMETERS.

 1 ALL DIMENSIONS SHOWN ARE APPROXIMATE, SUBJECT TO NORMAL MANUFACTURING TOLERANCES, AND TO OCCASIONAL CHANGES WITHOUT NOTICE THROUGH REDESION AND/OR RELOCATION OF COMPONENTS, ETC. DO NOT USE FOR CONSTRUCTION UNLESS CERTIFIED, AND IN NO EVENT PRE-PIPE CLOSER THAN FIVE FEET FROM MACHINE, FACTORY MUST BE CONSULTED FOR DIMENSIONS IF MACHINE IS TO BE MOVED THROUGH NARROW OR LOW CORRIDORS OR OPENINGS.

MOST REGULATORY AUTHORITIES (INCLUDING OSHA IN THE USA) HOLD THE OWNER/USER ULTIMATELY RESPONSIBLE TO MAINTAIN A SAFE WORKING ENVIRONMENT. ACCORDINGLY, THE OWNER/USER MUST REOCONIZE ALL PORESEABLE SAFETY HAZARDS, FURNISH SAFETY INSTRUCTIONS AND GUIDANCE TO ALL PERSONNEL WHO MAY COME IN CONTACT WITH THE INSTALLATION, AND PROVIDE ALL NECESSARY ADDITIONAL SAFETY GUARDS, RECKES, RESTRANTS, DEVICES, ETC., NOT FURNISHED BY THE EQUIPMENT MANUFACTURER OR VENDOR.

MANUFACTURER OR VENDOR.

ATTENTION

THE FLOOR AND/OR OTHER SUPPORT COMPONENTS MUST HAVE SUFFICIENT
STRENGTH (AND RIGIDITY WITH DUE CONSIDERATION FOR NATURAL OR RESONANT
FREQUENCY THEREOF) TO WITHSTAND THE FULLY LOADED WEIGHT OF THE MACHINE
INCLUDING THE GOODS, THE WATER, AND ANY REPEATED SINUSOIDAL (ROTATING) FORCE:
GENERATED DURING ITS OPERATION. WITH THE FACTORY FOR ADDITIONAL MACHINE
DATA FOR USE BY A COMPETENT SOIL AND/OR STRUCTURAL ENGINEER.

42026X7R OPTIONS





