


Published Manual Number/ECN: H03 01100A/2001054N

- Publishing System: TPAS
- Access date: 1/31/01
- Document ECN's: Latest Available



Kit Instruction— K03 01100A



Please Read

About the Manual Identifying Information on the Cover

The front cover displays pertinent identifying information for this manual. Most important, are the published manual number (part number) /ECN (date code). Generally, when a replacement manual is furnished, it will have the same published manual number, but the latest available ECN. This provides the user with the latest information applicable to his machine. Similarly all documents comprising the manual will be the latest available as of the date the manual was printed, **even though older ECN dates for those documents may be listed in the table of contents.**

When communicating with the Milnor factory regarding this manual, please also provide the other identifying information shown on the cover, including the publishing system, access date, and whether the document ECN's are the latest available or exact.

References to Yellow Troubleshooting Pages

This manual may contain references to "yellow pages." Although the pages containing troubleshooting procedures are no longer printed on yellow paper, troubleshooting instructions, if any, will be contained in the easily located "Troubleshooting" chapter or section. See the table of contents.

Trademarks of Pellerin Milnor Corporation

The following, some of which may be used in this manual, are trademarks of Pellerin Milnor Corporation:

| | | | | |
|-------------------------|----------------------------|----------------------------|---------------------|--------------------------|
| Ampsaver [®] | Dye-Extractor [®] | Gear Guardian [®] | Milnet [®] | Staph-Guard [®] |
| Autolint [®] | Dyextractor [®] | Hands-Off [®] | Milnor [®] | System 4 [®] |
| Auto-Purge [®] | E-P Express [®] | Hydro-Cushion [®] | Miltrac | System 7 [®] |
| Autovac | E-P OneTouch [®] | Mildata [®] | Miltron | Totaltrol [®] |
| CBW [®] | E-P Plus [®] | | | |

Comments and Suggestions

Help us to improve this manual by sending your comments to:


Pellerin Milnor Corporation
Attn: Technical Publications
P. O. Box 400
Kenner, LA 70063-0400

Fax: (504) 469-1849


CHANGING FROM ONE TYPE OF
TEMPERATURE CONTROLLER TO ANOTHER

Three types of two-temperature controllers are used on MILNOR equipment:


- “MOTOMETER” No. KS100-22
- “MOTOMETER” No. KS100-04
- “STORK COMBISTAT”



“MOTOMETER”
No. KS100-22



“MOTOMETER”
No. KS100-04



“STORK COMBISTAT”

TEMPERATURE CONTROLLERS TERMINALS

These controllers are interchangeable but the terminal numbering scheme is different for each type (see above figures). When changing from one type to another, disregard wire color and reconnect the wires as follows:

| WIRE FOR | “MOTOMETER” No. KS100-22 TERMINALS | “MOTOMETER” No. KS100-204 TERMINALS | “STORK COMBISTAT” TERMINALS |
|---------------|--|---|-----------------------------------|
| Green Needle | 1 | 2 | 5 |
| Common | 2 | 5 | 1 + 4 (See Note) |
| Yellow Needle | 3 | 3 | 2 |

NOTE: You must attach a jumper wire between terminals 1 and 4 on the “Stork Combistat”.